

# bewellconnect<sup>®</sup>

Compatible Devices list

|   |    |
|---|----|
| 10.or .....                               | 1  |
| 3Q .....                                  | 1  |
| 4good .....                               | 1  |
| 7Eleven .....                             | 1  |
| <b>A.O.I. ELECTRONICS FACTORY</b> .....   | 1  |
| AG Mobile .....                           | 1  |
| AMTC .....                                | 1  |
| ANS .....                                 | 1  |
| AOC .....                                 | 1  |
| AOpen .....                               | 1  |
| AT&T .....                                | 1  |
| AV .....                                  | 1  |
| AZBox .....                               | 1  |
| AZPEN .....                               | 1  |
| Abocom .....                              | 1  |
| Accent .....                              | 1  |
| Acer .....                                | 1  |
| Adart .....                               | 3  |
| <b>Admiral Overseas Corporation</b> ..... | 3  |
| Advan digital .....                       | 3  |
| Affix .....                               | 3  |
| Aikun .....                               | 3  |
| Airtel .....                              | 3  |
| Aiuto .....                               | 3  |
| Aiwa .....                                | 3  |
| Alba .....                                | 3  |
| AllView .....                             | 3  |
| Allfine .....                             | 4  |
| Alphascan .....                           | 4  |
| Altice .....                              | 4  |
| Amgoo .....                               | 4  |
| Amplify .....                             | 5  |
| Anydata .....                             | 5  |
| Apex .....                                | 5  |
| Aprix .....                               | 5  |
| Arcelik .....                             | 5  |
| Archos .....                              | 5  |
| Ark .....                                 | 8  |
| <b>Ascom Wireless Solutions</b> .....     | 8  |
| Ashna .....                               | 8  |
| Astak .....                               | 8  |
| Astro Queo .....                          | 8  |
| AstroQueo .....                           | 8  |
| Asus .....                                | 8  |
| AtGames-zooti .....                       | 10 |

|                           |    |
|---------------------------|----|
| <b>Auchan</b>             | 10 |
| <b>Audi AG</b>            | 11 |
| <b>Audiovox</b>           | 11 |
| <b>Avaya</b>              | 11 |
| <b>Avoca</b>              | 11 |
| <b>Avvio</b>              | 11 |
| <b>Axioo</b>              | 11 |
| <b>Azumi</b>              | 11 |
| <b>BGH S.A.</b>           | 11 |
| <b>BKAV</b>               | 11 |
| <b>BMobile</b>            | 11 |
| <b>BQru</b>               | 12 |
| <b>BYD</b>                | 12 |
| <b>Bang &amp; Olufsen</b> | 12 |
| <b>Barel</b>              | 12 |
| <b>Barnes and Noble</b>   | 12 |
| <b>Becrypt</b>            | 12 |
| <b>Beeline</b>            | 12 |
| <b>BenQ</b>               | 12 |
| <b>Benesse</b>            | 13 |
| <b>Bentley</b>            | 13 |
| <b>Best Buy</b>           | 13 |
| <b>Bigben</b>             | 13 |
| <b>Billion</b>            | 13 |
| <b>Binatone</b>           | 13 |
| <b>Bitel</b>              | 13 |
| <b>Bitmore</b>            | 13 |
| <b>Bittium</b>            | 13 |
| <b>BlackBerry</b>         | 13 |
| <b>Blackview</b>          | 13 |
| <b>Blaupunkt</b>          | 13 |
| <b>Blu</b>                | 13 |
| <b>Bluebird</b>           | 14 |
| <b>Bluedot</b>            | 15 |
| <b>Booken</b>             | 15 |
| <b>Boost</b>              | 15 |
| <b>Borqs</b>              | 15 |
| <b>Bouygues Telecom</b>   | 15 |
| <b>Brightstar</b>         | 15 |
| <b>British Telecom</b>    | 15 |
| <b>Bullitt Group</b>      | 15 |
| <b>Bunbungame</b>         | 15 |
| <b>Bush</b>               | 15 |
| <b>C&amp;M</b>            | 15 |
| <b>CCC</b>                | 15 |

|                       |    |
|-----------------------|----|
| <b>CHN TELECOM</b>    | 15 |
| <b>CJHelloVision</b>  | 15 |
| <b>CMCC</b>           | 15 |
| <b>CX Argentina</b>   | 15 |
| <b>CZ Electronics</b> | 15 |
| <b>Camelus</b>        | 15 |
| <b>Candor</b>         | 15 |
| <b>Captiva</b>        | 15 |
| <b>Carrefour</b>      | 15 |
| <b>Casio</b>          | 16 |
| <b>Casper</b>         | 16 |
| <b>Cat</b>            | 16 |
| <b>Cathay</b>         | 16 |
| <b>Ceibal</b>         | 16 |
| <b>Celkon</b>         | 16 |
| <b>Cell_C</b>         | 16 |
| <b>Cellon</b>         | 16 |
| <b>Centric</b>        | 16 |
| <b>CenturyLink</b>    | 16 |
| <b>Cherry Mobile</b>  | 16 |
| <b>China Mobile</b>   | 17 |
| <b>Cipherlab</b>      | 17 |
| <b>Cisco</b>          | 17 |
| <b>Claresta</b>       | 17 |
| <b>Clarmin</b>        | 17 |
| <b>Clementoni</b>     | 17 |
| <b>Click</b>          | 17 |
| <b>ClickN Kids</b>    | 17 |
| <b>CloudFone</b>      | 17 |
| <b>Code</b>           | 17 |
| <b>CoinComputers</b>  | 17 |
| <b>ColorsMobile</b>   | 17 |
| <b>Comio</b>          | 17 |
| <b>Compal</b>         | 17 |
| <b>Condor</b>         | 18 |
| <b>Connectce</b>      | 18 |
| <b>Connex</b>         | 18 |
| <b>Coolpad</b>        | 18 |
| <b>Coppel</b>         | 20 |
| <b>Coppernic</b>      | 20 |
| <b>Covia</b>          | 20 |
| <b>Crema</b>          | 20 |
| <b>Crosscall</b>      | 20 |
| <b>Cspire</b>         | 20 |
| <b>Cubot</b>          | 20 |

|                                |    |
|--------------------------------|----|
| <b>DBM Maroc</b> .....         | 20 |
| <b>DEA Factory</b> .....       | 20 |
| <b>DEXP</b> .....              | 20 |
| <b>DIFRNCE</b> .....           | 20 |
| <b>DL</b> .....                | 20 |
| <b>DNA</b> .....               | 21 |
| <b>Danew</b> .....             | 21 |
| <b>Ddm</b> .....               | 21 |
| <b>Dell</b> .....              | 21 |
| <b>Dialog Blaze</b> .....      | 21 |
| <b>DigiLand</b> .....          | 21 |
| <b>Digilite</b> .....          | 21 |
| <b>Diginnos</b> .....          | 21 |
| <b>Digital2</b> .....          | 21 |
| <b>DigitalStream</b> .....     | 21 |
| <b>Digitron</b> .....          | 21 |
| <b>Digix</b> .....             | 21 |
| <b>Digma</b> .....             | 21 |
| <b>Dish</b> .....              | 22 |
| <b>Ditecma</b> .....           | 22 |
| <b>Ditigron</b> .....          | 22 |
| <b>Docomo</b> .....            | 22 |
| <b>Doogee</b> .....            | 22 |
| <b>Doopro</b> .....            | 22 |
| <b>Dopo</b> .....              | 22 |
| <b>Doppio</b> .....            | 22 |
| <b>Doro</b> .....              | 22 |
| <b>Dragontouch</b> .....       | 23 |
| <b>Dreamax</b> .....           | 23 |
| <b>Dtac</b> .....              | 23 |
| <b>Dunns</b> .....             | 23 |
| <b>E-Boda</b> .....            | 23 |
| <b>EBN</b> .....               | 23 |
| <b>ECS</b> .....               | 23 |
| <b>ENTITY</b> .....            | 23 |
| <b>ESI Enterprises</b> .....   | 23 |
| <b>EXO S.A.</b> .....          | 23 |
| <b>Echo Mobiles</b> .....      | 23 |
| <b>Edcon</b> .....             | 23 |
| <b>Eks Mobility</b> .....      | 23 |
| <b>Electroland Ghana</b> ..... | 23 |
| <b>Elevate</b> .....           | 23 |
| <b>Ematic</b> .....            | 23 |
| <b>Emdoor</b> .....            | 24 |
| <b>Emerson</b> .....           | 24 |

|                                 |    |
|---------------------------------|----|
| <b>Emtec</b>                    | 24 |
| <b>Enspert</b>                  | 24 |
| <b>Entel</b>                    | 24 |
| <b>Envizen</b>                  | 24 |
| <b>Envizen Digital</b>          | 24 |
| <b>Essential Products</b>       | 24 |
| <b>EssentielB</b>               | 24 |
| <b>Estar</b>                    | 24 |
| <b>Etuline</b>                  | 24 |
| <b>EuroLeague</b>               | 24 |
| <b>Evercross</b>                | 24 |
| <b>Every</b>                    | 24 |
| <b>Eviant</b>                   | 25 |
| <b>Evolio</b>                   | 25 |
| <b>Evolveo</b>                  | 25 |
| <b>Explay</b>                   | 25 |
| <b>FBC</b>                      | 25 |
| <b>FaceVtion</b>                | 25 |
| <b>Fairphone</b>                | 25 |
| <b>FarEasTone</b>               | 25 |
| <b>Fero</b>                     | 25 |
| <b>Figo</b>                     | 25 |
| <b>Finggo</b>                   | 25 |
| <b>FirstNationalBank</b>        | 25 |
| <b>Flnet</b>                    | 25 |
| <b>Fluo</b>                     | 25 |
| <b>Fly</b>                      | 25 |
| <b>Fossil</b>                   | 26 |
| <b>Foxconn</b>                  | 26 |
| <b>Foxtel</b>                   | 27 |
| <b>Freebit</b>                  | 27 |
| <b>Freebox</b>                  | 27 |
| <b>Freetel</b>                  | 27 |
| <b>Fujitsu</b>                  | 27 |
| <b>Funai Electric</b>           | 28 |
| <b>Future Mobile Technology</b> | 28 |
| <b>G Y P NEW TREE SA</b>        | 28 |
| <b>G53</b>                      | 28 |
| <b>GD Classbook</b>             | 28 |
| <b>GSmart</b>                   | 28 |
| <b>Galapad</b>                  | 28 |
| <b>Galexia</b>                  | 28 |
| <b>Garmin</b>                   | 28 |
| <b>Geanee</b>                   | 28 |
| <b>General Dynamics</b>         | 28 |

|   |    |
|---|----|
| <b>General Mobile</b> .....                       | 28 |
| <b>GeneralMobile</b> .....                        | 28 |
| <b>Geniatech</b> .....                            | 28 |
| <b>Gesellschaft fr SMK mBH</b> .....              | 28 |
| <b>Getac</b> .....                                | 28 |
| <b>Gigabyte</b> .....                             | 29 |
| <b>Gigaset</b> .....                              | 29 |
| <b>Gini</b> .....                                 | 29 |
| <b>Ginzzu</b> .....                               | 29 |
| <b>Gionee</b> .....                               | 29 |
| <b>GoClever</b> .....                             | 30 |
| <b>Google</b> .....                               | 30 |
| <b>Gplus</b> .....                                | 30 |
| <b>Gradiente</b> .....                            | 30 |
| <b>Greatwall</b> .....                            | 31 |
| <b>Grundig</b> .....                              | 31 |
| <b>Gryphon</b> .....                              | 31 |
| <b>Gtel</b> .....                                 | 31 |
| <b>Guess</b> .....                                | 31 |
| <b>HKC</b> .....                                  | 31 |
| <b>HKT</b> .....                                  | 31 |
| <b>HP</b> .....                                   | 31 |
| <b>HTC</b> .....                                  | 31 |
| <b>Hafury</b> .....                               | 37 |
| <b>Haier</b> .....                                | 37 |
| <b>Handheld Group</b> .....                       | 38 |
| <b>HannSpree</b> .....                            | 38 |
| <b>Harris</b> .....                               | 38 |
| <b>Helio</b> .....                                | 38 |
| <b>HighScreen</b> .....                           | 38 |
| <b>Hipstreet</b> .....                            | 38 |
| <b>Hisense</b> .....                              | 38 |
| <b>Hoffmann</b> .....                             | 42 |
| <b>Hon Hai Precision Industry Co., Ltd.</b> ..... | 42 |
| <b>Honda</b> .....                                | 42 |
| <b>Honeywell</b> .....                            | 42 |
| <b>How</b> .....                                  | 43 |
| <b>Huawei</b> .....                               | 43 |
| <b>Hurricane</b> .....                            | 52 |
| <b>Hyundai</b> .....                              | 52 |
| <b>Hyve</b> .....                                 | 53 |
| <b>ICL-KME CS OJSC</b> .....                      | 53 |
| <b>IDEA</b> .....                                 | 53 |
| <b>IMO(In My Opinion)</b> .....                   | 53 |
| <b>INQ Mobile</b> .....                           | 53 |

|                        |    |
|------------------------|----|
| <b>IPRODA</b>          | 53 |
| <b>IUNI</b>            | 53 |
| <b>IUSA</b>            | 53 |
| <b>IView</b>           | 53 |
| <b>Ice Phone</b>       | 53 |
| <b>Icon</b>            | 53 |
| <b>IkuMobile</b>       | 53 |
| <b>Ilike</b>           | 53 |
| <b>ImageMobile</b>     | 53 |
| <b>Impecca</b>         | 53 |
| <b>Inet-Tablet</b>     | 53 |
| <b>Infinity</b>        | 53 |
| <b>Infinix</b>         | 53 |
| <b>Infocus</b>         | 54 |
| <b>Inhon</b>           | 54 |
| <b>Innjoo</b>          | 54 |
| <b>Insignia</b>        | 55 |
| <b>Intel</b>           | 55 |
| <b>Intenso</b>         | 55 |
| <b>Intermec</b>        | 55 |
| <b>Intex</b>           | 55 |
| <b>Irbis</b>           | 55 |
| <b>Itel</b>            | 55 |
| <b>Itworks</b>         | 56 |
| <b>JLab</b>            | 56 |
| <b>JP Sacouto</b>      | 56 |
| <b>JVC</b>             | 56 |
| <b>JabrBox</b>         | 56 |
| <b>Janam</b>           | 56 |
| <b>Jide</b>            | 56 |
| <b>Jivi</b>            | 56 |
| <b>Just5</b>           | 56 |
| <b>K-Lite,</b>         | 56 |
| <b>K-Touch</b>         | 56 |
| <b>KAAN</b>            | 56 |
| <b>KAZAM</b>           | 56 |
| <b>KD Interactive</b>  | 57 |
| <b>KDDI</b>            | 57 |
| <b>KOOOK</b>           | 57 |
| <b>KT Tech</b>         | 57 |
| <b>Kalley</b>          | 57 |
| <b>Kapsys</b>          | 57 |
| <b>Karbons</b>         | 57 |
| <b>Kempler Strauss</b> | 57 |
| <b>Kenbo</b>           | 57 |



|                                |    |
|--------------------------------|----|
| <b>Kennex</b> .....            | 57 |
| <b>Ketablet</b> .....          | 57 |
| <b>Kiano</b> .....             | 57 |
| <b>Klipad</b> .....            | 57 |
| <b>Kobo</b> .....              | 58 |
| <b>Kodak</b> .....             | 58 |
| <b>Kogan</b> .....             | 58 |
| <b>Konrow</b> .....            | 58 |
| <b>Kruger&amp;Matz</b> .....   | 58 |
| <b>Kubo</b> .....              | 58 |
| <b>Kult</b> .....              | 58 |
| <b>Kyocera</b> .....           | 58 |
| <b>Kyowon</b> .....            | 59 |
| <b>LGE</b> .....               | 59 |
| <b>LGU+</b> .....              | 68 |
| <b>LIAONING YIYATONG</b> ..... | 68 |
| <b>LINSAY</b> .....            | 68 |
| <b>LT Electronics</b> .....    | 68 |
| <b>LUVO</b> .....              | 68 |
| <b>LUXYA</b> .....             | 68 |
| <b>Laiq</b> .....              | 68 |
| <b>Lanix</b> .....             | 68 |
| <b>Lark</b> .....              | 69 |
| <b>Lava</b> .....              | 69 |
| <b>Lazer</b> .....             | 70 |
| <b>Le</b> .....                | 70 |
| <b>Le Pan</b> .....            | 70 |
| <b>LeTV</b> .....              | 70 |
| <b>Lechpol</b> .....           | 70 |
| <b>Leeco</b> .....             | 70 |
| <b>Lenovo</b> .....            | 70 |
| <b>Lexibook</b> .....          | 75 |
| <b>Lgcns</b> .....             | 75 |
| <b>LifeWatch</b> .....         | 75 |
| <b>LinkNet</b> .....           | 75 |
| <b>Listo</b> .....             | 75 |
| <b>Logic Instrument</b> .....  | 75 |
| <b>Logic Mobility</b> .....    | 75 |
| <b>Logicom</b> .....           | 75 |
| <b>Logitech</b> .....          | 76 |
| <b>Louis Vuitton</b> .....     | 76 |
| <b>Lumigon</b> .....           | 76 |
| <b>Lyf</b> .....               | 76 |
| <b>M4tel</b> .....             | 76 |
| <b>MG Series</b> .....         | 76 |

|  |    |
|--|----|
| <b>MG series</b> .....                 | 76 |
| <b>MJS</b> .....                       | 76 |
| <b>MPman</b> .....                     | 77 |
| <b>MSI</b> .....                       | 77 |
| <b>MTC</b> .....                       | 77 |
| <b>MTN Group</b> .....                 | 77 |
| <b>MTN-E70</b> .....                   | 77 |
| <b>MTT</b> .....                       | 77 |
| <b>Mach Speed</b> .....                | 77 |
| <b>MachSpeed (Apollo Brands)</b> ..... | 77 |
| <b>Mad Catz</b> .....                  | 77 |
| <b>Manta</b> .....                     | 77 |
| <b>Marshall</b> .....                  | 77 |
| <b>Masstel</b> .....                   | 77 |
| <b>Maxcom</b> .....                    | 77 |
| <b>MeanIT</b> .....                    | 77 |
| <b>Mecer</b> .....                     | 77 |
| <b>Medion</b> .....                    | 77 |
| <b>MegaFon</b> .....                   | 78 |
| <b>Megahouse</b> .....                 | 78 |
| <b>Meitu</b> .....                     | 78 |
| <b>Meizu</b> .....                     | 78 |
| <b>Memorex</b> .....                   | 78 |
| <b>Micromax</b> .....                  | 78 |
| <b>Microtech</b> .....                 | 80 |
| <b>MiiA</b> .....                      | 80 |
| <b>Mint</b> .....                      | 80 |
| <b>Mio Tab</b> .....                   | 80 |
| <b>Miophone</b> .....                  | 80 |
| <b>Misfit</b> .....                    | 80 |
| <b>Mito</b> .....                      | 80 |
| <b>Mobicell</b> .....                  | 80 |
| <b>MobiiStar</b> .....                 | 80 |
| <b>MobileTeleSystem</b> .....          | 81 |
| <b>Mobily</b> .....                    | 81 |
| <b>Mobiola</b> .....                   | 81 |
| <b>Mobistel</b> .....                  | 81 |
| <b>Mobiwire</b> .....                  | 81 |
| <b>Modecom</b> .....                   | 81 |
| <b>Mohu</b> .....                      | 81 |
| <b>Monster</b> .....                   | 81 |
| <b>Montblanc</b> .....                 | 81 |
| <b>Most Computers</b> .....            | 81 |
| <b>Motorola</b> .....                  | 81 |
| <b>Motorola Solutions</b> .....        | 84 |

|                           |    |
|---------------------------|----|
| <b>Movado</b>             | 84 |
| <b>Movitelco Trade</b>    | 84 |
| <b>Moxee Technologies</b> | 84 |
| <b>Multilaser</b>         | 84 |
| <b>My Go</b>              | 84 |
| <b>MyPhone (PL)</b>       | 84 |
| <b>Myphone</b>            | 84 |
| <b>Myria</b>              | 85 |
| <b>NASCO</b>              | 85 |
| <b>NAXA</b>               | 85 |
| <b>NEC</b>                | 85 |
| <b>NESO</b>               | 86 |
| <b>NGM Italia SRL</b>     | 86 |
| <b>NVIDIA</b>             | 86 |
| <b>NYX Mobile</b>         | 86 |
| <b>Nabi</b>               | 86 |
| <b>NanoTech</b>           | 86 |
| <b>Navitel</b>            | 86 |
| <b>Navon</b>              | 86 |
| <b>Ncredible</b>          | 86 |
| <b>Neffos</b>             | 86 |
| <b>Neostra</b>            | 87 |
| <b>Netgear</b>            | 87 |
| <b>New Balance</b>        | 87 |
| <b>Nexian</b>             | 87 |
| <b>Next Learning</b>      | 87 |
| <b>Nextbase</b>           | 87 |
| <b>Nextbit</b>            | 87 |
| <b>Nextbook</b>           | 87 |
| <b>Nextel</b>             | 87 |
| <b>Nikon</b>              | 87 |
| <b>Nixon</b>              | 87 |
| <b>Njoy</b>               | 87 |
| <b>Nobis</b>              | 87 |
| <b>Noblex</b>             | 87 |
| <b>Nokia</b>              | 87 |
| <b>Nomi</b>               | 87 |
| <b>Nous</b>               | 87 |
| <b>NuAns</b>              | 88 |
| <b>Nubia</b>              | 88 |
| <b>Nuu</b>                | 88 |
| <b>Nuvision</b>           | 88 |
| <b>ODYS</b>               | 88 |
| <b>Obi</b>                | 88 |
| <b>Oceusnetworks</b>      | 88 |

|                            |    |
|----------------------------|----|
| <b>Odys</b> .....          | 88 |
| <b>Oioo</b> .....          | 88 |
| <b>Olive Oil</b> .....     | 88 |
| <b>Olivetti</b> .....      | 88 |
| <b>Ollee</b> .....         | 88 |
| <b>OnePlus</b> .....       | 88 |
| <b>Onkyo</b> .....         | 88 |
| <b>OpenPeak</b> .....      | 88 |
| <b>Oppo</b> .....          | 88 |
| <b>Opticon</b> .....       | 90 |
| <b>Oraimo</b> .....        | 90 |
| <b>Orange</b> .....        | 90 |
| <b>Orbic</b> .....         | 90 |
| <b>Other</b> .....         | 91 |
| <b>Oukitel</b> .....       | 91 |
| <b>OwnMobile</b> .....     | 91 |
| <b>Oysters</b> .....       | 91 |
| <b>PC Smart</b> .....      | 91 |
| <b>PCD Argentina</b> ..... | 91 |
| <b>POC</b> .....           | 91 |
| <b>Packard Bell</b> .....  | 91 |
| <b>Panasonic</b> .....     | 91 |
| <b>Pantech</b> .....       | 92 |
| <b>Partner</b> .....       | 93 |
| <b>Pavapro</b> .....       | 93 |
| <b>Pegatron</b> .....      | 93 |
| <b>Philco</b> .....        | 93 |
| <b>Philips</b> .....       | 93 |
| <b>Pioneer</b> .....       | 94 |
| <b>Pixela</b> .....        | 94 |
| <b>Plaisio</b> .....       | 94 |
| <b>Plus4</b> .....         | 94 |
| <b>Plusone</b> .....       | 94 |
| <b>PointMobile</b> .....   | 94 |
| <b>Polar</b> .....         | 94 |
| <b>Polaris</b> .....       | 94 |
| <b>Polaroid</b> .....      | 94 |
| <b>Polytron</b> .....      | 95 |
| <b>Porsche</b> .....       | 95 |
| <b>Positivo</b> .....      | 95 |
| <b>Positivo BGH</b> .....  | 95 |
| <b>Premio</b> .....        | 96 |
| <b>Prestige</b> .....      | 96 |
| <b>Prestigio</b> .....     | 96 |
| <b>Proscan</b> .....       | 97 |

|                                 |     |
|---------------------------------|-----|
| <b>Protab</b> .....             | 97  |
| <b>QLA</b> .....                | 97  |
| <b>QMobile</b> .....            | 97  |
| <b>QOOQ</b> .....               | 98  |
| <b>Qilive</b> .....             | 98  |
| <b>Quanta</b> .....             | 98  |
| <b>Quantum</b> .....            | 98  |
| <b>RCA</b> .....                | 98  |
| <b>REACH</b> .....              | 98  |
| <b>Rainbow</b> .....            | 99  |
| <b>Razer</b> .....              | 99  |
| <b>Reeder</b> .....             | 99  |
| <b>Reliance</b> .....           | 99  |
| <b>Revo</b> .....               | 99  |
| <b>Revtel</b> .....             | 99  |
| <b>Royaltek</b> .....           | 99  |
| <b>Ruggear</b> .....            | 99  |
| <b>Ruio</b> .....               | 99  |
| <b>SAKAISIO</b> .....           | 99  |
| <b>SED Wireless</b> .....       | 99  |
| <b>SELECLINE</b> .....          | 99  |
| <b>SFR</b> .....                | 99  |
| <b>SK Broadband</b> .....       | 99  |
| <b>SK Telesys</b> .....         | 99  |
| <b>SOSMART</b> .....            | 99  |
| <b>SPC Mobile</b> .....         | 99  |
| <b>STF Mobile</b> .....         | 99  |
| <b>STK(Santok)</b> .....        | 100 |
| <b>Saltillo</b> .....           | 100 |
| <b>Samsung</b> .....            | 100 |
| <b>Sansui</b> .....             | 115 |
| <b>Sanyo</b> .....              | 115 |
| <b>Schok</b> .....              | 115 |
| <b>Seemahale Telecoms</b> ..... | 115 |
| <b>Senseit</b> .....            | 115 |
| <b>Senwa</b> .....              | 115 |
| <b>Sharp</b> .....              | 115 |
| <b>SiAL</b> .....               | 117 |
| <b>Sico SmartPhone</b> .....    | 117 |
| <b>Silent Circle</b> .....      | 117 |
| <b>Simbans</b> .....            | 117 |
| <b>Siragon</b> .....            | 117 |
| <b>Sirin</b> .....              | 117 |
| <b>Sky Devices</b> .....        | 117 |
| <b>SkyLife</b> .....            | 117 |

|   |     |
|---|-----|
| <b>Skyworth</b> .....                     | 117 |
| <b>Smartab</b> .....                      | 117 |
| <b>Smartfren</b> .....                    | 118 |
| <b>Smartron</b> .....                     | 118 |
| <b>Sonimtech</b> .....                    | 118 |
| <b>Sony</b> .....                         | 118 |
| <b>Sony Ericsson</b> .....                | 120 |
| <b>Sophix_Digix</b> .....                 | 121 |
| <b>Sourcing Creation</b> .....            | 121 |
| <b>Southern Telecom</b> .....             | 121 |
| <b>SpectraPrecision</b> .....             | 122 |
| <b>Spectralink</b> .....                  | 122 |
| <b>Spice</b> .....                        | 122 |
| <b>Sprint</b> .....                       | 122 |
| <b>StarMobile</b> .....                   | 122 |
| <b>Starlight</b> .....                    | 122 |
| <b>Storex</b> .....                       | 122 |
| <b>Stream</b> .....                       | 122 |
| <b>Sts-tottori</b> .....                  | 122 |
| <b>Stylo</b> .....                        | 122 |
| <b>Stylus</b> .....                       | 122 |
| <b>Sugar</b> .....                        | 122 |
| <b>Sumitomo Electric Industries</b> ..... | 122 |
| <b>Sumitomo Electric Networks</b> .....   | 122 |
| <b>Swisstone</b> .....                    | 122 |
| <b>Symphony</b> .....                     | 122 |
| <b>T-Mobile</b> .....                     | 123 |
| <b>TA71CA5_JP</b> .....                   | 123 |
| <b>TAG Heuer</b> .....                    | 123 |
| <b>TCL</b> .....                          | 123 |
| <b>TCT (Alcatel)</b> .....                | 123 |
| <b>TG&amp;Co.</b> .....                   | 132 |
| <b>THTF</b> .....                         | 132 |
| <b>TIM</b> .....                          | 132 |
| <b>TJC</b> .....                          | 132 |
| <b>TMAX</b> .....                         | 132 |
| <b>TPS</b> .....                          | 132 |
| <b>TSUNAMi</b> .....                      | 132 |
| <b>TUNTUN English</b> .....               | 132 |
| <b>TUPAD</b> .....                        | 132 |
| <b>TaiwanMobile</b> .....                 | 132 |
| <b>Takara</b> .....                       | 133 |
| <b>Technicolor</b> .....                  | 133 |
| <b>Techpad</b> .....                      | 133 |
| <b>Tecno</b> .....                        | 133 |

|  |     |
|--|-----|
| <b>Teknosa</b>                         | 134 |
| <b>Tekwind</b>                         | 134 |
| <b>Telcel</b>                          | 134 |
| <b>Tele2</b>                           | 134 |
| <b>Telecable</b>                       | 134 |
| <b>Teleepoch</b>                       | 134 |
| <b>Telefunken</b>                      | 134 |
| <b>Telenor</b>                         | 134 |
| <b>Telkom</b>                          | 134 |
| <b>TellyTablet</b>                     | 134 |
| <b>Telus</b>                           | 134 |
| <b>Tesco</b>                           | 134 |
| <b>Tesla</b>                           | 134 |
| <b>Tetratab</b>                        | 134 |
| <b>Thinpad</b>                         | 134 |
| <b>Thomson</b>                         | 134 |
| <b>Timovi</b>                          | 134 |
| <b>Tinhvan</b>                         | 134 |
| <b>Tobii DynaVox</b>                   | 134 |
| <b>Tonino Lamborghini</b>              | 134 |
| <b>Toshiba</b>                         | 134 |
| <b>Toughshield</b>                     | 135 |
| <b>Trekstor</b>                        | 135 |
| <b>Trimble Navigation</b>              | 135 |
| <b>Trio</b>                            | 135 |
| <b>True</b>                            | 135 |
| <b>Tunisie Telecom</b>                 | 135 |
| <b>Turbonet</b>                        | 135 |
| <b>Turk Telekom</b>                    | 136 |
| <b>UNOWHY</b>                          | 136 |
| <b>USA111</b>                          | 136 |
| <b>Ubiquiti</b>                        | 136 |
| <b>Ufone</b>                           | 136 |
| <b>Umax</b>                            | 136 |
| <b>Umx(Ultimate Mobile Experience)</b> | 136 |
| <b>Utopia</b>                          | 136 |
| <b>V7</b>                              | 136 |
| <b>VAIO</b>                            | 136 |
| <b>VENSTAR</b>                         | 136 |
| <b>VIBE Z</b>                          | 136 |
| <b>VSN</b>                             | 136 |
| <b>VT</b>                              | 136 |
| <b>Vaxcare</b>                         | 136 |
| <b>Venturer</b>                        | 136 |
| <b>VerD</b>                            | 136 |



|                                  |     |
|----------------------------------|-----|
| <b>Verizon Wireless</b> .....    | 136 |
| <b>Vernee</b> .....              | 136 |
| <b>Verssed</b> .....             | 136 |
| <b>Vertex</b> .....              | 136 |
| <b>Vertu</b> .....               | 136 |
| <b>Verykool</b> .....            | 137 |
| <b>Vestel</b> .....              | 137 |
| <b>ViewSonic</b> .....           | 137 |
| <b>Visiontouch</b> .....         | 137 |
| <b>Visual Land</b> .....         | 137 |
| <b>Vitsmo</b> .....              | 138 |
| <b>Vivo</b> .....                | 138 |
| <b>Viwa</b> .....                | 138 |
| <b>Vizio</b> .....               | 138 |
| <b>Vodafone</b> .....            | 138 |
| <b>Vonino</b> .....              | 139 |
| <b>Vsun</b> .....                | 139 |
| <b>Vulcan</b> .....              | 139 |
| <b>W.e.</b> .....                | 139 |
| <b>Wacom</b> .....               | 139 |
| <b>Walton</b> .....              | 139 |
| <b>WeTek</b> .....               | 139 |
| <b>Weimei</b> .....              | 140 |
| <b>Welgate</b> .....             | 140 |
| <b>Wenu</b> .....                | 140 |
| <b>Wiko</b> .....                | 140 |
| <b>Wileyfox</b> .....            | 141 |
| <b>Wink</b> .....                | 141 |
| <b>Wintec</b> .....              | 141 |
| <b>Wistron</b> .....             | 141 |
| <b>Woongjin</b> .....            | 141 |
| <b>X-TIGI</b> .....              | 141 |
| <b>Xiaomi</b> .....              | 141 |
| <b>Xolo</b> .....                | 142 |
| <b>Xplore Technologies</b> ..... | 142 |
| <b>YU</b> .....                  | 142 |
| <b>Yes</b> .....                 | 142 |
| <b>Yezz</b> .....                | 142 |
| <b>Yota Devices</b> .....        | 142 |
| <b>Yuho</b> .....                | 142 |
| <b>ZTE</b> .....                 | 142 |
| <b>Zebex</b> .....               | 152 |
| <b>Zebra</b> .....               | 152 |
| <b>Zeki</b> .....                | 152 |
| <b>Zen</b> .....                 | 152 |



|                         |     |
|-------------------------|-----|
| <b>Zettaly</b> .....    | 153 |
| <b>Zilo</b> .....       | 153 |
| <b>Ziox</b> .....       | 153 |
| <b>Zopo</b> .....       | 153 |
| <b>Zuk</b> .....        | 153 |
| <b>Zuum</b> .....       | 153 |
| <b>bq</b> .....         | 153 |
| <b>i-Buddie</b> .....   | 153 |
| <b>i-Mobile</b> .....   | 153 |
| <b>iCraig</b> .....     | 153 |
| <b>iDea USA</b> .....   | 153 |
| <b>iDeaUSA</b> .....    | 153 |
| <b>iGet</b> .....       | 154 |
| <b>iLa Mobile</b> ..... | 154 |
| <b>iNO Mobile</b> ..... | 154 |
| <b>iNanny</b> .....     | 154 |
| <b>iRiver</b> .....     | 154 |
| <b>iRulu</b> .....      | 154 |
| <b>iVOOMi</b> .....     | 154 |
| <b>pendo</b> .....      | 154 |
| <b>sugar_aums</b> ..... | 154 |
| <b>tecmobile</b> .....  | 154 |
| <b>ucall</b> .....      | 154 |
| <b>videocon</b> .....   | 154 |

## 10.or

1. D - D
2. E - E
3. G - G

## 3Q

1. OC1020A - OC1020A

## 4good

1. 4GOOD Light B100 - Light B100
2. A103 - Light A103

## 7Eleven

1. IN265 - IN265

## A.O.I. ELECTRONICS FACTORY

1. A.O.I. - TR10CS1

## AG Mobile

1. AG BOOST 2 - E4010
2. AG Flair - Flair
3. AG Go Tab Access 2 - AG\_Go\_Tab\_Access\_2
4. AG Ultra2 - Ultra 2
5. AG\_Go-Tab\_Access - AG Go-Tab Access
6. AG\_Tab\_7\_0 - AG\_Tab\_7\_0
7. Boost - Boost
8. Chacer - Chacer
9. Freedom Access - Freedom Access
10. Freedom E - Freedom E
11. Freedom Plus LTE - Freedom Plus LTE
12. Ghost - Ghost
13. Glow - Glow
14. HASHTAG - Hashtag
15. Hype - Hype
16. Neon - Neon
17. Quest - Quest
18. Rage - Rage
19. STYLE PLUS - STYLE\_PLUS
20. Shine - Shine
21. Status - Status
22. Style - Style
23. Style\_2 - Style 2
24. Swift - Swift
25. Swift\_Plus - Swift\_Plus
26. ULTRA - Ultra
27. Zenith - Zenith
28. Zone - Zone
29. Zoom - Zoom

## AMTC

1. MD1001 Tablet - MD1001
2. MD7008 - MD7008
3. MD7081 - MD7081

## ANS

1. Trailblazer - H450R
2. UL40 - UL40

## AOC

1. A110\_E - A110\_E
2. AOC - A731
3. AOC - A732G

## AOpen

1. RK3288 10" Chromebase - AOpen Chromebase Mini
2. RK3288 Mini Chromebox - AOpen Chromebox Mini

## AT&T

1. 9020A - 9020A

## AV

1. AV10 - AV10
2. AV7 - AV7

## AZBox

1. AZDroid - AZDroid

## AZPEN

1. A720 - A720
2. A920 - A920

## Abocom

1. A08SM - A08S

## Accent

1. FAST7 3G - FAST7 3G
2. SPEED S8 - SPEED\_S8

## Acer

1. C6 - Acer E320
2. C6 - Acer E320-orange
3. C7 - E330
4. C8n - E350
5. K3 - E130
6. T2 - AT390
7. T603T - TD600
8. a3 - Stream
9. a5 - S300
10. c4 - E310
11. k4 - E140
12. k5 - E210
13. A1-713 - A1-713
14. A1-734 - A1-734
15. A1-810 - A1-810
16. A1-811 - A1-811
17. A1-830 - A1-830
18. A100 - A100
19. A101 - A101
20. A110 - A110
21. A3-A10 - A3-A10
22. A3-A11 - A3-A11
23. A3-A20 - A3-A20
24. A3-A20FHD - A3-A20FHD
25. A3-A30 - A3-A30
26. A3-A40 - A3-A40
27. AK330s - AK330S

28. Acer Chromebook R13 - Acer Chromebook R13 (CB5-312T)
29. Acer Holo360 - C01
30. Aspire A3 - AA3-600
31. B1-710 - B1-710
32. B1-711 - B1-711
33. B1-720 - b1-720
34. B1-721 - b1-721
35. B1-723 - B1-723
36. B1-730 - B1-730
37. B1-730HD - B1-730HD
38. B1-733 - B1-733
39. B1-780 - B1-780
40. B1-790 - B1-790
41. B1-820 - B1-820
42. B1-850 - B1-850
43. B1-A71 - B1-A71
44. B3-A30 - B3-A30
45. B3-A32 - B3-A32
46. B3-A40 - B3-A40
47. B3-A40FHD - B3-A40FHD
48. C01 - C01
49. Chromebook 14 for work - Chromebook 14 for work (CP5-471)
50. Chromebook 15 (CB3-532) - Acer Chromebook 15 (CB3-532)
51. Chromebook 15 CB515-1HT/1H - sand
52. Chromebook R11 (C738T) - Acer Chromebook R11
53. Chromebook R11 (C738T) - Acer Chromebook R11 (CB5-132T / C738T)
54. CloudMobile S500 - S500
55. DA220HQL - DA220HQL
56. DA221HQL - DA221HQL
57. DA222HQL - DA222HQL
58. DA222HQLA - DA222HQLA
59. DA222HQLA - DA222HQLA
60. DA223HQL - DA223HQL
61. DA226HQ - DA226HQ
62. DA241HL - DA241HL
63. DA245HQL - DA245HQL
64. E380 - E380
65. G1-715 - G1-715
66. G100W - G100W
67. GT-810 - GT-810
68. I110 - I110
69. Icona One 7 - B1-730HD
70. Iconia One 10 - B3-A32
71. Iconia One 10 - B3-A20
72. Iconia One 10 - B3-A20B
73. Iconia One 7 - G1-725
74. Iconia One 7 - B1-7A0
75. Iconia One 7 - B1-730HD
76. Iconia One 7 - B1-750
77. Iconia One 7 - B1-730
78. Iconia One 8 - B1-860A
79. Iconia One 8 - A1-850
80. Iconia One 8 - B1-810
81. Iconia Tab 10 - A3-A50
82. Iconia Tab 10 - A3-A20
83. Iconia Tab 10 - A3-A20FHD
84. Iconia Tab 7 - A1-713
85. Iconia Tab 7 - A1-713HD
86. Iconia Tab 8 - A1-840FHD
87. Iconia Tab 8 - A1-840
88. Iconia Tab 8 - A1-841
89. Iconia Tab A100 (VanGogh) - A100
90. Iconia Tab A100 (VanGogh) - A101
91. Iconia Tab A200 - A200
92. Iconia Tab A210 - A210
93. Iconia Tab A211 - A211
94. Iconia Tab A500 - A500
95. Iconia Tab A501 - A501
96. Iconia Tab A510 - A510
97. Iconia Tab A511 - A511
98. Iconia Tab A700 - A700
99. Iconia Tab A701 - A701
100. Iconia TalkTab 7 - A1-724
101. Liquid - Acer Liquid
102. Liquid - Acer S100
103. Liquid - Liquid
104. Liquid 200 - Z200
105. Liquid C1 - I110
106. Liquid E1 - V360
107. Liquid E2 - V370
108. Liquid E3 - E380
109. Liquid E3 - E380
110. Liquid E3S - Z130
111. Liquid E600 - E600
112. Liquid E700 - E39
113. Liquid Gallant E350 - AK330
114. Liquid Gallant E350 - E350
115. Liquid Jade - S55
116. Liquid Jade 2 - S58A
117. Liquid Jade S - S56
118. Liquid Jade Z - S57
119. Liquid Mini - E310
120. Liquid S1 - S510
121. Liquid S2 - S520
122. Liquid S3 - S53
123. Liquid X1 - S53
124. Liquid X2 - S59
125. Liquid Z200 - Z200
126. Liquid Z205 - Z205
127. Liquid Z205 - Z205
128. Liquid Z205 - Z205P
129. Liquid Z220 - Z220
130. Liquid Z3 - Z130
131. Liquid Z3 - Z130
132. Liquid Z320 - T012
133. Liquid Z330 - T01
134. Liquid Z4 - Z160
135. Liquid Z410 - Z410
136. Liquid Z5 - Z150
137. Liquid Z500 - Z500
138. Liquid Z520 - Z520
139. Liquid Z530 - T02
140. Liquid Z530S - T05
141. Liquid Z6 - T09
142. Liquid Z6 Plus - T11
143. Liquid Z630 - T03
144. Liquid Z630S - T04
145. Liquid Z6E - T10
146. Liquid Zest - T06
147. Liquid Zest 4G - T07

148. Liquid Zest Plus - T08
149. LiquidMT - Acer Liquid Metal
150. LiquidMT - Liquid MT
151. LiquidMT - Liquid Metal
152. M3-2200 - M3-2200
153. MWND1 - MWND1
154. N3-2200 - N3-2200
155. Picasso - A501
156. Picasso - A500
157. Picasso - G100W
158. Picasso - TPA60W
159. TA2 - TA272HUL
160. TA272HUL - TA272HUL
161. TPA60W - TPA60W
162. Tab 7 - TD070VA1
163. Z110 - Z110
164. Z120 - Z120

### **Adart**

1. ALIGATOR RX510 - ALIGATOR RX510
2. ALIGATOR S4080 Duo - ALIGATOR S4080
3. ALIGATOR S4082 Duo - S4082 Duo
4. ALIGATOR S5062 Duo - S5062 Duo
5. ALIGATOR S5510 Duo - Aligator S5510
6. RX550 - RX550
7. S5060 Duo - ALIGATOR S5060

### **Admiral Overseas Corporation**

1. A2272PW4T - G3SMNTA22
2. A2272PW4T - G3SMNTA24
3. A2272PWHT - G2SMNT
4. A2472PW4T - G3SMNTA24
5. A7 - A7
6. C7 - C7
7. O7 - O7

### **Advan digital**

1. 5041 - 5041
2. 5059 - 5059
3. 5060 - 5060
4. 5061 - 5061
5. A8 - A8
6. E1C - E1C\_3G
7. G1 - G1
8. G1 PRO - i5K
9. I Tab - i7\_Plus
10. I55A - I55A
11. I5E - I5E
12. I5E - i5E
13. I7D - I7D
14. M4 - ADVAN M4
15. S45E - S45E
16. S4T - S4T
17. S4Z - S4Z
18. S5E\_NXT - S5E\_NXT
19. S7A - S7A
20. S7C - S7C
21. T2J - T2J
22. T2K - T2K
23. X7 Pro - 7008
24. i10 - i10

25. i5C - i5C
26. i5C plus - 5058
27. i7 - i7
28. i7A - i7A

### **Affix**

1. T737 - AFFIX T737

### **Aikun**

1. EDSTAR LC-TS08A - LC-TS08A
2. EDSTAR LC-TS08S - LC-TS08S
3. RX300 - X300
4. Solely Tab S7 - S7
5. Solely Tab S8 - S8

### **Airtel**

1. SH960S-AT - SH960S-AT

### **Aiuto**

1. AT1001 - AT1001
2. AT701 - AT701

### **Aiwa**

1. AW790 - AW790
2. Z9 - Z9
3. Z9 PLUS - Z9 PLUS

### **Alba**

1. Alba\_8in - Alba\_8in

### **AllView**

1. A5 Easy - A5\_Easy
2. A5 Easy - A5\_Easy\_TM
3. A5 Lite - A5\_Lite
4. A5 Quad Plus - A5\_Quad\_Plus
5. A5 Quad Plus - A5\_Quad\_Plus\_TM
6. A5 Ready - A5\_Ready
7. A5 Ready - A5\_Ready\_TM
8. A6 Duo - A6\_Duo
9. A6 Lite - A6\_Lite
10. A7 Lite - A7\_Lite
11. A8 Lite - A8\_Lite
12. A8 Lite TM - A8\_Lite\_TM
13. A9 Lite - A9\_Lite
14. AX4 Nano Plus - AX4Nano\_plus
15. AX501Q - AX501Q
16. C6 Duo - C6\_Duo
17. C6 Quad 4G - C6Quad\_4G
18. E2 Jump - E2\_Jump
19. E3 Jump - E3\_Jump
20. E3 Living - E3\_Living
21. E3 Sign - E3\_Sign
22. E4 - E4
23. E4 Lite - E4\_Lite
24. P4 Pro - P4\_Pro
25. P4 Quad - P4\_Quad
26. P4 eMagic - P4\_eMagic
27. P4 eMagic - P4\_eMagic\_TM
28. P41 eMagic - P41\_eMagic

29. P41 eMagic - P41\_eMagic\_TM  
30. P42 - P42  
31. P5 Energy - P5\_Energy  
32. P5 Life - P5Life\_TM  
33. P5 Lite - P5\_Lite  
34. P5 Pro - P5\_Pro  
35. P5 eMagic - P5\_eMagic  
36. P5 eMagic - P5\_eMagic\_TM  
37. P5Life - P5Life  
38. P5\_Pro - P5\_Pro\_TM  
39. P6 Plus - P6\_plus  
40. P6 Energy - P6\_Energy\_TM  
41. P6 Energy Lite - P6\_Energy\_Lite  
42. P6 Energy Lite - P6\_Energy\_Lite\_TM  
43. P6 Energy mini - P6\_Energy\_mini  
44. P6 Life - P6\_Life  
45. P6 Lite - P6\_lite  
46. P6 Lite - P6\_lite\_TM  
47. P6 Lite - P6\_lite\_mTEL  
48. P6 Pro - P6\_Pro  
49. P6 Qmax - P6\_Qmax  
50. P6 eMagic - P6\_eMagic  
51. P6\_Energy - P6\_Energy  
52. P7 PRO - P7\_PRO  
53. P7 PRO\_TM - P7\_PRO\_TM  
54. P8 Energy - P8\_Energy  
55. P8 Energy Pro - P8\_Energy\_PRO  
56. P8 Energy mini - P8\_Energy\_mini  
57. P8 Energy mini - P8\_Energy\_mini\_TM  
58. P8 Life - P8\_Life  
59. P8 eMagic - P8\_eMagic  
60. P8 eMagic - P8\_eMagic\_TM  
61. P9 Energy - P9\_Energy  
62. P9 Energy Lite - P9\_Energy\_Lite  
63. P9 Energy Lite 2017 - P9\_Energy\_Lite\_2017  
64. P9 Energy Mini - P9\_Energy\_mini\_TM  
65. P9 Energy S - P9\_Energy\_S  
66. P9 Energy mini - P9\_Energy\_mini  
67. V1 Viper E - V1\_Viper\_E  
68. V1 Viper I4G - V1\_Viper\_I4G  
69. V1 Viper I4G - V1\_Viper\_I4G\_PL  
70. V1 Viper I4G - V1\_Viper\_I4G\_TM  
71. V1 Viper I4G - V1\_Viper\_I4G\_PL  
72. V1 Viper L - V1\_Viper\_L  
73. V1 Viper S4G - V1\_Viper\_S4G  
74. V2 Viper - V2\_Viper  
75. V2 Viper E - V2\_Viper\_E  
76. V2 Viper I - V2\_Viper\_I  
77. V2 Viper I - V2\_Viper\_I\_TM  
78. V2 Viper I4G - V2\_Viper\_I4G  
79. V2 Viper S - V2\_Viper\_S  
80. V2 Viper X - V2\_Viper\_X  
81. V2 Viper X plus - V2\_Viper\_X\_plus  
82. V2 Viper Xe - V2\_Viper\_Xe  
83. Viva 1001G - Viva\_1001G  
84. Viva C701 - Viva\_C701  
85. Viva C702 - Viva\_C702  
86. Viva H10 LTE - VivaH10LTE  
87. Viva H1001 LTE - Viva\_H1001\_LTE  
88. Viva H1002 LTE - Viva\_H1002\_LTE  
89. Viva H7 LTE - VivaH7LTE  
90. Viva H8 LTE - VivaH8LTE

91. Viva H8 Life - H8\_Life  
92. Viva H801 - Viva\_H801  
93. Viva H801 LTE - Viva\_H801\_LTE  
94. Viva H802 LTE - Viva\_H802\_LTE  
95. Viva H802 LTE - Viva\_H802\_LTE\_TM  
96. Viva i10HD - Viva\_i10HD  
97. Viva i701G - Viva\_H701\_LTE\_CZ  
98. Viva i701G - Viva\_i701G  
99. Viva i701G - Viva\_i701G\_TM  
100. Viva i7G - Viva\_i7G  
101. Viva\_H701\_LTE - Viva\_H701\_LTE  
102. X2 Soul Lite - X2\_Soul\_Lite  
103. X2 Soul Lite - X2\_Soul\_Lite\_TM  
104. X2 Soul Mini - X2\_Soul\_Mini  
105. X2 Soul PRO - X2\_Soul\_PRO  
106. X2 Soul Style - X2\_Soul\_Style  
107. X2 Soul Style - X2\_Soul\_Style\_TM  
108. X2 Soul Style+ - X2\_Soul\_Style\_Plus  
109. X2 Soul Xtreme - X2\_Soul\_Xtreme  
110. X3 Soul Lite - X3\_Soul\_Lite  
111. X3 Soul Lite - X3\_Soul\_Lite\_TM  
112. X3 Soul Plus - X3\_Soul\_PLUS  
113. X3 Soul Pro - X3\_Soul\_PRO  
114. X3 Soul Style - X3\_Soul\_Style  
115. X3 Soul mini - X3\_Soul\_mini  
116. X3Soul - X3\_Soul  
117. X4 Soul - X4\_Soul  
118. X4 Soul Infinity L - X4\_Soul\_Infinity\_L  
119. X4 Soul Infinity N - X4\_Soul\_Infinity\_N  
120. X4 Soul Infinity S - X4\_Soul\_Infinity\_S  
121. X4 Soul Lite - X4\_Soul\_Lite  
122. X4 Soul Mini - X4\_Soul\_Mini  
123. X4 Soul Mini S - X4\_Soul\_Mini\_S  
124. X4 Soul Mini S - X4\_Soul\_Mini\_S\_TM  
125. X4 Soul Style - X4\_Soul\_Style  
126. X4 Soul Vision - X4\_Soul\_Vision  
127. X4 Soul Xtreme - X4\_Soul\_Xtreme

### Allfine

1. M721 - M721
2. PC1038Q - PC1038Q

### Alphascan

1. SAT2242 WorkTab - G2SMNT

### Altice

1. ALTICE S70 - S70
2. S60 - S60
3. STARNAUTE 4 - STARNAUTE4
4. STARNAUTE3 - STARNAUTE 3
5. STARXTREM5 - STARXTREM5
6. Staractive - STARACTIVE

### Amgoo

1. AM350 - AM350
2. AM402 - AM402
3. AM410 - AM410
4. AM415 - AM415
5. AM506 - AM506
6. AM508 - AM508



7. AM509 - AM509
8. AM509 - AM509
9. AM515 - AM515
10. AM518 - AM518
11. AM520 - AM520
12. AM530 - AM530
13. AM535 - AM535

## Amplify

1. TL10RA3 - TL10RA3
2. TR10CD3 - TR10CD3
3. TR10CD3 - TR10CD3

## Anydata

1. ASP320Q\_GSM - ASP320Q\_ANDi
2. Aquaris I8 - bq Aquaris
3. Auchan MID7317CP Tablet - MID7317CP
4. COBY MID7055 - MID7055
5. Carrefour CT710 - CT710
6. Carrefour CT720 / Emdoor EM63 Tablet - EM63
7. Coby MID1065 - MID1065
8. Coby MID7065 - MID7065
9. Coby MID8065 - MID8065
10. D2-721G - D2-721G
11. D2-727G - D2-727
12. DOPO GMS-718 Tablet / Discovery - GS-718
13. DOTPAD DP3D8 / Gadmei - DP3D8
14. Digix TAB-840\_G - TAB-840\_G
15. Eviant MT8000 - MT8000
16. Garmin nuvi3590 - nuvi 3590
17. Garmin nuvi3595 - nuvi 3595
18. Grundig GR-TB10S Tablet - GR-TB10S
19. HCL ME TABLET PC U2 - U2
20. HKC P771A - P771A
21. HKC P774A - P774A
22. HKC P776A - P776A
23. HKC P778A - P778A
24. HKC P886A - P886A
25. HS\_7DTB14 - HS\_7DTB14
26. Insignia NS-13T001 Tablet - NS-13T001
27. Jiateng JT1241 - JT1241
28. Lazer MD7305 Tablet / AMTC - MD7305
29. Le Pan S - Le Pan S
30. LePanII - LePanII
31. Leader I10A-LE - I10A-LE
32. Mach\_Speed Trio G2 Tablet - G2
33. Marquis Tablet - Marquis\_MP977
34. Matsunichi M97 - M97
35. Monster M7 Tablet - M7
36. Nextbook NX007HD Tablet - NX007HD
37. Nextbook NX008HD8G Tablet - NX008HD8G
38. Nextbook NX008HI Tablet / Carrefour CT810 - NX008HI
39. Nextbook Next7D12 Tablet - Next7D12
40. Nextbook Next7P12 - Next7P12
41. Pendo PNDPP48GP - PNDPP48GP
42. Philips W336 - Philips W336
43. Philips W536 - Philips W536
44. Philips W626 - W626
45. Philips W632 - Philips W632
46. Philips W832 - Philips W832

47. Proscan PLT7223G - PLT7223G
48. Proscan PLT7777 - PLT7777
49. Proscan PLT8223G - PLT8223G
50. RCA RCT6078W2 - RCT6078W2
51. RCA RCT6078W2 - RCT6078W2
52. TecToy TT-2500 - TECTOYTT2500
53. Visual Land Prestige 7D - PRO7D
54. Vivitar Camelio Tablet - Camelio Family tablet
55. Vivitar XO Tablet - XO Learning tablet
56. Zeki TBDG773 - TBDG773
57. ematic EGP008 - EGP008
58. ematic EGP010 - EGP010
59. ematic EGS004 - EGS004
60. ematic EGS102 - EGS102
61. essentielb ST8003/FT8001 Tablet - Smart\TAB 8003
62. iCraig CMP748 - CMP748
63. iCraig CMP749 - CMP749

## Apex

1. MT-734G - MT-734G
2. TM772 - TM772
3. TM785CH - TM785CH

## Aprix

1. Phat6 - Aprix\_Phath6
2. Tab64 - Aprix Tab64
3. X4 - Aprix\_X4

## Arcelik

1. B55L 9682 5AS - arcelik\_uhd\_powermax\_at

## Archos

1. A101S - ARCHOS 101G9
2. A101S - Archos 101 Internet Tablet
3. A80S - ARCHOS 80G9
4. A80S - Archos 80 Internet Tablet
5. 101 Childpad - ARCHOS 101 CHILDPAD
6. 101 Cobalt - Archos 101 Cobalt
7. 101 Copper - Archos 101 Copper
8. 101 G9 - ARCHOS 101G9
9. 101 Helium - Archos 101 Helium
10. 101 Helium Lite - Archos 101 Helium Lite
11. 101 Magnus - ARCHOS 101 Magnus
12. 101 Neon - Archos 101 Neon
13. 101 Oxygen - Archos 101 Oxygen
14. 101 Platinum - ARCHOS 101 PLATINUM
15. 101 Titanium - ARCHOS 101 Titanium
16. 101 XS - ARCHOS 101G10
17. 101 Xenon - Archos 101 Xenon
18. 101 Xenon - Archos 101c Xenon
19. 101 Xenon - Archos 101 Xenon v2
20. 101 Xenon Lite - Archos 101 Xenon Lite
21. 101D Neon - Archos 101d Neon
22. 101XS2 - ARCHOS 101 XS 2
23. 101XS3 - Archos 101XS3
24. 101b Copper - Archos 101b Copper
25. 101b Helium - Archos 101b Helium
26. 101b Neon - Archos 101b Neon
27. 101b Oxygen - Archos 101b Oxygen
28. 101b Platinum - Archos 101b Platinum

29. 101b XS2 - ARCHOS 101b XS2
30. 101b Xenon - Archos 101b Xenon v2
31. 101c Copper - Archos 101c Copper
32. 101c Neon - Archos 101c Neon
33. 101c Platinum - Archos 101c Platinum
34. 101d Platinum v2 - Archos 101d Platinum v2
35. 101d Platinum v3 - Archos 101d Platinum v3
36. 101e Neon - Archos 101e Neon
37. 101e neon - Archos 101e Neon
38. 121 Neon - Archos 121 Neon
39. 133 Oxygen - Archos 133 Oxygen
40. 35b Titanium - Archos 35b Titanium
41. 40 Helium - Archos 40 Helium
42. 40 Neon - Archos 40 Neon
43. 40 Power - Archos 40 Power
44. 40 Power - Archos 40 Power
45. 40 Titanium - Archos 40 Titanium
46. 40b Titanium - Archos 40b Titanium Surround
47. 40c Titanium - Archos 40c Titanium
48. 40c Titanium - ARCHOS 40C Tlv2
49. 40d Titanium - ARCHOS 40d Titanium
50. 45 Helium 4G - Archos 45 Helium 4G
51. 45 Neon - Archos 45 Neon
52. 45 Platinum - Archos 45 Platinum
53. 45 Titanium - Archos 45 Titanium
54. 45b Helium - AC45BHE
55. 45b Helium - ARCHOS 45b Helium
56. 45b Neon - Archos 45b Neon
57. 45b Platinum - Archos 45b Platinum
58. 45c Helium - Archos 45c Helium
59. 45c Platinum - Archos 45c Platinum
60. 45c Titanium - Archos 45c Titanium
61. 45d Platinum - Archos 45d Platinum
62. 50 Cobalt - Archos 50 Cobalt
63. 50 Diamond - Archos 50 Diamond
64. 50 Helium 4G - Archos 50 Helium 4G
65. 50 Helium Plus - Archos 50 Helium Plus
66. 50 Neon - Archos 50 Neon
67. 50 Oxygen - Archos 50 Oxygen
68. 50 Oxygen plus - Archos 50 Oxygen Plus
69. 50 Platinum - Archos 50 Platinum
70. 50 Platinum 4G - Archos 50 Platinum 4G
71. 50 Power - Archos 50 Power
72. 50 Saphir - Archos 50 Saphir
73. 50 Titanium - Archos 50 Titanium
74. 50 Titanium 4G - A50TI
75. 50 d Helium - AC50DHE
76. 50B Cobalt - Archos 50B Cobalt
77. 50F Neon - Archos 50f Neon
78. 50b Helium - AC50BHE
79. 50b Helium - Archos 50b Helium 4G
80. 50b Neon - Archos 50b Neon
81. 50b Oxygen - Archos 50b Oxygen
82. 50b Platinum - Archos 50b Platinum
83. 50c Helium - Archos 50c Helium
84. 50c Neon - ARCHOS 50c Neon
85. 50c Neon - Archos 50c Neon
86. 50c Oxygen - Archos 50c Oxygen
87. 50c Platinum - Archos 50c Platinum
88. 50d Neon - Archos 50d Neon
89. 50d Oxygen - Archos 50d Oxygen
90. 50e Helium - Archos 50e Helium
91. 50e Neon - Archos 50e Neon
92. 50f Helium - Archos 50f Helium
93. 50f Neon - Archos 50F Neon
94. 52 Platinum - Archos 52 Platinum
95. 53 Platinum - Archos 53 Platinum
96. 53 Titanium - Archos 53 Titanium
97. 55 Cobalt Plus - Archos 55 Cobalt Plus
98. 55 Cobalt Plus - Archos 55 Cobalt plus
99. 55 Diamond Selfie - Archos 55 diamond Selfie
100. 55 Helium - Archos 55 Helium
101. 55 Helium Plus - Archos 55 Helium Plus
102. 55 platinum - Archos 55 Platinum
103. 55B Cobalt - Archos 55B Cobalt
104. 55b Platinum - Archos 55B Platinum
105. 59 Titanium - Archos 59 Titanium
106. 59 Xenon - Archos 59 Xenon
107. 60 Platinum - Archos 60 Platinum
108. 62 Xenon - Archos 62 Xenon
109. 64 Xenon - Archos 64 Xenon
110. 70 Cobalt - ARCHOS 70 Cobalt
111. 70 Copper - Archos 70 Copper
112. 70 Helium - Archos 70 Helium
113. 70 Neon - Archos 70 Neon
114. 70 Neon Plus - Archos 70 Neon Plus
115. 70 Oxygen - Archos 70 Oxygen
116. 70 Platinum - Archos 70 Platinum
117. 70 Platinum 3G - Archos 70 Platinum 3G
118. 70 Platinum v2 - Archos 70 Platinum v2
119. 70 Titanium - ARCHOS 70 Titanium
120. 70 Xenon - Archos 70 Xenon
121. 70 Xenon Color - Archos 70 Xenon Color
122. 70 platinum - Archos 70 Platinum v3
123. 70b Cobalt - Archos 70b Cobalt
124. 70b Copper - Archos 70b Copper
125. 70b Helium - Archos 70b Helium
126. 70b Neon - Archos 70b Neon
127. 70b Titanium - ARCHOS 70b TITANIUM
128. 70b Xenon - Archos 70b Xenon
129. 70c Cobalt - Archos 70c Cobalt
130. 70c Neon - Archos 70c Neon
131. 70c Titanium - Archos 70c Titanium
132. 70c Xenon - Archos 70c Xenon
133. 70it 2 - ARCHOS 70it2
134. 70it 2 - ARCHOS 70it2G8
135. 79 Cobalt - Archos 79 Cobalt
136. 79 Neon - Archos 79 Neon
137. 79 Platinum - ARCHOS 79 Platinum
138. 79 Xenon - Archos 79 Xenon
139. 80 Carbon - ARCHOS 80 Carbon
140. 80 Childpad - ARCHOS 80 CHILDPAD
141. 80 Cobalt - ARCHOS 80 COBALT
142. 80 G9 - ARCHOS 80G9
143. 80 Helium - Archos 80 Helium 4G
144. 80 Oxygen - Archos 80 Oxygen
145. 80 Platinum - ARCHOS 80 Platinum
146. 80 Platinum - Archos 80 Platinum
147. 80 Platinum v2 - Archos 80 Platinum v2
148. 80 Titanium - ARCHOS 80 TITANIUM
149. 80 XS - ARCHOS 80XSK
150. 80 Xenon - Archos 80 Xenon
151. 80b Helium - Archos 80b Helium
152. 80b Helium - Archos 80b Helium v2

153. 80b Platinum - ARCHOS 80b PLATINUM
154. 80b xenon - Archos 80b Xenon
155. 80c Xenon - Archos 80c Xenon
156. 80d Xenon - Archos 80d Xenon
157. 9.4\'' FFF - 9.4\'' FFF
158. 90 Copper - Archos 90 Copper
159. 90 Neon - Archos 90 Neon
160. 90b Copper - Archos 90b Copper
161. 90b Neon - Archos 90b Neon
162. 96 Xenon - Archos 96 Xenon
163. 97 Carbon - ARCHOS 97 CARBON
164. 97 Cobalt - Archos 97 Cobalt
165. 97 Platinum - ARCHOS 97 Platinum
166. 97 Titanium HD - ARCHOS 97 TITANIUMHD
167. 97 Xenon - ARCHOS 97 XENON
168. 97b Platinum - ARCHOS 97b PLATINUM
169. 97b Titanium - ARCHOS 97B TITANIUM
170. 97c Platinum - Archos 97c Platinum
171. ALBA 5 - ALBA 5
172. ALBA4 - ALBA 4
173. Alba 10 - ALBA 10 TABLET
174. Alba 10" - Alba 10"
175. Alba 4 - Alba 4.0" Smartphone
176. Alba 4 - ALBA 4
177. Alba 4" Android - Alba 4" Android
178. Alba 5 - ALBA 5
179. Alba 5 - ALBA 5
180. Alba 7 - ALBA 7 TABLET
181. Alba 7\'' - Alba 7
182. Alba 7\'' - Alba 7"
183. Alba 8 - Alba 8"
184. Alba 8\'' - Alba 8"
185. ArcBook - Archos 101 DB
186. Archos 101 Platinum 3G - Archos 101 Platinum 3G
187. Archos 101 Platinum 3G - Archos 101 Platinum 3G
188. Archos 101b Oxygen - Archos 101b Oxygen
189. Archos 101b Xenon - Archos 101b Xenon v3
190. Archos 101c Helium - Archos 101c Helium
191. Archos 101c Platinum - Archos 101c Platinum
192. Archos 101c Xenon - Archos 101c Xenon
193. Archos 116 Neon - Archos 116 Neon
194. Archos 156 Oxygen - Archos 156 Oxygen
195. Archos 50c Platinum - ALBA 8 TABLET
196. Archos 70 platinum - Archos 70 Platinum
197. Archos 70d Titanium - Archos 70d Titanium
198. Archos 79b Neon - Archos 79b Neon
199. Archos 80 Oxygen - Archos 80 Oxygen
200. Archos 80c Platinum - Archos 80c Platinum
201. Archos 97c Platinum - Archos 97c Platinum
202. Archos Access 40 3G - Archos Access 40 3G
203. Archos Core 101 3G - Archos Core 101 3G
204. Archos Core 101 4G - Archos Core 101 4G
205. Archos Core 50 4G - Archos Phone
206. Archos Core 50P - Archos Core 50P
207. Archos Core 55P - Archos Core 55P
208. Archos Core 70 3G - Archos Core 70 3G
209. Archos Sense 50 DC - Archos Sense 50 DC
210. Archos Sense 55 DC - Archos Sense 55 DC
211. Archos Sense 55 DC - Archos Phone
212. Archos80cpl\_loreal - Archos 80c Platinum
213. Auchan QiLive 45 - Qilive 45
214. Auchan QiLive 50 - Qilive 50
215. Auchan Qilive 40 - Qilive 40
216. Auchan Qilive8 - QiLive 8
217. Auchan Qilive8QC - QiLive 8QC
218. Auchan Qilive97 - QiLive 97
219. Auchan Qilive97R - QiLive 97R
220. Auchan Selecline 10 - Selecline 10
221. BUSH SPIRA B3 5.5 - BUSH SPIRA B3 5.5
222. BUSH SPIRA B5 POWER - BUSH SPIRA B5 POWER
223. BUSH SPIRA D3 5 - BUSH SPIRA D3 5
224. BUSH SPIRA D5 Dual Camera - BUSH SPIRA D5 Dual Camera
225. BUSH SPIRA D5.5 Dual Camera - BUSH SPIRA D5.5 Dual Camera
226. Bush 10\'' - Bush 10" Android
227. Bush 10.0 MyTablet - Bush 10.0 MyTablet
228. Bush 4" Android Phone - Bush 4 Android
229. Bush 5 4G - Bush 5" 4G
230. Bush 5 4G - Bush Spira C2 5" Smartphone
231. Bush 5 4G - Bush 5.5" 4G
232. Bush 5 4G - Bush Spira D2 5.5" Smartphone
233. Bush 5" Android - Bush 5" Android
234. Bush 5" Android Phone - BUSH 5 Android
235. Bush 7.0 MyTablet - Bush 7.0 MyTablet
236. Bush 7.85 My Tablet - Archos 79c Neon
237. Bush 8" - Bush 8" LTE Android
238. Bush 8\'' - Bush 8 Android
239. Bush 8.0 MyTablet - Bush 8.0 MyTablet
240. Bush MyTablet 7 - Archos 70 Carbon
241. Bush MyTablet 7 - BUSH 7.0 TABLET
242. Bush Mytablet 2 - Bush Mytablet 2
243. Bush Spira B1 10.1 - Bush Spira B1 10.1"
244. Bush Spira B1 10.1\'' - Bush Spira B1 10.1"
245. Bush Spira B1 8\'' - Bush Spira B1 8"
246. Bush Spira B2 8 tablet - Bush Spira B2 8 tablet
247. ChefPad - Archos Chefpad
248. Diamond 2 plus - Archos 55 Diamond 2 Plus
249. Diamond Plus - Archos 55 Diamond Plus
250. Diamond Plus - Archos Diamond Plus
251. Diamond S - Archos Diamond S
252. FamilyPad 2 - ARCHOS FAMILYPAD 2
253. Fieldbook G1 - Logic Fieldbook G1
254. GamePad - ARCHOS GAMEPAD
255. GamePad 2 - ARCHOS GAMEPAD2
256. KUNO 4+ - KUNO 4+
257. Kodak Tab 10 - KODAK Tablet 10
258. Kodak Tab 7 - KODAK Tablet 7
259. Kuno - KUNO4
260. My Tablet 101 - BUSH 10.1 TABLET
261. QiLive 101 - QILIVE 101
262. Qilive 45 - 4G - Qilive 45 - 4G
263. Qilive 50 QC - Qilive 50 QC
264. Qilive 53 - Qilive 53
265. Qilive 7 - Qilive 7
266. Qilive 97R2 - Qilive 97R-2
267. Qilive79 - Qilive 79
268. Qilive7V2 - Qilive 70v2
269. Quechua Phone 5 - Quechua Phone 5
270. Quechua Tablet 8 - A80RG11
271. Smart Home Tablet - Archos Smart Home Tablet
272. Smarthome La Poste - Archos Smart Home Tablet
273. TV Connect - ARCHOS LUDOG10
274. alba 10 - ALBA 10 TABLET



275. alba 10 - Alba 10"

## Ark

1. Bebenefit M551 - Benefit\_M551
2. Benefit M503 - Benefit\_M503
3. Benefit M505 - Benefit\_M505
4. Benefit M8 - Benefit\_M8
5. Impulse P2 - Impulse\_P2

## Ascom Wireless Solutions

1. Ascom Myco 2 Cellular - SH1
2. Ascom Myco 2 WiFi - SH1
3. Ascom Myco Cellular - SH1
4. Ascom Myco Cellular - SH1
5. Ascom Myco Wi-Fi - SH1

## Ashna

1. X55 - X55
2. X66 - X66
3. Z600 - Z600

## Astak

1. NEOS - NEOS

## Astro Queo

1. A712 - A712

## AstroQueo

1. polaris\_wifionly - A912

## Asus

1. EP71 - ME171
2. TF300T - ASUS Transformer Pad TF300T
3. a10 - Asus A10
4. a10 - Garmin-Asus A10
5. ventana - Transformer TF101
6. ASUS Chromebook Flip C302 - ASUS Chromebook Flip C302
7. ASUS Live (G500TG) - ASUS\_Z00YD
8. ASUSPRO Tablet (M1000C) - P023
9. ASUSPRO Tablet (M1000CL) - P01T
10. ASUSPRO Tablet (M700C) - P01W
11. ASUSPRO Tablet (M700KL) - P002
12. Chromebook C202SA/C300SA/C301SA - ASUS Chromebook C202SA
13. Chromebook Flip C100PA - ASUS Chromebook Flip C100PA
14. Chromebook Flip C101PA - bob
15. Commercial tablet 10" (M1000M) - P00C
16. Commercial tablet 10" (R1000M) - P00C
17. Commercial tablet 8" (M800M) - P00A
18. Commercial tablet 8" (R800M) - P00A
19. Cube - asus\_google\_cube
20. ETBW11AA - ETBW11AA
21. ETBW11AA - ETBW11AA
22. Eee Pad - Transformer TF101
23. Eee Pad - Transformer TF101G
24. Eee Pad Slider - Slider SL101
25. Eee Pad TF101 - TF101
26. Eee Pad TF101 - Transformer TF101
27. Eee Pad TF101-WiMAX - TF101-WiMAX
28. Eee Pad Transformer - Transformer TF101
29. Eee Pad Transformer Prime - TF201
30. Eee Pad Transformer Prime - Transformer Prime TF201
31. Eee Pad Transformer Prime - Transformer TF201
32. EeePad Slider SL101 - Slider SL101
33. Fonepad 7 (FE170CG) - K012
34. Fonepad 7 (FE171CG) - K01N
35. Fonepad 7 (FE171CG) - K01N
36. Fonepad 7 (FE171MG) - K01F
37. Fonepad 7 (FE375CG) - K019
38. Fonepad 7 (FE375CXG) - K019
39. Fonepad 7 (FE375CXG) - K019
40. Fonepad 7 (FE375CXG) - K019
41. Fonepad 7 (ME175CG) - K00Z
42. Fonepad 7 (ME372CG) - K00E
43. Fonepad 7 LTE (FE375CL) - K01Q
44. Fonepad 7 LTE (ME372CL) - K00Y
45. Fonepad 8 (FE380CG) - K016
46. Fonepad 8 (FE380CG) - K016
47. Fonepad 8 (FE380CXG) - K016
48. Fonepad 8 (FE380CXG) - K016
49. Fonepad ME371MG - ME371MG
50. Fonepad Note 6 (ME560CG) - K00G
51. MeMO PAD - ME172V
52. MeMO Pad (ME103K) - K01E
53. MeMO Pad (ME103K) - K01E
54. MeMO Pad 10 (ME102A) - K00F
55. MeMO Pad 7 (FE7010CG) - K012\_2
56. MeMO Pad 7 (ME170C) - K017
57. MeMO Pad 7 (ME171C) - K01U
58. MeMO Pad 7 (ME171C) - K01U
59. MeMO Pad 7 (ME176C) - K013
60. MeMO Pad 7 (ME176CE) - K013C
61. MeMO Pad 7 (ME176CX) - K013
62. MeMO Pad 7 (ME572C) - K007
63. MeMO Pad 7 (ME70C) - K01A
64. MeMO Pad 7 LTE (ME375CL) - ASUS MeMO Pad 7
65. MeMO Pad 7 LTE (ME572CL) - K00R
66. MeMO Pad 7 LTE (ME7530CL) - K00X
67. MeMO Pad 8 (AST21) - AST21
68. MeMO Pad 8 (ME181C) - K011
69. MeMO Pad 8 (ME181CX) - K011
70. MeMO Pad 8 (ME581C) - K01H
71. MeMO Pad 8 (ME581CL) - K015
72. MeMO Pad FHD 10 (ME302KL) - ME302KL
73. MeMO Pad HD 7 (ME173X) - ME173X
74. MeMO Pad HD 7 (ME173XX) - K00U
75. MeMO Pad HD 8 (ME180A) - K00L
76. MeMO Pad HD7 Dual SIM (ME175KG) - ASUS K00S
77. MeMO Pad Smart 10 - ME301T
78. MeMo Pad 10 (ME302C) - ME302C
79. MeMo Pad HD 7 (ME173XX) - K00U
80. Nexus 7 (2012) - Nexus 7
81. Nexus 7 (2012) - Nexus 7
82. Nexus 7 (2013) - Nexus 7
83. Nexus 7 (2013) - Nexus 7
84. Nexus Player - Nexus Player
85. Nuvifone - Garmin-Asus A50
86. PadFone - PadFone

87. PadFone 2 - PadFone 2
88. PadFone E (A68M) - PadFone T008
89. PadFone Infinity - PadFone Infinity
90. PadFone Infinity - PadFone Infinity
91. PadFone Mini - PadFone T00C
92. PadFone S (PF500KL) - ASUS\_T00N
93. PadFone X (A91) - ASUS PadFone X
94. PadFone X mini (PF450CL) - ASUS PadFone X mini
95. PadFone X mini (PF450CL) - ASUS\_T00T
96. PadFone mini - PadFone T00C
97. PadFone mini - ASUS\_T00E
98. R Series Tablet (R1001MFL) - P00L
99. R Series Tablet (R1001ML) - P00L
100. RTC-700A - RTC-tablet
101. T101TA - T10xTA
102. TF700T - ASUS Pad TF700T
103. TF700T - ASUS Transformer Pad TF700T
104. TX201LAF - TX201LAF
105. The new PadFone Infinity (A86) - PadFone T004
106. Trans AiO P1801 - ASUS Tablet P1801-T
107. TransBook Trio - TX201LA
108. Transformer AiO P1801 - ASUS Tablet P1801-T
109. Transformer AiO P1802 - ASUS Tablet P1802-T
110. Transformer Book Trio - TX201LA
111. Transformer Pad - K010
112. Transformer Pad - ASUS Pad TF300T
113. Transformer Pad - ASUS Transformer 300
114. Transformer Pad - ASUS Transformer Pad TF300T
115. Transformer Pad (TF103C) - K010
116. Transformer Pad (TF103C) - K010
117. Transformer Pad (TF103CE) - K010E
118. Transformer Pad (TF103CE) - K010E
119. Transformer Pad (TF103CG) - K018
120. Transformer Pad (TF303CL) - K014
121. Transformer Pad (TF303K) - K01B
122. Transformer Pad Infinity - ASUS Transformer Pad TF700KL
123. Transformer Pad Infinity (TF701T) - K00C
124. Transformer Pad TF300TG - ASUS Transformer Pad TF300TG
125. Transformer Pad TF300TL - ASUS Transformer Pad TF300TL
126. Transformer Pad TF502T - ASUS Transformer Pad TF502T
127. Transformer Pad TF600T - ASUS Transformer Pad TF600T
128. Transformer TF101G - Transformer TF101G
129. ZenFone 2 (ZE500CL) - ASUS ZenFone 2
130. ZenFone 2 (ZE500CL) - ASUS ZenFone 2E
131. ZenFone 2 (ZE500CL) - Z00D
132. ZenFone 2 (ZE550ML) - ASUS\_Z008D
133. ZenFone 2 (ZE551ML) - ASUS\_Z00AD
134. ZenFone 2 (ZE551ML) - ASUS\_Z00ADA
135. ZenFone 2 (ZE551ML) - ASUS\_Z00AD
136. ZenFone 2 (ZE551ML) - ASUS\_Z00ADB
137. ZenFone 2 (ZE551ML) - ASUS\_Z00AD
138. ZenFone 2 Laser (ZE500KG) - ASUS\_Z00RD
139. ZenFone 2 Laser (ZE500KG) - ASUS\_Z00RD
140. ZenFone 2 Laser (ZE500KL) - ASUS\_Z00ED
141. ZenFone 2 Laser (ZE500KL) - ASUS\_Z00ED
142. ZenFone 2 Laser (ZE500KL) - ASUS\_Z00EDB
143. ZenFone 2 Laser (ZE500KL) - ASUS\_Z00ED
144. ZenFone 2 Laser (ZE500KL) - ASUS\_Z00ED
145. ZenFone 2 Laser (ZE550KG) - ASUS\_Z00WD
146. ZenFone 2 Laser (ZE550KL) - ASUS\_Z00LD
147. ZenFone 2 Laser (ZE550KL) - ASUS\_Z00LDC
148. ZenFone 2 Laser (ZE550KL) - ASUS\_Z00LD
149. ZenFone 2 Laser (ZE550KL) - ASUS\_Z00LD
150. ZenFone 2 Laser (ZE550KL) - ASUS\_Z00LD
151. ZenFone 2 Laser (ZE551KL) - ASUS\_Z00TD
152. ZenFone 2 Laser (ZE600KL) - ASUS\_Z00MD
153. ZenFone 2 Laser (ZE601KL) - ASUS\_Z011D
154. ZenFone 3 (ZE520KL) - ASUS\_Z017D
155. ZenFone 3 (ZE520KL) - ASUS\_Z017DA
156. ZenFone 3 (ZE552KL) - ASUS\_Z012D
157. ZenFone 3 (ZE552KL) - ASUS\_Z012DA
158. ZenFone 3 (ZE552KL) - ASUS\_Z012DE
159. ZenFone 3 Deluxe (ZS550KL) - ASUS\_Z01FD
160. ZenFone 3 Deluxe (ZS570KL) - ASUS\_Z016D
161. ZenFone 3 Deluxe (ZS570KL) - ASUS\_Z016DA
162. ZenFone 3 Deluxe (ZS570KL) - ASUS\_Z016S
163. ZenFone 3 Deluxe (ZS570KL) - ASUS\_Z016D
164. ZenFone 3 Laser (ZC551KL) - ASUS\_Z01BD
165. ZenFone 3 Laser (ZC551KL) - ASUS\_Z01BDA
166. ZenFone 3 Laser (ZC551KL) - ASUS\_Z01BDC
167. ZenFone 3 Laser (ZC551KL) - ASUS\_Z01BS
168. ZenFone 3 Max (ZC520TL) - ASUS\_X008D
169. ZenFone 3 Max (ZC520TL) - ASUS\_X008DA
170. ZenFone 3 Max (ZC520TL) - ASUS\_X008DB
171. ZenFone 3 Max (ZC520TL) - ASUS\_X008D
172. ZenFone 3 Max (ZC520TL) - ASUS\_X008DA
173. ZenFone 3 Max (ZC520TL) - ASUS\_X008DB
174. ZenFone 3 Max (ZC520TL) - ASUS\_X008DC
175. ZenFone 3 Max (ZC553KL) - ASUS\_X00DD
176. ZenFone 3 Max (ZC553KL) - ASUS\_X00DDA
177. ZenFone 3 Ultra (ZU680KL) - ASUS\_A001
178. ZenFone 3 Zoom (ZE553KL) - ASUS\_Z01HD
179. ZenFone 3 Zoom (ZE553KL) - ASUS\_Z01HDA
180. ZenFone 4 (A400CG) - ASUS\_T00I
181. ZenFone 4 (A400CG) - ASUS\_T00I-D
182. ZenFone 4 (A450CG) - ASUS\_T00Q
183. ZenFone 4 (ZE554KL) - ASUS\_Z01KD
184. ZenFone 4 (ZE554KL) - ASUS\_Z01KDA
185. ZenFone 4 (ZE554KL) - ASUS\_Z01KD
186. ZenFone 4 Max - ASUS\_X00HD
187. ZenFone 4 Max - ASUS\_X00HD
188. ZenFone 4 Max - ASUS\_X00HD
189. ZenFone 4 Max - ASUS\_X00HDA
190. ZenFone 4 Max - ASUS\_X00HD
191. ZenFone 4 Max (ZC554KL) - ASUS\_X00ID
192. ZenFone 4 Max (ZC554KL) - ASUS\_X00ID
193. ZenFone 4 Max (ZC554KL) - ASUS\_X00ID
194. ZenFone 4 Pro (ZS551KL) - ASUS\_Z01GD
195. ZenFone 4 Selfie (ZD553KL) - ASUS\_X00LD
196. ZenFone 4 Selfie Pro (ZD552KL) - ASUS\_Z01MD
197. ZenFone 5 - ASUS\_T00F
198. ZenFone 5 - ASUS\_T00J
199. ZenFone 5 (A500CG) - ASUS\_T00F
200. ZenFone 5 (A500CG) - ASUS\_T00F
201. ZenFone 5 (A501CG) - ASUS\_T00J
202. ZenFone 5 (A502CG) - ASUS\_T00K
203. ZenFone 5 LTE (A500KL) - ASUS\_T00P
204. ZenFone 6 - ASUS\_T00G
205. ZenFone 6 (A600CG) - ASUS\_T00G

206. ZenFone 6 (A601CG) - ASUS\_Z002  
207. ZenFone AR - ASUS\_A002A  
208. ZenFone AR (ZS571KL) - ASUS\_A002  
209. ZenFone C (ZC451CG) - ASUS\_Z007  
210. ZenFone Go (ZB450KL) - ASUS\_X009DB  
211. ZenFone Go (ZB452KG) - ASUS\_X014D  
212. ZenFone Go (ZB452KG) - ASUS\_X014D  
213. ZenFone Go (ZB500KG) - ASUS\_X00BD  
214. ZenFone Go (ZB500KL) - ASUS\_X00AD  
215. ZenFone Go (ZB551KL) - ASUS\_X013DA  
216. ZenFone Go (ZB551KL) - ASUS\_X013DB  
217. ZenFone Go (ZB551KL) - ASUS\_X013DA  
218. ZenFone Go (ZB551KL) - ASUS\_X013DB  
219. ZenFone Go (ZB552KL) - ASUS\_X007D  
220. ZenFone Go (ZB690KG) - ASUS\_L001  
221. ZenFone Go (ZB690KG) - ASUS\_L001  
222. ZenFone Go (ZC451TG) - ASUS\_Z00SD  
223. ZenFone Go (ZC500TG) - ASUS\_Z00VD  
224. ZenFone Live (ZB501KL) - ASUS\_A007  
225. ZenFone Live Plus (ZB553KL) - ASUS\_X00LDB  
226. ZenFone Live Plus (ZB553KL) - ASUS\_X00LDA  
227. ZenFone Live Plus (ZB553KL) - ZB553KL  
228. ZenFone Selfie (ZD551KL) - ASUS\_Z00UD  
229. ZenFone Selfie (ZD551KL) - ASUS\_Z00UDA  
230. ZenFone Selfie (ZD551KL) - ASUS\_Z00UD  
231. ZenFone Zoom (ZX551ML) - ASUS\_Z00XS  
232. ZenFone Zoom (ZX551ML) - ASUS\_Z00XSA  
233. ZenFone Zoom (ZX551ML) - ASUS\_Z00XSB  
234. ZenFone Zoom (ZX551ML) - ASUS\_Z00XS  
235. ZenFone Zoom (ZX551ML) - ASUS\_Z00XSA  
236. ZenFone Zoom (ZX551ML) - ASUS\_Z00XS  
237. ZenPad 10 (Z300C) - P023  
238. ZenPad 10 (Z300C) - P023  
239. ZenPad 10 (Z300CG) - P021  
240. ZenPad 10 (Z300CG) - P021  
241. ZenPad 10 (Z300CL) - P01T\_1  
242. ZenPad 10 (Z300M) - P00C  
243. ZenPad 10 (Z300M) - P00C  
244. ZenPad 10 (Z301M) - P028  
245. ZenPad 10 (Z301MF) - P028  
246. ZenPad 10 (Z301MFL) - P00L  
247. ZenPad 10 (Z301ML) - P00L  
248. ZenPad 3 8.0 - P008  
249. ZenPad 3 8.0 - P008  
250. ZenPad 3S 10 (Z500M) - P027  
251. ZenPad 3S 10 LTE (Z500KL) - ASUS\_P00I  
252. ZenPad 7.0 (Z370C) - P01W  
253. ZenPad 7.0 (Z370CG) - P01V  
254. ZenPad 7.0 (Z370CG) - P01V  
255. ZenPad 7.0 (Z370KL) - P002  
256. ZenPad 7.0 (Z370KL) - P002  
257. ZenPad 8.0 (Z380KL) - P024  
258. ZenPad 8.0 (Z380KL) - P024  
259. ZenPad 8.0 (Z380KL) - P024  
260. ZenPad 8.0 (Z380KL) - P024  
261. ZenPad 8.0 (Z380M) - P00A  
262. ZenPad 8.0 (Z380M) - P00A  
263. ZenPad C 7.0 - P01Y  
264. ZenPad C 7.0 - P01Y\_S  
265. ZenPad C 7.0 (Z170C) - P01Z  
266. ZenPad C 7.0 (Z170C) - P01Z  
267. ZenPad C 7.0 (Z170CG) - P01Y  
268. ZenPad C 7.0 (Z170CG) - P01Y  
269. ZenPad C 7.0 (Z170MG) - P001  
270. ZenPad C 7.0 (Z170MG) - P001  
271. ZenPad S 8.0 (Z580C) - P01M  
272. ZenPad S 8.0 (Z580C) - P01M  
273. ZenPad S 8.0 (Z580CA) - P01MA  
274. ZenPad S 8.0 (Z580CA) - P01MA  
275. ZenPad S 8.0 (Z580CA) - P01MA  
276. ZenPad Z10 - P00I  
277. ZenPad Z8s - ASUS\_P00J  
278. ZenPadC 7.0 (Z170MG) - P001\_2  
279. ZenWatch - ASUS ZenWatch  
280. ZenWatch 2 - ASUS ZenWatch 2  
281. ZenWatch 2 - ASUS ZenWatch 2  
282. ZenWatch 3 - ASUS ZenWatch 3  
283. Zenbo - Zenbo  
284. Zenbo Qrobot - Zenbo  
285. Zenfone 4V (V520KL) - ASUS\_A006  
286. Zenfone Go (ASUS\_X00BD) - ASUS\_X00BD  
287. Zenfone Go (T500) - ASUS\_X003  
288. Zenfone MAX - ASUS\_X00GD  
289. Zenfone MAX - ASUS\_Z010DA  
290. Zenfone MAX - ASUS\_Z010DB  
291. Zenfone MAX - ASUS\_Z010D  
292. Zenfone MAX - ASUS\_Z010DA  
293. Zenfone MAX (ZC550KL) - ASUS\_Z010D  
294. Zenfone Max - ASUS\_Z010DD  
295. Zenfone V Live (Verizon) - ASUS\_A009  
296. Zenpad 8.0 (Z380C) - P022  
297. Zenpad 8.0 (Z380C) - P022  
298. (T500KLC) - ASUS\_X003  
299. (T500TLT) - ASUS\_X002  
300. 5000 (T551TLC) - ASUS\_X005  
301. 2 Plus (T550KLC) - ASUS\_X550

### AtGames-zooti

1. ZOOTI PAD ZT-701 - ZT-701

### Auchan

1. AUCHAN - Q7T9INK
2. LI12210IN - LI12210IN
3. LI902T9IN - LI902T9IN
4. Q.4514 - Q4514
5. Q4S6IN4G - Q4S6IN4G
6. Q4T10IN - Q4T10IN
7. Q4T7IN - Q4T7IN
8. Q4T7IN3G - Q4T7IN3G
9. Q4T8IN - Q4T8IN
10. Q5S55IN4G - Q5S55IN4G
11. Q5S5IN4G - Q5S5IN4G
12. Q6T10IN - Q6T10IN
13. Q6T10IN4G - Q6T10IN4G
14. Q6T7IN - Q6T7IN
15. Q6T7IN4G - Q6T7IN4G
16. Q6T7INK - Q6T7INK
17. Q7S55IN4G - Q7S55IN4G
18. Q7S5IN4G - Q7S5IN4G
19. Q7S5IN4GP - Q7S5IN4GP
20. Q7T10INP - Q7T10INP
21. Q7T7INK - Q7T7INK
22. Q8S55IN4G - Q8S55IN4G



23. Q8S55IN4G2 - Q8S55IN4G2
24. Q8S6IN4G - Q8S6IN4G
25. Q8T10IN - Q8T10IN
26. Q8T7IN - Q8T7IN
27. Q8T7IN4G - Q8T7IN4G
28. QILIVE - Q4T10INK
29. S3T10IN - S3T10IN
30. S3T10IN3G - S3T10IN3G
31. S3T7IN - S3T7IN
32. S3T7IN - S3T7IN
33. S3T7IN3G - S3T7IN3G
34. S4S5IN3G - S4S5IN3G
35. S4S5IN4G - S4S5IN4G
36. S4S6IN3G - S4S6IN3G
37. S4T10IN3G - S4T10IN3G
38. S4T7IN - S4T7IN
39. S4T7IN3G - S4T7IN3G
40. S4T9IN - S4T9IN
41. S5S4IN3G - S5S4IN3G
42. S5S5IN4G - S5S5IN4G
43. S5T10IN3G - S5T10IN3G
44. S5T7IN3G - S5T7IN3G
45. S5T9INDVD - S5T9INDVD
46. S6S4IN3G - S6S4IN3G
47. S6S55IN3G - S6S55IN3G
48. S6S5IN3G - S6S5IN3G
49. Selecline X35T - X35T
50. Selecline-854599 - Selecline-854599
51. Smartphone 5" Q.4094 - Q.4094

## Audi AG

1. Audi Tab CN - Audi tablet
2. Audi tablet - Audi tablet
3. RSE-III - RSEIII

## Audiovox

1. T752 Tablet - T752
2. T852 Tablet - T852

## Avaya

1. Vantage - Avaya Vantage
2. Vantage - K175
3. Vantage - Avaya Vantage
4. Vantage - K165

## Avoca

1. STB7012 - STB7012
2. STB7013 - STB7013
3. STB8098 - STB8098
4. STB9097 - STB9097

## Avvio

1. Avvio PRO450 - Avvio\_Pro450

## Axioo

1. Axioo AX4 - Axioo\_AX4

## Azumi

1. A40 Style Plus - A40\_Style\_Plus

2. A40C - A40C
3. A50 Style Plus - A50\_Style\_Plus
4. A50LT - A50LT
5. AX5 - Azumi AX5
6. AZUMI\_Daburu\_A55O - Azumi\_Daburu\_A55O
7. Azumi\_Extend\_Akaru\_55\_QL - Azumi Extend Akaru 55 QL
8. Azumi\_KIREI\_A45\_D - Azumi\_KIREI\_A45\_D
9. Azumi\_KIREI\_A4\_D - Azumi\_KIREI\_A4\_D
10. Azumi\_KIREI\_A5\_D - Azumi\_KIREI\_A5\_D
11. Azumi\_Speed\_Pro\_55 - Azumi\_Speed\_Pro\_55
12. DOSHI A55 QL - Azumi\_DOSHI\_A55\_QL
13. EXTEND 55 QL - EXTEND 55 QL
14. IRO A4Q - Azumi\_IRO\_A4\_Q
15. IRO A4Q - Azumi\_IRO\_A4\_Q
16. IRO A5 QL - Azumi\_IRO\_A5\_QL
17. IRO A5 QL - Azumi\_IRO\_A5\_QL
18. IRO A5 QLT - Azumi\_IRO\_A5\_QLT
19. IRO A55 Q - IRO A55 Q
20. IRO A55 QL - Azumi\_IRO\_A55\_QL
21. IRO A5Q - Azumi\_IRO\_A5\_Q
22. IRO A5Q - Azumi\_IRO\_A5\_Q
23. IRO A5QL - Azumi\_IRO\_A5\_QL
24. IRO\_A4\_Q\_Pro - Azumi\_IRO\_A4\_Q\_PRO
25. IRO\_A55\_Q\_Pro - Azumi\_IRO\_A55\_Q\_Pro
26. IRO\_A6\_Q - IRO A6 Q
27. KINZO A55 OLi - Azumi\_KINZO\_A55\_OLi
28. KINZO A55QL - Azumi\_KINZO\_A55\_OLi
29. KINZO ICHI A5 QL - KINZO\_ichi\_A5\_QL
30. Speed 55 - Speed\_55
31. T7 3G - Azumi\_T7\_3G

## BGH S.A.

1. BGH Joy 303 - BGH Joy 303

## BKAV

1. B2017 - B2017
2. Bphone - Bphone B1111
3. Bphone - Bphone B1112
4. Bphone - Bphone B1114
5. Bphone - Bphone B1115
6. Bphone - Bphone B1116

## BMobile

1. AX1010 - AX1010
2. AX1010 - Bmobile AX1010
3. AX1015 - AX1015
4. AX1015 - AX1015
5. AX1020 - AX1020
6. AX1020 - AX1020
7. AX1030 - AX1030
8. AX1035 - AX1035
9. AX1040 - AX1040
10. AX1045E - AX1045
11. AX1055 - AX1055
12. AX1055 - AX1055
13. AX1060 - AX1060
14. AX1065 - AX1065
15. AX1065E - AX1065E
16. AX1070E - AX1070
17. AX1070E - AX1070

18. AX1071 - AX1071
19. AX1075 - AX1075
20. AX1085 - AX1085
21. AX1091 - Bmobile\_AX1091
22. AX660 - AX660
23. AX680+ - AX680+
24. AX681 - AX681
25. AX681 - AX681
26. AX684 - AX684
27. AX685 - AX685
28. AX685 - Bmobile\_AX685
29. AX686 - AX686
30. AX700 - AX700
31. AX810 - Bmobile\_AX810
32. AX810 - Bmobile\_AX810
33. AX820 - AX820
34. AX821 - AX821
35. AX822 - AX822
36. AX822 - AX822
37. AX920 - AX920
38. AX921 - AX921
39. AX921 - Bmobile\_AX921
40. AX922 - AX922

## **BQru**

1. 5060 - BQru-5060
2. BQ 5503 NICE 2 - BQru-5503
3. BQ-1056L - BQru-1056L
4. BQ-1057L - BQru-1057L
5. BQ-4028UP! - BQru-4028
6. BQ-4072 Strike Mini - BQru-4072
7. BQ-4500L - BQru-4500
8. BQ-5000L - BQru-5000
9. BQ-5033 Shark - BQru-5033
10. BQ-5035 Velvet - BQru-5035
11. BQ-5044 Strike LTE - BQru-5044
12. BQ-5057 Strike 2 - BQru-5057
13. BQ-5058 Strike Power Easy - BQru\_BQru-5058
14. BQ-5059 Strike Power - BQru-5059
15. BQ-5201 - BQru-5201
16. BQ-5202 - BQru-5202
17. BQ-5203 Shark - BQru-5203
18. BQ-5204 Strike Selfie - BQru-5204
19. BQ-5504StrikeSelfieMax - BQru-5504
20. BQ-5510 Strike Power Max 4G - BQru-5510
21. BQ-5521 STRIKE POWER MAX - BQru-5521
22. BQ-5590 Spring - BQru\_5590
23. BQ-7081G - BQru-7081
24. BQru-1081G - BQru-1081G
25. BQru-4526 - BQru-4526
26. BQru-5022 - BQru-5022
27. BQru-7082 - BQru-7082
28. BQru-7083 - BQru-7083
29. Bqru-5037 - BQru-5037
30. CRYSTAL - BQru-5054
31. FOX POWER - BQru-4583
32. FOX POWER - BQru-4583

## **BYD**

1. DynaVox T10 - T10
2. FarEastone Smart 502 - Smart 502

3. INHON G3 - G3
4. K-Touch E815 - E815
5. M601 - M601
6. Moii E996+ - moii E996+
7. PT452E - Digma Linx 4.5 PT452E
8. Prestigio PAP5430 - PAP5430
9. SI4301 - SI4301
10. SOLO S450 - S450
11. SP355AWG - SP355AWG
12. Smart 401 - Smart 401
13. Smart 402 - Smart402
14. Solo S350 - S350
15. WISKY W032I - W032I
16. X910 - XOLO X910
17. Zippers - Vexia Zippers

## **Bang & Olufsen**

1. BeoVision - QM153E

## **Barel**

1. Cavion Solid 4.5 - Cavion\_Solid\_4\_5

## **Barnes and Noble**

1. HD - BNTV400
2. HD+ - BNTV600
3. NOOK HD - BNTV400
4. NOOK HD+ - BNTV600

## **Becrypt**

1. Convex 430 - Becrypt Convex 430
2. Convex 430 - Becrypt Indigo 430

## **Beeline**

1. BeelinePro 4 - Beeline Pro 4
2. BeelineTab Fast 2 - Beeline Tab Fast 2
3. BeelineTabPro - Beeline Tab Pro
4. Fast - Beeline Fast
5. Fast HD - Beeline Fast HD
6. Fast-Plus - Beeline Fast +
7. Pro 2 - Beeline Pro 2
8. Pro 3 - Beeline\_Pro\_3
9. Pro 6 - Beeline\_Pro\_6
10. Pro5 - A451
11. Smart 6 - Beeline Smart 6
12. Smart Dual - Beeline Smart Dual
13. Smart\_8 - A221
14. Smart\_8 - A239
15. Tab - Beeline Tab
16. Tab 2 - Tab\_2
17. Tab IS - Beeline\_Tab\_IS
18. Tab\_Fast - Beeline\_Tab\_Fast

## **BenQ**

1. A3 - A3
2. A3c - BenQ A3c
3. Agora 4G - Agora 4G
4. Agora\_4G\_Pro - Agora 4G Pro
5. Agora\_Lite - Agora Lite
6. B50 - B50

7. B502 - B502
8. B502 - B502\_SA
9. B505 - B505
10. B506 - B506\_TW
11. B50\_CHT - B50\_CHT
12. F3 - F3
13. F4 - BenQ A3s
14. F5 - BenQ F5
15. F5 - BenQ F5
16. F52 - F52\_05
17. F52\_09 - F52\_09
18. F55 - BenQ F55
19. F5\_06 - F5\_06
20. F5\_13 - F5\_13
21. F5\_15 - F5\_15
22. F5\_16 - F5\_16
23. F5\_18 - F5\_18
24. F5\_19 - F5\_19
25. Harrier - Harrier from EE
26. Harrier Mini - Harrier Mini from EE
27. Harrier Tab - Harrier Tab from EE
28. JD-150 - JD-150
29. JM-250 - JM-250
30. JM-250 - JM-250
31. Kogan 4G+ - Agora 4G+
32. Kogan Agora 4G Lite - Kogan Agora 4G Lite
33. PT2200 - PT2200
34. T3 - BenQ T3
35. T3 - BenQ T3
36. T3\_08 - BenQ T3
37. T3\_17A - BenQ T3
38. T47 - T47\_05
39. T47\_09 - T47\_09
40. T55 - T55

### **Benesse**

1. TAB-A03-BR - TAB-A03-BR
2. TAB-A03-BS - TAB-A03-BS

### **Bentley**

1. Tab - BENTLEY ENTERTAINMENT TABLET

### **Best Buy**

1. Transformer Pad (TF103C) - K010

### **Bigben**

1. BB8252 - BB8252
2. GAMETAB-ONE - GAMETAB-ONE

### **Billion**

1. Billion Capture+ - Capture+

### **Binatone**

1. SMART64 - SMART64
2. Smart 63 - SMART63
3. Smart 66 - SMART66

### **Bitel**

1. B8416 - B8416

2. B9401 - B9401
3. B9502 - B9502

### **Bitmore**

1. GTAB700 - NID\_7010
2. GTAB900 - S952
3. LUXYA MID704DC Tablet / Bitmore Tab770 - Tab770
4. Tab870 - Tab870

### **Bittium**

1. Air-Lynx ALS14000 - Bittium Tough Mobile
2. Mx Smart - Mx Smart
3. Tough Mobile - Bittium Tough Mobile

### **BlackBerry**

1. Aurora - BBC100-1
2. BlackBerry MOTION - BBD100-1
3. BlackBerry MOTION - BBD100-2
4. BlackBerry MOTION - BBD100-6
5. Blackberry Keyone - BBB100-7
6. DTEK50 - STH100-1
7. DTEK50 - STH100-2
8. DTEK50 by BlackBerry - STH100-1
9. DTEK50 by BlackBerry - STH100-2
10. DTEK60 - BBA100-1
11. DTEK60 - BBA100-2
12. DTEK60 by BlackBerry - BBA100-1
13. DTEK60 by BlackBerry - BBA100-2
14. KEYone - BBB100-1
15. KEYone - BBB100-2
16. KEYone - BBB100-3
17. KEYone - BBB100-4
18. KEYone - BBB100-6
19. PRIV by BlackBerry - STV100-1
20. PRIV by BlackBerry - STV100-2
21. PRIV by BlackBerry - STV100-3
22. PRIV by BlackBerry - STV100-4

### **Blackview**

1. A5 - A5
2. A7 - A7
3. A8 MAX - A8 MAX
4. A9 Pro - A9\_Pro
5. BV4000 - BV4000
6. BV6000 - BV6000
7. BV6000s - BV6000S
8. BV7000 - BV7000
9. BV7000 Pro - BV7000 Pro
10. BV8000 Pro - BV8000Pro
11. Blackview P2 - P2
12. E7S - E7s
13. P2 Lite - P2Lite

### **Blaupunkt**

1. Blaupunkt SL 01 - Blaupunkt SL 01
2. Blaupunkt SL 02 - Blaupunkt SL 02
3. Blaupunkt SL 04 - Blaupunkt SL 04
4. Blaupunkt SM 01 - Blaupunkt SM 01
5. Endeavour101 - Endeavour101
6. SLplus02 - SLplus02

## Blu

1. ADVANCE 4.0 L2 - BLU ADVANCE 4.0 L2
2. ADVANCE 4.0 L3 - Advance 4.0 L3
3. ADVANCE 5.0 HD - Advance 5.0 HD
4. Advance 4.0M - Advance 4.0M
5. Advance 4.0M - Studio M4
6. Advance 5.2 - Advance 5.2
7. Advance A5 LTE - Advance A5 LTE
8. Advance A6 - Advance A6
9. AdvanceA5PlusLTE - Advance A5 Plus LTE
10. BLU Studio G3 - Studio G3
11. DASH L2 - BLU DASH L2
12. DASH M2 - BLU DASH M2
13. DASH X LTE - BLU DASH X LTE
14. DASH X PLUS LTE - DASH X PLUS LTE
15. DASH X2 - BLU DASH X2
16. DIAMOND M - DIAMOND M
17. Dash 4.5 - Dash 4.5
18. Dash G - Dash G
19. Dash L3 - Dash L3
20. Dash X - BLU DASH X
21. Dash X2 - Dash X2
22. Dash XL - Dash XL
23. Dash XL - Studio M5 Plus
24. Dash\_L3 - Dash L3
25. ENERGY XL - ENERGY XL
26. ENERGY DIAMOND - BLU ENERGY DIAMOND
27. ENERGY DIAMOND MINI - ENERGY\_DIAMOND\_MINI
28. ENERGY M - BLU ENERGY M
29. ENERGY X PLUS 2 - BLU ENERGY X PLUS 2
30. ENERGY\_DIAMOND\_MINI - ENERGY\_DIAMOND\_MINI
31. Energy X 2 - Energy X 2
32. Energy X LTE - Energy X LTE
33. GRAND 5.5 HD - BLU GRAND 5.5 HD
34. Grand Energy - Grand Energy
35. Grand M - Grand M
36. Grand MAX - Grand Max
37. Grand Mini - Grand Mini
38. Grand X - Grand X
39. Grand X LTE - BLU Grand X LTE
40. Grand X LTE - Grand X LTE
41. Grand XL - Grand XL
42. Grand\_M2 - Grand M2
43. LIFE ONE X - BLU LIFE ONE X
44. LIFE ONE X - Life One X
45. LIFE ONE X2 - Life One X2
46. LIFE ONE X2 MINI - Life One X2 Mini
47. LIFE XL - BLU LIFE XL
48. Life Mark - BLU LIFE MARK
49. Life Max - Life Max
50. NEO ENERGY MINI - BLU NEO ENERGY MINI
51. NEO X - BLU NEO X
52. NEO X LTE - BLU NEO X LTE
53. NEO X MINI - BLU NEO X MINI
54. NEO X PLUS - BLU NEO X PLUS
55. NEO XL - BLU NEO XL
56. Neo X2 - Neo X2
57. PURE XL - PURE XL
58. PURE XR - Pure XR
59. R1 HD - BLU R1 HD
60. R1 HD - R1 HD
61. R1 PLUS - R1 PLUS
62. R1 Plus - R1 PLUS
63. R2 - R2 3G
64. R2 LTE - R2 LTE
65. R2 LTE - R2 LTE
66. STUDIO 7.0 LTE - BLU STUDIO 7.0 LTE
67. STUDIO 7.0 LTE - BLU STUDIO 7.0 LTE
68. STUDIO C 8+8 LTE - BLU STUDIO C 8+8 LTE
69. STUDIO G - BLU STUDIO G
70. STUDIO G HD - BLU Studio G HD
71. STUDIO G HD LTE - Studio G HD LTE
72. STUDIO G MAX - Studio G Max
73. STUDIO G PLUS - BLU STUDIO G PLUS
74. STUDIO G PLUS HD - Studio G Plus HD
75. STUDIO G2 - BLU STUDIO G2
76. STUDIO M HD - STUDIO M HD
77. STUDIO M LTE - STUDIO M LTE
78. STUDIO MAX - Studio Max
79. STUDIO ONE PLUS - BLU STUDIO ONE PLUS
80. STUDIO SELFIE 2 - BLU STUDIO SELFIE 2
81. STUDIO TOUCH - BLU Studio Touch
82. STUDIO XL LTE - BLU STUDIO XL LTE
83. STUIDIO C 8+8 - BLU STUDIO C 8+8
84. STUIDIO SELFIE 2 - BLU STUDIO SELFIE 2
85. SUTDIO ENERGY 2 - STUDIO ENERGY 2
86. Studio 5.5 HD - STUDIO 5.5 HD
87. Studio C HD - BLU STUDIO C HD
88. Studio C HD - Studio C HD
89. Studio G HD - STUDIO\_G\_HD
90. Studio G Mini - Studio\_G Mini
91. Studio G2 HD - Studio G2 HD
92. Studio J1 - Advance A4
93. Studio J1 - Studio J1
94. Studio J2 - Advance A5
95. Studio J2 - Studio J2
96. Studio J2 - Studio M5
97. Studio J5 - Studio J5
98. Studio J8 - Studio J8
99. Studio M5 Plus LTE - Studio M5 Plus LTE
100. Studio M6 - Studio M6
101. Studio Mega - Studio Mega
102. Studio One - BLU STUDIO ONE
103. Studio Pro - Studio Pro
104. Studio Selfie LTE - BLU STUDIO SELFIE LTE
105. Studio X Mini - BLU STUDIO X MINI
106. Studio XL 2 - Studio M6 LTE
107. Studio XL 2 - Studio XL 2
108. TOUCHBOOK M7 - BLU TOUCHBOOK M7
109. Tank Xtreme 4.0 - Tank Xtreme 4.0
110. Tank Xtreme 5.0 - Tank Xtreme 5.0
111. Tank Xtreme Pro - Tank Xtreme Pro
112. VIVO 5 - VIVO 5
113. VIVO 5R - Vivo 5R
114. VIVO 6 - Vivo 6
115. VIVO XL - VIVO XL
116. VIVO XL2 - Vivo XL2
117. Vivo 5 Mini - Vivo 5 Mini
118. Vivo 8 - Vivo 8

## Bluebird

1. BM180 - BM180
2. EF400 - EF400
3. EF500 - EF500



- SF550 - SF550

## Bluedot

- BNT-700K - BNT-700K

## Booken

- Cybook Tablet - Cybook-Tablet

## Boost

- Cabana - Cabana
- Cabana - Cabana
- Moova Shuffle - MoovaShuffle
- Moova Soul - Moova-Soul
- Pulse Glide - Pulse Glide
- Pulse Jive - Jive
- Pulse Power - Power
- Pulse Retro - Pulse Retro
- Pulse Sky - Pulse Sky
- Shaker-Slim - Shaker-Slim
- ShakerBeat - ShakerBeat
- Smarty II - Smarty\_II
- StrikaPlay - StrikaPlay
- X4503 - X4503

## Borqs

- Falcon - falcon

## Bouygues Telecom

- Bbox Miami - BouygtelTV
- Bs 451 - Bs 451

## Brightstar

- M8046IU - M8047IU

## British Telecom

- BT Home SmartPhone III - E81
- HomeSmartphone d800 - BT Home SmartPhone S II

## Bullitt Group

- Cat S60 - S60
- CatS31 - S31
- S30 - S30

## Bunbungame

- KALOS - KALOS
- MiSS - MiSS

## Bush

- 5 android - Bush 5 Android
- BUSH SPIRA B3 10 TABLET - BUSH SPIRA B3 10 TABLET
- BUSH SPIRA B3 8 TABLET - BUSH SPIRA B3 8 TABLET
- BUSH SPIRA B5.5 POWER - BUSH SPIRA B5.5 POWER
- MyTablet 79 - BUSH 7.85 TABLET
- SPIRA B3 5 - BUSH SPIRA B3 5
- SPIRA B4 5 - BUSH SPIRA B4 5
- SPIRA B4 5.5 - BUSH SPIRA B4 5.5
- SPIRA D3 5.5 - BUSH SPIRA D3 5.5

- SPIRA D4 5 - BUSH SPIRA D4 5
- SPIRA E3X 5.5 - BUSH SPIRA E3X 5.5
- SPIRA E4X - BUSH SPIRA E4X
- Spira B2 10 tablet - Bush Spira B2 10 tablet
- Spira B2 7 tablet - Bush Spira B2 7 tablet
- Spira D4 5.5 - BUSH SPIRA D4 5.5
- Spira E2X 5\'' - Bush Spira E2X 5" Smartphone

## C&M

- SH950C-CM - SH950C-CM
- Smart TV II - SX930C-CC

## CCC

- AirStick - AirStick
- LifeStick - LifeStick
- TSUTAYA Stick - TStick

## CHN TELECOM

- CHN-UCAN MJ - CHN-UCAN MJ

## CJHelloVision

- Hello TV Smart - SX930C\_CJ
- viewing - kr101

## CMCC

- M811 - M811
- M811 - M811

## CX Argentina

- CX9011 - CX9011

## CZ Electronics

- M3CR - M3CR
- M3CRD - M3CRD
- M3s - M3s
- M5CR - M5CR
- M5CRD - M5CRD
- M7 Sapphire - M7
- MX16 - MX16
- Mint\_Iris - M7L\_Sapphire
- Mint\_Jane - M5E01

## Camelus

- L10 - L10
- L7 - L7

## Candor

- PHS-601 - PHS-601

## Captiva

- CAPTIVA Pad 10 3G Plus - Captiva Pad 10 3G Plus

## Carrefour

- CT1000 - CT1000
- CT1020W - CT1020W
- CT1050 - TVE9603I
- CT726 - CT726



5. CT820 - CT820
6. CT826 - CT826

## Casio

1. IT-G400 - IT-G400
2. Smart Outdoor Watch WSD-F10 - CASIO WSD-F10
3. WSD-F20 - CASIO WSD-F20
4. WSD-F20 - CASIO WSD-F20S

## Casper

1. TA80CA2 - TA80CA2
2. VIA M3 - CASPER\_VIA\_M3
3. VIA T7D - VIA-T7D
4. VIA T7D 3G - VIA-T7D-3G
5. VIA\_A1 - VIA\_A1
6. VIA\_A1\_1 - VIA\_A1\_1
7. VIA\_A1\_1 - VIA\_F1
8. VIA\_A1\_Plus - VIA\_A1\_Plus
9. VIA\_P2 - VIA\_P2
10. VIA\_S17 - VIA\_S17
11. VIA\_S18 - VIA\_S18
12. VIA\_T41 - VIA\_T41

## Cat

1. B15 - B15
2. B15Q - B15Q
3. B15Q - B15Q
4. Cat S41 - S41
5. CatS50c - S50c
6. S30 - S30
7. S40 - S40
8. S50 - S50

## Cathay

1. AS01M - AS01M

## Ceibal

1. TC80RA1 - TC80RA1
2. TC80RA6 - TC80RA6

## Celkon

1. Swift 4G - Swift 4G

## Cell\_C

1. Cell C Evolve - CELLC\_Evolve
2. Cell C Nitro - CELLC\_Nitro
3. CellC\_Extreme - CELLC\_Extreme
4. Fantasy - Fantasy
5. JAZZ - Jazz
6. Summit - Summit
7. Summit Plus - Cell\_C\_Summit\_Plus
8. Titan - Titan
9. WIZ - Wiz
10. deluxe - Deluxe

## Cellon

1. A27 - A27
2. A5801 - A5801
3. Alpha Ice - Alpha Ice

4. C3668 - C3668
5. CI - CI
6. CJ-1984 - C8690
7. CJ-1984 - CJ-1984
8. CJ-1984 - ELITE 4.7 HD
9. EI - EI
10. EIII - EIII
11. EK-8680 - EK-8680
12. Explosion - Explosion
13. HW-W900 - HW-W900
14. HWW820 - HW-W820
15. Houston - Houston
16. ICON - ICON
17. IQ 1.1 - i-mobile IQ1-1
18. Linx PS474S - Linx PS474S
19. MTC SMART Run - MTC SMART Run
20. Mach - Mach
21. Newman N2 - Newman N2
22. Q - Q
23. S21 - Q-Smart S21
24. SI - SI
25. SM55 - C8660
26. SM55 - SM55
27. Starmobile KNIGHT - Starmobile KNIGHT
28. VEON\_C8680 - VEON\_C8680
29. i-STYLE7 - i-mobile i-STYLE 7
30. i-STYLE7A - i-mobile i-STYLE 7A
31. i-mobile IQ X - i-mobile IQ X
32. i-mobile IQ X - i-mobile IQ XA
33. i-mobile IQ X2A - i-mobile IQ X2
34. i-mobile IQ X2A - i-mobile IQ X2A
35. iris pro 30 - iris pro 30
36. starTIM1 - starTIM1

## Centric

1. G1 - G1

## CenturyLink

1. PureTV - CTLPlayer
2. PureTV - S60CLI

## Cherry Mobile

1. Cherry W900 LTE - W900 LTE
2. Desire R7 Lite - Desire R7 Lite
3. FB100 - FB100
4. Flare 5 - Flare\_5
5. Flare A1 - FlareA1
6. Flare A5 - Cherry\_X740
7. Flare HD 3 - Flare HD 3
8. Flare HD Max - Flare\_HD\_MAX
9. Flare J2 Mini - Flare J2 Mini
10. Flare J2S - Flare J2S
11. Flare J3 - FlareJ3
12. Flare J3 - Flare\_J3
13. Flare J3 Plus - FlareJ3Plus
14. Flare J3 Plus - Flare\_J3\_Plus
15. Flare J7 - Flare J7
16. Flare Lite 3S - Flare\_Lite\_3S
17. Flare P1 - Flare P1
18. Flare P1 Lite - Flare\_P1\_Lite
19. Flare P1 Mini - Flare\_P1\_Mini

20. Flare P1 Plus - Flare P1 Plus
21. Flare S5 - Flare S5
22. Flare S5 Lite DTV - FlareS5LiteDTV
23. Flare S5 Max - FLARE S5 MAX
24. Flare S5 Plus - Flare S5 Plus
25. Flare S6 - Flare S6
26. Flare X - Flare\_X\_V2
27. Flare\_J3\_Lite - Flare\_J3\_Lite
28. Flare\_S6\_Lite - Flare\_S6\_Lite
29. H220 - H220
30. Iris - iris
31. Lenoxx - CX940
32. Omega HD 3S - OMEGA HD 3S
33. Omega HD 4 - Omega\_HD\_4
34. Omega HD3 - Omega HD 3
35. Omega Icon 2 - Omega Icon 2
36. Omega Lite 3C - Omega\_Lite\_3C
37. One - H940
38. Spin Max - Spin Max
39. Touch HD - Cherry\_Mobile\_Touch\_HD
40. ZP785 - ZP785

### China Mobile

1. A3 - M651G
2. n1 max - M823

### Cipherlab

1. RS30 - CipherLab RS30
2. RS31 - RS31
3. Saturn - RS50

### Cisco

1. CP-DX650 - CP-DX650
2. DX70 - CP-DX70
3. Desktop Collaboration Experience DX70 - CP-DX70
4. Desktop Collaboration Experience DX80 - CP-DX80

### Claresta

1. F3 - F3
2. G4 - G4
3. G5 - G5
4. G6 - G6
5. S6Plus - S6Plus

### Clarmin

1. B8 - B8
2. B8Lite - B8Lite
3. B8plus - B8plus

### Clementoni

1. Clempad 4.4 Basic Special - Clempad2\_special
2. Clempad 4.4 Plus - Clempad2\_plus
3. Clempad 4.4 XL - Clempad2\_XL
4. Clempad 5.0 XL - Clempad\_HR\_XL
5. Clempad 6.0 - Clempad\_6
6. Clempad 6.0 XL - Clempad\_6\_XL
7. Clempad 8 - Clempad\_8
8. Clempad Call - CLEMPADCALL
9. Clempad HR - Clempad\_HR

10. Clempad HR Plus - Clempad\_HR\_Plus
11. Clempad\_6\_S - Clempad\_6\_S
12. Clempad\_7\_S - Clempad\_7\_S
13. Clemphone - ClemPhone
14. Clemphone 7.0 - ClemPhone\_7
15. My First Clempad 6.0 - MFC\_6
16. My First Clempad 7 - MFC\_7
17. My First Clempad HR - MFC\_HR
18. My First Clempad HR Plus - MFC\_HR\_Plus
19. My first Clempad 4.4 Basic Special - MFC2\_Special
20. My first Clempad 4.4 Plus - MFC2\_Plus

### Click

1. M9021G - M9021G
2. S7043G - S7043G
3. Tab 7" - I7043G

### ClickN Kids

1. ClickN Kids - CK07T

### CloudFone

1. Cloudpad One 6.95 - one695\_1
2. Cloudpad One 6.95 - one695\_1\_coho
3. Cloudpad One 7.0 - one7\_0\_4
4. Cloudpad One 7.0 - one7\_0\_4\_coho
5. Cloudpad One 8.0 - one8\_0\_1
6. Cloudpad One 8.0 - one8\_0\_1\_coho
7. Excite Prime 2 - Excite Prime 2
8. Excite Prime 2 Pro - Excite Prime 2 Pro
9. Thrill Boost 2 - Thrill Boost 2
10. Thrill Plus 2 - Thrill Plus 2
11. Thrill Power N - Thrill Power N
12. Thrill Snap - Thrill Snap
13. Thrill View - Thrill View

### Code

1. CR4900 - CR4900

### CoinComputers

1. TF10EA2 - TF10EA2

### ColorsMobile

1. P45 - Colors P45
2. S1 - Colors S1

### Comio

1. AD7003 - AD7003
2. COMIO C1 - COMIO C1
3. COMIO C2 - COMIO C2
4. COMIO P1 - COMIO P1
5. COMIO S1 - COMIO S1

### Compal

1. CA22 - COSMO DUO
2. CAP5 - A600
3. CAP6 - A600
4. CAP7 - A300
5. CAP7 - A8
6. CAP7 - W12

7. cap2 - Andy
8. penguin - AX 8.6
9. TANK 4.5 - TANK 4.5

## Condor

1. A9 - PGN-507
2. Allure M1 - Allure M1
3. Allure A55 Plus - PGN613
4. Allure M1 Plus - Allure M1 Plus
5. C1+ - C1+
6. C6+ - PGN-508
7. C7 - PGN-506
8. C\_5 - C-6
9. G6 Pro - PHQ526
10. Griffe G5 - Griffe G5
11. Griffe G5 - PHQ520
12. Griffe G5 Plus - PAM524
13. Griffe T1 - SP413
14. HS-U939 - HS-U939
15. PGN404 - PGN404
16. PGN409 - PGN409
17. PGN410 - PGN410
18. PGN507 - PGN-507
19. PGN509 - PGN509
20. PGN511 - PGN511
21. PGN513 - PGN513
22. PGN514 - PGN514
23. PGN515 - PGN515
24. PGN516 - PGN516
25. PGN517 - PGN517
26. PGN518 - PGN518
27. PGN521 - PGN521
28. PGN522 - PGN522
29. PGN523 - PGN523
30. PGN605 - PGN605
31. PGN606 - PGN606
32. PGN607 - PGN607
33. PGN608 - PGN608
34. PGN609 - PGN609
35. PGN610 - PGN610
36. PGN611 - PGN611
37. PGN612 - PGN612
38. PHQ525 - PHQ525
39. Plume P4 Plus - PGN527
40. Plume P6 Pro LTE - PGN528
41. SP530 - Griffe T2
42. T705 - TGW710G
43. TFX711G - TFX711G
44. TFX712G - TFX712G
45. TFX713L - TFX713L
46. TFX714L - TFX714L
47. TGW102L - TGW102L
48. TGW706 - TGW706
49. TGW801G - TGW801G
50. TGW801L - TGW801L
51. TMK715L - TMK715L

## Connectce

1. Connect Alpha - CNT07002
2. Connect Core 6 - CP6001A

## Connex

1. CTAB-1044 - CTAB-1044

## Coolpad

1. 7019\_msm7627a - Coolpad 7019
2. 7560U - Nivo
3. 801E - 801E
4. 8710 - 8710
5. 9960 - YL-Coolpad 9960
6. CP5832 - 5832
7. CP5880 - 5880
8. CP7728 - Coolpad7728
9. CP8870 - 8870
10. CP9130 - N930
11. Coolpad7290 - Coolpad 7290
12. Coolpad9080W - Coolpad 9080W
13. dkb - 8150
14. dkb - 8180
15. dkb - 8810
16. msm7627\_5820 - Coolpad 5820
17. msm7627\_SP150 - MTS-SP150
18. msm7627\_surf - 5860
19. msm7627\_surf - 7260
20. msm7627\_w706 - Coolpad W706+
21. msm7627\_w706T - Coolpad W706+
22. msm7627\_w708 - Coolpad W708
23. msm7627a\_5860S - 5860S
24. msm7627a\_5870 - 5870
25. msm7627a\_7230 - 7230
26. msm7627a\_7266 - 7266
27. msm7627a\_9120 - 9120
28. msm7627a\_PAP4000 - PAP4000
29. msm7627a\_cp5910 - 5910
30. msm7627a\_ea58 - Coolpad 5010
31. msm7627a\_ea92 - Coolpad 5210
32. msm7627a\_sku3 - 5110
33. msm7627a\_sku3 - 5860A
34. msm7627a\_sku3 - 7260A
35. msm8660\_9900 - 9900
36. msm8660\_CP8950 - 8950
37. 3300A - Coolpad 3300A
38. 3320A - Coolpad 3320A
39. 3503I - Coolpad 3503I
40. 3503I - Coolpad CP3503I
41. 3505I\_A00 - Coolpad E503
42. 3505I\_U00 - Coolpad E503
43. 3600i - 3600i
44. 3600i - Coolpad 3600i
45. 3622A - Coolpad 3622A
46. 3622A-mpcs - Coolpad 3622A
47. 3623A - Coolpad 3623A
48. 3632A - Coolpad 3632A
49. 3632A-mpcs - Coolpad 3632A
50. 3636a - cp3636a
51. 3700A - CP3700A
52. 5109 - Coolpad 5109
53. 5200 - Coolpad 5200
54. 5216D - Coolpad 5216D
55. 5217 - Coolpad 5217
56. 5218S - Coolpad 5218S
57. 5219 - Coolpad 5219

58. 5219\_C00 - Coolpad 5219\_C00
59. 5267 - Coolpad 5267
60. 5267C - Coolpad 5267
61. 5270 - Coolpad 5270
62. 5367 - Coolpad 5367
63. 5367C - Coolpad 5367C
64. 5370 - Coolpad 5370
65. 5380CA - Coolpad 5380CA
66. 5860E - 5860E
67. 5891 - Coolpad 5891
68. 5891S - Coolpad 5891S
69. 5951 - Coolpad 5951
70. 7061 - Coolpad 7061
71. 7230S - Coolpad 7230S
72. 7232 - Coolpad 7232
73. 7251 - Coolpad 7251
74. 7270 - Coolpad 7270
75. 7270I - Idea ULTRA Pro
76. 7275 - Coolpad 7275
77. 7295A - Coolpad 7295+
78. 7295A - Coolpad 7295A
79. 7296 - Coolpad 7296
80. 7620L - Coolpad 7620L
81. 801EM - 801EM
82. 8079 - Coolpad 8079
83. 8122 - Coolpad 8122
84. 8198W - Coolpad 8198W
85. 8297D - Coolpad 8297D
86. 8297L-I00 - Coolpad 8297L-I00
87. 8298-M02 - CP8298\_M02
88. 8676-I03 - CP8676\_I03
89. 8712 - Coolpad 8712
90. 8712SV - Coolpad 8712
91. 8718 - Coolpad 8718
92. 8722 - Coolpad 8722
93. 8722-U00 - Coolpad E570
94. 8722V - Coolpad 8722V
95. 8722\_S00 - Coolpad E570
96. 8729 - Coolpad 8729
97. 8730L - Coolpad 8730L
98. 8736 - Coolpad 8736
99. 8737A - Coolpad 8737A
100. 8970L - Coolpad 8970L
101. 8971 - Coolpad 8971
102. 9150W - Coolpad 9150W
103. 9190\_T00 - Coolpad 9190\_T00
104. 9970L - Coolpad 9970L
105. 9976A - Coolpad 9976A
106. A8 - Coolpad A8
107. A8-831 - Coolpad A8-831
108. A8-930 - Coolpad A8-930
109. A8-931 - Coolpad A8-931
110. A8-931 - Coolpad A8-931N
111. A8-932 - Coolpad A8-932
112. B770 - Coolpad B770
113. B770S - Coolpad B770S
114. Bs501 - Bs 501
115. C1-S02 - Coolpad R116
116. C103 - C103
117. C106-8 - C106-8
118. CK2-01 - CK2-01
119. CK3-01 - CK3-01
120. CK3-01 - CK3-M1
121. CM001 - Coolpad CM001
122. CP5108 - Coolpad 5108
123. CP5210A - Coolpad 5210A
124. CP5310 - Coolpad 5310
125. CP5660S - 5560S
126. CP5952 - Coolpad 5952
127. CP8021 - Coolpad 8021
128. CP8089 - Coolpad 8089
129. CP8089Q - Coolpad 8089Q
130. CP8295M - Coolpad8295M
131. CP8735 - Coolpad 8735
132. CP8750 - Coolpad8750
133. CP9190L - Coolpad 9190L
134. CP9250L - Coolpad 9250L
135. CP9970 - Coolpad 9970
136. CPA520 - Coolpad A520
137. CPT1 - Coolpad T1
138. Cool C1 - C106
139. Cool C1 - C106-6
140. Cool C1 - C106-7
141. Cool C1 - C106-9
142. Cool C1 - C107-9
143. Coolmini - Coolmini
144. Coolpad 3636a\_m - cp3636a
145. Coolpad 5370\_I00 - coolpad E2
146. Coolpad C1-U02 - C1-U02
147. Coolpad COL-A0 - COL-A0
148. Coolpad COR-I0 - Coolpad COR-I0
149. Coolpad CVC-A0 - CVC-A0
150. Coolpad CVC-M0 - CVC-M0
151. Coolpad GRA-M0 - GRA-M0
152. Coolpad POL-A0 - POL-A0
153. Coolpad VCR-I0 - VCR-I0
154. Coolpad5218D - Coolpad\_5218D
155. Coolpad5315 - Coolpad 5315
156. Coolpad5872 - Coolpad 5872
157. Coolpad5879T - Coolpad 5879T
158. Coolpad5891Q - Coolpad 5891Q
159. Coolpad5892 - Coolpad 5892
160. Coolpad5950 - Coolpad 5950
161. Coolpad5950T - Coolpad 5950T
162. Coolpad7270\_W00 - Coolpad 7270\_W00
163. Coolpad7295C - Coolpad 7295C
164. Coolpad7295C\_C00 - Coolpad 7295C\_C00
165. Coolpad7295I - Spice Mi-515
166. Coolpad7295T - Coolpad 7295T
167. Coolpad7296S - Coolpad 7296S
168. Coolpad7298A - Coolpad 7298A
169. Coolpad7298D - Coolpad 7298D
170. Coolpad7320 - Coolpad 7320
171. Coolpad7920 - Coolpad7920
172. Coolpad801ES - 801ES
173. Coolpad8085Q - Coolpad8085Q
174. Coolpad8198T - Coolpad8198T
175. Coolpad8297W - Coolpad 8297W
176. Coolpad8705 - Coolpad 8705
177. Coolpad8720L - Coolpad 8720L
178. Coolpad8908 - Coolpad8908
179. E561 - Coolpad E561
180. Flo - Coolpad Flo
181. Forward\_EVOLVE - Forward\_EVOLVE



182. Idea ULTRA - Idea ULTRA
183. K2L\_S00 - Coolpad E580
184. Karbonn Titanium S5 Plus - Karbonn Titanium S5 Plus
185. MEDION P5001 - MEDION P5001
186. MEDION P5001 - MEDION P5001
187. Mtag 353 - Mtag 353
188. R106 - Coolpad R106
189. R108 - Coolpad R108
190. SK3-U00 - Coolpad E561\_EU
191. SS1-03 - ivvi SS1-03
192. SS2-01 - SS2-01
193. SS2-01 - ivvi SS2-01
194. STARADDICT III - STARADDICT III
195. Spice Mi-496 - Spice Mi-496
196. VCR-A0 - VCR-A0
197. Vodafone Smart 4G - Vodafone Smart 4G
198. VodafoneSmart4 - Vodafone Smart 4
199. VodafoneSmart4turbo - Vodafone Smart 4 turbo
200. Y72-921 - Coolpad Y72-921
201. Y72-921 - Coolpad E571
202. Y803-8 - Coolpad Y803-8
203. Y803-9 - Coolpad Y803-9
204. Y83-900 - Coolpad Y83-900
205. Y83-I00 - Coolpad Y83-I00
206. Y83\_S00 - Coolpad E502
207. Y83\_U00 - Coolpad E502
208. Y90 - Coolpad Y90
209. Y91-921 - Coolpad Y891
210. Y91-921 - Coolpad Y91-921
211. Y92-9 - Coolpad Y92-9
212. cp7236 - Coolpad 7236
213. i1 - ivvi i1
214. i1-01 - ivvi i1-01
215. i3-M1 - ivvi i3-M1
216. ivvi SK5 - ivvi SK5
217. ivvi SK5\_S - ivvi SK5\_S
218. ivvi V1M-S - ivvi V1M-S
219. ivvi i1-S - ivvi i1-S
220. ivvi i3-01 - ivvi i3-01
221. ivvi i3P-02 - ivvi i3P-02

## Coppel

1. ROCKET - ROCKET

## Coppernic

1. C-eight - C-eight
2. C-five - C-five
3. C-five - C-five

## Covia

1. CP-J55a - CP-J55a
2. CP-J55aW - CP-J55aW
3. CP-L45s - CP-L45s
4. g06+ - g06

## Crema

1. CREMA0810T - CREMA0810T

## Crosscall

1. L636 - TREKKER-X3

2. L761 - ACTION-X3
3. L761 - Action-X3
4. ODYSSEY - ODYSSEY
5. TREKKER-M1 CORE - TREKKER-M1 CORE
6. Trekker- M1 - Trekker-M1

## Cspire

1. FT7 - Android Tablet FT7

## Cubot

1. CUBOT MAGIC - CUBOT MAGIC
2. CUBOT MAGIC - CUBOT R9
3. DINOSAUR - CUBOT DINOSAUR
4. ECHO - CUBOT ECHO
5. MANITO - CUBOT\_MANITO
6. MAX - CUBOT MAX
7. NOTE S - CUBOT CHEETAH 2
8. NOTE S - CUBOT\_NOTE\_S
9. RAINBOW 2 - RAINBOW 2
10. Rainbow - RAINBOW

## DBM Maroc

1. ACCENT SURF 1000 - SURF1000
2. Accent Speed Y2 - Speed-Y2
3. Accent Speed Y3 - Speed-Y3
4. FAST A6 - FAST A6
5. FAST7 4G - FAST7\_4G
6. Pearl A2 - PEARL\_A2
7. Speed X2 - Speed-X2

## DEA Factory

1. KTAB - KTAB

## DEXP

1. DEXP Ixion X150 - Ixion X150
2. DEXP P170 - P170
3. EL450 - Ixion EL450
4. ES355 - Ixion ES355
5. ES550 - Ixion ES550
6. ES850 - Ixion ES850
7. Ixion M355 - Ixion M355
8. Ixion ML350 - Ixion ML350
9. M340 - Ixion M340
10. M545 - Ixion M545
11. M750 - Ixion M750
12. ML245 - Ixion ML245
13. MS650 - MS650
14. Ixion MS255 - Ixion MS255

## DIFRNCE

1. DIT702201 - NID\_7010

## DL

1. 3406 - Tablet DL 3406
2. 3420 - Tablet DL 3420
3. 3420 - Tablet\_DL\_3420
4. 3903 - Tablet\_DL\_3903
5. Creative Kids - Tablet\_DL\_3721
6. Creative Tab - Tablet\_DL\_3723

7. DL3920 - Tablet\_DL\_3920
8. Mobi Tab - Tablet\_DL\_2810
9. Mobi Tab - Tablet\_DL\_2811
10. Sabiches - Tablet\_DL\_3722
11. TabFcil - Tablet\_DL\_2820
12. TabKids Plus - Tablet DL 3411
13. TabPhone 710 pro - Tablet DL 3421
14. X\_Quad\_Pro - Tablet DL 3410
15. YZU\_DS53 - Smartphone\_YZU\_DS53
16. i-Player\_KIDS - Tablet\_DL\_3910

## DNA

1. DNA TV-hubi - DNA Android TV

## Danew

1. DSlide 710 - Dslide710
2. DSlide 750 - DSlide750
3. Dslide 1013 - DSlide 1013
4. Dslide 714 - Dslide714\_v2
5. Dslide1014 - Dslide1014
6. Dslide714 - Dslide714
7. Dslide971DC - Dslide971DC
8. Konnect 504 - Konnect\_504
9. Konnect 510 colors - Konnect\_510\_colors
10. Surnaturel\_R500 - Surnaturel\_R500
11. konnect 601 - Konnect\_601

## Ddm

1. ANDY 5EI - ANDY 5EI

## Dell

1. Dell\_Grappa - Dell Aero
2. Dell\_Grappa - Mini\_3iG
3. Streak10Pro - Dell Streak 10 Pro
4. qsd8250\_surf - Dell Mini 5
5. qsd8250\_surf - Dell Streak
6. streak7 - Dell Streak 7
7. streak7 - streak7
8. streakpro - 101DL
9. streakpro - Dell V04B
10. streakpro - GS01
11. venue - BizSmartPhone
12. venue - Dell Venue
13. Chromebook 11 Model 3180 - Chromebook 11 Model 3180
14. Chromebook 13 3380 - Dell Chromebook 13 3380
15. Cloud Connect - CS-1A13
16. Streak - 001DL
17. Streak - Dell M01M
18. Streak - Dell Streak
19. Venue 10 - Venue 10 5050
20. Venue 7 - Venue 7 3741
21. Venue 7 - Venue 7 3740
22. Venue 7 - Venue7 3740
23. Venue 7 - Venue7 3740 LTE
24. Venue 7 - Venue 7 3730
25. Venue 7 - Venue 7 HSPA+
26. Venue 7040 - Venue 10 7040
27. Venue 8 - Venue 8 7840
28. Venue 8 - Venue 8 7840 LTE

29. Venue 8 - Venue 8 3840
30. Venue 8 - Venue8 3840
31. Venue 8 - Venue8 3840 LTE
32. Venue 8 - Venue 8 3830
33. Venue 8 - Venue 8 HSPA+

## Dialog Blaze

1. M50E-1A - M50E-1A

## DigiLand

1. CompumaxBlue - Compumax\_Blue\_6030-805-0001
2. DL1001 - DL1001
3. DL1008M - DL1008M
4. DL1010Q - DL1010Q
5. DL1018A - DL1018A
6. DL1026 - DL1026
7. DL1168A - DL1168A
8. DL7006 - DL7006
9. DL700D - DL700D
10. DL701Q - DL701Q
11. DL718M - DL718M
12. DL721RB - DL721-RB
13. DL785D - PLT7803G
14. DL8006 - DL8006
15. DL9002 - DL9002
16. NBDVDTAB9 - NBDVDTAB9
17. NS-P16AT08 - NS-P16AT08
18. NS-P16AT785HD - NS-P16AT785HD

## Digilite

1. TA70CA1 - TA70CA1
2. TA70CA2 - TA70CA2
3. TA70CA3 - TA70CA3
4. TR10CD1 - TR10CD1
5. TR10CS1 - TR10CS1

## Diginnos

1. DG-A97QT - DG-A97QT
2. DG-D07S/GP - DG-D07SGP
3. DG-Q08M - DG-Q08M

## Digital2

1. Deluxe - Digital2-Deluxe
2. Platinum - Digital2 Platinum
3. Plus - Digital2 Plus

## DigitalStream

1. DWA1015D Tablet - DWA1015D

## Digitron

1. i-Buddie - TR10CD1
2. i\_Buddie - TR10CS1

## Digix

1. TAB-740\_G - TAB-740\_G

## Digma

1. DIGMA CITI 1544 3G CS1154MG -

- CITI\_1544\_3G\_CS1154MG
- 2. DIGMA CITI 7543 3G CS7153MG - CITI\_7543\_3G\_CS7153MG
- 3. DIGMA HIT Q500 3G HT5035PG - HIT Q500 3G HT5035PG
- 4. DIGMA Optima Prime 3 3G TS7131MG - Optima\_Prime\_3\_3G\_TS7131MG
- 5. DIGMA Plane 1523 3G PS1135MG - Plane\_1523\_3G\_PS1135MG
- 6. DIGMA Plane 1537E 3G PS1149MG - Plane\_1537E\_3G\_PS1149MG
- 7. DIGMA Plane 1538E 3G PS1150ML - Plane\_1538E\_4G\_PS1150ML
- 8. DIGMA Plane 1550S 3G PS1163MG - Plane\_1550S\_3G\_PS1163MG
- 9. DIGMA Plane 1551S 4G PS1164ML - Plane\_1551S\_4G\_PS1164ML
- 10. DIGMA Plane 7535E 3G PS7147MG - Plane\_7535E\_3G\_PS7147MG
- 11. DIGMA Plane 7539E 4G PS7155ML - Plane 7539E 4G PS7155ML
- 12. DIGMA VOX Flash 4G VS5015ML - VOX Flash 4G VS5015ML
- 13. DIGMA VOX G450 3G VS4001PG - VOX G450 3G VS4001PG
- 14. DIGMA VOX G501 4G VS5033ML - VOX\_G501\_4G\_VS5033ML
- 15. LINX A452 3G - LINX A452 3G LT4030PG
- 16. Plane 7546S 3G - Plane\_7546S\_3G\_PS7158PG
- 17. Plane 7547S 3G - Plane\_7547S\_3G\_PS7159PG
- 18. Plane 8536E 3G PS8148MG - Plane\_8536E\_3G\_PS8148MG
- 19. Plane\_7548S\_4G\_PS7160PL - Plane\_7548S\_4G\_PS7160PL
- 20. Plane\_8548S\_3G - Plane\_8548S\_3G\_PS8161PG
- 21. Plane\_8549S\_4G - Plane\_8549S\_4G\_PS8162PL
- 22. VOX\_S508\_3G - VOX S508 3G VS5031PG
- 23. VOX\_S509\_3G - VOX S509 3G VS5032PG

## Dish

- 1. AirTV Player - AirTV Player
- 2. EVOLVE - SH960C-DS

## Ditecma

- 1. M1092R - M1092R

## Ditigran

- 1. i-Buddie - TR10CD1

## Docomo

- 1. MEDIAS TAB UL N-08D - N-08D
- 2. d-01J - d-01J

## Doogee

- 1. BL5000 - BL5000
- 2. BL7000 - BL7000
- 3. Mix - MIX
- 4. S30 - S30
- 5. S60 - S60
- 6. Shoot\_1 - Shoot\_1

- 7. T5 - T5
- 8. T5S - T5S
- 9. X10 - DOOGEE X10
- 10. X20 - X20
- 11. X20L - X20L
- 12. X30 - X30
- 13. X5 MAX - X5max
- 14. X5 max pro - X5max\_PRO
- 15. X6pro - X6pro
- 16. X7 - X7
- 17. X7Pro - X7pro
- 18. X9 Mini - X9 Mini
- 19. X9 Mini - X9 Mini
- 20. X9 Pro - X9pro
- 21. X9S - X9S
- 22. Y6 - Y6
- 23. Y6 C - Y6C
- 24. Y6 Max - Y6 Max
- 25. shoot 2 - Shoot\_2

## Doopro

- 1. C1 - C1
- 2. C1\_Pro - C1\_Pro
- 3. P1 - P1
- 4. P1\_Pro - P1\_Pro
- 5. P2 - P2
- 6. P2\_Pro - P2\_Pro

## Dopo

- 1. DP7856K - DP7856K
- 2. DPA23D - DPA23D
- 3. DPM1081 - DPM1081
- 4. DPM7827 - DPM7827
- 5. EM63 Tablet - EM63
- 6. GS-918 - GS-918

## Doppio

- 1. Doppio\_SL505 - SL505
- 2. SG402 - SG402
- 3. SG504 - SG504
- 4. SL452 - SL452
- 5. SL513 - SL513
- 6. U400 - U400
- 7. U450 - U450
- 8. U500 - U500

## Doro

- 1. 8020x - Doro\_8020x
- 2. 8031 - Doro 8031
- 3. 8040 - Doro 8040
- 4. 822 - Doro 8030
- 5. 822 - Doro 8031
- 6. 824 - Doro 824
- 7. 825A - Doro 824
- 8. 825A - Doro Liberto 825
- 9. DSB0010 - Doro 8030
- 10. DSB0010 - Doro 8030/8031/8028
- 11. Liberto 810 - Doro Liberto 810
- 12. Liberto 810 - Doro Liberto 810-orange
- 13. Liberto 810 - Doro Liberto 810

14. Liberto 820 - Doro Liberto 820
15. Liberto 820 Mini - Doro Liberto 820 Mini
16. Liberto 822 / 8030 - Doro 8030
17. Liberto 822 / 8030 - Doro 8030/8031/8028
18. Liberto 822 / 8030 - Doro 8031
19. Liberto 822 / 8030 - Doro Liberto 822
20. Liberto 825 - 825\_T-Mobile

## Dragontouch

1. K8 - K8
2. M10 - M10
3. V10 - V10
4. X10 - X10
5. X10 - X10
6. X80 - X80
7. X80 Plus - X80 Plus
8. Y88X Plus - Y88X Plus
9. Y88X Plus - Y88X\_PLUS

## Dreamax

1. DMX-ST7A - DMX-ST7A

## Dtac

1. Phone M2 - dtacPhoneM2
2. Phone S2 - dtac\_Phone\_S2
3. Phone S3 - dtacPhoneS3
4. Phone T2 - dtacPhoneT2
5. Phone X3 - dtacPhoneX3
6. dtacPhoneS3 - dtacPhoneS3
7. dtacPhoneT3 - dtacPhoneT3
8. dtac\_Phone\_S2 - dtac\_Phone\_S2

## Dunns

1. Dunns Slinger - Dunns Slinger

## E-Boda

1. Eclipse G400M - Eclipse\_G400M
2. Eclipse G500HD - Eclipse G500HD
3. Eclipse G500M - Eclipse\_G500M

## EBN

1. NEBUPOS3 - NEBUPOS3

## ECS

1. RealPad MA7BX2 - RealPad MA7BX2
2. TC69CA2 - TC69CA2
3. TC70RA1 - TC70RA1
4. TF10EA2 - TF10EA2
5. TF10EA2 - TF10EA2
6. TF10EA2 - TF10EA2\_P8
7. TI10RA1 - TI10RA1
8. TL10RA2 - TL10RA2
9. TP10RA1 - TP10RA1
10. TR10CS1 - TR10CS1
11. TR10CS1 - TR10CS1
12. TR10RS1 - TR10RS1
13. TR10RS1 - TR10RS1
14. TR10RS1 - TR10RS1

## ENTITY

1. GDENTMY7317 - GDENTMY7317

## ESI Enterprises

1. CKT3 - CKT3
2. DT101Bv51 - DT101Bv51
3. DT7v51B - DT7v51B
4. EPIK Learning Tab 8\\' - ELT0801
5. EPIK Learning Tab Jr. - ELT0702
6. EPIK\_ELTO703 - ELT0703
7. Monster M7 Tablet - M7
8. Trinity T101 - Trinity T101
9. Trinity T900 - Trinity T900

## EXO S.A.

1. wave-i007w - wave-i007w

## Echo Mobiles

1. Moon - MOON

## Edcon

1. Motion E1.1 - MotionE11
2. Platium vp.1 - Verssed VP1
3. Platium vp.2 - Verssed VP2
4. VERSSED platinum vp.2.1 - VERSSED vp2.1
5. Verssed Platinum VP3.0 - VERSSED vp3

## Eks Mobility

1. X4U+ - X4UPlus

## Electroland Ghana

1. NASCO\_Allure - NASCO\_Allure

## Elevate

1. R50A - R50A
2. V55C - V55C

## Ematic

1. Cubby - SproutChannelCubby
2. EBM104JB - EBM104JB
3. EGD078 - EGD078
4. EGD103 - EGD103
5. EGD170 - Ematic EGD170
6. EGD172 - EGD172
7. EGD213 - EGD213
8. EGQ178 - EGQ178
9. EGQ180 - EGQ180
10. EGQ223 - EGQ223
11. EGQ235SK - EGQ235SK
12. EGQ307 - EGQ307
13. EGQ327M - EGQ327M
14. EGQ337 - EGQ337
15. EGQ347 - EGQ347
16. EGQ367 - EGQ367
17. EGQ377 - EGQ377
18. EGQ780 - EGQ780
19. EGS017 - EGS017
20. EMATICEGS109 - EGS109



21. ETH102 - ETH102
22. FunTab 2 - FunTab2
23. FunTab 3 - FunTabPlay
24. FunTab 3 - FunTab3
25. GTB103B - GTB103M
26. PBS Kids PlayPad - PBSKD12
27. Sprout Channel Cubby - SproutChannelCubby

## Emdoor

1. EM\_i8180 - em\_i8180

## Emerson

1. EM749/748 - EM749\_748
2. EM9 - EM9

## Emtec

1. F400 - f400
2. Gaming Android Gem Box - Gem Box F500

## Enspert

1. E-TAB - E-TAB
2. ESP\_E301 - ESP\_E301BK
3. ESP\_E301 - ESP\_E301V
4. ESP\_E301 - ESP\_E301VD
5. ESP\_E301 - ESP\_E301VE
6. e201 - ESP\_E201V7
7. e201 - enspert\_e201
8. illuminus - ITP-S100WD
9. s8073 - Miracle
10. CINK KING - CINK KING
11. CINK KING - Cynus T2
12. CINK KING - IMD501
13. CINK KING - freebit Panda
14. CINK SLIM - CINK SLIM
15. CINK SLIM - Fly\_IQ442
16. CINK SLIM - WIKO-CINK SLIM
17. Carrefour CT1010 - CT1010
18. Cynus F3 - Cynus F3
19. DARKSIDE - Cinema
20. DARKSIDE - DARKSIDE
21. Lazer X40E - X40E
22. MG - A930
23. STAIRWAY - STAIRWAY
24. WIKO CINK PEAX - CINK PEAX
25. WIKO CINK PEAX - EverClassic
26. WIKO CINK+ - CINKPLUS
27. WIKO SUBLIM - SUBLIM
28. Wiko CINK FIVE - CINK FIVE
29. Wiko CINK FIVE - Cynus T5
30. orion - NGM Orion
31. vanitysmart - NGM Vanity Smart

## Entel

1. OWN I62S - OWN-I62S
2. S3015 - S3015

## Envizen

1. ClickTabDSh18 - ClickTabDSh18
2. V1018A - V1018A

3. VMD9002 - VMD9002

## Envizen Digital

1. V100MD - V100MD
2. V917G - V917G
3. VMD1029 - VMD1029

## Essential Products

1. PH-1 - PH-1

## EssentielB

1. Black Diamond - Essentielb-Black Diamond
2. Pyxis - Essentielb-Pixis
3. ST7001 Tablet - ST7001
4. Smart\TAB 7800 - Smart\Tab\_7800
5. Smart\TAB 9001 - Smart\TAB 9001

## Estar

1. BEAUTY 2 HD Quad core - eSTAR BEAUTY 2 HD Quad core
2. GO! HD Quad core 3G - eSTAR GO HD Quad core 3G
3. GO! IPS Quad core 3G - eSTAR GO! IPS Quad core 3G
4. GRAND HD Quad Core - eSTAR GRAND HD Quad core
5. Grand IPS Quad core 3G - eSTAR Grand IPS Quad core 3G
6. eSTAR BEAUTY 2 HD Quad core - eSTAR BEAUTY 2 HD Quad core
7. eSTAR GRAND HD Quad Core - eSTAR GRAND HD Quad core

## Etuline

1. ETL-S4521 - ETL-S4521
2. ETL-S5042 - ETL-S5042

## EuroLeague

1. I7a - EuroleaguePhone

## Evercross

1. A75 MAX - A75 MAX
2. A75B - A75B
3. M50 - M50
4. One X - EVERCOSS A65
5. R40K - R40K
6. R45 - R45
7. R5C - R5C
8. R6 - R6
9. R70A - R70A
10. S50 - S50
11. S55A - S55A
12. U50 - U50
13. U50A - U50A
14. U50A\_PLUS - U50A\_PLUS
15. U50B - U50B
16. U50C - U50C
17. U55 - U55
18. U70 - U70

## Every

1. E701 - E701

## Eviant

1. EVC10Q - EVIANT\_EVT10Q
2. EVC8Q - EVC8Q

## Evolio

1. M5Pro - Evolio\_M5Pro
2. M6 - Evolio\_M6
3. M8 - Evolio\_M8

## Evolveo

1. EVOLVEO StrongPhone G4 - EVOLVEO StrongPhone G4
2. StrongPhone Q9 - StrongPhoneQ9

## Explay

1. 4Game - 4Game
2. ATV - ATV
3. Air - Air
4. Atom - Atom
5. Bit - Bit
6. Brilliant - Brilliant
7. Cosmic - Cosmic
8. Craft - Craft
9. Discovery - Discovery
10. Easy - Easy
11. Favorite - Favorite
12. Fog - Fog
13. Fresh - Fresh
14. Fresh - Fresh\_NF
15. Gravity - Gravity
16. Hit - Hit
17. Imperium 7 - Imperium7
18. Imperium 8 - Imperium8
19. Indigo - Indigo
20. Joy TV - Joy\_TV
21. Leader - Leader
22. Light - Light
23. Light 3G - Light
24. M1 Plus - M1\_Plus
25. Onliner 4 - Onliner4
26. Onyx - Onyx
27. Party - Party
28. Phantom - Phantom
29. Planet - Planet
30. Prime - Prime
31. Pulsar - Pulsar
32. Rio Play - RioPlay
33. Shine - Shine
34. Style - Style
35. Surfer777 3G - Surfer7773G
36. Tab Mini - TabMini
37. Tornado - Tornado
38. Tornado 3G - Tornado3G
39. Vega - Vega
40. Winner - Winner
41. Winner 7 - Winner7
42. Winner 8 - Winner8

## FBC

1. M24IS810 - TDA02
2. M24IS820 - M24IS820

## FaceVSION

1. OC1020A - FV-FG6

## Fairphone

1. FP2 - FP2

## FarEasTone

1. Smart 403 - Smart 403
2. Smart 505 - Smart 505
3. Smart501 - Smart501
4. Smart503 - Smart503
5. Smart601 - Smart601

## Fero

1. Royale X2 - Royale\_X2

## Figo

1. ATRIUM II F55L2 - ATRIUM II F55L2

## Finggo

1. FWSP-S1000 - FWSP-S1000
2. FWTA-T1000 - FWTA-T1000

## FirstNationalBank

1. FNB - SP5045V

## Flnet

1. BandOTT - ba101

## Fluo

1. F - F
2. F Plus - F\_Plus

## Fly

1. 5\_S - 5S
2. Champ - FS529
3. Cirrus 11 - FS517
4. Cirrus 12 - FS516
5. Cirrus 13 - FS518
6. Cirrus 14 - FS522
7. Cirrus 16 - FS523
8. Cirrus 17 - FS525
9. Cirrus 2 - FS504
10. Cirrus 3 - FS506
11. Cirrus 4 - FS507
12. Cirrus 6 - Cirrus 6
13. Cirrus 6 - FS508
14. Cirrus 7 - FS511
15. Cirrus 8 - FS514
16. Cirrus 9 - FS553
17. Dune 3 - IQ4507
18. Dune 4 - Fly IQ4508
19. ERA Nano 7 - IQ4407

20. EVO Chic 1 - Fly IQ4405\_Quad  
21. Ego Art 2 - Fly Ego Art 2  
22. Era Energy 1 - IQ4502 Quad  
23. Era Life 2 - IQ456  
24. Era Nano 6 - IQ4406  
25. Era Nano 8 - IQ4400  
26. Era Nano 9 - IQ436i  
27. Era Style 3 - IQ4415 Quad  
28. Evo Chic 2 - IQ459  
29. Evo Chic 2 - IQ459 Quad  
30. Evo Energy4 - Evo Energy4  
31. Evo Tech 3 - IQ4414 Quad  
32. FS402 - FS402  
33. FS451 - FS451  
34. FS502 - FS502  
35. Flylife Connect 10.1 - Flylife Connect 10.1 3G 2  
36. Flylife Connect 7 3G 2 - Flylife Connect 7 3G 2  
37. Flylife Connect 7.85 3G 2 - Flylife Connect 7.85 3G 2  
38. IQ434 - IQ434  
39. IQ4401 - IQ4401  
40. IQ4409 Quad - IQ4409 Quad  
41. IQ4413 Quad - IQ4413\_Quad  
42. IQ4415 - IQ4415  
43. IQ4416 - IQ4416  
44. IQ4417 Quad - IQ4417 Quad  
45. IQ4418 - Fly IQ4418 AF  
46. IQ4418 - IQ4418  
47. IQ4420 Quad - IQ4420 Quad  
48. IQ4421 Quad - IQ4421 Quad  
49. IQ4490i - IQ4490i  
50. IQ4503 - FLY IQ4503  
51. IQ4503 Quad - IQ4503 Quad  
52. IQ4504 Quad - IQ4504 Quad  
53. IQ4505 - Fly IQ4505  
54. IQ4505 Quad - IQ4505 Quad  
55. IQ4509 - IQ4509  
56. IQ4512 Quad - IQ4512 Quad  
57. IQ4513 - IQ4513  
58. IQ4513 Octa - IQ4513 Octa  
59. IQ4514 Quad - Fly IQ4514  
60. IQ4514 Quad - Fly IQ4514 AF  
61. IQ4514 Quad - IQ4514 Quad  
62. IQ4515 Quad - IQ4515 Quad  
63. IQ4516 Octa - IQ4516  
64. IQ4516 Octa - IQ4516 Octa  
65. IQ4551 - IQ4551  
66. IQ458 Quad Evo Tech 2 - IQ458 Quad  
67. IQ4601 - IQ4601  
68. IQ4602 - Fly IQ4602  
69. IQ4602 - IQ4602 Quad  
70. Iris - FLY\_IQ4400\_AF  
71. Knockout - FS524  
72. Memory Plus - FS528  
73. Nimbus 10 - FS512  
74. Nimbus 11 - FS455  
75. Nimbus 12 - FS510  
76. Nimbus 14 - FS456  
77. Nimbus 15 - FS457  
78. Nimbus 16 - FS459  
79. Nimbus 2 - FS452  
80. Nimbus 4 - FS551  
81. Nimbus 7 - FS505

82. Nimbus 8 - FS454  
83. Nimbus 9 - Nimbus 9  
84. Nimbus3 - FS501  
85. Phoenix 2 - Phoenix 2  
86. Power Plus 1 - FS521  
87. Power Plus 2 - FS526  
88. Power Plus FHD - FS554  
89. Selfie 1 - FS520  
90. Stratus - FS407  
91. Stratus 1 - FS401  
92. Stratus 3 - FS404  
93. Stratus 4 - FS405  
94. Stratus 5 - FS406  
95. Stratus 7 - FS458  
96. Stratus 8 - FS408  
97. Stratus 9 - FS409  
98. Tornado One - FLY IQ4511  
99. Tornado One - IQ4511 Octa  
100. Tornado One - IQ4511 TR

## Fossil

1. Fossil Q Explorist / Michael Kors Grayson / Emporio Armani Connected / Diesel Full Guard - Alberto
2. Fossil Q Explorist / Michael Kors Grayson / Emporio Armani Connected / Diesel Full Guard - EA Connected
3. Fossil Q Venture - Sofie
4. Q Founder - Q Founder
5. Q Wander / Q Marshal / Q Founder 2.0 / Bradshaw / Dylan - Bradshaw
6. Q Wander / Q Marshal / Q Founder 2.0 / Bradshaw / Dylan - Q Marshal
7. Q Wander / Q Marshal / Q Founder 2.0 / Bradshaw / Dylan - Q Wander

## Foxconn

1. A1 - MUCHTEL A1
2. A800 - WellcoM-A800
3. Boston - Boston
4. Boston - Orange\_Boston
5. FE6 - FE6
6. G1305 - GSmart-G1305
7. K2 - E120
8. K3 - E130
9. SF4Y6 - SF4Y6
10. a1 - Rstream-A1
11. a800 - WellcoM-A800
12. a89 - WellcoM-A89
13. a99 - WellcoM-A99
14. axioo - PICOpad-QGN
15. fb0 - FIH-FB0
16. fm600 - Camangi-FM600
17. hd710 - Commtiva-HD710
18. m500 - MUSN-M500
19. magnumhd - cherry-MagnumHD
20. mangrove7 - Camangi-Mangrove7
21. mi410 - CSL-MI410
22. msm7627\_surf - EV-S110
23. msm7627\_surf - FIH-F0X
24. msm7627\_surf - FIH-FM6
25. msm7627\_surf - KT-F100
26. msm7627\_surf - KT-S110

27. muchtela2 - MUCHTEL-A2
28. musn-t800 - Cherry-MUSN-T800
29. superion - cherry mobile-SUPERION
30. t800 - MUSN-T800
31. vigo410 - Axioo-VIGO410
32. vt100 - V-T100
33. A5 - A5
34. CSL Spice MI700 - CSL\_Spice\_MI700
35. CSL Spice MI700 - Spice\_MI700
36. Casper\_VIA\_A6108 - Casper\_VIA\_A6108
37. Commtiva N700 - Commtiva-N700
38. Dolphin 70e Black - Dolphin 70e Black
39. InFocus IN260 - IN260
40. MUSN COUPLE - COUPLE
41. SH530U - SH530U
42. SH930W - SH930W
43. SHARP SH837W - SH837W
44. SHARP SH630E - SHP-SH630E
45. SHARP SH631W - SH631W
46. SHARP SH837W - SH837W
47. ViewPhone3 - ViewPhone3
48. XOLO - X900
49. XOLO\_X1000 - XOLO\_X1000
50. vizio VP700 - VP700
51. vizio VP800 - VP800

## Foxtel

1. Foxtel Now box - Foxtel Now box

## Freebit

1. A55J - TONE m15
2. Tone m15 - TONE m15

## Freebox

1. Mini 4K - Freebox Player Mini
2. Mini 4K - Freebox Player Mini v2

## Freetel

1. FUN PLUS - FUN PLUS
2. ICE2 - FTE161E
3. ICE2plus - FTE161G
4. ICE3 - FTE171A
5. Miyabi 2 Dual - FTJ17B00
6. Priori4 - FT162D
7. Priori4 - FTJ162D
8. RAIJIN - FTJ162E
9. SAMURAI REI - FTJ161B
10. SAMURAI REI 2 - FTJ17A00

## Fujitsu

1. ARROWS A SoftBank 101F - 101F
2. ARROWS A SoftBank 201F - 201F
3. ARROWS A SoftBank 202F - 202F
4. ARROWS A SoftBank 301F - 301F
5. ARROWS ES IS12F - IS12F
6. ARROWS Kiss F-03D - F-03D
7. ARROWS Kiss F-03E - F-03E
8. ARROWS M01 - M01
9. ARROWS M305 - M305
10. ARROWS M357 - M357

11. ARROWS M555 - M555
12. ARROWS M555 - M555
13. ARROWS Me F-11D - F-11D
14. ARROWS NX F-06E - F-06E
15. ARROWS S EM01F - EM01F
16. ARROWS Tab F-05E - F-05E
17. ARROWS Tab FJT21 - FJT21
18. ARROWS Tab LTE F-01D - F-01D
19. ARROWS Tab Wi-Fi FAR70B - FAR70B
20. ARROWS Tab Wi-Fi FAR75A/70A - FAR7
21. ARROWS V F-04E - F-04E
22. ARROWS X F-02E - F-02E
23. ARROWS X F-10D - F-10D
24. ARROWS X LTE F-05D - F-05D
25. ARROWS Z FJL22 - FJL22
26. ARROWS Z ISW11F - ISW11F
27. ARROWS Z ISW13F - ISW13F
28. ARROWS ef FJL21 - FJL21
29. ARROWS mu F-07D - F-074
30. ARROWS mu F-07D - F-07D
31. ARROWS mu F-07D - FJJB091
32. Disney Mobile on docomo F-07E - F-07E
33. Disney Mobile on docomo F-08D - F-08D
34. F-01F - F-01F
35. F-01H - F-01H
36. F-01J - F-01J
37. F-02F - F-02F
38. F-02G - F-02G
39. F-02H - F-02H
40. F-03F - F-03F
41. F-03G - F-03G
42. F-03H - F-03H
43. F-04F - F-04F
44. F-04G - F-04G
45. F-04H - F-04H
46. F-04J - F-04J
47. F-05F - F-05F
48. F-05G - F-05G
49. F-06F - F-06F
50. F-09D ANTEPRIMA - F-09D
51. F-09E - F-09E
52. F-12C - F-12C
53. FARTM9334P1 - FARTM9334P1
54. FARTM933KZ - FARTM933KZ
55. FARTMB611Y - FARTMB611Y
56. FHMD001 - FHMD001
57. M02 - M02
58. M305 - M305
59. M305 - M305
60. M363/P - M363/P
61. M555 - M555
62. Patio100 - Patio100
63. Patio100 - Patio100\_3G
64. REGZA Phone IS11T - IS11T
65. REGZA Phone T-01C - IS04
66. REGZA Phone T-01C - T-01C
67. REGZA Phone T-01D - T-01D
68. REGZA Phone T-02D - T-02D
69. RM02 - RM02
70. Raku-Raku SMART PHONE F-12D - F-12D
71. Raku-Raku SMART PHONE2 F-08E - F-08E
72. STYLISTIC M350/CA2 - M350



73. STYLISTIC M532 - M532
74. STYLISTIC M702 - M702
75. STYLISTIC MH350 - MH350
76. STYLISTIC S01 - S01-orange
77. SZJ-JS101 - SZJ-JS101
78. TM20 - TM20
79. TONE m17 - TONE-m17
80. arrows Be F-05J - F-05J
81. arrows M02 - M02
82. arrows M03 - arrowsM03
83. arrows M04 - arrowsM04
84. arrows M04 PREMIUM - arrowsM04-PREMIUM
85. arrows Tab M01T - M01T

## Funai Electric

1. smdkv210 - ALM-001J

## Future Mobile Technology

1. B-52 - 176HS1050232
2. DRONE - FMT-NM7108-01
3. Dual 8 - FMT-NT8A42-01
4. Eagle - 175WT1050231
5. FMT-NM7054-01 - FMT-NM7054-01
6. FMT-NM7054-03 - FMT-NM7054-03
7. FMT-NM7058-03 - FMT-NM7058-03
8. Falcon - 176HS1050531
9. Flash - FMT-NM7058-02
10. Netsurfer STORM - 16M4HI105024
11. Netsurfer TYPHOON - 16M5HI105023
12. Tomcat - 175HS1050231
13. Viper - 175FT1050241
14. netsurferDUAL 7 - FMT-NM7116-01

## G Y P NEW TREE SA

1. VIEWPAD M10M - VIEWPAD M10M

## G53

1. TA71CA3 - TA71CA3

## GD Classbook

1. TA80CA1 - TA80CA1

## GSmart

1. Akta A4 - Akta\_A4
2. Aku A1 - GSmart Aku A1
3. Alto A2 - GSmart Alto A2
4. Arty A3 - GSmart Arty A3
5. Classic - Classic
6. Classic\_Pro - Classic\_Pro
7. Elite - Elite
8. GS202+ - GSmart GS202+
9. GSmart SX1 - GSmart SX1
10. GX2 - GX2
11. Guru G1 - GSmart Guru G1
12. Maya M1 - GSmart Maya M1
13. Maya M1 v2 - GSmart Maya M1 v2
14. Mika M2 - GSmart Mika M2
15. Mika M3 - GSmart Mika M3
16. Rey R3 - GSmart Rey R3

17. Rio R1 - GSmart Rio R1
18. Roma R2 - GSmart Roma R2
19. SX1 - GSmart SX1
20. Saga\_S3 - GSmart Saga S3
21. Sierra S1 - GSmart Sierra S1
22. Simba SX1 - Simba SX1
23. Simba SX1 - Simba SX1
24. T4 - GSmart T4
25. Tuku T2 - GSmart Tuku T2

## Galapad

1. Galapad S6 - GALAPAD\_S6

## Galexia

1. GL9002 - GL9002

## Garmin

1. a10 - Garmin-Asus A10
2. Monterra - Monterra
3. Nuvi 3595 - nuvi 3595
4. Nuvifone - Garmin-Asus A50
5. Nuvifone - Garminfone
6. Nuvifone - nuvifone A50
7. Nuvifone - nvifone A50
8. nuvi 3590 - nuvi 3590
9. nuvi 3592 - nuvi 3592
10. nuvi 3595 - nuvi 3595

## Geanee

1. FXC-5A - FXC-5A

## General Dynamics

1. GD Tough Mobile - GD Tough Mobile

## General Mobile

1. 4G - General Mobile 4G
2. 4G - General Mobile 4G
3. 4G Dual - General Mobile 4G Dual
4. 5 - GM 5
5. Discovery Air - Discovery Air
6. Discovery II Mini - Discovery II Mini
7. E-tab 4 - e-tab4
8. Etab5 - Etab5
9. GM 6 d - GM 6 d
10. GM 6 s - GM 6
11. GM5 Plus - GM 5 Plus
12. GM5 Plus Turkcell - GM 5 Plus
13. GM5 Plus d - GM 5 Plus d

## GeneralMobile

1. E-Tab10 - E-Tab10

## Geniatech

1. Enjoy TV Quad-Core Box - Enjoy TV Quad-Core Box

## Gesellschaft fr SMK mBH

1. Tough Mobile - CP600



## Getac

1. MX50 - mx50
2. Z710 - Getac Z710
3. ZX70 - ZX70
4. ZX70 - zx70

## Gigabyte

1. G1317S - GSmart G1317S
2. 9788 - 9788
3. Boston 4G - Boston 4G
4. E9771 - E9771
5. EL-20-3710 - EL-20-3050
6. EL-20-3710 - EL-20-3710
7. GSmart G1310 - GSmart G1310
8. GSmart G1315 - GSmart G1315
9. GSmart G1317 - GSmart G1317D
10. GSmart G1342 - GSmart G1342
11. GSmart G1345 - GSmart G1345
12. GSmart G1355 - GSmart G1355
13. GSmart G1362 - GSmart G1362
14. GSmart GS202 - GSmart GS202
15. Hipstreet 9DTB7 / Lazer MY9308P - 9DTB7
16. Hipstreet 9DTB7 / Lazer MY9308P - MY9308P
17. P102g - P102G
18. PAPILIO G1 - INHON PAPILIO G1
19. PROSCAN PLT1066 / MAG MAGPAD / TEAC TEACTAB / DOPO GS-1008 - GS-1008
20. PROSCAN PLT1066 / MAG MAGPAD / TEAC TEACTAB / DOPO GS-1008 - MAGPAD
21. PROSCAN PLT1066 / MAG MAGPAD / TEAC TEACTAB / DOPO GS-1008 - PLT1066
22. PROSCAN PLT1066 / MAG MAGPAD / TEAC TEACTAB / DOPO GS-1008 - TEACTAB
23. SAF3011 - SAF3011
24. SB506 - SB506
25. SB510 / IBT-102 - SB510
26. TB100 - Gigabyte TB100
27. TB100 - TB100
28. TECNO P3S - TECNO P3S
29. TM105 - TM105
30. TM105A - Aero1021/P1021HCBA4C1VXX
31. TM105A - Glacier
32. TM105A - Qrypton1010
33. TM105A - TM105A
34. TM75A - GSmart7Tab
35. TM75A - Qrypton7
36. TM75A - TM75A
37. TM75A - Voyager
38. TM75A-V - TM75A-V
39. W5510 - W5510
40. W6360 - W6360
41. mexico - iliumPAD

## Gigaset

1. GS160 - Gigaset GS160
2. GS170 - Gigaset GS170
3. Gigaset GS170 - Gigaset GS170
4. Gigaset GS270 - GS270
5. Gigaset GS270 plus - GS270 plus
6. Gigaset Maxwell 10 - Maxwell-10
7. ME - GS55-6

8. ME Pro - GS57-6
9. ME Pure - GS53-6
10. Maxwell 10 - 80-1
11. Maxwell-10 - 80-1
12. Maxwell-10 - Maxwell-10
13. QV1030 - Gigaset QV1030
14. QV830 - Gigaset QV830
15. QV831 - Gigaset QV831
16. SL930 - SL930

## Gini

1. N6 - N6
2. e6\_plus - e6
3. e6\_plus - e6\_plus
4. n7 - n7
5. n8 - Gini n8
6. s4 - s4
7. s4\_pro - s4\_pro
8. w5 - w5
9. w6 - w6

## Ginzu

1. GT-1015 - GT-1015
2. GT-1045 - GT-1045
3. GT-1050 - Ginzu GT-1050
4. GT-7100 - GT-7100
5. GT-7115 - Ginzu GT-7115
6. GT-7205 - GT-7205
7. GT-7210 - Ginzu GT-7210
8. GT-8105 - GT-8105
9. GT-8110 - Ginzu GT-8110
10. RS8501 - RS8501
11. S5002 - S5002
12. S5021 - S5021
13. S5230 - S5230
14. SMART Race 4G - SMART Race 4G

## Gionee

1. A1 - GIONEE A1
2. A1 Lite - A1 lite
3. A1 Plus - A1 Plus
4. E8 - E8
5. E8 - GN9008
6. F100 - F100
7. F100A - F100A
8. F100B - F100B
9. F100L - F100L
10. F100S - F100S
11. F103 - F103
12. F103 Pro - F103 Pro
13. F103L - F103L
14. F103S - F103S
15. F105 - F105
16. F105L - F105L
17. F106 - F106
18. F106L - F106L
19. F301 - F301
20. F303 - F303
21. F5 - F5
22. F5L - F5L
23. ForwardZero - V6L

24. GIONEE F109 - GIONEE F109  
25. GIONEE F109L - GIONEE F109L  
26. GIONEE F109N - GIONEE F109N  
27. GIONEE GN5007 - GIONEE GN5007  
28. GIONEE GN5007L - GIONEE GN5007L  
29. GN152 - GN152  
30. GN3001 - GN3001  
31. GN3001L - GN3001L  
32. GN3002 - GN3002  
33. GN3002L - GN3002L  
34. GN3003 - GN3003  
35. GN3003L - GN3003L  
36. GN5001 - GN5001  
37. GN5001L - GN5001L  
38. GN5001S - GN5001S  
39. GN5002 - GN5002  
40. GN5003 - GN5003  
41. GN5005 - GN5005  
42. GN5005 - GN5005L  
43. GN8001 - GN8001  
44. GN8001L - GN8001L  
45. GN8003L - GN8003L  
46. GN9000 - GN9000  
47. GN9006 - GN9006  
48. GN9006 - GIONEE S7  
49. GN9007 - GN9007  
50. GN9010L - GN9010L  
51. GN9012 - GN9012  
52. Gtel\_X5pro - Gtel\_X5pro  
53. M2 - M2  
54. M2017 - M2017  
55. M2mini - M2mini  
56. M3 - M3  
57. M3 - M3  
58. M3S - M3S  
59. M3mini - M3mini  
60. M4 - M4  
61. M5 - M5  
62. M5 Lite - M5\_lite  
63. M5 Plus - M5 Plus  
64. M5 mini - M5 mini  
65. M5L - M5L  
66. M6 - GN8003  
67. M6 - M6  
68. M6 Lite - M6 lite  
69. M6 Plus - GN8002  
70. M6 Plus - GN8002S  
71. M6 mirror - M6 mirror  
72. M6SLPlus - M6SLPlus  
73. M6SPlus - M6SPlus  
74. P2M - P2M  
75. P3S - P3S  
76. P4 - P4  
77. P4S - P4S  
78. P5 mini - P5 mini  
79. P5L - P5  
80. P5L - P5L  
81. P5W - P5W  
82. P6 - P6  
83. P7 - GIONEE P7  
84. P7 - GIONEE P7  
85. P7 - P7

86. P7 Max - P7 Max  
87. P8 Max - P8 Max  
88. P8M - P8M  
89. P8W - P8W  
90. S plus - S\_plus  
91. S10 - GIONEE S10  
92. S10B - GIONEE S10B  
93. S10BL - GIONEE S10BL  
94. S10C - GIONEE S10C  
95. S10CL - GIONEE S10CL  
96. S10L - GIONEE S10L  
97. S5.1 - GN9005  
98. S5.1 - S5.1  
99. S5.5 - S5.5  
100. S6 - GN9010  
101. S6 - S6  
102. S6 Pro - GN9012  
103. S6 Pro - S6 Pro  
104. S6s - S6s  
105. S8 - GN9011  
106. S9 - S9  
107. S9 - S9  
108. V4S - V4S  
109. V5 - V5  
110. W900S - W900S  
111. W909 - W909  
112. X1 - GIONEE X1  
113. X1S - X1S

## GoClever

1. INSIGNIA 550i - INSIGNIA\_550i
2. QUANTUM 1010N - QUANTUM\_1010N
3. QUANTUM 400 LITE - QUANTUM\_400\_LITE
4. QUANTUM\_550 - QUANTUM\_550
5. QUANTUM\_700S/QUANTUM 700S - QUANTUM\_700S
6. TQ700/QUANTUM 700/TAB - TQ700

## Google

1. Chromebook - Chromebook 14 (CB3-431)
2. Chromebook - Lenovo N23 Yoga/Flex 11 Chromebook
3. Chromebook - RK3288 Chrome OS Device
4. Chromebook - RK3288 Chrome OS Device
5. Chromebook - reef
6. Chromebook - Braswell Chrome OS Device
7. Chromebook Pixel (2015) - Google Chromebook Pixel (2015)
8. Emulator - Android SDK built for x86
9. Galaxy S4 Google Play edition - GT-I9505G
10. Pixel - Pixel
11. Pixel 2 - Pixel 2
12. Pixel 2 XL - Pixel 2 XL
13. Pixel C - Pixel C
14. Pixel XL - Pixel XL
15. Pixelbook - Google Pixelbook
16. Project Tango Tablet Development Kit - Project Tango Tablet Development Kit
17. Project Tango Tablet Development Kit - Yellowstone

## Gplus

1. FW6950 - GPLUS\_FW6950
2. S9701 - GPLUS\_S9701

## Gradiente

1. iphone C600 - iphone C600
2. iphone C600 - iphone C600

## Greatwall

1. T709GW - Great Wall T709

## Grundig

1. GTB1030 - TA10CA2
2. GTB1050 - GTB 1050
3. GTB850 - GTB 850
4. TC69CA2 - GTB 801

## Gryphon

1. Veil - Veil

## Gtel

1. A7100 X3 - A7100\_X3
2. A7101\_X3\_mini - A7101\_X3\_mini
3. A713\_Vivo\_Pro - A713\_Vivo\_Pro
4. A714 Vivo Play - A714\_Vivo\_Play
5. A7155\_X4\_mini - A7155\_X4\_mini
6. A715\_Inspire\_One - A715\_Inspire\_One
7. A716 Inspire Life - A716\_Inspire\_Life
8. A726 Infinity Lite - A726\_Infinity\_Lite
9. A727\_Infinity\_Pro - A727\_Infinity\_Pro
10. A728\_XP2 - A728\_XP2
11. A737\_XploraZ - A737\_XploraZ
12. A770\_SL8\_Pro - A770\_SL8\_Pro
13. A770\_XL7 - A770\_XL7
14. Gtel\_Vivo3 - Gtel\_Vivo3
15. Gtel\_X5mini - Gtel\_X5mini
16. Gtel\_X5s - Gtel\_X5s
17. X5 - Gtel X5
18. X5plus - Gtel X5plus

## Guess

1. GUESS Connect - GUESS Connect

## HKC

1. A79 Tablet - A79

## HKT

1. eye3 - eye3

## HP

1. 10 - HP 10
2. 10 Plus - HP 10 Plus
3. 7 G2 - HP 7 G2
4. 7 Plus - HP 7 Plus
5. 7 Plus G2 - HP 7 Plus G2
6. 7 Tablet - HP 7
7. 7 Voice Tab - HP 7 VoiceTab
8. 7 VoiceTab - HP 7 VoiceTab
9. 7.1 - HP 7.1
10. 8 - HP 8
11. 8 G2 - HP 8 G2
12. Bonsai 10 HD - HP Slate 10 HD

13. Chromebook x360 11 G1 EE - HP Chromebook x360 11 G1 EE
14. Pro 8 Tablet with Voice - HP Pro 8 Tablet with Voice
15. Pro Slate 10 EE G1 - HP Pro Slate 10 EE G1
16. Pro Slate 10 EE G1 - HP Pro Slate 10 EE G1
17. Pro Slate 10 EE G1 - HP Pro Slate 10 EE G1
18. Pro Slate 10 EE G1 - HP Pro Slate 10 EE G1
19. Pro Slate 12 - HP Pro Slate 12
20. Pro Slate 8 - HP Pro Slate 8
21. Slate 10 HD - HP Slate 10 HD
22. Slate 10 Plus - HP Slate 10 Plus
23. Slate 17 - HP Slate 17
24. Slate 21 Pro - Slate 21 Pro
25. Slate 6 Voice Tab - HP Slate 6 Voice Tab
26. Slate 6 Voice Tab II - HP Slate 6 Voice Tab II
27. Slate 6 VoiceTab Plus - HP Slate 6 VoiceTab Plus
28. Slate 7 - HP Slate 7
29. Slate 7 Beats Special Edition - HP Slate 7 Beats Special Edition
30. Slate 7 Beats Special Edition - HP Slate7 Beats Special Edition
31. Slate 7 Extreme - HP Slate7 Extreme
32. Slate 7 HD - HP Slate 10 HD
33. Slate 7 HD - HP Slate 7 HD
34. Slate 7 Voice Tab - HP Slate 7 Voice Tab
35. Slate 7 VoiceTab Ultra - HP Slate 7 VoiceTab Ultra
36. Slate 8 Plus - HP Slate 8 Plus
37. Slate 8 Pro - HP Slate 8 Pro
38. Slate21 - Slate 21
39. Slate7 Plus - HP Slate 7 Plus
40. Slate8 Pro - HP Slate 8 Pro
41. SlateBook 10 x2 PC - HP SlateBook 10 x2 PC
42. SlateBook 14 - HP SlateBook 14 PC
43. Tablet 10 - HP\_10\_Tablet
44. Voice Tab 7 - HP Slate 7 Voice Tab

## HTC

1. express - HTC Flyer
2. express - PG41200
3. expresskt - HTC\_P515E
4. rider - HTC\_X515E
5. tagh - HTC Incredible E S715e
6. \t HTC One X9 dual sim - HTC One X9 dual sim
7. \tADR6325 - ADR6325
8. 0P3P5 - HTC\_0P3P5
9. 0P4E2 - HTC\_0P4E2
10. 0P9C8 - HTC 0P9C8
11. 0P9C8 - HTC Desire 816 dual sim
12. 0PFJ50 - HTC\_0PFJ50
13. 0PK72 - HTC 0PK72
14. 0PK72 - HTC One M9PLUS
15. 10 - HTC 10
16. 10 - HTC 10 Lifestyle
17. 10 - HTC 2PS63
18. 10 - HTC M10u
19. 10 - HTC 10
20. 10 - HTC 2PS6200
21. 10 - HTC M10h
22. 10 - HTC\_M10h
23. 10 - HTV32
24. 10 - 2PS64
25. 10 - HTC 10

26. 10 - HTC6545LVW
27. 10 - MSM8996 for arm64
28. 10 evo - HTC 10 evo
29. 10 evo - HTC\_M10f
30. 10 evo - HTC 10 evo
31. 5060 dual sim - HTC Desire 500 dual sim
32. 601e - HTC 601e
33. 606w - HTC 606w
34. 606w - HTC Desire 600
35. 606w - HTC Desire 600 dual sim
36. 606w - HTC PO49120
37. 608t - HTC 608t
38. 609d - HTC 609d
39. 6160 - HTC 6160
40. 619d - HTC 619d
41. 7060 - HTC\_7060
42. 710C - 710C
43. 802d - HTC 802d
44. 803e - HTC 803e
45. 8060 - HTC 8060
46. 8088 - HTC 8088
47. 809d - HTC 809d
48. 8160 - HTC 8160
49. 9060 - HTC 901e
50. 9060 - HTC 801e
51. 9060 - HTC 802w
52. 9088 - HTC 9088
53. 919d - HTC 919d
54. A510c - HTC\_A510c
55. ADR6330VW - ADR6330VW
56. ADR6425LVW - ADR6425LVW
57. AT&T HTC One X+ - HTC EVARE\_UL
58. AT&T HTC One X+ - HTC One X+
59. Amaze\_4G - HTC Amaze 4G
60. Amaze\_4G - HTC Ruby
61. Amaze\_4G - HTC\_Amaze\_4G
62. Aria - HTC Aria
63. Aria - HTC Aria A6380
64. Aria - HTC Gratia A6380
65. Aria - HTC Liberty
66. Butterfly - HTC Butterfly
67. Butterfly - HTC DLX\_U
68. Butterfly - HTC X920e
69. Butterfly - HTC Butterfly
70. Butterfly - HTC DLXUB1
71. Butterfly 2 - HTC Butterfly 2
72. Butterfly 2 - HTC\_B810x
73. Butterfly 3 - HTC\_B830x
74. Butterfly S - HTC Butterfly s
75. Butterfly S - HTC\_Butterfly\_s\_901s
76. Butterfly s 9060 - HTC 9060
77. Chacha - HTC ChaCha A810b
78. Chacha - HTC ChaCha A810e
79. Chacha - HTC ChaChaCha A810e
80. Chacha - HTC Status
81. D10w - HTC D10w
82. D316d - HTC D316d
83. D610t - HTC D610t
84. D616t - HTC D626t
85. D626q - HTC Desire 626 dual sim
86. D626q - HTC\_D626q
87. D626t - HTC D626t
88. D628u - HTC\_D628u
89. D728w - HTC D728w
90. D728w - HTC Desire 728 dual sim
91. D728x - HTC\_D728x
92. D816d - HTC D816d
93. D816d - HTC\_D816d
94. D816e - HTC D816e
95. D816h - HTC D816h
96. D816t - HTC D816t
97. D816v - HTC D816v
98. D816w - HTC D816w
99. D820 Mini - HTC D820mt
100. D820f - HTC\_D820f
101. D820t - HTC\_D820t
102. D820u - HTC D820u
103. D820u - HTC\_D820u
104. D820ys - HTC\_D820ts
105. D820ys - HTC\_D820ys
106. D820ys - HTC\_D820ys
107. D826t - HTC D826t
108. DROID DNA - HTC6435LRA
109. DROID Incredible 4G LTE - ADR6410LRA
110. DROID Incredible 4G LTE - ADR6410LVW
111. DROID Incredible 4G LTE - ADR6410OM
112. Desire - HTC Desire
113. Desire - X06HT
114. Desire - PB99400
115. Desire 10 compact - HTC 2PZS1
116. Desire 10 compact - HTC Desire 10 compact
117. Desire 10 compact - a37dj dugl
118. Desire 10 lifestyle - HTC Desire 10 lifestyle
119. Desire 10 lifestyle - HTC Desire 10 lifestyle
120. Desire 10 lifestyle - HTC\_D10u
121. Desire 10 lifestyle - HTC Desire 10 lifestyle
122. Desire 10 pro - HTC Desire 10 pro
123. Desire 10 pro - HTC Desire 10 pro
124. Desire 10 pro - HTC\_D10i
125. Desire 10 pro - HTC 2PYA3
126. Desire 10 pro - HTC Desire 10 pro
127. Desire 200 - HTC Desire 200
128. Desire 200 - HTC\_Desire\_200
129. Desire 210 dual sim - HTC Desire 210 dual sim
130. Desire 300 - HTC 301e
131. Desire 300 - HTC Desire 300
132. Desire 300 - HTC\_OP6A1
133. Desire 300 - HTC\_Desire\_300
134. Desire 310 - HTC D310w
135. Desire 310 - HTC Desire 310 dual sim
136. Desire 310 - HTC Desire 310
137. Desire 310 - HTC\_D310n
138. Desire 310 - HTC\_V1
139. Desire 320 - HTC 0PF11
140. Desire 320 - HTC 0PF120
141. Desire 320 - HTC Desire 320
142. Desire 326G dual sim - HTC 2PNT1
143. Desire 326G dual sim - HTC Desire 326G dual sim
144. Desire 500 - HTC Desire 500
145. Desire 500 - HTC\_Desire\_500
146. Desire 500 dual sim - HTC 5060
147. Desire 500 dual sim - HTC Desire 500 dual sim
148. Desire 501 - HTC Desire 501
149. Desire 501 - HTC\_603h



150. Desire 501 dual sim - HTC Desire 501 dual sim
151. Desire 5088 - HTC 5088
152. Desire 510 - 0PCV1
153. Desire 510 - HTC 0PCV20
154. Desire 510 - HTC Desire 510
155. Desire 510 - HTC\_0PCV2
156. Desire 510 - HTC Desire 510
157. Desire 512 - HTC Desire 512
158. Desire 516 - HTC D516d
159. Desire 516 - HTC D516t
160. Desire 516 - HTC C2
161. Desire 516 - HTC D516w
162. Desire 516 - HTC V2
163. Desire 516 dual sim - HTC Desire 516 dual sim
164. Desire 516 dual sim - HTC Desire 516 dual sim
165. Desire 516 dual sim - HTC V2
166. Desire 520 - HTC 0PGQ1
167. Desire 526 - HTC 0PM31
168. Desire 526 - HTC Desire 526
169. Desire 526 - HTCD100LVW
170. Desire 526 - HTCD100LVWPP
171. Desire 526G+ dual sim - HTC 0PL41
172. Desire 526G+ dual sim - HTC 0PL4100
173. Desire 526G+ dual sim - HTC Desire 526G dual sim
174. Desire 526G+ dual sim - HTC Desire 526GPLUS dual sim
175. Desire 526G+ dual sim - HTC\_D526h
176. Desire 526GPLUS - HTC 0PL41
177. Desire 526GPLUS - HTC Desire 526G
178. Desire 530 - HTC 2PST1
179. Desire 530 - HTC 2PST2
180. Desire 530 - HTC Desire 530
181. Desire 530 - HTC\_D530u
182. Desire 530 - HTC 2PST3
183. Desire 530 - HTC Desire 530
184. Desire 530 - HTCD160LVW
185. Desire 530 - HTCD160LVWPP
186. Desire 550/ 555 - HTC Desire 550
187. Desire 550/ 555 - HTC Desire 555
188. Desire 600 - HTC Desire 600
189. Desire 600 Dual SIM - HTC Desire 600 dual sim
190. Desire 600c Dual SIM - HTC 609d
191. Desire 600c Dual SIM - HTC Desire 600c dual sim
192. Desire 601 - HTC Desire 601
193. Desire 601 - HTC\_0P4E2
194. Desire 601 - HTC Desire 601
195. Desire 601 - HTC0P4E1
196. Desire 601 dual sim - HTC Desire 601 dual sim
197. Desire 606w - HTC 606w
198. Desire 609d - HTC 609d
199. Desire 610 - HTC Desire 610
200. Desire 610 - HTC\_0P9O2
201. Desire 610 - HTC\_D610x
202. Desire 610 - HTC Desire 610
203. Desire 612 - HTC 0P9O30
204. Desire 612 - HTC Desire 612
205. Desire 616 dual sim - HTC D616w
206. Desire 616 dual sim - HTC Desire 616 dual sim
207. Desire 616 dual sim - HTC V3
208. Desire 620 - HTC 0PE64
209. Desire 620 - HTC Desire 620
210. Desire 620 dual sim - HTC\_D620u
211. Desire 620G dual sim - HTC 0PE65
212. Desire 620G dual sim - HTC Desire 620G dual sim
213. Desire 620G dual sim - HTC\_D620h
214. Desire 626 - HTC D626d
215. Desire 626 - HTCD200LVW
216. Desire 626 - HTCD200LVWPP
217. Desire 626 - HTC Desire 626
218. Desire 626 - HTC\_D626x
219. Desire 626 - HTC\_D630x
220. Desire 626 - HTC Desire 626
221. Desire 626 - HTC\_0PKX2
222. Desire 626 dual sim - HTC Desire 626 dual sim
223. Desire 626G+ dual sim - HTC 0PM11
224. Desire 626G+ dual sim - HTC Desire 626G dual sim
225. Desire 626G+ dual sim - HTC Desire 626GPLUS dual sim
226. Desire 626G+ dual sim - HTC\_D626ph
227. Desire 626s - HTC Desire 625
228. Desire 626s - HTC Desire 626s
229. Desire 626s - HTC Desire 626s
230. Desire 626s - 0PM92
231. Desire 626s - HTC 0PM92
232. Desire 626s - HTC Desire 626s
233. Desire 628 - HTC Desire 628
234. Desire 628 dual sim - HTC Desire 628 dual sim
235. Desire 630 dual sim - HTC 2PST5
236. Desire 630 dual sim - HTC Desire 630 dual sim
237. Desire 650 - HTC 2PYR1
238. Desire 650 - HTC Desire 650
239. Desire 650 - HTC\_D650h
240. Desire 650 dual sim - A37 DUGL
241. Desire 650 dual sim - HTC Desire 650 dual sim
242. Desire 700 dual sim - HTC Desire 700 dual sim
243. Desire 700 dual sim - HTC Desire 700 dual sim
244. Desire 700 dual sim - HTC\_709d
245. Desire 7060 - HTC\_7060
246. Desire 7088 - HTC 7088
247. Desire 709d - HTC 709d
248. Desire 728 - HTC 2PQ84
249. Desire 728 - HTC Desire 728
250. Desire 728 dual sim - HTC Desire 728 dual sim
251. Desire 728G dual sim - HTC 2PQ83
252. Desire 728G dual sim - HTC Desire 728G dual sim
253. Desire 816 - HTC Desire 816
254. Desire 816 - HTC Desire 816
255. Desire 816 - HTC\_0P9C2
256. Desire 816 - HTC\_D816x
257. Desire 816 dual sim - HTC Desire 816 dual sim
258. Desire 816 dual sim - HTC Desire 816 dual sim
259. Desire 816G dual - HTC Desire 816G dual sim
260. Desire 816G dual sim - HTC Desire 816G dual sim
261. Desire 816G dual sim - HTC D816h
262. Desire 816G dual sim - HTC Desire 816G dual sim
263. Desire 820 - HTC 0PFJ4
264. Desire 820 - HTC Desire 820
265. Desire 820 dual sim - HTC Desire 820 dual sim
266. Desire 820G PLUS dual sim - HTC Desire 820G PLUS dual sim
267. Desire 820G PLUS dual sim - HTC Desire 820G dual sim
268. Desire 820G PLUS dual sim - HTC\_D820pi
269. Desire 820q dual sim - HTC Desire 820q dual sim



270. Desire 820s - HTC D820ts  
271. Desire 820s - HTC D820us  
272. Desire 820s - HTC Desire 820s dual sim  
273. Desire 820s dual sim - HTC Desire 820s dual sim  
274. Desire 825 - HTC 2PUK2  
275. Desire 825 - HTC Desire 825  
276. Desire 825 - HTC\_D825u  
277. Desire 825 dual sim - HTC 2PUK1  
278. Desire 825 dual sim - HTC Desire 825 dual sim  
279. Desire 826 - HTC D826w  
280. Desire 826 - HTC D826d  
281. Desire 826 - HTC\_D826y  
282. Desire 826 4G () - HTC D826t  
283. Desire 826 dual sim - HTC Desire 826 dual sim  
284. Desire 826 dual sim - HTC Desire 826 dual sim  
285. Desire 828 - HTC D828w  
286. Desire 828 - HTC\_D828x  
287. Desire 828 - HTC 2PRE4  
288. Desire 828 - HTC Desire 828  
289. Desire 828 - HTC\_D828g  
290. Desire 828 dual sim - HTC Desire 828 dual sim  
291. Desire 828 dual sim - HTC 2PRE2  
292. Desire 828 dual sim - HTC Desire 828 dual sim  
293. Desire 830 - HTC Desire 830  
294. Desire 830 - HTC\_D830x  
295. Desire 830 dual sim - HTC 2PVD1  
296. Desire 830 dual sim - HTC D830u  
297. Desire 830 dual sim - HTC Desire 830 dual sim  
298. Desire C - HTC Desire C  
299. Desire C - HTC Desire C  
300. Desire D626w - HTC D626w  
301. Desire D820mini - HTC D820mt  
302. Desire D820mini - HTC D820mu  
303. Desire D826 - HTC D826d  
304. Desire EYE - HTC 0PFH2  
305. Desire EYE - HTC Desire EYE  
306. Desire EYE - HTC\_M910x  
307. Desire EYE - HTC 0PFH11  
308. Desire EYE - HTC Desire EYE  
309. Desire EYE - HTC Desire Eye  
310. Desire HD - 001HT  
311. Desire HD - Desire HD  
312. Desire HD - HTC Desire HD A9191  
313. Desire HD - Inspire HD  
314. Desire L by HTC - Desire L by HTC  
315. Desire L dual sim - HTC Desire L dual sim  
316. Desire P - HTC Desire P  
317. Desire S - HTC Desire S  
318. Desire SV - HTC Desire SV  
319. Desire V - HTC Desire Q  
320. Desire V - HTC Desire U  
321. Desire V - HTC Desire U dual sim  
322. Desire V - HTC Desire V  
323. Desire V - HTC PROMIN\_U  
324. Desire V - HTC PRO\_DS  
325. Desire V - HTC T327w  
326. Desire V - HTC T328w  
327. Desire VC - HTC Desire VC  
328. Desire VC - HTC Desire VC T328d  
329. Desire VC - HTC PRO\_DD  
330. Desire VC - HTC T328d  
331. Desire X - HTC Desire X  
332. Desire X - HTC POO\_U  
333. Desire X dual sim - HTC Desire X dual sim  
334. Desire XC dual sim - HTC Desire XC dual sim  
335. Desire320 - HTC\_Desire\_320  
336. Desire626 - HTC 0PKX2  
337. Desire626 - HTC Desire 626  
338. Desire626s - HTC 0PM912  
339. Desire626s - HTC Desire 626  
340. Desire815G - HTC Desire 816G  
341. Desrie D530 - HTC 2PST1  
342. Desrie D530 - HTC Desire 530  
343. Droid DNA - HTC6435LRA  
344. Droid DNA - HTC6435LVW  
345. Droid Eris - Eris  
346. Droid Eris - Pulse  
347. Droid Incredible - ADR6300  
348. E9pt - HTC E9pt  
349. E9pw - HTC E9pw  
350. E9pw - HTC\_E9pw  
351. E9t - HTC E9t  
352. E9w - HTC E9w  
353. E9x - HTC\_E9x  
354. EVO 3D - HTCEVOV4G  
355. EVO 3D - PG86100  
356. EVO 3D ISW12HT - ISW12HT  
357. EVO 3D X515m - HTC EVO 3D X515a  
358. EVO 3D X515m - HTC EVO 3D X515m  
359. EVO 3D X515m - HTC Inspire 3D  
360. EVO 4G LTE - EVO  
361. EVO LTE 4G - EVO  
362. EVO Shift 4G - PG06100  
363. Evo 4G - PC36100  
364. Explorer A310e - HTC Explorer  
365. Explorer A310e - HTC Explorer A310b  
366. Explorer A310e - HTC Explorer A310e  
367. Flyer - HTC Flyer  
368. Flyer - HTC Flyer P510e  
369. Flyer - HTC Flyer P511e  
370. Flyer - HTC Flyer P512  
371. Flyer - HTC\_Flyer\_P512\_NA  
372. G1 - HTC Dream  
373. G2 - HTC Vision  
374. G2 - T-Mobile G2  
375. HTC Desire 610 - HTC Desire 610  
376. HTC Desire 628 dual sim - HTC 2PVG2  
377. HTC Desire 628 dual sim - HTC Desire 628 dual sim  
378. HTC One - HTC One  
379. HTC One mini - HTC One mini  
380. HTC U11 - HTC 2PZC100  
381. HTC U11 life - HTC U11 life  
382. HTC U11 life - HTC U11 Life  
383. HTC U11 life - HTC U11 life  
384. HTC U11+ - HTC\_2Q4D100  
385. HTC6435LVW - HTC6435LVW  
386. HTC909d - HTC 919d  
387. HTCDesire612VZW - HTC331ZLVW  
388. HTCDesire612VZW - HTC331ZLVWPP  
389. HTCEVODesign4G - HTC Acquire  
390. HTCEVODesign4G - HTC EVO Design C715e  
391. HTCEVODesign4G - HTC Hero S  
392. HTCEVODesign4G - HTC Kingdom  
393. HTCEVODesign4G - HTCEVODesign4G

394. HTCEVODesign4G - PH44100  
395. HTCOneMaxVZW - HTC6600LVW  
396. HTL23 - HTL23  
397. HTV31 - HTV31  
398. Hero - ERA G2 Touch  
399. Hero - HTC Hero  
400. Hero - T-Mobile G2 Touch  
401. Hero - T-Mobile\_G2\_Touch  
402. Hero - dopod A6288  
403. Hero - HERO200  
404. ISW13HT - ISW13HT  
405. Incredible 2 - ADR6350  
406. Incredible 2 - HTC IncredibleS S710d  
407. Incredible S - HTC Incredible S  
408. Incredible S - HTC\_S710E  
409. J Butterfly - HTL21  
410. J One - HTL22  
411. J Z321e - HTC J Z321e  
412. KDDI Infobar A02 - HTX21  
413. Legend - HTC Legend  
414. M10 - HTC 10  
415. M8si - HTC M8si  
416. M8t - HTC M8t  
417. M9 - HTC One M9  
418. M9e - HTC M9e  
419. M9e - HTC One M9\_Prime Camera Edition  
420. M9e - HTC One M9s  
421. M9e - HTC\_M9e  
422. M9et - HTC M9et  
423. M9ew - HTC M9ew  
424. M9ew - HTC\_M9ew  
425. M9pw - HTC M9pw  
426. M9pw - HTC M9pw  
427. M9px - HTC\_M9px  
428. M9w - HTC M9w  
429. Nexus 9 - Nexus 9  
430. Nexus 9 LTE - Nexus 9  
431. Nexus One - Nexus One  
432. ONE - HTC One dual sim  
433. ONE M8s - HTC One M8s  
434. ONE M8s - HTC\_0PKV1  
435. ONE S - HTC One S  
436. ONE SV - HTC K2\_U  
437. ONE SV - HTC One SV  
438. ONE SV - HTC One SV  
439. One - HTC 801e  
440. One - HTC One  
441. One - HTC One 801e  
442. One - HTC\_PN071  
443. One - HTC 802t  
444. One - HTC 802t 16GB  
445. One - HTC 802w  
446. One - HTC One dual sim  
447. One - HTC 802d  
448. One - HTC One dual 802d  
449. One - HTC One dual sim  
450. One - HTC One  
451. One - HTCONE  
452. One - HTC One  
453. One - HTC6500LVW  
454. One (E8) - HTC M8Sd  
455. One (E8) - HTC M8St  
456. One (E8) - HTC One\_E8  
457. One (E8) - HTC One\_E8  
458. One (E8) - HTC\_M8Sx  
459. One (E8) - 0PAJ5  
460. One (E8) dual sim - HTC One\_E8 dual sim  
461. One (E8) dual sim - HTC\_M8Sy  
462. One (E8) dual sim - HTC 0PAJ4  
463. One (E8) dual sim - HTC M8Sd  
464. One (E8) dual sim - HTC One\_E8 dual sim  
465. One (E8) - HTC M8St  
466. One (E8) 4G LTE - HTC M8Sw  
467. One (E8) 4G LTE - HTC M8Ss  
468. One (M8 EYE) - HTC 0P6B900  
469. One (M8 EYE) - HTC One\_M8 Eye  
470. One (M8 Eye) - HTC 0P6B9  
471. One (M8 Eye) - HTC One\_M8 Eye  
472. One (M8) - HTC M8w  
473. One (M8) - HTC One\_M8  
474. One (M8) - HTC\_0P6B  
475. One (M8) - HTC\_0P6B6  
476. One (M8) - HTC\_M8x  
477. One (M8) - HTC One\_M8 dual sim  
478. One (M8) - HTC M8d  
479. One (M8) - 831C  
480. One (M8) - HTC One\_M8  
481. One (M8) - HTC6525LVW  
482. One (M8) (4G LTE ) - HTC M8e  
483. One 801e - HTC One 801e  
484. One 801e - HTC One 801s  
485. One A9 - HTC A9w  
486. One A9 - HTC One A9  
487. One A9 - HTC\_A9u  
488. One A9 - HTC One A9  
489. One A9 - 2PQ93  
490. One A9s - HTC 2PWD1  
491. One A9s - HTC One A9s  
492. One A9s - HTC\_A9sx  
493. One A9s - HTC 2PWD2  
494. One A9s - HTC One A9s  
495. One Dual 802d - HTC One dual 802d  
496. One Dual Sim - HTC One dual sim  
497. One E8 dual - HTC\_M8Sd  
498. One E9 dual sim - HTC 0PL31  
499. One E9 dual sim - HTC One E9 dual sim  
500. One E9PLUS dual sim - HTC One E9PLUS dual sim  
501. One E9s dual sim - HTC D826sw  
502. One E9s dual sim - HTC One E9s dual sim  
503. One E9s dual sim - HTC\_E9sx  
504. One Google Play edition - HTC One  
505. One M8 eye 4G LTE - HTC M8Et  
506. One M8 eye 4G LTE - HTC M8Ew  
507. One M9 - 0PJA10  
508. One M9 - HTC 0PJA10  
509. One M9 - HTC One M9  
510. One M9 - HTC\_0PJA10  
511. One M9 - HTC\_M9u  
512. One M9 - HTC One M9  
513. One M9 - HTC One M9  
514. One M9 - 0PJA2  
515. One M9 - HTC One M9  
516. One M9 - HTC6535LRA  
517. One M9 - HTC6535LVW

518. One M9+ - HTC 0PK71  
519. One M9+ - HTC M9pt  
520. One M9+ - HTC One M9PLUS  
521. One M9+ - HTC\_M9pw  
522. One M9+ (Prime Camera Edition) - HTC 0PK71  
523. One M9+ (Prime Camera Edition) - HTC One M9PLUS\_Prime Camera Edition  
524. One M9PLUS - HTC One M9PLUS  
525. One ME dual sim - HTC 0PLA1  
526. One ME dual sim - HTC One ME dual sim  
527. One S - HTC One S  
528. One S - HTC VLE\_U  
529. One S - HTC One S  
530. One S - HTC Z560e  
531. One S Special Edition - HTC One S Special Edition  
532. One S9 - HTC 2PRG100  
533. One S9 - HTC One S9  
534. One S9 - HTC\_S9u  
535. One SC - HTC One SC  
536. One SC - HTC One SC T528d  
537. One SV - C525c  
538. One SV - HTC One SV  
539. One SV - HTC K2\_UL  
540. One SV - HTC One SV  
541. One SV BLK - HTC One SV  
542. One SV BLK - HTC One SV BLK  
543. One V - HTC One V  
544. One V - HTC ONE V  
545. One V - HTC One V  
546. One VX - HTC One VX  
547. One X - HTC One X  
548. One X - HTC S720e  
549. One X - HTC One X  
550. One X+ - HTC One X+  
551. One X+ - HTC One X+  
552. One X10 - HTC 2PXH1  
553. One X10 - HTC One X10  
554. One X10 - HTC 2PXH2  
555. One X10 - HTC One X10  
556. One X10 - HTC\_X10u  
557. One X10 - HTC 2PXH3  
558. One X9 - HTC 2PS5200  
559. One X9 dual sim - HTC One X9 dual sim  
560. One X9 dual sim - HTC X9u  
561. One X9 dual sim - HTC\_X9u  
562. One XL - HTC One X  
563. One XL - HTC One XL  
564. One XL - HTC\_One\_XL  
565. One XL - HTC EVA\_UTL  
566. One max - HTC One max  
567. One max - HTC\_One\_max  
568. One max - HTC0P3P7  
569. One mini - HTC One mini  
570. One mini - HTC One mini  
571. One mini - HTC\_One\_mini\_601e  
572. One mini - HTC\_PO582  
573. One mini 2 - HTC One mini 2  
574. One mini 2 - HTC\_M8MINx  
575. One mini 2 - HTC\_One\_mini\_2  
576. One mini 601E - HTC\_One\_mini\_601e  
577. One remix - HTC6515LVW  
578. One\_E8 - HTC One\_E8  
579. Onex X - HTC One X  
580. PO091 - HTC PO091  
581. Puccini - HTC PG09410  
582. Puccini - HTC-P715a  
583. Rhyme S510b - HTC Rhyme S510b  
584. S720e - HTC S720e  
585. Salsa C510e - HTC Salsa C510b  
586. Salsa C510e - HTC Salsa C510e  
587. Sensation 4G - HTC Sensation  
588. Sensation 4G - HTC Sensation 4G  
589. Sensation 4G - HTC Sensation XE with Beats Audio  
590. Sensation 4G - HTC Sensation XE with Beats Audio Z715a  
591. Sensation 4G - HTC Sensation XE with Beats Audio Z715e  
592. Sensation 4G - HTC Sensation Z710a  
593. Sensation 4G - HTC Sensation Z710e  
594. Sensation 4G - HTC-Z710a  
595. Sensation XL with Beats Audio X315e - HTC Sensation XL with Beats Audio X315b  
596. Sensation XL with Beats Audio X315e - HTC Sensation XL with Beats Audio X315e  
597. Sensation XL with Beats Audio X315e - HTC-X315E  
598. Sensation XL with Beats Audio X315e - Sensation XL with Beats Audio  
599. T329d - HTC T329d  
600. T528w - HTC Desire L dual sim  
601. Telstra Signature Premium - HTC 2PQ910  
602. Thunderbolt - ADR6400L  
603. Thunderbolt - HTC Mecha  
604. U Play - HTC U Play  
605. U Play - HTC\_U-2u  
606. U Play - HTC 2PZM3  
607. U Play - HTC U Play  
608. U Play - HTC 2PWD1  
609. U Ultra - HTC U-1w  
610. U Ultra - HTC U Ultra  
611. U Ultra - HTC\_U-1u  
612. U Ultra - HTC 2PZF1  
613. U Ultra - HTC U Ultra  
614. U11 - HTC U-3w  
615. U11 - HTC U11  
616. U11 - HTC\_U-3u  
617. U11 - HTC 2PZC100  
618. U11 - HTC U11  
619. U11 - 601HT  
620. U11 - HTV33  
621. U11 - 2PZC5  
622. U11 - HTC U11  
623. Velocity 4G - HTC PH39100  
624. Velocity 4G - HTC Raider X710e  
625. Velocity 4G - HTC Velocity 4G  
626. Velocity 4G - HTC Velocity 4G X710s  
627. Velocity 4G - HTC-X710a  
628. WF5w - HTC WF5w  
629. Wildfire - HTC Wildfire  
630. Wildfire CDMA - HTC Bee  
631. Wildfire CDMA - HTC Wildfire  
632. Wildfire S - HTC Wildfire S  
633. Wildfire S - HTC Wildfire S A510b  
634. Wildfire S - HTC Wildfire S A510e  
635. Wildfire S - HTC-A510a



- 636. Wildfire S A515c - HTC Wildfire S A515c
- 637. Wildfire S A515c - HTC-PG762
- 638. Wildfire S A515c - USCCADR6230US
- 639. X2-HT - X2-HT
- 640. desire 400 dual sim - HTC Desire 400 dual sim
- 641. desire 608t - HTC 608t
- 642. desire 610 - HTC Desire 610
- 643. desire x - HTC Desire X
- 644. first - HTC first
- 645. myTouch 3G - HTC Magic
- 646. myTouch 3G - T-Mobile myTouch 3G
- 647. myTouch 3G Slide - T-Mobile myTouch 3G Slide
- 648. myTouch 4G - HTC Glacier
- 649. myTouch 4G - HTC Panache
- 650. myTouch 4G Slide - myTouch\_4G\_Slide

## Hafury

- 1. HAFURY MIX - HAFURY MIX
- 2. HAFURY UMAX - HAFURY UMAX

## Haier

- 1. A-TT00 - A-TT00
- 2. A36C5H - Andromax A36C5H
- 3. A42P - Haier A42P
- 4. AD6B1H - Smartfren Andromax AD6B1H
- 5. AL40 - Haier\_AL40
- 6. AP54 - AP54
- 7. AT7003 - AT7003
- 8. Beeline Smart 3 - Beeline Smart 3
- 9. C46B2H - Andromax C46B2H
- 10. CDP7TAB4C8 - CDP7TAB4C8
- 11. CDP8TAB16SD - CDP8TAB16SD
- 12. CEDTAB70616W8 - CEDTAB70616W8
- 13. CETAB10KML9 - CETAB10KML9
- 14. CETAB7ML9 - CETAB7ML9
- 15. CETAB9ML9 - CETAB9ML9
- 16. CMP\_765 - CMP\_765
- 17. CT1030 - CT1030
- 18. CT301\_W818 - CT301\_W818
- 19. CT825 - CT825
- 20. CYCLONE\_ODYSSEY - CYCLONE\_ODYSSEY
- 21. D2-721 - D2-721G
- 22. D2-751G - D2-751G
- 23. D2-927G - D2-927G
- 24. D2-961G - D2-961G
- 25. Fast - Beeline Fast
- 26. G21 - G21
- 27. G30 - G30
- 28. G31s - G31s
- 29. G40 - G40
- 30. G50 - G50
- 31. G55 - G55
- 32. G7 - G7
- 33. G7 - HM-G552-FL
- 34. G700 - G700
- 35. G7s - G7s
- 36. GF88 - I7A-LE
- 37. HG-9041 - HG-9041
- 38. HM-I557-FL - HM-I557-FL
- 39. HM-N501-FL - HM-N501-FL
- 40. HS-10DTB4 - HS-10DTB4

- 41. HS-7DTB25 - HS-7DTB25
- 42. HS-7DTB29-8GB - HS-7DTB29-8GB
- 43. HS-9DTB37 - HS\_9DTB37
- 44. HT-I860 - HT-I860
- 45. HW-I509-W - FORZA
- 46. Haier - Binatone Homesurf744 / Hubble Smart7 (Homesurf744)
- 47. Haier - PAD69H
- 48. Haier - pad\_d85
- 49. Haier - W627
- 50. Haier - W861
- 51. HaierG61 - HM-G701-FL
- 52. HomeSurf742\_AT7003 - HomeSurf742\_AT7003
- 53. Homesurf844 - Binatone Homesurf844 / Hubble Smart8 (Homesurf844)
- 54. Hyasong T1 - HyasongT1
- 55. I50 - I50
- 56. INGO-TAB - INGO-TAB
- 57. Kogan Agora 8 - Kogan Agora 8
- 58. Konnect\_350 - Konnect\_350
- 59. L11 - HM-G152-FL
- 60. L50 - L50
- 61. L52 - L52
- 62. LE32U5000A - LE32U5000A
- 63. LE39M7000CF - LE39M7000CF
- 64. LE40U5000A - LE40U5000A
- 65. LE43B7600A - LE43B7600A
- 66. LE43U5000A - LE43U5000A
- 67. LE48M7000CF - LE48M7000CF
- 68. LE49U5000A - LE49U5000A
- 69. LE55M7000CF - LE55M7000CF
- 70. Logicom S9782 - Logicom-S9782
- 71. M7808 - M7808
- 72. MD-01P - MD-01P
- 73. MD210 - MD210
- 74. MEGAFON MS3A - MS3A
- 75. MT-700 - MT-700
- 76. MXG308 - MXG308
- 77. MXG408 - MXG408
- 78. NEO10-1 - NEO10-1
- 79. NEO7-1 - NEO7-1
- 80. NEO7-2 - NEO7-2
- 81. NEO8-1 - NEO8-1
- 82. P2 - P2
- 83. PAD1021 - PAD1021
- 84. PAD1042 - PAD1042
- 85. PAD712 - PAD712
- 86. PAD722 - PAD722
- 87. PAD841 - PAD841
- 88. PADCT1010W - PADCT1010W
- 89. PAD\_1042 - PAD\_1042
- 90. PNDPP410GP - PNDPP410GP
- 91. PNDPP44Q7GPBLK - PNDPP44Q7GPBLK
- 92. PNDPP47GP - PNDPP47GP
- 93. SP-5100 - SP-5100
- 94. Skill - Skill
- 95. Smartfren Andromax AD681H - Smartfren Andromax AD681H
- 96. Smartfren Andromax AD9A1H - Smartfren Andromax AD9A1H
- 97. StarQ\_Q5002 - Q5002
- 98. T50 - Haier T50

99. T52P - Haier T52P
100. T54P - Haier T54P
101. T785B - T785B
102. TAB-700 - TAB-700
103. TAB-700 - TAB700MPG
104. TMK27A2 - TMK27A2
105. V3 - V3
106. Voyage V6 - HM-V6
107. W717 - W717
108. W757 - W757
109. W860 - W860
110. haier lesure L7 - HM-N700-FL
111. i50 - Haier\_i50

## Handheld Group

1. Algiz RT7 - Algiz RT7
2. HandHeld NAUTIZ X2 - NAUTIZ\_X2

## HannSpree

1. HSG1279 - HSG1279
2. HSG1341 - HSG1341
3. HSG1351 - HSG1351
4. HSG1360 - HSG1360

## Harris

1. 12131-1000 - Harris 12131-1000
2. LMC-1000 - LMC-1000
3. RF-3590-RT - Harris 12131-1000

## Helio

1. S10 - S10
2. S2 - S2
3. S25 - S25

## HighScreen

1. Bay - Bay
2. Easy Power - Easy-Power
3. Easy Power Pro - Easy-Power-Pro
4. Easy XL - Easy\_XL
5. Easy XL Pro - Easy\_XL\_Pro
6. Fest XL - FestXL
7. Fest XL PRO - FestXL-Pro
8. Power Five - PowerFive
9. Power Four - PowerFour
10. Power Ice - Power Ice
11. Power Ice EVO - Power Ice Evo
12. Power Rage - Power Rage
13. PowerIceMax - Power Ice Max
14. PowerRageEvo - Power Rage Evo
15. Prime L - Prime L
16. Tasty - Tasty

## Hipstreet

1. 785TB4 - 785TB4
2. 7DTB25 - 7DTB25
3. 7DTB37 - 7DTB37
4. 9DTB38 - 9DTB38
5. 9DTB39 - 9DTB39
6. Beeline Smart 4 - Beeline Smart 4

7. Beeline Smart 5 - Beeline Smart 5
8. CP-VL5A - CP-VL5A
9. ETAB\_M7023G - ETAB\_M7023G
10. Electron - 8DTB38
11. Electron 2 - 8DTB40
12. F100 - f100\_65u
13. HS-10DTB12 - HS-10DTB12
14. HS-10DTB12A - 10DTB12A
15. HS-10DTB12A - HS\_10DTB12A
16. HS-10DTB41 - HS-10DTB41-8GB
17. HS-10DTB8 - HS-10DTB8
18. HS-7DTB27 - HS-7DTB27
19. HS-7DTB35 - HS-7DTB35
20. HS-7DTB35 - HS\_7DTB35
21. HS-7DTB39 - HS-7DTB39
22. HS-7DTB40 - HS-7DTB40-8GB
23. HS-9DTB7A - HS-9DTB7A
24. Joey Jet 2 - Dtac phone Joey Jet 2
25. LS-4004 - LS-4004
26. LS-5013 - LS-5013
27. LS-5017 - LS-5017
28. LS-5507 - LS-5507
29. LS-6001 - LS-6001
30. Micron - 7DTB41
31. Nanho T775 - Nanho\_T775
32. Phantom - 10DTB10
33. Phantom2 - 10DTB44
34. Phoenix2 - Phoenix2
35. Pilot - 10DTB42
36. Synergy - 11DTB1
37. YUPIROID - YUPIROID

## Hisense

1. AD683G - AD683G
2. AD685G - New Andromax-i
3. E820 - HS-E820
4. E910 - E910
5. E910 - HS-E910
6. E912 - HS-E912
7. E912S - HS-E912S
8. E920 - HS-E920
9. E926 - E926
10. E930 - HS-E930
11. E956 - HS-E956
12. E956Q - HS-E956Q
13. EG870 - HS-EG870
14. EG876 - HS-EG876
15. EG901 - HS-EG901
16. EG909 - HS-EG909
17. EG950 - HS-EG950
18. EG970 - HS-EG970
19. P4013 - MEDION-P4013
20. SIMPlus - MegaFon SIM+
21. T818 - HS-T818
22. TP9101 - HS-M170AT
23. TP9102 - M1101AT
24. U2 - U2
25. U8 - HS-U8
26. U820 - HS-U820
27. U820A - HS-U820
28. U820A - U1+
29. U820AVN - HS-U820



30. U860 - HS-U860  
31. U909 - HS-U909  
32. U909B - HS-U909B  
33. U909B\_6 - HS-U909  
34. U909B\_MN - U2S  
35. U912 - HS-U912  
36. U950 - HS-U950  
37. U950\_6 - HS-U950  
38. U950\_MN - U3  
39. U950\_ae - HS-U950  
40. U958 - HS-U958  
41. U960Q - HS-U960Q  
42. W2400 - W2400  
43. m3101 - M3101BW  
44. m370 - M370BW  
45. t909 - HS-T909  
46. t950 - HS-T950  
47. t958 - HS-T958  
48. t960 - HS-T960  
49. 55H6SG - Vision  
50. A2 - Hisense A2  
51. A2M - Hisense A2M  
52. A2T - Hisense A2T  
53. AGM A7 - AGM A7  
54. AJM X2 - AGM X2  
55. Andromax-c - Andromax-c  
56. C-4 - C-4  
57. C1 - Hisense C1  
58. C1AE - Hisense C1  
59. C1AE-1 - Hisense C1  
60. C1AE-2 - Hisense C1  
61. C1BE - Hisense C1  
62. C1M - Hisense C1M  
63. C1T - Hisense C1T  
64. C20F - Hisense C20  
65. C20FE-1 - Hisense C20  
66. C20S - Hisense C20S  
67. C20W - Hisense C20  
68. C30 - Hisense C30  
69. C30 - Hisense C30\_02  
70. C30 Lite - Hisense C30 Lite  
71. C30 Lite - STARACTIVE 2  
72. C30 Lite - SX40  
73. CMB405 - CMB405  
74. CMB501 - CMB501  
75. CMB510 - CMB510  
76. D1-M - Hisense D1-M  
77. D2-M - D2-M  
78. D5 - Hisense D5  
79. E10 - E10  
80. E100T - Hisense E100T  
81. E100TAE - LT-W1  
82. E200T - HS-E200T  
83. E2070 - E2070  
84. E20T - Hisense E20T  
85. E2371CH - E2371CH  
86. E260T - HS-E260T  
87. E260U - Hisense E260U  
88. E270BSA - E270BSA  
89. E360M - Hisense E360M  
90. E50-T - Hisense E50-T  
91. E51-F - Hisense E51  
92. E51-M - Hisense E51-M  
93. E51-W - Hisense E51  
94. E600MH02 - HS-E600M  
95. E601M - E601M  
96. E602T - Hisense E602T  
97. E613M - Hisense E613M  
98. E620M - Hisense E602M  
99. E621T - Hisense E621T  
100. E622M - Hisense E622M  
101. E625T - Hisense E625T  
102. E70-T - Hisense E70-T  
103. E71-M - Hisense E71-M  
104. E71-T - Hisense E71-T  
105. E75M - Hisense E75M  
106. E75T - Hisense E75T  
107. E76 - Hisense E76  
108. E76E\_11 - Hisense E76  
109. E77M - Hisense E77M  
110. E77MINI - Hisense E77MINI  
111. E860 - E860  
112. E9 - Hisense E9  
113. EG606 - EG606  
114. EG680 - EG680  
115. EG68AE - LT668  
116. EG929 - EG929  
117. EG936D - HS-EG936D  
118. EG950 - EG950  
119. EG970 - EG970  
120. EG978 - HS-EG978  
121. EG98 - EG98  
122. EG98 - EG98  
123. EG981 - HS-EG981  
124. F10 - BM001  
125. F10 - Hisense F10  
126. F10 - Hisense L675 Pro  
127. F10 - RIVIERA F10  
128. F102 - Hisense F102  
129. F102 - Hisense Hi 3  
130. F20 - F20  
131. F20 - Hisense F20  
132. F20T - Hisense F20T  
133. F21T - Hisense F21T  
134. F22 - F22  
135. F22 - Hisense F22  
136. F22 - Hisense F22  
137. F22M - Hisense F22M  
138. F23 - Hisense F23  
139. F23 - RIVIERA F23  
140. F23 - Hisense F23  
141. F23M - Hisense F23M  
142. F270BW - F270BW  
143. F30 - F30  
144. F30 - Hisense F30  
145. F31 - Hisense F31  
146. F31E\_11 - Hisense F31  
147. F31M - Hisense F31M  
148. F32 - Hisense F32  
149. F5070 - F5070  
150. F5180 - F5180  
151. F5281CH - F5281CH  
152. G1 - G1  
153. G2-3GP - G2-3GP

154. G610M - Hisense G610M  
155. H800T - HS-H800T  
156. H910 - Hisense H910  
157. H910 - Hisense H910  
158. H910-F01 - Hisense H910  
159. HS- G610 - HS-G610  
160. HS- L682 - HS-L682  
161. HS-E600M - HS-E600M  
162. HS-E620M - HS-E620M  
163. HS-E917 - HS-E917  
164. HS-E936 - HS-E936  
165. HS-E968 - HS-E968  
166. HS-EG916 - HS-EG916  
167. HS-EG929 - HS-EG929  
168. HS-EG929 - msm8625  
169. HS-EG939 - HS-EG939  
170. HS-EG958 - HS-EG958  
171. HS-EG966 - HS-EG966  
172. HS-EG971 - HS-EG971  
173. HS-EG980 - HS-EG980  
174. HS-EG98C - HS-EG98C  
175. HS-G610 - HS-G610  
176. HS-I630M - HS-I630M  
177. HS-I630T - HS-I630T  
178. HS-T9 - HS-T9  
179. HS-T926 - HS-T926  
180. HS-T928 - HS-T928  
181. HS-T939 - HS-T939  
182. HS-T959 - HS-T959  
183. HS-T959S - HS-T959S  
184. HS-T959S1 - HS-T959S1  
185. HS-T966 - HS-T966  
186. HS-T967 - HS-T967  
187. HS-T968 - HS-T968  
188. HS-T968S - HS-T968S  
189. HS-T970 - HS-T970  
190. HS-T978 - HS-T978  
191. HS-T980 - HS-T980  
192. HS-U601 - HS-U601  
193. HS-U820 - HS-U820  
194. HS-U9 - HS-U9  
195. HS-U912 - HS-U912  
196. HS-U912 - HS-U912  
197. HS-U912 - HS-U912  
198. HS-U929 - HS-U929  
199. HS-U929 - HS-U929  
200. HS-U936 - HS-U936  
201. HS-U939 - HS-U939  
202. HS-U939 - HS-U939  
203. HS-U939 - HS-U939  
204. HS-U939 - HS-U939  
205. HS-U939 - HS-U939  
206. HS-U950 - HS-U950  
207. HS-U961 - HS-U961  
208. HS-U961 - HS-U961  
209. HS-U961 - HS-U961  
210. HS-U966 - HS-U966  
211. HS-U966 - HS-U966  
212. HS-U970 - HS-U970  
213. HS-U970 - HS-U970  
214. HS-U970E - HS-U970E  
215. HS-U971 - HS-U971  
216. HS-U978 - HS-U978  
217. HS-U98 - U98  
218. HS-U98 - HS-U98  
219. HS-U980 - HS-U980  
220. HS-U980 - HS-U980  
221. HS-U980 - HS-U980  
222. HS-U980 - HS-U980  
223. HS-U980 - HS-U980  
224. HS-U980 - HS-U980  
225. HS-U980 - HS-U980  
226. HS-U980 - HS-U980  
227. HS-U980 - HS-U980  
228. HS-X5T - HS-X5T  
229. HS-X68T - HS-X68T  
230. HS-X6T - HS-X6T  
231. HS-X8C - HS-X8C  
232. HS-X8T - HS-X8T  
233. HS-X8U - HS-X8U  
234. Hisense E76MINIM - Hisense E76MINIM  
235. Hisense E77 - Hisense E77  
236. Hisense F8 MINI - Hisense F8 MINI  
237. Hisense M36 - Hisense M36  
238. Hisense P1 - Hisense P1  
239. I300T - Hisense I300T  
240. I56D2G - Andromax I56D2G  
241. I630U - Hisense I630U  
242. I631M - Hisense I631M  
243. I632M - Hisense I632M  
244. I632T - Hisense I632T  
245. I635T - Hisense I635T  
246. I639M - Hisense I639M  
247. I639T - Hisense I639T  
248. I639T - Hisense I639T  
249. I639T - Hisense I639T  
250. IRON 2 - IRON 2  
251. K1 - Hisense K1  
252. K220\_FHD - K220\_FHD  
253. L635E\_1 - Trekker-M1  
254. L671 - HS-L671  
255. L671 - Hisense L671  
256. L671W - HS-L671  
257. L671W - Hisense L671  
258. L671WE\_1 - Hisense L671  
259. L671WE\_2 - Hisense L671  
260. L675 - Hisense L675  
261. L676BE-1 - Hisense L676  
262. L676BE-2 - Hisense L676  
263. L678 - Hisense L678  
264. L681 - L681  
265. L682 - HS-L682  
266. L682 - Hisense L682  
267. L691 - HS-L691  
268. L691 - HS-L691  
269. L691AE - HS-L691  
270. L695 - HS-L695  
271. L695W - HS-L695  
272. L695W - Hisense L695  
273. L695WE\_2 - Hisense L695  
274. L697 - L697  
275. L730 - STARADDICT 6  
276. LED32G180 - LED32G180  
277. LED32K220 - LED32K220

278. LED32K280J3D - LED32K280J3D  
279. LED32K360 - LED32K360  
280. LED32K360J - LED32K360J  
281. LED32K360J3D - LED32K360J3D  
282. LED32K360X3D - LED32K360X3D  
283. LED32K370 - LED32K370  
284. LED32K600J - LED32K600J  
285. LED32K600X3D - LED32K600X3D  
286. LED32K610X3D - LED32K610X3D  
287. LED32L288 - LED32L288  
288. LED39K280J3D - LED39K280J3D  
289. LED39K360J - LED39K360J  
290. LED39K360X3D - LED39K360X3D  
291. LED39K600X3D - LED39K600X3D  
292. LED39K600X3DU - LED39K600X3DU  
293. LED39K610X3D - LED39K610X3D  
294. LED39K680X3DU - LED39K680X3DU  
295. LED40K260X3D - LED40K260X3D  
296. LED40K360J - LED40K360J  
297. LED40K360X3D - LED40K360X3D  
298. LED40K370 - LED40K370  
299. LED40K681X3DU - LED40K681X3DU  
300. LED40L288 - LED40L288  
301. LED42G200 - LED42G200  
302. LED42K280J3D - LED42K280J3D  
303. LED42K330X3D - LED42K330X3D  
304. LED42K360J - LED42K360J  
305. LED42K360X3D - LED42K360X3D  
306. LED42K370 - LED42K370  
307. LED42K380U - LED42K380U  
308. LED42K560X3D - LED42K560X3D  
309. LED42K600A3D - LED42K600A3D  
310. LED42K600X3D - LED42K600X3D  
311. LED42K610J3DP - LED42K610J3DP  
312. LED42K610X3D - LED42K610X3D  
313. LED42K660X3D - LED42K660X3D  
314. LED42K680X3DU - LED42K680X3DU  
315. LED42L288 - LED42L288  
316. LED46K260X3D - LED46K260X3D  
317. LED46K280J3D - LED46K280J3D  
318. LED46K330X3D - LED46K330X3D  
319. LED46K360J - LED46K360J  
320. LED46K360X3D - LED46K360X3D  
321. LED46K660X3D - LED46K660X3D  
322. LED47K560J3D - LED47K560J3D  
323. LED47K600X3D - LED47K600X3D  
324. LED47K610J3DP - LED47K610J3DP  
325. LED48K360X3D - LED48K360X3D  
326. LED48K370 - LED48K370  
327. LED48K380U - LED48K380U  
328. LED48K681X3DU - LED48K681X3DU  
329. LED48L288 - LED48L288  
330. LED50G05 - LED50G05  
331. LED50K260X3D - LED50K260X3D  
332. LED50K360J - LED50K360J  
333. LED50K360X3D - LED50K360X3D  
334. LED50K370 - LED50K370  
335. LED50K380U - LED50K380U  
336. LED50K610X3D - LED50K610X3D  
337. LED50K660X3D - LED50K660X3D  
338. LED50K680X3DU - LED50K680X3DU  
339. LED50L288 - LED50L288  
340. LED50XT880G3D - LED50XT880G3D  
341. LED50XT880G3DU - LED50XT880G3DU  
342. LED50XT900X3DU - LED50XT900X3DU  
343. LED55K260X3D - LED55K260X3D  
344. LED55K360X3D - Hisense LED55K360X3D  
345. LED55K370 - LED55K370  
346. LED55K380U - LED55K380U  
347. LED55K600A3D - LED55K600A3D  
348. LED55K600X3D - LED55K600X3D  
349. LED55K610X3D - LED55K610X3D  
350. LED55K680X3DU - LED55K680X3DU  
351. LED55L288 - LED55L288  
352. LED55XT780G3D - LED55XT780G3D  
353. LED55XT810X3DU - LED55XT810X3DU  
354. LED55XT880G3DU - LED55XT880G3DU  
355. LED55XT900X3DU - LED55XT900X3DU  
356. LED58K280J - LED58K280J  
357. LED58K280U - LED58K280U  
358. LED58K610X3D - LED58K610X3D  
359. LED58K680X3DU - LED58K680X3DU  
360. LED58XT880G3D - LED58XT880G3D  
361. LED58XT880J3DU - LED58XT880J3DU  
362. LED60K380 - LED60K380  
363. LED65K560J3DTB - LED65K560J3DTB  
364. LED65K560J3DTR - LED65K560J3DTR  
365. LED65K600X3D - LED65K600X3D  
366. LED65K680X3DU - LED65K680X3DU  
367. LED65XT780G3D - LED65XT780G3D  
368. LED65XT800X3DU - LED65XT800X3DU  
369. LED65XT810X3DU - LED65XT810X3DU  
370. LED65XT880G3D - LED65XT880G3D  
371. LED65XT880G3DF - LED65XT880G3DF  
372. LED65XT880G3DU - LED65XT880G3DU  
373. LED65XT890G3D - LED65XT890G3D  
374. LED65XT900G3DU - LED65XT900G3DU  
375. LED65XT900X3DU - LED65XT900X3DU  
376. LED75XT890G3D - LED75XT890G3D  
377. LED75XT910G3DU - LED75XT910G3DU  
378. LED84XT900G3D - LED84XT900G3D  
379. LED85XT910G3DU - Vision20  
380. LT100K6900A - LT100K6900A  
381. LT610 - LT610  
382. M10-M - Hisense M10-M  
383. M20- T - Hisense M20-T  
384. M20-M - Hisense M20-M  
385. M30 - Hisense M30  
386. M30M - Hisense M30M  
387. M30T - Hisense M30T  
388. M3101BCD - M3101BCD  
389. M36 - Hisense M36  
390. M470BSA - M470BSA  
391. M470BSD - M470BSD  
392. M470BSE - M470BSE  
393. M470BSG - M470BSG  
394. M470BSS - M470BSS  
395. M701 - M701  
396. M821 - M821  
397. M821H - M821H  
398. M821T - SMART 4G HD Voice  
399. MEDION E4001 - MEDION E4001  
400. MEDION X4701 - MEDION X4701  
401. Oysters Pacific 800 - Oysters Pacific 800



402. PX1900 - PX1900  
403. PX1900ES - PX7  
404. PX2000 - PX2000  
405. PX2700 - PX2700  
406. PX2800 - PX2800  
407. PX3000 - Hisense PX3000  
408. PX3000 - PX3000  
409. PX3100 - PX3100  
410. PX510 - PX510  
411. PX530 - PX8  
412. S1 - S1  
413. SKi630t - SKi630t  
414. STARSHINE 4 - STARSHINE 4  
415. STARTRAIL 9 - S40  
416. STARTRAIL 9 - STARTRAIL 9  
417. STARTRAIL 6 4G - STARTRAIL 6 4G  
418. Sero 7 - E2171CA  
419. Sero 7 - E2171MX  
420. Sero 7 - E2171TK  
421. Sero 8 - E2281  
422. Sero 8 - E2281CA  
423. Sero 8 - E2281MX  
424. Sero 8 - E2281TK  
425. Sero 8 - E2281UK  
426. Sero 8 pro - F5281  
427. Sero7 - E2171SS  
428. Sero7 LE - E2371  
429. Sero8 - E2281SS  
430. SoundTab MA-317 - Hisense SoundTab MA-317  
431. SoundTab MA-327 - Hisense SoundTab MA-327  
432. T963 - Hisense T963  
433. TV - hisense\_gx1200v  
434. U601S - Hisense U601S  
435. U602 - HS-U602  
436. U606 - STARSHINE III  
437. U606AE - HS-U606  
438. U606AE - PHS-402  
439. U607 - Bouygues Telecom Bs 403  
440. U609 - HS-U609  
441. U610 - HS-U610  
442. U610 - HS-U610  
443. U688 - HS-U688  
444. U688BE - HS-U688  
445. U800 - HS-U800  
446. U800E-1 - HS-U800  
447. U800E-1 - HS-U800E-1  
448. U963 - Hisense U963  
449. U963 - RIVIERA U963  
450. U966 - U966  
451. U970 - U970  
452. U988 - HS-U988  
453. U988AE - HS-U988  
454. U988E-1 - HS-U988  
455. U988E-2 - HS-U988  
456. U989 - Hisense U989  
457. U989 Pro - Hisense U989 Pro  
458. VH777 - VH777  
459. VIDAA\_TV - VIDAA\_TV  
460. VIDAA\_TV - VIDAA\_TV  
461. VIDAA\_TV - VIDAA\_TV  
462. VIDAA\_TV - VIDAA\_TV  
463. VIDAA\_TV - VIDAA\_TV

464. VIDAA\_TV - VIDAA\_TV  
465. VIDAA\_TV - VIDAA\_TV  
466. VIDAA\_TV - VIDAA\_TV  
467. VIDAA\_TV - VIDAA\_TV  
468. Vidaa - H7  
469. Vision - Vision  
470. Vision 2.5 - vision2\_5  
471. W2 - W2  
472. W270BD - W270BD  
473. WA912 - WA912  
474. WA960 - WA960  
475. WM8 - WM8  
476. X1E1 - HS-X1  
477. XOLO - XOLO T1000  
478. c20 - Hisense C20  
479. c20ae - C20  
480. c20fe-3 - Hisense C20  
481. e76mini - Hisense E76mini  
482. l676be - Hisense L676  
483. l691 - HS-L691  
484. l830 - Hisense L830  
485. l830 - STARXTREM 6  
486. lt971 - LT971  
487. u972 - U972  
488. vision2\_1 - vision2\_1

## Hoffmann

1. X Max - X-Max

## Hon Hai Precision Industry Co., Ltd.

1. EP10\_wifi - PocketBook A10
2. EP5A\_wifi - PocketBook A7
3. Germany - LIFETAB\_S9714
4. nabi\_XD - NABIXD-NV10C

## Honda

1. A-DA - 14A-DA
2. A-DA - MY15ADA
3. A-DA - MY17ADA
4. Accord - MY16ADA
5. MY15ADA - MY15ADA
6. NSX - MY15ADA
7. Pilot - MY15ADA
8. Ridgeline - MY15ADA
9. Spiorior - MY15ADA
10. Unit Assy AVN - SiRFSoC Android

## Honeywell

1. 70eL00 - Dolphin 70e Black
2. 70eLGN - Dolphin 70e Black
3. 70eLGN - Dolphin 70e Black
4. 70eLW0 - Dolphin 70e Black
5. 70eLWN - Dolphin 70e Black
6. CK75 - CX75 AC0
7. CK75 - CX75 AN0
8. CN51 - CN51 NC0
9. CN51 - CN51 NCF
10. CN51 - CN51 NCU
11. CN51 - CN51 NN0
12. CN51 - CN51 QC0

13. CN51 - CN51 QCF
14. CN51 - CN51 QCU
15. CN51 - CN51 QN0
16. CN75 - CX75 NC0
17. CN75 - CX75 NCF
18. CN75 - CX75 QC0
19. CN75 - CX75 QCF
20. CN75E - CX75 NC0
21. CN75E - CX75 NCF
22. CN75E - CX75 QC0
23. CN75E - CX75 QCF
24. CT50 - CT50
25. CT50 - CT50
26. CT50 - CT50
27. CT50 - CT50
28. CT50 - CT50
29. CT50 - CT50
30. CT50 - CT50
31. D75E - D75E
32. Dolphin 70e Black - Dolphin 70e Black
33. Dolphin 70e Black - Dolphin 70e Black
34. Dolphin 70e Black - Dolphin 70e Black
35. Dolphin 70e Black - Dolphin 70e Black
36. Dolphin CT50 - CT50
37. Dolphin CT50 - CT50
38. Dolphin CT50 - CT50
39. EDA50 - EDA50
40. EDA50 - EDA50
41. EDA50 - Glory50
42. EDA50 - EDA50
43. EDA50K - EDA50K
44. EDA50K - EDA50K
45. EDA50K - Glory EDA50K
46. EDA70 - EDA70
47. EDA70 - EDA70
20. U8110 - Turkcell T10
21. U8110 - U8110
22. U8110 - life:) Android
23. U8300 - U8300
24. U8500 - HUAWEI IDEOS U8500
25. U8500 - MTC\_EVO
26. dtab01 - dtab01
27. hwc8813Q - HUAWEI C8813Q
28. hwc8860E - HUAWEI C8860E
29. hwG520-T10 - HUAWEI G520-T10
30. hws42HW - S42HW
31. hws7-901w - A01HW
32. hwT8830Pro - T8830Pro
33. hwU9202L - U9202L-1
34. hwU9202L - U9202L-3
35. hwc8500 - C8500
36. hwc8511 - C8511
37. hwc8511 - MTS-SP101
38. hwc8512 - C8512
39. hwc8600 - C8600
40. hwc8650 - C8650
41. hwc8650e - HUAWEI C8650+
42. hwc8655 - HUAWEI C8655
43. hwc8800 - C8800
44. hwc8800 - MTS-SP140
45. hwc8810 - HUAWEI C8810
46. hwc8812E - HUAWEI C8812E
47. hwc8813 - HUAWEI C8813
48. hwc8825D - HUAWEI C8825D
49. hwc8860E - HUAWEI C8860E
50. hwc8860V - C8860V
51. hwc8950D - HUAWEI C8950D
52. hwc980 - CM980
53. hwh866c - H866C
54. hwh866c - HUAWEI H866C
55. hwh867g - Huawei-H867G
56. hwh868c - HUAWEI H868C
57. hwh881c - HUAWEI H881C
58. hwm650 - Express
59. hwm650 - M650
60. hwm660 - M660
61. hwm860 - HUAWEI-M860
62. hwm865c - M865C
63. hwm866 - HUAWEI M866
64. hwm866 - M866
65. hwm866 - USCCADR3310
66. hwm886 - M886
67. hwm920 - HUAWEI-M920
68. hwm931 - HUAWEI-M931
69. hwp2-0000 - HUAWEI P2-0000
70. hwp2-6011 - HUAWEI P2-6011
71. hwp2-6011 - HUAWEI P2-6011-orange
72. hws10101u - MediaPad 10 FHD
73. hws10101w - GT01
74. hws10101w - MediaPad 10 FHD
75. hws10201u - MediaPad 10 LINK
76. hws7300c - HUAWEI MediaPad
77. hws7300u - HUAWEI MediaPad
78. hws7300u - Huawei S7-312u
79. hws7300u - MediaPad
80. hws7300u - SpringBoard
81. hws7300w - HUAWEI MediaPad

## How

1. HT-704 - HT-704
2. HT-704plus - HT-704plus
3. HT704-G - 704-G

## Huawei

1. C8600 - C8600
2. CHT8000 - CHT8000
3. HuaweiU8180 - Huawei Ideos X1
4. HuaweiU8180 - HuaweiU8180
5. HuaweiU8180 - IDEOS X1
6. HuaweiU8180 - Kyivstar Terra
7. HuaweiU8180 - Starshine
8. HuaweiU8180 - Stockholm
9. HuaweiU8180 - U8180
10. Pulse - Pulse
11. T8300 - HUAWEI T8300
12. T8600 - HUAWEI T8600
13. T8828 - HUAWEI T8828
14. U8110 - EQ U8110
15. U8110 - Huawei
16. U8110 - Huawei U8110
17. U8110 - MTC\_A
18. U8110 - Pulse Mini
19. U8110 - TSP21



82. hws7930w - MediaPad 7 Lite  
83. hwt8620 - T8620  
84. hwt8830 - T8830  
85. hwt8833 - HUAWEI T8833  
86. hwt8950 - HUAWEI T8950  
87. hwt8950N - HUAWEI T8950N  
88. hwt8951 - HUAWEI T8951  
89. hwt9200 - T9200  
90. hwt9510e - T9510E  
91. hwu8180 - Netphone 501  
92. hwu8180 - U8180  
93. hwu8185 - U8185  
94. hwu8186 - U8186  
95. hwu8230 - U8230  
96. hwu8350 - Barcelona  
97. hwu8350 - GM FOX  
98. hwu8350 - HuaweiU8350  
99. hwu8350 - MTC Pro  
100. hwu8350 - Personal U8350  
101. hwu8350 - Temptation  
102. hwu8350 - U8350  
103. hwu8350 - U8350-51  
104. hwu8500 - Grameenphone Crystal  
105. hwu8500 - HUAWEI\_IDEOS\_U8500  
106. hwu8500 - HuaweiU8500  
107. hwu8500 - ICE  
108. hwu8500 - MF8503  
109. hwu8500 - MTC Evo  
110. hwu8500 - MegaFon U8500  
111. hwu8500 - U8500  
112. hwu8510 - Beeline\_E500  
113. hwu8510 - GM Ultimate Slim  
114. hwu8510 - Huawei IDEOS X3  
115. hwu8510 - HuaweiU8510  
116. hwu8510 - MTC Bravo  
117. hwu8510 - S41HW  
118. hwu8510 - U8510  
119. hwu8520 - U8520  
120. hwu8600 - U8600  
121. hwu8650 - HUAWEI SONIC  
122. hwu8650 - HUAWEI\_IDEOS\_U8650  
123. hwu8650 - HuaweiU8650  
124. hwu8650 - Kyivstar Aqua  
125. hwu8650 - MTC 955  
126. hwu8650 - SONIC  
127. hwu8650 - Turkcell T20  
128. hwu8650 - U8650  
129. hwu8650 - U8650-1  
130. hwu8651 - Astro  
131. hwu8651 - Prism  
132. hwu8651 - U8651  
133. hwu8651 - U8651T  
134. hwu8652-51 - U8652-51  
135. hwu8655 - Etisalat  
136. hwu8655 - HUAWEI IDEOS Y 200  
137. hwu8655 - Personal U8655-51  
138. hwu8655 - STARTRAIL II  
139. hwu8655 - U8655  
140. hwu8655 - U8655-1  
141. hwu8655 - U8655-51  
142. hwu8660 - SONIC  
143. hwu8661 - HUAWEI U8661  
144. hwu8666 - MTC Fit  
145. hwu8666 - U8666-1  
146. hwu8666 - U8666-51  
147. hwu8666-51 - U8666-51  
148. hwu8666e - HUAWEI U8666E  
149. hwu8666e - MegaFon SP-A3  
150. hwu8666e-51 - HUAWEI U8666E  
151. hwu8666e-51 - HUAWEI U8666E-51  
152. hwu8666n - HUAWEI U8666N  
153. hwu8667 - U8667  
154. hwu8680 - T-Mobile myTouch  
155. hwu8681 - HUAWEI U8681  
156. hwu8730 - T-Mobile myTouch Q  
157. hwu8800 - IDEOS X5  
158. hwu8800 - MTC Neo  
159. hwu8800 - U8800  
160. hwu8800 - Ucell  
161. hwu8800 - u8800  
162. hwu8800Pro - HUAWEI\_IDEOS\_X5  
163. hwu8800Pro - HuaweiU8800Pro  
164. hwu8800Pro - IDEOS X5  
165. hwu8800Pro - MTC Neo  
166. hwu8800Pro - RBM\_HD  
167. hwu8800Pro - U8800 Pro  
168. hwu8800Pro - U8800Pro  
169. hwu8815 - HUAWEI Ascend G 300  
170. hwu8815 - HUAWEI U8815  
171. hwu8815 - HUAWEI\_Ascend G 300  
172. hwu8815 - Personal U8815-51  
173. hwu8815 - U8815  
174. hwu8815 - U8815-51  
175. hwu8815n - HUAWEI U8815N  
176. hwu8815n - U8815N  
177. hwu8816 - MTC Viva  
178. hwu8816 - U8816  
179. hwu8818 - HUAWEI U8818  
180. hwu8818 - U8818  
181. hwu8820 - U8820  
182. hwu8825-1 - Bs 401  
183. hwu8825-1 - HUAWEI Ascend G 330  
184. hwu8825-1 - HUAWEI U8825-1  
185. hwu8825D - HUAWEI U8825D  
186. hwu8850 - 007HW  
187. hwu8860 - GS02  
188. hwu8860 - HUAWEI\_U8860  
189. hwu8860 - TURKCELL MaxiPRO5  
190. hwu8860 - U8860  
191. hwu8860 - U8860-51  
192. hwu8867Z - U8867Z  
193. hwu8950-1 - HUAWEI U8950-1  
194. hwu8950-51 - HUAWEI U8950-51  
195. hwu8950D - HUAWEI U8950D  
196. hwu8950N-1 - HUAWEI U8950N-1  
197. hwu8950N-51 - HUAWEI U8950N-51  
198. hwu9200 - U9200  
199. hwu9200 - U9200E  
200. hwu9200-92 - GS03  
201. hwu9200-92 - U9200  
202. hwu9200E - U9200E  
203. hwu9201L - 201HW  
204. hwu9500 - U9500E  
205. hwu9501L - HW-01E

206. hwu9508 - HUAWEI U9508  
207. hwu9510 - HUAWEI U9510  
208. hwu9510 - U9510  
209. hwu9510e - HUAWEI U9510E  
210. hwu9700L - GL07S  
211. hwum840 - UM840  
212. hwy210-0010 - HUAWEI Y210-0010  
213. hwy210-0100 - HUAWEI Ascend Y 210  
214. hwy210-0100 - HUAWEI Y210-0100  
215. hwy210-0151 - HUAWEI Y210-0151  
216. hwy210-0200 - HUAWEI Ascend Y 210D  
217. hwy210-0200 - HUAWEI Asend Y 210D  
218. hwy210-0200 - HUAWEI Y210-0200  
219. hwy210-0200 - Leopard MF808  
220. hwy210-0200 - NATCOM N8302  
221. hwy210-0200 - VIETTEL V8404  
222. hwy210-0251 - HUAWEI Y210-0251  
223. hwy210-2010 - HUAWEI Y210-2010  
224. msm7201a - Pulse  
225. msm7201a - U8230  
226. msm7225 - Beeline\_E300  
227. msm7225 - Grameenphone Crystal  
228. msm7225 - HUAWEI IDEOS U8500  
229. msm7225 - HUAWEI IDEOS\_U8500  
230. msm7225 - Huawei  
231. msm7225 - HuaweiU8300  
232. msm7225 - Ideos  
233. msm7225 - MTC Evo  
234. msm7225 - Pulse Mini  
235. msm7225 - RBM C  
236. msm7225 - S31HW  
237. msm7225 - Smile  
238. msm7225 - Tactile internet  
239. msm7225 - Turkcell T10  
240. msm7225 - U8110  
241. msm7225 - U8300  
242. msm7225 - U8500  
243. msm7225 - Vodafone 845  
244. msm7227 - 004HW  
245. msm7230 - IDEOS X5  
246. msm7230 - u8800  
247. msm7625 - C8600  
248. msm7625 - HUAWEI-M860  
249. msm7625 - Ideos  
250. msm7625 - M860  
251. msm7625 - U8180  
252. orinoquiac8688V - ORINOQUIA C8688V  
253. qsd8k\_s7 - HUAWEI-S7  
254. qsd8k\_s7 - IDEOS S7  
255. qsd8k\_s7 - Ideos S7  
256. qsd8k\_s7 - Oysters SmaKit S7  
257. qsd8k\_s7 - S7  
258. qsd8k\_slim - IDEOS S7 Slim  
259. u8800 - u8800  
260. A199 - HUAWEI A199  
261. ATH-TL00 - ATH-TL00  
262. ATH-TL00H - ATH-TL00H  
263. ATH-UL00 - ATH-UL00  
264. Ascend D - U9500  
265. Ascend G510 - HUAWEI G510-0251  
266. Ascend G525 - HUAWEI Ascend G525  
267. Ascend G525 - HUAWEI G525-U00  
268. B199 - HUAWEI B199  
269. C199 - HUAWEI C199  
270. C199s - HUAWEI C199s  
271. C8812 - HUAWEI C8812  
272. C8813D - HUAWEI C8813D  
273. C8813DQ - HUAWEI C8813DQ  
274. C8815 - HUAWEI C8815  
275. C8816 - HUAWEI C8816  
276. C8816D - HUAWEI C8816D  
277. C8817D - C8817D  
278. C8817E - HUAWEI C8817E  
279. C8817L - HUAWEI C8817L  
280. C8818 - HUAWEI C8818  
281. C8826D - HUAWEI C8826D  
282. C8850 - HUAWEI-C8850  
283. CHC-U03 - CHC-U03  
284. CHC-U23 - CHC-U23  
285. CHM-CL00 - CHM-CL00  
286. CHM-U01 - CHM-U01  
287. CM990 - CM990  
288. CUN-AL00 - CUN-AL00  
289. CUN-TL00 - CUN-TL00  
290. Che1-CL10 - Che1-CL10  
291. Che1-CL20 - Che1-CL20  
292. Che1-L04 - Che1-L04  
293. Che2-L11 - Che2-L11  
294. Che2-L23 - Che2-L23  
295. Che2-TL00 - Che2-TL00  
296. Che2-TL00H - Che2-TL00H  
297. Che2-TL00M - Che2-TL00M  
298. Che2-UL00 - Che2-UL00  
299. Cherry Mini - CHC-U01  
300. China - M330  
301. Copper Plus - H1611  
302. Copper Plus - HUAWEI H1611  
303. D2 - HUAWEI D2-0082  
304. D2 - HUAWEI D2-2010  
305. D2 - HUAWEI D2-6070  
306. DAV - HUAWEI P8max  
307. ECO - HUAWEI LUA-L03  
308. ECO - HUAWEI LUA-L13  
309. ECO - HUAWEI LUA-L23  
310. ECO - HUAWEI LUA-U03  
311. ECO - HUAWEI LUA-U23  
312. ES8100 - ES8100  
313. ES8500 - HuaweiES8500  
314. FRD-L02 - FRD-L02  
315. Fusion 2 - Huawei-U8665  
316. G350 - HUAWEI G350  
317. G350 - HUAWEI G350-U00  
318. G350-U20 - HUAWEI G350-U20  
319. G506 - HUAWEI G506-U151  
320. G510 - HUAWEI G510-0010  
321. G510 - HUAWEI G510-0100  
322. G510 - HuaweiG510-0100  
323. G510 - HuaweiG510-0100-orange  
324. G510 - HUAWEI Ascend G510  
325. G510 - HUAWEI G510-0200  
326. G510 - Orange Daytona  
327. G520 - HUAWEI G520-5000  
328. G521-L076 - HUAWEI G521-L076  
329. G521-L176 - HUAWEI G521-L176

330. G526 - G526-L11  
331. G526 - G526-L22  
332. G526 - G526-L33  
333. G527 - G527-U081  
334. G535-L11 - HUAWEI G535-L11  
335. G535-L11 - Kestrel  
336. G535-L11 - Orange Gova  
337. G535-L11 - Speedsurfer  
338. G535-L11 - Ultym5  
339. G6 - HUAWEI G6-T00  
340. G6-C00 - HUAWEI G6-C00  
341. G6-L11 - HUAWEI G6-L11  
342. G6-L22 - HUAWEI G6-L22  
343. G6-L33 - HUAWEI G6-L33  
344. G6-U00 - HUAWEI G6-U00  
345. G6-U10 - HUAWEI G6-U10  
346. G6-U251 - HUAWEI G6-U251  
347. G6-U34 - HUAWEI G6-U34  
348. G606 - HUAWEI G606-T00  
349. G606-T00 - HUAWEI G606-T00  
350. G610 - HUAWEI G610-T00  
351. G610 - G610-U00  
352. G610 - HUAWEI G610-U00  
353. G610 - HUAWEI G610-U30  
354. G610-T01 - HUAWEI G610-T01  
355. G610-T11 - HUAWEI G610-T11  
356. G610-U15 - HUAWEI G610-U15  
357. G610-U20 - HUAWEI G610-U20  
358. G610C - HUAWEI G610-C00  
359. G615-U10 - G615-U10  
360. G615-U10 - HUAWEI G615-U10  
361. G616-L076 - HUAWEI G616-L076  
362. G620-A2 - HUAWEI G620-A2  
363. G620-L72 - HUAWEI G620-L72  
364. G620-L75 - G620-L75  
365. G620S-L01 - G620S-L01  
366. G620S-L02 - G620S-L02  
367. G620S-L03 - G620S-L03  
368. G620S-L03 - HUAWEI G620  
369. G620S-L03 - Personal Huawei G620S  
370. G620S-UL00 - G620S-UL00  
371. G621-TL00 - G621-TL00  
372. G621-TL00M - G621-TL00M  
373. G628-TL00 - HUAWEI G628-TL00  
374. G629-UL00 - HUAWEI G629-UL00  
375. G630 - HUAWEI G630-T00  
376. G630-U00 - HUAWEI G630-U00  
377. G630-U10 - G630-U10  
378. G630-U20 - G630-U20  
379. G630-U251 - G630-U251  
380. G630-U251 - HUAWEI G630-U251  
381. G660-L075 - HUAWEI G660-L075  
382. G7 Plus - HUAWEI RIO-TL00  
383. G7 Plus - HUAWEI RIO-UL00  
384. G7-L01 - G7-L01  
385. G7-L01 - HUAWEI G7-L01  
386. G7-L02 - HUAWEI G7-L02  
387. G7-L03 - G7-L03  
388. G7-L03 - HUAWEI G7  
389. G7-L03 - HUAWEI G7-L03  
390. G7-L11 - HUAWEI G7-L11  
391. G7-TL00 - G7-TL00  
392. G7-TL00 - HUAWEI G7-TL00  
393. G7-UL20 - HUAWEI G7-UL20  
394. G700 - HUAWEI G700-T00  
395. G700 - HUAWEI G700-U00  
396. G700-T01 - HUAWEI G700-T01  
397. G700-U10 - HUAWEI G700-U10  
398. G700-U20 - HUAWEI G700-U20  
399. G716 - HUAWEI G716-L070  
400. G718 - HUAWEI G718  
401. G730 - HUAWEI G730-C00  
402. G730 - HUAWEI G730-T00  
403. G730 - HUAWEI G730-U00  
404. G730-L075 - HUAWEI G730-L075  
405. G730-U10 - HUAWEI G730-U10  
406. G730-U251 - HUAWEI G730-U251  
407. G730-U27 - HUAWEI G730-U27  
408. G730-U30 - HUAWEI G730-U30  
409. G735-L03 - G735-L03  
410. G735-L12 - G735-L12  
411. G735-L23 - G735-L23  
412. G740 - G740-L00  
413. G740 - Orange Yumo  
414. G750-T00 - HUAWEI G750-T00  
415. G750-T01 - HUAWEI G750-T01  
416. G750-T01M - HUAWEI G750-T01M  
417. G750-T20 - HUAWEI G750-T20  
418. G750-U10 - HUAWEI G750-U10  
419. G7500 - HUAWEI G7500  
420. G8 - HUAWEI RIO-L02  
421. G8 - HUAWEI RIO-L03  
422. G8 - RIO-L03  
423. G8 - HUAWEI RIO-L02  
424. G8 - HUAWEI RIO-L03  
425. G9 Plus - HUAWEI MLA-TL00  
426. G9 Plus - HUAWEI MLA-TL10  
427. G9 Plus - HUAWEI MLA-UL00  
428. G9 Plus - MLA-TL00  
429. G9 Plus - MLA-UL00  
430. G9 - HUAWEI VNS-AL00  
431. GR3 - HUAWEI TAG-L01  
432. GR3 - HUAWEI TAG-L03  
433. GR3 - HUAWEI TAG-L13  
434. GR3 - HUAWEI TAG-L21  
435. GR3 - HUAWEI TAG-L22  
436. GR3 - HUAWEI TAG-L23  
437. GR3 2017 - DIG-L01  
438. GR3 2017 - DIG-L21  
439. GR3 2017 - DIG-L22  
440. GR3 Smart touch - HUAWEI TAG-L32  
441. GR5 - HUAWEI KII-L03  
442. GR5 - HUAWEI KII-L05  
443. GR5 - HUAWEI KII-L21  
444. GR5 - HUAWEI KII-L22  
445. GR5 - HUAWEI KII-L23  
446. GR5 - HUAWEI KII-L33  
447. GR5 - KII-L21  
448. GR5W - H1621  
449. GT3 - HUAWEI NMO-L21  
450. GT3 - HUAWEI NMO-L22  
451. GT3 - HUAWEI NMO-L23  
452. GT3 - HUAWEI NMO-L31  
453. GX8 - HUAWEI



454. GX8 - HUAWEI RIO-L01  
455. Gran\_Roraima - Orinoquia Gran Roraima + S7-722u  
456. H30-C00 - H30-C00  
457. H30-L01 - HONOR H30-L01  
458. H30-L01M - HONOR H30-L01M  
459. H30-L02 - H30-L02  
460. H30-L02 - HONOR H30-L02  
461. H30-T00 - H30-T00  
462. H60 - H60-L01  
463. H60-J1 - HW-H60-J1  
464. H60-L01 - H60-L01  
465. H60-L02 - H60-L02  
466. H60-L03 - H60-L03  
467. H60-L04 - H60-L04  
468. H60-L11 - H60-L11  
469. H60-L12 - H60-L12  
470. H60-L21 - H60-L21  
471. H60-L21 - H60-L21  
472. H871G - HUAWEI H871G  
473. H882L - H882L  
474. H891L - HUAWEI H891L  
475. H892L - HUAWEI H892L  
476. HONOR 4X - Che2-L12  
477. HUAWEI GR5 2017 - BLL-L21  
478. HUAWEI GR5 2017 - BLL-L22  
479. HUAWEI GR5 2017 - HUAWEI BLL-L21  
480. HUAWEI GR5 2017 - HUAWEI BLL-L22  
481. HUAWEI Mate 9 lite - BLL-L23  
482. HUAWEI Mate 9 lite - HUAWEI BLL-L23  
483. HUAWEI Y3 2017 - CRO-L02  
484. HUAWEI Y3 2017 - CRO-L22  
485. HUAWEI Y3 2017 - HUAWEI CRO-L02  
486. HUAWEI Y3 2017 - HUAWEI CRO-L22  
487. HUAWEI Y5 lite 2017 - CRO-L03  
488. HUAWEI Y5 lite 2017 - CRO-L23  
489. HUAWEI Y5 lite 2017 - HUAWEI CRO-L03  
490. HUAWEI Y5 lite 2017 - HUAWEI CRO-L23  
491. HUAWEI Y6 2017 - MYA-L11  
492. HUAWEI Y6II - HUAWEI CAM-L53  
493. HUAWEI nova 2 Plus - BAC-L21  
494. HUAWEI nova 2 Plus - BAC-L22  
495. HW-03E - HW-03E  
496. HWT31 - HWT31  
497. Hol-T00 - Hol-T00  
498. Hol-U10 - Hol-U10  
499. Hol-U19 - Hol-U19  
500. Honor 4A - SCC-U21  
501. Honor 4A - SCL-AL00  
502. Honor 4A - SCL-CL00  
503. Honor 4A - SCL-TL00  
504. Honor 4A - SCL-TL00H  
505. Honor 5A - HUAWEI LYO-L21  
506. Honor 5A - LYO-L21  
507. Honor 5C - NEM-L21  
508. Honor 5C - NEM-L22  
509. Honor 5C - NEM-L51  
510. Honor 5X - KIW-L21  
511. Honor 5X - KIW-TL00H  
512. Honor 6A - DLI-L22  
513. Honor 6A - DLI-TL20  
514. Honor 6X - BLN-L24  
515. Honor 7 - PLK-AL10  
516. Honor 7 - PLK-CL00  
517. Honor 7 - PLK-L01  
518. Honor 7 - PLK-TL00  
519. Honor 7 - PLK-TL01H  
520. Honor 7 - PLK-UL00  
521. Honor 7i - ATH-AL00  
522. Honor 7i - ATH-CL00  
523. Honor 8 - FRD-AL00  
524. Honor 8 - FRD-AL10  
525. Honor 8 - FRD-DL00  
526. Honor 8 - FRD-L04  
527. Honor 8 - FRD-L09  
528. Honor 8 - FRD-L14  
529. Honor 8 - FRD-L19  
530. Honor 8 - FRD-TL00  
531. Honor 8 Pro - DUK-L09  
532. Honor 8 Smart - VEN-L22  
533. Honor 9 - STF-AL00  
534. Honor 9 - STF-AL10  
535. Honor 9 - STF-L09  
536. Honor 9 - STF-TL10  
537. Honor Box - M321  
538. Honor Box Pro - HiTV-M1  
539. Honor Box voice - M311  
540. Honor Magic - HUAWEI NTS-AL00  
541. Honor Magic - NTS-AL00  
542. Honor V8 - KNT-AL10  
543. Honor V8 - KNT-AL20  
544. Honor V8 - KNT-TL10  
545. Honor V8 - KNT-UL10  
546. Honor V9 - DUK-AL20  
547. Honor V9 - DUK-TL30  
548. Honor3 - H30-T10  
549. Honor3 - H30-U10  
550. Honor3 - HUAWEI HN3-U00  
551. Honor3 - HUAWEI HN3-U01  
552. Huawei Nova 2 - PIC-LX9  
553. IDEOS - Comet  
554. IDEOS - Ideos  
555. IDEOS - Ideos  
556. Ice-Twist - Ice-Twist  
557. Ideos X5 - Huawei U8800-51  
558. Ideos X5 - IDEOS X5  
559. Ideos X5 - U8800  
560. Ideos X5 - U8800-51  
561. Kiwi-2 - H1622  
562. LISZT - HUAWEI M2-A01L  
563. LISZT - HUAWEI M2-A01W  
564. M2 - HUAWEI M2-801L  
565. M2 - HUAWEI M2-801W  
566. M2 - HUAWEI M2-802L  
567. M2 - HUAWEI M2-803L  
568. M220 - M220  
569. M220 - M220c  
570. M220 - dTV01  
571. M3 - BTV-DL09  
572. M3 - BTV-W09  
573. M310 - M310  
574. M620 - M620  
575. M620 - TB01  
576. M835 - HUAWEI-M835  
577. M860 - M860

578. M865 - M865  
579. M865 - USCCADR3305  
580. M868 - HUAWEI M868  
581. MAIMANG 6 - RNE-AL00  
582. MS4C - MS4C  
583. MT1 - HUAWEI MT1-U06  
584. MT2-L01 - HUAWEI MT2-L01  
585. MT2-L02 - HUAWEI MT2-L02  
586. MT2-L03 - MT2L03  
587. MT2-L05 - HUAWEI MT2-L05  
588. MT2L03LITE - MT2L03  
589. Mate - HUAWEI MT1-T00  
590. Mate 10 - ALP-AL00  
591. Mate 10 - ALP-L09  
592. Mate 10 - ALP-L29  
593. Mate 10 - ALP-TL00  
594. Mate 10 Pro - BLA-AL00  
595. Mate 10 Pro - BLA-L09  
596. Mate 10 Pro - BLA-L29  
597. Mate 10 Pro - BLA-TL00  
598. Mate 10 lite - RNE-L01  
599. Mate 10 lite - RNE-L03  
600. Mate 10 lite - RNE-L21  
601. Mate 10 lite - RNE-L23  
602. Mate 7 - HUAWEI MT7-CL00  
603. Mate 7 - HUAWEI MT7-J1  
604. Mate 7 - HUAWEI MT7-L09  
605. Mate 7 - HUAWEI MT7-TL00  
606. Mate 7 - HUAWEI MT7-TL10  
607. Mate 7 - HUAWEI MT7-UL00  
608. Mate 8 - HUAWEI NXT-AL10  
609. Mate 8 - HUAWEI NXT-CL00  
610. Mate 8 - HUAWEI NXT-DL00  
611. Mate 8 - HUAWEI NXT-L09  
612. Mate 8 - HUAWEI NXT-L29  
613. Mate 8 - HUAWEI NXT-TL00  
614. Mate 8 - HUAWEI NXT-TL00B  
615. Mate 8 - NXT-AL10  
616. Mate 8 - NXT-CL00  
617. Mate 8 - NXT-DL00  
618. Mate 8 - NXT-L09  
619. Mate 8 - NXT-L29  
620. Mate 8 - NXT-TL00  
621. Mate 9 - MHA-AL00  
622. Mate 9 - MHA-L09  
623. Mate 9 - MHA-L29  
624. Mate 9 - MHA-TL00  
625. Mate 9 Pro - LON-AL00  
626. Mate 9 Pro - LON-L29  
627. Mate S - HUAWEI CRR-CL00  
628. Mate S - HUAWEI CRR-CL20  
629. Mate S - HUAWEI CRR-L09  
630. Mate S - HUAWEI CRR-TL00  
631. Mate S - HUAWEI CRR-UL00  
632. Mate S - HUAWEI CRR-UL20  
633. Mate2 - HUAWEI MT2-C00  
634. MediaPad - HUAWEI MediaPad T1 7.0 3G  
635. MediaPad - T1 7.0  
636. MediaPad - T1-701u  
637. MediaPad - T1-701ua  
638. MediaPad - T1-701us  
639. MediaPad - T1-701w  
640. MediaPad - Telpad QS  
641. MediaPad 10 FHD - MediaPad 10 FHD  
642. MediaPad 10 Link - MediaPad 10 LINK  
643. MediaPad 10 Link - dtab 01  
644. MediaPad 10 Link+ - 402HW  
645. MediaPad 10 Link+ - MediaPad 10 Link+  
646. MediaPad 10 Link+ - S10-232L  
647. MediaPad 10 Link+ - SpeedTAB  
648. MediaPad 7 Lite - MediaPad 7 Lite  
649. MediaPad 7 Lite Quad - Telpad QS  
650. MediaPad 7 Lite Quad - Telpad Quad S  
651. MediaPad 7 Vogue - MediaPad 7 Vogue  
652. MediaPad 7 Youth2 - MediaPad 7 Youth 2  
653. MediaPad 7 Youth2 - S7-721u  
654. MediaPad M1 8.0 - 403HW  
655. MediaPad M1 8.0 - CNPC Security Pad S1  
656. MediaPad M1 8.0 - HUAWEI MediaPad M1 8.0  
657. MediaPad M1 8.0 - MediaPad M1 8.0  
658. MediaPad M1 8.0 - MediaPad M1 8.0 (LTE)  
659. MediaPad M1 8.0 - MediaPad M1 8.0 (WIFI)  
660. MediaPad M1 8.0 - S8-303L  
661. MediaPad M1 8.0 - S8-303LT  
662. MediaPad M1 8.0 - S8-306L  
663. MediaPad T2 10.0 Pro - 605HW  
664. MediaPad T2 10.0 Pro - 606HW  
665. MediaPad T2 10.0 Pro - FDR-A05L  
666. MediaPad T2 10.0 pro - FDR-A01L  
667. MediaPad T2 10.0 pro - FDR-A01w  
668. MediaPad T2 10.0 pro - FDR-A03L  
669. MediaPad T2 7.0 - BGO-DL09  
670. MediaPad T2 7.0 - BGO-L03  
671. MediaPad T2 8.0 Pro - JDN-AL00  
672. MediaPad T2 8.0 Pro - JDN-L01  
673. MediaPad T2 8.0 Pro - JDN-W09  
674. MediaPad Vogue - MediaPad 7 Lite II  
675. MediaPad Vogue - MediaPad 7 Vogue  
676. MediaPad X1 7.0 - 7D-501u  
677. MediaPad X1 7.0 - MediaPad X1  
678. MediaPad X1 7.0 - MediaPad X1 7.0  
679. MediaPad X1 7.0 - X1 7.0  
680. MediaPad Youth - MediaPad 7 Youth  
681. MediaPad7 - MediaPad 7 Vogue  
682. Nexus 6P - Nexus 6P  
683. P10 - VTR-AL00  
684. P10 - VTR-L09  
685. P10 - VTR-L29  
686. P10 - VTR-TL00  
687. P10 Plus - VKY-AL00  
688. P10 Plus - VKY-L09  
689. P10 Plus - VKY-L29  
690. P10 Plus - VKY-TL00  
691. P10 lite - WAS-L03T  
692. P10 lite - WAS-LX1  
693. P10 lite - WAS-LX1A  
694. P10 lite - WAS-LX2  
695. P10 lite - WAS-LX2J  
696. P10 lite - WAS-LX3  
697. P2 - HUAWEI P2-6070  
698. P6 - HUAWEI P6-C00  
699. P6 - HUAWEI P6-T00  
700. P6 - HUAWEI P6-T00V  
701. P6 - HUAWEI Ascend P6



702. P6 - HUAWEI P6-U06  
703. P6 - HUAWEI P6-U06-orange  
704. P6S - P6 S-L04  
705. P6S-L04 - 302HW  
706. P6S-U06 - HUAWEI P6 S-U06  
707. P7 - HUAWEI P7-L00  
708. P7 - HUAWEI P7-L05  
709. P7 - HUAWEI P7-L07  
710. P7 - HUAWEI P7-L10  
711. P7 - HUAWEI P7-L11  
712. P7 - HUAWEI P7-L12  
713. P7 mini - HUAWEI P7 mini  
714. P7-L09 - HUAWEI P7-L09  
715. P8 - HUAWEI GRA-CL00  
716. P8 - HUAWEI GRA-CL10  
717. P8 - HUAWEI GRA-L09  
718. P8 - HUAWEI GRA-TL00  
719. P8 - HUAWEI GRA-UL00  
720. P8 - HUAWEI GRA-UL10  
721. P8 Lite - 503HW  
722. P8 Lite - ALE-L02  
723. P8 Lite - ALE-L21  
724. P8 Lite - ALE-L23  
725. P8 Lite - Autana LTE  
726. P8 Lite - HUAWEI ALE-CL00  
727. P8 Lite - HUAWEI ALE-L04  
728. P8 lite 2017 - PRA-LA1  
729. P8 lite 2017 - PRA-LX1  
730. P8 - ALE-TL00  
731. P8 - ALE-UL00  
732. P8max - HUAWEI P8max  
733. P9 - EVA-AL00  
734. P9 - EVA-AL10  
735. P9 - EVA-CL00  
736. P9 - EVA-DL00  
737. P9 - EVA-L09  
738. P9 - EVA-L19  
739. P9 - EVA-L29  
740. P9 - EVA-TL00  
741. P9 Plus - VIE-AL10  
742. P9 Plus - VIE-L09  
743. P9 Plus - VIE-L29  
744. PE-CL00 - PE-CL00  
745. PE-TL00M - PE-TL00M  
746. PE-TL10 - PE-TL10  
747. PE-TL20 - PE-TL20  
748. PE-UL00 - PE-UL00  
749. Prism II - Prism II  
750. Q22 - Q22  
751. RIO-CL00 - HUAWEI RIO-CL00  
752. S10 - MediaPad 10 FHD  
753. S10 - MediaPad 10 LINK  
754. S7 - MediaPad 7 Vogue  
755. S7 - MediaPad 7 Vogue  
756. S7 - MediaPad 7 Youth  
757. S7 - Orinoquia Roraima S7-932u  
758. S7 - MediaPad 7 Lite+  
759. S7 - Telpad Dual S  
760. SC-CL00 - HUAWEI SC-CL00  
761. SC-UL10 - HUAWEI SC-UL10  
762. Sensa LTE - H710VL  
763. Sensa LTE - H715BL  
764. ShotX - HUAWEI ATH-UL01  
765. ShotX - HUAWEI ATH-UL06  
766. T-Mobile Pulse - Huawei\_8100-9  
767. T-Mobile Pulse - Tactile internet  
768. T-Mobile Pulse - U8100  
769. T-Mobile Pulse - Videocon\_V7400  
770. T1 - T1-821L  
771. T1 - T1-821W  
772. T1 - T1-821w  
773. T1 - T1-823L  
774. T1 - T1-823L  
775. T1 10 - HUAWEI MediaPad T1 10 4G  
776. T1 10 - T1-A21L  
777. T1 10 - T1-A21W  
778. T1 10 - T1-A21w  
779. T1 10 - T1-A22L  
780. T1 10 - T1-A23L  
781. T101 - T-101  
782. T101 - T101 PAD  
783. T102 - QH-10  
784. T102 - T102 PAD  
785. T801 - T801 PAD  
786. T802 - MT-803G  
787. T802 - T802 PAD  
788. T8808D - HUAWEI T8808D  
789. TANGO - HUAWEI TAG-AL00  
790. TANGO - HUAWEI TAG-CL00  
791. TANGO - HUAWEI TAG-TL00  
792. U8120 - Vodafone 845  
793. U8220 - Pulse  
794. U8220 - U8220  
795. U8220 - U8220PLUS  
796. U8230 - U8230  
797. U8652 - Huawei-U8652  
798. U8652 - U8652  
799. U8687 - Huawei-U8687  
800. U8812D - U8812D  
801. U8832D - U8832D  
802. U8836D - U8836D  
803. U8850 - HUAWEI-U8850  
804. U9000 - HUAWEI-U9000  
805. UNION - Y538  
806. V858 - Huawei 858  
807. V858 - MTC 950  
808. V858 - MTC Mini  
809. V858 - Vodafone 858  
810. Vogue7 - MediaPad 7 Classic  
811. Vogue7 - MediaPad 7 Lite II  
812. Vogue7 - MediaPad 7 Vogue  
813. WATCH - HUAWEI WATCH  
814. WATCH - HUAWEI-WATCH  
815. Watch 2 - LEO-BX9  
816. Watch 2 - LEO-DLXX  
817. X2 - GEM-701L  
818. X2 - GEM-702L  
819. X2 - GEM-703L  
820. X2 - GEM-703LT  
821. Y210 - Orinoquia Auyantepui Y210  
822. Y220 - Y220-U00  
823. Y220 - Y220-U05  
824. Y220 - Y220-U17  
825. Y220-T10 - HUAWEI Y220-T10

826. Y220-U10 - Y220-U10  
827. Y220T - HUAWEI Y 220T  
828. Y221-U03 - HUAWEI Y221-U03  
829. Y221-U03 - ORINOQUIA Auyantepui+Y221-U03  
830. Y221-U12 - HUAWEI Y221-U12  
831. Y221-U22 - HUAWEI Y221-U22  
832. Y221-U33 - HUAWEI Y221-U33  
833. Y221-U43 - HUAWEI Y221-U43  
834. Y221-U53 - HUAWEI Y221-U53  
835. Y300 - HUAWEI Ascend Y300  
836. Y300 - HUAWEI Y300-0100  
837. Y300 - HUAWEI Y300-0151  
838. Y300 - Pelephone-Y300-  
839. Y300-0000 - HUAWEI Y300-0000  
840. Y301A1 - Huawei Y301A1  
841. Y301A2 - Huawei Y301A2  
842. Y310-5000 - HUAWEI Y310-5000  
843. Y310-T10 - HUAWEI Y310-T10  
844. Y320 - HUAWEI Y320-C00  
845. Y320-T00 - HUAWEI Y320-T00  
846. Y320-U01 - HUAWEI Y320-U01  
847. Y320-U01 - Y320-U01  
848. Y320-U10 - HUAWEI Y320-U10  
849. Y320-U151 - HUAWEI Y320-U151  
850. Y320-U30 - HUAWEI Y320-U30  
851. Y320-U351 - HUAWEI Y320-U351  
852. Y321 - HUAWEI Y321-U051  
853. Y321 - HUAWEI Y321-C00  
854. Y325-T00 - HUAWEI Y325-T00  
855. Y330 - Bucare Y330-U05  
856. Y330 - HUAWEI Y330-U05  
857. Y330 - HUAWEI Y330-U21  
858. Y330-C00 - HUAWEI Y330-C00  
859. Y330-U01 - HUAWEI Y330-U01  
860. Y330-U01 - Luno  
861. Y330-U07 - HUAWEI Y330-U07  
862. Y330-U08 - HUAWEI Y330-U08  
863. Y330-U11 - HUAWEI Y330-U11  
864. Y330-U11 - V8510  
865. Y330-U15 - HUAWEI Y330-U15  
866. Y330-U17 - HUAWEI Y330-U17  
867. Y336-A1 - HUAWEI Y336-A1  
868. Y336-U02 - HUAWEI Y336-U02  
869. Y336-U12 - HUAWEI Y336-U12  
870. Y340-U081 - Y340-U081  
871. Y360-U03 - HUAWEI Y360-U03  
872. Y360-U103 - HUAWEI Y360-U103  
873. Y360-U12 - HUAWEI Y360-U12  
874. Y360-U23 - HUAWEI Y360-U23  
875. Y360-U31 - HUAWEI Y360-U31  
876. Y360-U42 - HUAWEI Y360-U42  
877. Y360-U61 - HUAWEI Y360-U61  
878. Y360-U72 - HUAWEI Y360-U72  
879. Y360-U82 - HUAWEI Y360-U82  
880. Y360-U93 - Delta Y360-U93  
881. Y360-U93 - HUAWEI Y360-U93  
882. Y3II - HUAWEI LUA-L01  
883. Y3II - HUAWEI LUA-L02  
884. Y3II - HUAWEI LUA-L21  
885. Y3II - HUAWEI LUA-U02  
886. Y3II - HUAWEI LUA-U22  
887. Y3III - CRO-U00

888. Y3III - CRO-U23  
889. Y3III - HUAWEI CRO-U00  
890. Y3III - HUAWEI CRO-U23  
891. Y5 - HUAWEI Y560-L02  
892. Y5 - HUAWEI Y560-L23  
893. Y5 - HUAWEI Y560-U03  
894. Y5 2017 - MYA-AL00  
895. Y5 2017 - MYA-L02  
896. Y5 2017 - MYA-L03  
897. Y5 2017 - MYA-L13  
898. Y5 2017 - MYA-L22  
899. Y5 2017 - MYA-L23  
900. Y5 2017 - MYA-TL00  
901. Y5 2017 - MYA-U29  
902. Y500-T00 - HUAWEI Y500-T00  
903. Y511-T00 - HUAWEI Y511-T00  
904. Y511-T00 - Y511-T00  
905. Y511-U00 - Y511-U00  
906. Y511-U10 - HUAWEI Y511-U10  
907. Y511-U251 - HUAWEI Y511-U251  
908. Y511-U30 - HUAWEI Y511-U30  
909. Y511-U30 - VIETTEL V8506  
910. Y516- - HUAWEI Y516-T00  
911. Y518-T00 - HUAWEI Y518-T00  
912. Y520-U03 - HUAWEI Y520-U03  
913. Y520-U12 - HUAWEI Y520-U12  
914. Y520-U22 - HUAWEI Y520-U22  
915. Y520-U33 - HUAWEI Y520-U33  
916. Y523-L076 - HUAWEI Y523-L076  
917. Y523-L176 - HUAWEI Y523-L176  
918. Y530 - HUAWEI Y530-U00  
919. Y530-U051 - HUAWEI Y530  
920. Y530-U051 - HUAWEI Y530-U051  
921. Y535 - HUAWEI Y535-C00  
922. Y535D-C00 - HUAWEI Y535D-C00  
923. Y536-A1 - HUAWEI Y536A1  
924. Y540-U01 - HUAWEI Y540-U01  
925. Y541-U02 - HUAWEI Y541-U02  
926. Y541-U02 - Y541-U02  
927. Y550-L01 - HUAWEI Y550-L01  
928. Y550-L02 - HUAWEI Y550-L02  
929. Y550-L02 - Y550-L02  
930. Y550-L03 - HUAWEI Y550  
931. Y550-L03 - HUAWEI Y550-L03  
932. Y550-L03 - Personal Huawei Y550  
933. Y550-L03 - Y550-L03  
934. Y560-CL00 - HUAWEI Y560-CL00  
935. Y560-L01 - HUAWEI Y560-L01  
936. Y560-L03 - HUAWEI Y560-L03  
937. Y560-U02 - HUAWEI Y560-U02  
938. Y560-U12 - HUAWEI Y560-U12  
939. Y560-U23 - HUAWEI Y560-U23  
940. Y5II - CUN-L22  
941. Y5II - HUAWEI CUN-L01  
942. Y5II - HUAWEI CUN-L02  
943. Y5II - HUAWEI CUN-L03  
944. Y5II - HUAWEI CUN-L21  
945. Y5II - HUAWEI CUN-L22  
946. Y5II - HUAWEI CUN-L23  
947. Y5II - HUAWEI CUN-L33  
948. Y5II - HUAWEI CUN-U29  
949. Y6 - HUAWEI SCC-U21

950. Y6 - SCC-U21  
951. Y6 - HUAWEI SCL-L01  
952. Y6 - HUAWEI SCL-L02  
953. Y6 - HUAWEI SCL-L03  
954. Y6 - HUAWEI SCL-L04  
955. Y6 - HUAWEI SCL-L21  
956. Y6 - HW-SCL-L32  
957. Y6 - SCL-L01  
958. Y6 - HUAWEI SCL-U23  
959. Y6 - HUAWEI SCL-U31  
960. Y6 - SCL-U23  
961. Y6 2017 - MYA-L41  
962. Y6 Elite - HUAWEI LYO-L02  
963. Y6 Pro - HUAWEI TIT-AL00  
964. Y6 Pro - HUAWEI TIT-AL00  
965. Y6 Pro - HUAWEI TIT-CL10  
966. Y6 Pro - HUAWEI TIT-L01  
967. Y6 Pro - HUAWEI TIT-TL00  
968. Y6 Pro - TIT-AL00  
969. Y6 Pro - TIT-L01  
970. Y6 Pro - HUAWEI TIT-CL00  
971. Y6 Pro - HUAWEI TIT-U02  
972. Y6 Compact - HUAWEI LYO-L01  
973. Y600 - HUAWEI Y600-U00  
974. Y600 - HUAWEI Y600-U151  
975. Y600 - HUAWEI Y600-U20  
976. Y600-U351 - HUAWEI Y600-U351  
977. Y600-U40 - HUAWEI Y600-U40  
978. Y600D-C00 - HUAWEI Y600D-C00  
979. Y610 - HUAWEI Y610-U00  
980. Y618 - HUAWEI Y618-T00  
981. Y625-U03 - Kavak Y625-U03  
982. Y625-U13 - HUAWEI Y625-U13  
983. Y625-U21 - HUAWEI Y625-U21  
984. Y625-U32 - HUAWEI Y625-U32  
985. Y625-U43 - HUAWEI Y625-U43  
986. Y625-U51 - HUAWEI Y625-U51  
987. Y635-CL00 - HUAWEI Y635-CL00  
988. Y635-L01 - Y635-L01  
989. Y635-L02 - HUAWEI Y635-L02  
990. Y635-L02 - Y635-L02  
991. Y635-L03 - HUAWEI Y635-L03  
992. Y635-L03 - Y635-L03  
993. Y635-L21 - Y635-L21  
994. Y635-TL00 - HUAWEI Y635-TL00  
995. Y635-TL00 - Y635-TL00  
996. Y6II - CAM-L03  
997. Y6II - CAM-L21  
998. Y6II - CAM-L23  
999. Y6II - CAM-U22  
1000. Y6II - HUAWEI CAM-L03  
1001. Y6II - HUAWEI CAM-L21  
1002. Y6II - HUAWEI CAM-L23  
1003. Y6II - HUAWEI CAM-U22  
1004. Y6II - CAM-L32  
1005. Y6Compact - HUAWEI LYO-L03  
1006. Y7 - TRT-L21A  
1007. Y7 - TRT-L53  
1008. Y7 - TRT-LX1  
1009. Y7 - TRT-LX2  
1010. Y7 - TRT-LX3  
1011. Youth - Orinoquia Gran Roraima S7-702u  
1012. ascend-5w - H1623  
1013. d-01G - d-01G  
1014. d-01H - d-01H  
1015. d-02H - d-02H  
1016. eH811 - eH811  
1017. honor 5X - KIW-L22  
1018. honor 5X - KIW-L23  
1019. honor 5X - KIW-L24  
1020. honor 6A Pro - DLI-L42  
1021. honor 6C - DIG-L21HN  
1022. honor 6C Pro - JMM-L22  
1023. honor 6x - BLN-L21  
1024. honor 6x - BLN-L22  
1025. hw204HW - 204HW  
1026. m881 - HUAWEI M881  
1027. nova - HUAWEI CAN-L01  
1028. nova - HUAWEI CAN-L02  
1029. nova - HUAWEI CAN-L03  
1030. nova - HUAWEI CAN-L11  
1031. nova - HUAWEI CAN-L12  
1032. nova - HUAWEI CAN-L13  
1033. nova - HUAWEI CAZ-AL10  
1034. nova - HUAWEI CAZ-AL00  
1035. nova - HUAWEI CAZ-AL10  
1036. nova - HUAWEI CAZ-TL10  
1037. nova - HUAWEI CAZ-TL20  
1038. nova 2 - PIC-AL00  
1039. nova 2 - PIC-TL00  
1040. nova 2 Plus - BAC-AL00  
1041. nova 2 Plus - BAC-L01  
1042. nova 2 Plus - BAC-L03  
1043. nova 2 Plus - BAC-L23  
1044. nova 2 Plus - BAC-TL00  
1045. nova 2i - RNE-L02  
1046. nova 2i - RNE-L22  
1047. nova lite - PRA-LX2  
1048. nova lite - PRA-LX3  
1049. nova plus - HUAWEI MLA-L01  
1050. nova plus - HUAWEI MLA-L02  
1051. nova plus - HUAWEI MLA-L03  
1052. nova plus - HUAWEI MLA-L11  
1053. nova plus - HUAWEI MLA-L12  
1054. nova plus - HUAWEI MLA-L13  
1055. nova plus - MLA-L01  
1056. nova plus - MLA-L02  
1057. nova plus - MLA-L03  
1058. nova plus - MLA-L11  
1059. nova plus - MLA-L12  
1060. nova plus - MLA-L13  
1061. nova - WAS-AL00  
1062. nova - WAS-TL10  
1063. t1\_8p0 - MediaPad T1 8.0  
1064. t1\_8p0 - S8-701u  
1065. t1\_8p0 - S8-701w  
1066. t1\_8p0lte - HUAWEI MediaPad T1 8.0 4G  
1067. t1\_8p0lte - Honor T1 8.0  
1068. t1\_8p0lte - MediaPad T1 8.0 Pro  
1069. t1\_8p0lte - S8-821w  
1070. t1\_8p0lte - T1-821w  
1071. t1\_8p0lte - T1-823L  
1072. G9 - HUAWEI VNS-DL00  
1073. G9 - HUAWEI VNS-TL00

1074. M3 (8 - 701HW  
1075. M3 (8 - 702HW  
1076. M3 (8 - CPN-AL00  
1077. M3 (8 - CPN-L09  
1078. M3 (8 - CPN-W09  
1079. M27.0 - PLE-701L  
1080. M27.0 - PLE-703L  
1081. 6 - NCE-AL00  
1082. 6 - NCE-AL10  
1083. 6 - NCE-TL10  
1084. 6S - DIG-AL00  
1085. 6S - DIG-TL10  
1086. 7 - SLA-AL00  
1087. 7 - SLA-TL10  
1088. V9 play - JMM-AL00  
1089. V9 play - JMM-AL10  
1090. V9 play - JMM-TL00  
1091. V9 play - JMM-TL10  
1092. 4A - SCL-AL00  
1093. 5X - KIW-AL10  
1094. 5X - KIW-AL20  
1095. 5X - KIW-CL00  
1096. 5X - KIW-TL00  
1097. 5X - KIW-UL00  
1098. 8 - PRA-AL00  
1099. 8 - PRA-AL00X  
1100. 8 - PRA-TL10  
1101. Note8 - EDI-AL10  
1102. Note8 - EDI-DL00  
1103. 7 Plus - TRT-AL00  
1104. 7 Plus - TRT-AL00A  
1105. 7 Plus - TRT-TL10  
1106. 7 Plus - TRT-TL10A  
1107. 6X - BLN-AL10  
1108. 6X - BLN-AL20  
1109. 6X - BLN-AL30  
1110. 6X - BLN-AL40  
1111. 6X - BLN-TL00  
1112. 6X - BLN-TL10  
1113. 4C - CHM-TL00  
1114. 4C - CHM-TL00H  
1115. 4C - CHM-UL00  
1116. 4X - CHE-TL00  
1117. 4X - CHE-TL00H  
1118. 5A - CAM-TL00  
1119. 5A - CAM-TL00H  
1120. 5A - CAM-UL00  
1121. 5A - CAM-AL00  
1122. 5A - CAM-CL00  
1123. 5A - CAM-TL00  
1124. 5A - CAM-TL00H  
1125. 5A - CAM-UL00  
1126. 5A - CAM-AL00  
1127. 5C - NEM-AL10  
1128. 5C - NEM-TL00  
1129. 5C - NEM-TL00H  
1130. 5C - NEM-UL10  
1131. 6 - MYA-AL10  
1132. 6 - MYA-TL10  
1133. 6A - DLI-AL10  
1134. 7X - BND-AL10  
1135. 7X - BND-TL10

1136. 2 9.6 - AGS-L03  
1137. 2 9.6 - AGS-L09  
1138. 2 9.6 - AGS-W09  
1139. 4 - HUAWEI RIO-AL00  
1140. 5 - HUAWEI MLA-AL00  
1141. 5 - HUAWEI MLA-AL10  
1142. 5 - MLA-AL00  
1143. 5 - MLA-AL10

## Hurricane

1. Ace - Ace
2. Air - Air
3. Archer - Archer
4. Atlas - Atlas
5. Beam - Beam
6. Blast - Blast
7. Blaze - Blaze
8. Bolt - Hurricane\_Bolt
9. Charge - Charge
10. Epic - Epic
11. Fire - Fire
12. Flame - Flame
13. Flex - Flex
14. Flint - Flint
15. Fuse - Fuse
16. Galaxy - Galaxy
17. Giga - HURRICANE\_GIGA
18. Ridge - Ridge
19. Rush - Rush
20. SWIRL - Swirl
21. Sprint - Sprint
22. Surge - Surge
23. Vega - Vega
24. Vegas - Vegas
25. Vibe - VIBE
26. Volt - Volt
27. Vortex - HURRICANE\_VORTEX
28. Vulcan - Vulcan
29. Wave - Wave

## Hyundai

1. A25563L - A25563L
2. A26062L - A26062L
3. A26062k - A26062K
4. CAR AVN SYSTEM - TCC893X\_EVM
5. Eternity A24 - A25024L
6. Eternity G22 - G25022K
7. Eternity G23 - G25523K
8. Eternity G24 - G25524K
9. Eternity G27 - G24027K
10. Eternity W42 - W25042L
11. Eternity W44 - W25544L
12. HT0702W08 - HT0702W08
13. HY1-5085 - HY1-5085
14. Hyundai Koral 10W - HT1002W16
15. Hyundai Koral 10X - HT1003X16
16. Hyundai Koral 7M3X - HT0703K16
17. L575 - L575
18. Ultra Active - Ultra Active
19. Ultra Charm - Ultra Charm
20. Ultra Dream - Ultra Dream



21. Ultra Energy Lite - Ultra Energy Lite
22. Ultra Energy Plus - Ultra Energy Plus
23. Ultra Latitude - Ultra Latitude
24. Ultra Live II - Ultra Live II
25. Ultra Shadow - Ultra Shadow
26. Ultra Storm - Ultra Storm
27. Ultra Style - Ultra Style
28. e501 - e501
29. e502 - e502
30. e551 - e551

## Hyve

1. Buzz BU01 - BU01
2. Pryme01 - Pryme 01
3. Storm ST01 - ST01

## ICL-KME CS OJSC

1. TR10CD1 - TR10CD1

## IDEA

1. i4901 - i4901

## IMO(In My Opinion)

1. IMO Q - IMO Q

## INQ Mobile

1. camden - Camden
2. camden - INQ Cloud Touch
3. camden - INQ Cloud Touch -parrot
4. msm7627\_surf - INQ Mayfair (EU)

## IPRODA

1. T1144 - T1144

## IUNI

1. N1 - IUNI N1

## IUSA

1. TR10CS1 - TR10CS1
2. TR10CS1 - TR10CS1

## IView

1. 1070TPC - 1070TPC
2. 769TPC - 769TPC
3. 776TPCIII - 776TPCIII
4. 778TPC - 778TPC
5. 788TPCII - 788TPCII
6. 920TPC - 920TPC
7. Retailer Stores - 730TPC
8. SupraPad i700 - i700
9. SupraPad i785Q - i785Q

## Ice Phone

1. Mini - Ice-Phone Mini

## Icon

1. Portal\_10i - NTMC17

## IkuMobile

1. K2 - K2
2. T1 - iKU T1

## Ilike

1. X3\_PRO\_SLIM - X3 PRO SLIM
2. X5\_PRO - X5\_PRO

## ImageMobile

1. Ipanema - C001
2. Rio - B001

## Impecca

1. ET7050D - ET7050D

## Inet-Tablet

1. D711HC\_PG - D711HC\_PG
2. D7911L3BC\_OGS - D7911L3BC\_OGS

## Infinity

1. 10.1-v2 - Infinity-10.1-v2
2. 10.1-v3 - Infinity-10.1-v3

## Infinix

1. HOT 2 - Infinix X510
2. HOT 3 - Infinix HOT 3 Pro
3. HOT 3 - Infinix-X554
4. HOT 3 LTE - Infinix HOT 3 LTE
5. HOT 3 LTE - Infinix HOT 3 LTE
6. HOT 4 - Infinix HOT 4
7. HOT 4 - Infinix HOT4 LTE
8. HOT 4 - Infinix HOT 4
9. HOT 4 - Infinix X557
10. HOT 4 - Infinix HOT 4
11. HOT 4 Lite - Infinix HOT 4 Lite
12. HOT 4 PRO - Infinix HOT 4 Pro
13. HOT 4 PRO - Infinix\_X556\_LTE
14. HOT 4 Pro - Infinix HOT 4 Pro
15. HOT 4 Pro - Infinix HOT 4 Pro
16. HOT NOTE - Infinix-X551
17. HOT5 - Infinix X559C
18. HOT5 Lite - Infinix X559
19. Infinix - Infinix X510
20. Infinix X5010 - Infinix X5010
21. Infinix X559 - Infinix X559
22. Infinix X571 - Infinix X571
23. Infinix X572 - Infinix X572
24. NOTE 3 - Infinix NOTE 3
25. NOTE 3 Pro - Infinix NOTE 3 Pro
26. NOTE 3 Pro - Infinix NOTE 3 Pro
27. NOTE 3 Pro - Infinix\_X601\_LTE
28. NOTE 4 - Infinix X572
29. NOTE 4 - Infinix X572-LTE
30. NOTE 4 Pro - Infinix X571
31. RACE Blot2 - Infinix X454
32. RACE Bolt 3 - Infinix X455
33. S2 - Infinix S2
34. S2 - Infinix S2 Pro
35. SURF 2 - Infinix X511

36. X405 - Infinix X405
37. X505 - Infinix X505
38. X521 - Infinix HOT S
39. X521 - Infinix-X521
40. X521 - Infinix-X521-LTE
41. X521 - Infinix\_X521
42. X521 - Infinix-X521
43. X521 - Infinix-X521
44. X521 - Infinix\_X521
45. X521 - Infinix\_X521\_LTE
46. X521-H1 - Infinix-X521
47. X521-H1 - Infinix\_X521
48. X521-I1 - Infinix\_X521
49. X521E1 - Infinix HOT S
50. X521E1 - Infinix-X521
51. X521E1 - Infinix\_X521
52. X521G1 - Infinix-X521
53. X521G1 - Infinix-X521\_LTE
54. X521G1 - Infinix\_X521
55. X521S - Infinix-X521S
56. X521S - Infinix\_X521S
57. X551 - INFINIX-X551
58. X552 - Infinix Zero 3
59. X552 - Infinix-X552
60. X552-C1 - Infinix-X552
61. X552-E1 - Infinix Zero 3
62. X552-E1 - Infinix-X552
63. X552-F1 - Infinix Zero 3
64. X552-F1 - Infinix-X552
65. X555 - Infinix Zero 4
66. X557F1 - Infinix HOT 4
67. X572 - Infinix X572
68. X572 - Infinix X572-LTE
69. X600 - INFINIX-X600
70. X600 - INFINIX-X600
71. X600 - Infinix-X600
72. X600 - Infinix-X600-LTE
73. Zero 2 - Infinix X509
74. Zero 4 - Infinix Zero 4
75. Zero 4 Plus - Infinix Zero 4 Plus
76. Zero 5 Pro - Infinix X603

## Infocus

1. A1S - InFocus M505
2. Amazing A8 - Amazing A8
3. Big Tab - IF195a
4. Big Tab - IF236a
5. C7 - C2107
6. CS1 8.0 - CS180
7. Epic 1 - TSP
8. FP-U320-INF-WLTW - FP-U320-INF-WLTW
9. IF9001 - IF9001
10. IF9002 - IF9002
11. IF9007 - IF9007
12. IF9007 - IF9007
13. IF9021 - IF9021
14. IN260 - IN260
15. IN335 - IN335
16. IN610 - IN610
17. IN810 - IN810
18. IN815 - IN815
19. InFocus M6S - IF9003

20. M2 - InFocus M2
21. M2+ - InFocus M2PLUS
22. M210 - M210
23. M260 - InFocus M260
24. M2\_3G - InFocus M2\_3G
25. M310 - InFocus M310
26. M320 - InFocus M320
27. M320e - InFocus M320e
28. M320m - InFocus M320m
29. M320u - InFocus M320u
30. M330 - InFocus M330
31. M350 - InFocus M350
32. M350 - InFocus M350
33. M370 - M370
34. M370i - M370i
35. M372 - M372
36. M377 - M377
37. M415 - InFocus M415
38. M425 - InFocus M425
39. M430 - InFocus M430
40. M460 - InFocus M460
41. M500 - InFocus M500
42. M510 - M510
43. M510t - InFocus M510t
44. M511 - M510
45. M511 - M511
46. M512 - InFocus M512
47. M512 - M512
48. M518 - M518
49. M530 - InFocus M530
50. M535 - InFocus M535
51. M535\_00WW - InFocus M535
52. M550 - InFocus M550
53. M550 3D - InFocus M550 3D
54. M560 - InFocus M560
55. M5s - IF9002
56. M680 - InFocus M680
57. M808 - InFocus M808
58. M808i - InFocus M808i
59. M810 - InFocus M810
60. M810t - InFocus M810t
61. M812 - InFocus M812
62. M812A - InFocus M812A
63. M812i - InFocus M812i
64. NewTab F1 - NewTab F1
65. Smart503 - Smart503
66. T3000 - T3000
67. VZH - VZH
68. VZU - VZU
69. XT-50IP600 - XT\_50IP600

## Inhon

1. L35 - L35
2. L55 - L55
3. V6 - Inhon\_V6

## Innjoo

1. 3 - InnJoo\_3
2. Halo 4 LTE - Halo 4 LTE
3. Halo2 LTE - Halo2 LTE
4. Halo4 mini LTE - Halo\_4\_mini\_LTE

5. Max3 LTE - Max3\_LTE

## Insignia

1. FLEX 8 LTE Android Tablet - NS-15T8LTE
2. Flex 10.1 - NS-14T004
3. Flex 8" - NS-15AT08
4. MID7802RA - NS-P16AT785HD
5. NS-14T002 - NS-14T002
6. NS-15AT07 - NS-15AT07
7. NS-15AT10 - NS-15AT10
8. NS-P08A7100 - NS-P08A7100
9. NS-P10A6100 - NS-P10A6100
10. NS-P10A7100 - NS-P10A7100
11. NS-P10A8100 - NS-P10A8100
12. NS-P10A8100K - NS-P10A8100K
13. NS-P11A8100 - NS-P11A8100
14. NS-P16AT08 - NS-P16AT08
15. NS-P16AT10 - NS-P16AT10

## Intel

1. SP-A20i - SP-A20i
2. blackbay - Xolo\_X900
3. noonhill - AZ210A
4. noonhill - AZ210B
5. noonhill - SP-A20i
6. AQ710A - AQ710A
7. Etisalat E-20 - BT230
8. Orange San Diego - AZ210A
9. Orange avec Intel Inside - AZ210B
10. TR10CD1(PVT2) - TR10CD1
11. TR10CD1(PVT2) - TR10CD1
12. TR10CS1 (PVT2) - TR10CS1
13. Xolo X500 - Xolo\_X500
14. Yolo - BT210

## Intenso

1. Tab734 - Tab734
2. Tab814S - Tab814S

## Intermec

1. CN51 - CN51 NCO
2. CN51 - CN51 NCF
3. CN51 - CN51 NCU
4. CN51 - CN51 NNO
5. CN51 - CN51 QCO
6. CN51 - CN51 QCF
7. CN51 - CN51 QCU
8. CN51 - CN51 QNO

## Intex

1. AQUA 4G MINI - INTEX AQUA 4G MINI
2. AQUA CRYSTAL - INTEX AQUA CRYSTAL
3. AQUA CRYSTAL+ - INTEX AQUA CRYSTAL+
4. AQUA LIONS 2 - INTEX AQUA LIONS 2
5. AQUA TREND LITE - INTEX AQUA TREND LITE
6. AQUA YOUNG 4G - INTEX AQUA YOUNG 4G
7. AQUA ZENITH - INTEX AQUA ZENITH
8. AQUA\_4.0\_4G - INTEX AQUA\_4.0\_4G
9. AQUA\_S3 - INTEX AQUA S3
10. Aqua 4.0 3G - INTEX AQUA 4.0 3G

11. Aqua 5.5 VR - Aqua 5.5 VR
12. Aqua 5.5 VR+ - INTEX AQUA 5.5 VR+
13. Aqua A4 - INTEX AQUA A4
14. Aqua A4+ - INTEX AQUA A4 PLUS
15. Aqua Aura 2GB - Aqua Aura 2GB
16. Aqua Jewel 2 - INTEX AQUA JEWEL 2
17. Aqua Lions 3 - INTEX AQUA LIONS 3
18. Aqua Power 4G - Aqua Power 4G
19. Aqua Power IV - INTEX AQUA POWER IV
20. Aqua Pride - Aqua Pride
21. Aqua Ring - Aqua\_Ring
22. Aqua Strong 5.1+ - Intex Aqua Strong 5.1+
23. Aqua Supreme+ - Intex Aqua Supreme+
24. Aqua View - Aqua View
25. Aqua\_Lions\_4G - INTEX AQUA LIONS 4G
26. Aqua\_Q8 - Aqua Q8
27. Cloud AX1 - INTEX CLOUD AX1
28. Cloud style 4G - Intex\_Cloud\_Style\_4G
29. Cloud\_Q11\_4G - Cloud Q11 4G
30. Cloud\_Q11\_4G - Cloud\_Q11\_4G
31. ELYT E1 - INTEX ELYT E1
32. ELYT E6 - INTEX ELYT E6
33. ELYT E7 - INTEX ELYT E7
34. Elite E1 - Intex Elite E1
35. INTEX AQUA Lions T1 - INTEX AQUA LIONS T1
36. INTEX AQUA AMAZE+ - INTEX AQUA AMAZE+
37. INTEX AQUA LIONS X1 - INTEX AQUA LIONS X1
38. INTEX AQUA LIONS X1+ - INTEX AQUA LIONS X1+
39. INTEX AQUA NOTE 5.5 - INTEX AQUA NOTE 5.5
40. INTEX AQUA S1 - INTEX AQUA S1
41. INTEX AQUA STYLE 3 - INTEX AQUA STYLE 3
42. INTEX Aqua Selfie - INTEX AQUA SELFIE

## Irbis

1. IRBIS TZ175 - TZ175
2. IRBIS TZ176 - TZ176
3. IRBIS TZ178 - TZ178
4. IRBIS TZ737 - TZ737
5. IRBIS TZ747 - TZ747
6. IRBIS TZ752 - TZ752
7. IRBIS TZ753 - TZ753
8. SP454 - SP454
9. SP455 - SP455
10. SP510 - SP510
11. SP550 - SP550
12. SP551 - SP551
13. TZ177 - TZ177
14. TZ55 - TZ55
15. TZ720 - TZ720
16. TZ777 - TZ777
17. TZ831 - TZ831
18. TZ841 - TZ841
19. TZ877 - TZ877
20. TZ885 - TZ885
21. TZ890 - TZ890
22. TZ960 - TZ960

## itel

1. A11 - itel A11
2. A12 - itel A12
3. A13 - itel A13

4. A21 - itel A21
5. A31 - itel A31
6. A41 - itel A41
7. A41 Plus - itel A41 Plus
8. A43 - itel A43
9. A51 - itel A51
10. P11 - itel P11
11. P12 - itel P12
12. P31 - itel P31
13. P51 - itel P51
14. Prime 4 - itel Prime 4
15. S11 - itel S11
16. S11 Plus - itel S11 Plus
17. S11 Plus - itel S11Plus
18. S21 - itel S21
19. S31 - itel S31
20. S41 - itel S41
21. it1355 - itel it1355
22. it1355M - itel it1355M
23. it1407 - itel it1407
24. it1408 - itel it1408
25. it1408 - itel it1408
26. it1409 - itel it1409
27. it1460 - itel it1460
28. it1460 - itel it1460 Pro
29. it1505 - itel\_it1505
30. it1506 - itel it1506
31. it1507 - itel it1507
32. it1507 - itel it1507
33. it1508 - itel it1508
34. it1508 - itel it1508
35. it1508 Plus - itel it1508
36. it1508 Plus - itel it1508 Plus
37. it1512 - it1512
38. it1513 - itel it1513
39. it1516 Plus - itel it1516 Plus
40. it1518 - itel it1518
41. it1520 - itel-it1520
42. it1550 - itel\_it1550
43. it1551 - itel it1551
44. it1551 - itel it1551
45. it1553 - itel-it1553
46. it1556 - itel it1556
47. it1556 Plus - itel it1556 Plus
48. it1556 Plus - itel it1556 plus
49. it1655 - itel it1655
50. it1655S - itel it1655S
51. it1702 - itel it1702
52. it1703 - itel it1703
53. itel A20 - itel A20
54. itel A31 - itel A31
55. itel A40 - itel A40
56. itel A41 - itel A41
57. itel A42 Plus - itel A42 Plus
58. itel P41 - itel P41
59. itel Prime 4 - itel Prime 4
60. itel S12 - itel S12

## Itworks

1. TM705 - NID\_7010

## JLab

1. PRO-7 - JLab PRO-7

## JP Sacouto

1. Flag Mill v2 - Flag Mill v2
2. Flag Mill v2 - Flag Mill v2
3. Flag Mill v2 - Flag Mill v2
4. MOVE\_S201 - MOVE\_S201
5. Mini Mill v2 - Mini Mill v2
6. TF10EA2 - CASEBOOK\_3
7. mymaga CLASS Plus 2 - mymaga CLASS Plus 2

## JVC

1. gener - RY-AP1
2. DM65UXR\\DM65USR\\DM85UXR - DM65UXR

## JabrBox

1. H460 - H460
2. H460B01 - H460
3. S502 - S502

## Janam

1. XM75 - XM75
2. XT100 - XT100
3. XT2 - XT2

## Jide

1. Remix Mini - Remix Mini

## Jivi

1. Energy E12 - Energy E12
2. Prime P444 - Prime P444

## Just5

1. CF8 - CF8
2. COSMO L707 - COSMO\_L707
3. FREEDOM C100 - FREEDOM C100
4. FREEDOM C100 - FREEDOM C105
5. Freedom M303 - FREEDOM\_M303
6. GINI Tab V7 - GINI\_Tab\_V7
7. Konrow - Just5
8. M503 - M503

## K-Lite,

1. K-LITE NEXT M1 - K-LITE\_NEXT\_M1

## K-Touch

1. whistler - W808
2. K-Touch920 - K-Touch 920
3. K3 - K-Touch K3
4. L930i - K-Touch L930i
5. M2s - K-Touch M2s
6. Touch 2C - K-Touch Tou ch 2c

## KAAN

1. A1 - KAAAN\_A1



## KAZAM

1. TROOPER X3.5 - Trooper\_X35
2. TROOPER X4.0 - Trooper\_X40
3. TROOPER X5.5 - Trooper\_X55
4. TV 4.5 - KAZAM TV 45
5. TV 4.5 - KAZAM TV 45
6. Thunder 345 - KAZAM Thunder 345
7. Thunder 345 LTE - KAZAM Thunder 345 LTE
8. Thunder 345 LTE - Thunder3 45 LTE
9. Thunder 345L - KAZAM Thunder 345L
10. Thunder 347 - Thunder 347
11. Thunder 350L - KAZAM Thunder 350L
12. Thunder 550 - KAZAM Thunder 550
13. Thunder 550L - KAZAM Thunder 550L
14. Thunder2 45L - KAZAM THUNDER2 45L
15. Thunder2 50 - KAZAM Thunder2 50
16. Tornado 348 - Tornado 348
17. Tornado 350 - KAZAM Tornado 350
18. Tornado 455L - KAZAM Tornado 455L
19. Tornado2 50 - KAZAM Tornado2 50
20. Trooper 440L - KAZAM Trooper 440L
21. Trooper 445L - KAZAM Trooper 445L
22. Trooper 450 - KAZAM Trooper 450
23. Trooper 450L - KAZAM\_Trooper\_450L
24. Trooper 451 - KAZAM Trooper 451
25. Trooper 455 - KAZAM Trooper 455
26. Trooper 540 - KAZAM Trooper 540
27. Trooper 550L - KAZAM Trooper 550L
28. Trooper 551 - KAZAM Trooper 551
29. Trooper 555 - KAZAM Trooper 555
30. Trooper 650 - KAZAM Trooper 650
31. Trooper 650 4G - KAZAM Trooper 650 4G
32. Trooper2 40 - KAZAM Trooper2 40
33. Trooper2 45 - Trooper2 45
34. Trooper2 50 - KAZAM Trooper2 50
35. Trooper2 60 - Kazam Trooper2 60

## KD Interactive

1. C15100i - C15100i
2. C15100m - C15100m
3. C15150m - C15150m
4. Kurio Phone - KurioPhone
5. Kurio Tab - Extrem - C14100
6. Kurio10S - Kurio10S
7. Kurio4S - Kurio4S
8. Kurio7S - Kurio7S
9. TAB3-Premium-XTREME3 - 01016
10. TAB3-Premium-XTREME3 - 01516

## KDDI

1. CablePlus STB - C02AS
2. Power Up Unit - C02BB1
3. STW2000 - STW2000

## KOOCK

1. C600 - C600

## KT Tech

1. s120 - KM-S120
2. s200 - KM-S200

3. s220 - KM-S220
4. s220H - KM-S220H
5. s300 - KM-S300
6. s330 - KM-S330
7. EV-S100 - EV-S100
8. TAKE SUIT - KM-E100

## Kalley

1. Klic - K4-02 4G

## Kapsys

1. SmartVision2 - KAP11000

## Karbons

1. A1 Indian - A1 Indian
2. A40 Indian - A40 Indian
3. A41 Power - A41 Power
4. A45 Indian - A45 Indian
5. Aura 4G - Aura 4G
6. Aura Note 2 - Aura Note 2
7. Aura Note 4G - Aura Note 4G
8. Aura Note Play - Aura Note Play
9. Aura Power - Aura\_Power
10. Aura Power 4G - Aura Power 4G
11. Aura Power 4G - Aura Power 4G Plus
12. Aura Power 4G Plus - Aura Power 4G Plus
13. Aura Sleek 4G - Aura Sleek 4G
14. K9 Kavach 4G - K9 Kavach 4G
15. K9 Smart 4G - K9 Smart 4G
16. K9 Smart Eco - K9 Smart Eco
17. K9 Smart Grand - K9 Smart Grand
18. K9 Smart Yuva - K9 Smart Yuva
19. K9 Viraat 4G - K9 VIRAAAT 4G
20. Karbons K9 Music 4G - K9 Music 4G
21. Karbons Yuva2 - Karbons Yuva 2
22. Sparkle V - Sparkle V
23. Titanium Frames S7 - Titanium Frames S7
24. Titanium Jumbo - Titanium Jumbo
25. Titanium Jumbo 2 - Titanium Jumbo 2
26. Titanium Vista 4G - Titanium Vista 4G

## Kempler Strauss

1. Alumini 3 Plus - Alumini\_3\_Plus

## Kenbo

1. O51 - O51

## Kennex

1. MD7053G - MD7053G

## Ketablet

1. Ketablet - TR10CS1

## Kiano

1. Elegance 5.1 - Elegance\_5\_1
2. Elegance 5.1 Pro - ELEGANCE\_5\_1\_PRO
3. Elegance 5.5 - Elegance\_5\_5
4. Elegance 5.5 Pro - Elegance\_5\_5\_Pro
5. Slim\_Tab\_8 - Slim\_Tab\_8

## Klipad

1. 7588AN - 7588AN
2. 7588AN - KL3838
3. KL600 - KLIPAD\_KL600
4. KLIPAD\_SMART\_D71 - KLIPAD\_SMART\_D71
5. PRO\_I746 - KLIPAD\_PRO\_I746
6. SMART\_D791 - KLIPAD\_SMART\_D791
7. SMART\_I745 - KLIPAD\_SMART\_I745
8. V355 - KLIPAD\_V355
9. V355B - KLIPAD\_V355B

## Kobo

1. Arc - Arc
2. Arc 10HD - arc 10HD
3. Arc 7 - arc 7
4. Arc 7HD - arc 7HD
5. Vox - Vox

## Kodak

1. Ektra - Ektra
2. IM5 - IM5
3. SP4 - SP4

## Kogan

1. Agora 6 Plus - Kogan Agora 6Plus
2. Kogan Agora 8 Plus - Agora 8 Plus

## Konrow

1. LINK55 - LINK55
2. Primo - PRIMO
3. Smartfive - Smartfive

## Kruger&Matz

1. DRIVE 5 - Kruger&Matz Drive 5
2. EAGLE 701 - KM0701\_1
3. EAGLE 804 - KM0804\_1
4. EAGLE 805 - KM0805\_1
5. FLOW - FLOW
6. FLOW 5 - FLOW\_5
7. FLOW 5+ - FLOW5PLUS
8. KM1066 - KM1066
9. KM1067 - KM1067
10. LIVE 5 - Kruger&Matz\_LIVE5\_KM0450
11. LIVE 5 PLUS - LIVE 5 PLUS
12. MOVE 7 - MOVE\_7

## Kubo

1. K5 - K5

## Kult

1. Gladiator - Gladiator
2. Kult Beyond - Beyond

## Kyocera

1. SCP-8600 - Zio
2. WX06K - WX06K
3. 404KC - 404KC
4. 503KC - 503KC

5. 602KC - 602KC
6. Android One S2 - S2
7. BASIO - KYV32
8. Brigadier - E6782
9. DIGNO - ISW11K
10. DIGNO - KYL22
11. DIGNO Dual - WX04K
12. DIGNO L - KYV36
13. DIGNO R - 202K
14. DIGNO S - KYL21
15. DIGNO T - 302KC
16. DIGNO V - KYV42\_u
17. DIGNO W - KYV40U
18. DIGNO rafre - KYV36
19. DM015K - DM015K
20. DuraForce - KYOCERA-E6560
21. DuraForce - E6560C
22. DuraForce - E6560L
23. DuraForce - E6560T
24. DuraForce - USCC-E6762
25. DuraForce PRO - KYOCERA-E6820
26. DuraForce PRO - E6820TM
27. DuraForce PRO - KYOCERA-E6820
28. DuraForce PRO - E6830
29. DuraForce PRO - E6833
30. DuraForce PRO with Sapphire Shield - E6810
31. DuraForce PRO with Sapphire Shield - E6810
32. DuraForce XD - KYOCERA-E6790
33. DuraForce XD - E6790TM
34. DuraScout - E6782L
35. Echo - KSP8000
36. Echo - M9300
37. Event - Event
38. HONEY BEE - 101K
39. Honeybee Touch - 201K
40. Hydro - C5170
41. Hydro - Hydro
42. Hydro AIR - KYOCERA-C6745
43. Hydro EDGE - C5215
44. Hydro Elite - C6750
45. Hydro ICON - C6730
46. Hydro LIFE - C6530
47. Hydro LIFE - C6530N
48. Hydro PLUS - Hydro
49. Hydro PLUS - Hydro\_PLUS
50. Hydro REACH - C6743
51. Hydro SHORE - KYOCERA-C6742A
52. Hydro VIBE - C6725
53. Hydro VIEW - C6742
54. Hydro VIEW - KYOCERA-C6742
55. Hydro WAVE - C6740
56. Hydro WAVE - C6740N
57. Hydro XTRM - C6522
58. Hydro XTRM - C6522N
59. Hydro XTRM - USCC-C6721
60. INFOBAR A03 - KYV33
61. KC-01 - KC-01
62. LUCE - KCP01K
63. LifeWatch Universal Gateway - CD8100
64. Milano - C5120
65. Milano - C5121
66. Qua phone - KYV42

67. Qua phone (KYV37) - KYV37
68. Rise - C5155
69. Rise - Rise
70. S301 - KC-S301AE
71. SZJ201 - SZJ-JS201
72. TORQUE - KC-100S
73. TORQUE - SKT01
74. TORQUE G01 - KYV24
75. TORQUE G02 - KYV35
76. TORQUE G03 - KYV41
77. TORQUE(KC-S701) - KC-S701
78. Torque - Torque
79. TorqueXT - E6715
80. URBANO L01 - KYV21
81. URBANO L02 - KYV22
82. URBANO L03 - KYV23
83. URBANO PROGRESSO - URBANO PROGRESSO
84. URBANO V01 - KYV31
85. URBANO V02 - KYV34
86. URBANO V03 - KYV38
87. WX10K - WX10K
88. Zio - Zio
89. miraie - KYL23
90. miraie f - KYV39
91. rafre - KYV40
92. zio - Zio
93. zio - Zio
94. zio - Zio

## Kyowon

1. All&G PAD - KA-E410W

## LGE

1. AS855 - LG-AS855
2. LGP970 - LG-P970
3. US855 - USCC-US855
4. alessi - LG-E720
5. alessi - LG-E720b
6. alohag\_302-220 - LG-C710h
7. black - LG-KU5900
8. bproj\_214-07 - LG-P970
9. bproj\_222-88 - LG-P970
10. bproj\_226-10 - LG-P970
11. bproj\_228-03 - LG-P970
12. bproj\_231-01 - LG-P970
13. bproj\_232-05 - LG-P970
14. bproj\_234-33 - LG-P970
15. bproj\_260-03 - LG-P970
16. bproj\_454-xxx - LG-P970
17. bproj\_530-XXX - LG-P970
18. bproj\_BAL-xxx - LG-P970
19. bproj\_OPEN-CN - LG-P970
20. bproj\_VDF-XXX - LG-P970
21. cosmo\_268-06 - LG-P920
22. cosmo\_302-720 - LG-P925g
23. cosmo\_454-XXX - LG-P920
24. cosmo\_466-92 - LG-P920
25. cosmo\_505-XXX - LG-P920
26. cosmo\_515-XXX - LG-P920
27. cosmo\_525-01 - LG-P920
28. cosmo\_525-05 - LG-P920

29. cosmo\_724-02 - LG-P920h
30. cosmo\_724-05 - LG-P920h
31. cosmo\_724-xxx - LG-P920h
32. cosmo\_BAL-XXX - LG-P920
33. cosmo\_CIS-XXX - LG-P920
34. cosmo\_ESA-XXX - LG-P920
35. cosmo\_H3G-XXX - LG-P920
36. cosmo\_MOR-XXX - LG-P920
37. cosmo\_OPEN-CN - LG-P920
38. cosmo\_OPT-XXX - LG-P920
39. cosmo\_TMO-XXX - LG-P920
40. cosmo\_VDF-XXX - LG-P920
41. cosmo\_tcl-mx - LG-P920h
42. cosmo\_viv-br - LG-P920h
43. e510\_724-XX - LG-E510f
44. envt2 - USCC-US760
45. envt2 - VS761
46. envt2 - enV Pro
47. envt2 - enV Touch2
48. gelato\_262-xx - LG-P690
49. gelato\_425-02 - LG-P690f
50. gelato\_460-xx - LG-P690
51. gelato\_460-xx - LG-P693
52. gelato\_are-xx - LG-P690
53. gelato\_bal-xx - LG-P690
54. gelato\_hkg-xx - LG-P690
55. gelato\_mor-xx - LG-P690
56. gelato\_nfc\_234-10 - LG-P692
57. gelato\_nfc\_530-24 - LG-P692
58. gelato\_nfc\_tim-it - LG-P692
59. gelato\_ngr-xx - LG-P690
60. gelato\_sgp-xx - LG-P690
61. gelato\_tmb-sk - LG-P690
62. gelato\_tur-xx - LG-P690
63. gelato\_win-it - LG-P690
64. gelatods\_bal-xxx - LG-P698
65. gelatods\_ngr-xxx - LG-P698
66. gelatods\_open-xx - LG-P698
67. gelatods\_tha-xxx - LG-P698f
68. hub - LG-LU3000
69. ku9500 - KU9500
70. l95g - LG-L95G
71. ls700 - LG-LS700
72. lu2300 - LU2300
73. lu3100 - LG-LU3100
74. msm8660\_surf - LG-LU6200
75. p2 - LG-P940h
76. p925g - LG-P925g
77. p940 - LG-P940
78. p990\_208-10 - LG-P990
79. p990\_214-01 - LG-P990
80. p990\_219-10 - LG-P990
81. p990\_226-01 - LG-P990
82. p990\_228-01 - LG-P990
83. p990\_234-xx - LG-P990
84. p990\_262-02 - LG-P990
85. p990\_454-xxx - LG-P990
86. p990\_466-92 - LG-P990
87. p990\_466-xxx - LG-P990
88. p990\_505-xxx - LG-P990
89. p990\_525-01 - LG-P990
90. p990\_525-05 - LG-P990

91. p990\_BAL-xxx - LG-P990  
92. p990\_esa-xxx - LG-P990  
93. p990h - LG-P990h  
94. p990h\_334-020 - LG-P990h  
95. p990h\_716-10 - LG-P990h  
96. p990h\_722-34 - LG-P990h  
97. p990h\_724-05 - LG-P990h  
98. p990h\_730-01 - LG-P990h  
99. p990h\_730-03 - LG-P990h  
100. p990h\_CTM-xxx - LG-P990h  
101. p990h\_SSV-xxx - LG-P990h  
102. p993 - LG-P993  
103. star - LG-P990hN  
104. univa\_228-01 - LG-E510  
105. univa\_454-xx - LG-E510  
106. univa\_525-01 - LG-E510  
107. univa\_525-05 - LG-E510  
108. univa\_722-34 - LG-E510g  
109. univa\_bal-xxx - LG-E510  
110. univa\_neu-xx - LG-E510  
111. univa\_open\_cn - LG-E510  
112. univa\_tha-xx - LG-E510f  
113. univa\_tmo-gr - LG-E510  
114. univa\_vdf-es - LG-E510  
115. v900aus - LG-V900  
116. v901twm - LG-V901  
117. x2\_450-08 - LG-KU8800  
118. x3 - LG-P880  
119. 070 touch - LG-FL40L  
120. AKA - LG-F520L  
121. AKA - LG-F520S  
122. AKA - LG-H788  
123. Ally - AS740  
124. Ally - Ally  
125. Ally - Aloha  
126. Ally - US740  
127. Android TV - LG Google TV  
128. Android TV - LG Android TV V4  
129. Android TV - LG Google TV G3  
130. Android TV - LG Google TV G3 KR  
131. Android TV G3 - LG Google TV G3  
132. B6 - LGT02  
133. DM-01G - DM-01G  
134. DM-02H - DM-02H  
135. Enact - VS890 4G  
136. Escape - LG-P870  
137. Eve - GW620  
138. Eve - LG GW620  
139. Eve - LG GW620F  
140. Eve - LG GW620R  
141. Eve - LG GW620g  
142. Eve - LG KH5200  
143. Eve - LG-GW620  
144. Eve - LG-KH5200  
145. F60 - LG-D390  
146. F60 - LG-D390AR  
147. F60 - LG-D392  
148. F60 - LG-D390n  
149. F60 - LG-D393  
150. F60 - LGMS395  
151. F60 - LGLS660  
152. F60 - VS810PP  
153. F70 - LGL31L  
154. Fortune - LG-M153  
155. Fortune - LG-M154  
156. G PAD 10.1 - LG-X760  
157. G PAD 10.1 - LG-X760E  
158. G PAD 10.1 - LG-X760W  
159. G Pad 10.1 - LG-V700  
160. G Pad 10.1 - LG-V700WJ  
161. G Pad 10.1 - LG-V700n  
162. G Pad 10.1 LTE - LG-VK700  
163. G Pad 10.1 LTE - VK700  
164. G Pad 7.0 - LG-V400  
165. G Pad 7.0 - LG-V400S1  
166. G Pad 7.0 - LG-V400Y1  
167. G Pad 7.0 - LG-V400Y7  
168. G Pad 7.0 LTE - LG-V410  
169. G Pad 7.0 LTE - LG-V411  
170. G Pad 7.0 LTE - LGUK410  
171. G Pad 8+ - AK815  
172. G Pad 8.0 - LG-V480  
173. G Pad II 8.0 - LG-V498  
174. G Pad II 8.0 - LG-V498S1  
175. G Pad II 8.0 - LG-V498S2  
176. G Pad III 8.0 Homeboy - LG-P451L  
177. G Pad 10.1 - LGUK932  
178. G Pad 10.1 FHD 4G LTE - LG-V935  
179. G Pad 10.1 FHD 4G LTE - LG-V935T  
180. G Pro Lite - LG-D685  
181. G Pro Lite - LG-D686  
182. G Pro Lite - LG-D683  
183. G Pro Lite - LG-D684  
184. G Pro Lite - LG-D680  
185. G Pro Lite - LG-D681  
186. G Pro Lite - LG-D682  
187. G Pro Lite - LG-D682TR  
188. G Pro2 - LG-F350K  
189. G Pro2 - LG-F350L  
190. G Pro2 - LG-F350S  
191. G Pro2 - LG-D838  
192. G Stylo - LG-F560K  
193. G Vista - LG-D690  
194. G Vista - VS880  
195. G Vista - VS880PP  
196. G Watch - G Watch  
197. G Watch R - G Watch R  
198. G pad 8.0 - LG-V480  
199. G pad 8.0 LTE - LG-V490  
200. G2 MINI - LG-D620  
201. G2 MINI - LG-D618  
202. G2 MINI - LG-D610  
203. G2 MINI - LG-D610AR  
204. G2 MINI - LG-D610TR  
205. G2 MINI - LG-D625  
206. G2 mini 4G LTE - LG-D625  
207. G3 Beat - LG-D726  
208. G3 Beat - LG-D728  
209. G3 Beat - LG-D729  
210. G3 Beat - LG-F470K  
211. G3 Beat - LG-F470L  
212. G3 Beat - LG-F470S  
213. G3 Beat - LG-D722J  
214. G3 Beat - LG-D727



215. G3 S - LG-D724  
216. G3 S - LG-D723  
217. G3 S - LG-D722  
218. G3 S - LG-D722AR  
219. G3 S - LG-D725PR  
220. G3 Screen - LG-F490L  
221. G3 Stylus - LG-D690n  
222. G3 Stylus - LG-D693  
223. G3 Stylus - LG-D693AR  
224. G3 Stylus - LG-D693TR  
225. G3 Stylus - LG-D693n  
226. G3 Vigor - LGLS885  
227. G3 Vigor - LG-D725  
228. GA7800 - LG Android TV V4  
229. GPAD 7.0 LTE - VK410  
230. Gentle - LG-F580L  
231. Gpad 7.0 - LG-V400  
232. Gx2 - LG-F430L  
233. Homeboy2 - LG-V607L  
234. Ice cream Smart - LG-F440L  
235. Intuition - VS950 4G  
236. K20 - RS501  
237. K3 2017 - LG-AS110  
238. K3 2017 - LGUS110  
239. K4 - LG-M151  
240. K4 (2017) - LGL157BL  
241. K4 (2017) - LGL57BL  
242. L Bello - LG-D335  
243. L Bello - LG-D335E  
244. L Bello - LG-D337  
245. L Fino - LG-D290  
246. L Fino - LG-D290AR  
247. L Fino - LG-D295  
248. L Fino - LG-D290  
249. L-01F - L-01F  
250. L20 - LG-D105  
251. L20 - LG-D100  
252. L20 - LG-D100AR  
253. L20 - LG-D107  
254. L30 Sporty - LG-D125  
255. L30 Sporty - LG-D120  
256. L30 Sporty - LG-D120AR  
257. L45 - LG-X130g  
258. L45 - LG-X132  
259. L50 Sporty - LG-D221  
260. L50 Sporty - LG-D227  
261. L50 Sporty - LG-D213  
262. L50 Sporty - LG-D213AR  
263. L50 Sporty - LG-D213  
264. L5000 - LG-F590  
265. L60 - LG-X135  
266. L60 - LG-X137  
267. L60 - LG-X140  
268. L60 - LG-X145  
269. L60 - LG-X147  
270. L65 - LG-D280  
271. L65 - LG-D285  
272. L65 - LG-D280  
273. L7 II - LG-P712  
274. L7 II - LG-P714  
275. L7 II Dual - LG-P716  
276. L70 - LG-D320  
277. L70 - LG-D320AR  
278. L70 - LG-D321  
279. L70 - LGAS323  
280. L70 - LGMS323  
281. L70 - LGLS620  
282. L70 - LG-D325  
283. L70 - LG-D320  
284. L70 - LG-D329  
285. L70 - LG-D340f8  
286. L70 CDMA - LGL41C  
287. L80 Dual - LG-D380  
288. L80 Dual - LG-D385  
289. L80 Single - LG-D370  
290. L80 Single - LG-D373  
291. L80 Single - LG-D375  
292. L80 Single - LG-D375AR  
293. L90 - LG-D400  
294. L90 - LG-D405  
295. L90 - LG-D415  
296. L90 - LG-D410  
297. L90 - LG-D400  
298. L90 - LG-D405  
299. L90 Dual - LG-D410  
300. LBello - LG-D331  
301. LBello - LG-D331AR  
302. LG AKA - LG-H778  
303. LG AKA - LG-H779  
304. LG AKA - LG-H788  
305. LG AKA - LG-H788SG  
306. LG AKA - LG-H788TR  
307. LG AKA - LG-H788n  
308. LG Aristo - LGMS210  
309. LG Bello II - LG-X150  
310. LG Bello II - LG-X155  
311. LG Bello II - LG-X165g  
312. LG Bello II - LG-X170g  
313. LG Class - LG-F620K  
314. LG Class - LG-F620L  
315. LG Class - LG-F620S  
316. LG Classic - LGL17AG  
317. LG Classic - LGL18VC  
318. LG Connect 4G - LG-MS840  
319. LG DOUBLEPLAY - LG-C729  
320. LG Destiny - LGL21G  
321. LG Enlighten - LG-VS700  
322. LG Enlighten - LG-VS700PP  
323. LG Escape 3 - LG-K373  
324. LG Escape2 - LG-H443  
325. LG Escape2 - LG-H445  
326. LG Esteem - LG-MS910  
327. LG F570S - LG-F570S  
328. LG F70 - LG-D315  
329. LG F70 - LG-D315I  
330. LG F70 - LG-F370K  
331. LG F70 - LG-F370L  
332. LG F70 - LG-F370S  
333. LG Fiesta 2 LTE - LGL163BL  
334. LG Fiesta 2 LTE - LGL164VL  
335. LG Fiesta LTE - LGL63BL  
336. LG Fiesta LTE - LGL64VL  
337. LG G Flex - LG-D950  
338. LG G Flex - LG-D950G

339. LG G Flex - LG-D951  
340. LG G Flex - LG-D955  
341. LG G Flex - LG-D956  
342. LG G Flex - LG-D958  
343. LG G Flex - LG-D959  
344. LG G Flex - LG-F340K  
345. LG G Flex - LG-F340L  
346. LG G Flex - LG-F340S  
347. LG G Flex - LG-LS995  
348. LG G Flex - LGL23  
349. LG G Flex2 - LG-F510K  
350. LG G Flex2 - LG-F510L  
351. LG G Flex2 - LG-F510S  
352. LG G Flex2 - LG-H950  
353. LG G Flex2 - LG-H955  
354. LG G Flex2 - LG-H959  
355. LG G Flex2 - LGAS995  
356. LG G Flex2 - LGLS996  
357. LG G Flex2 - LGUS995  
358. LG G Pad 8.0 L Edition - LGT01  
359. LG G Pad 8.0 LTE - LG-P490L  
360. LG G Pad 8.3 - LG-V500  
361. LG G Pad 8.3 Google Play Edition - LG-V510  
362. LG G Pad 8.3 LTE - VK810 4G  
363. LG G Pad 8.3 homeBoy - LG-V507L  
364. LG G Pad F 8.0 - LG-AK495  
365. LG G Pad F 8.0 - LG-UK495  
366. LG G Pad F 8.0 - LG-V495  
367. LG G Pad F 8.0 - LG-V496  
368. LG G Pad F 8.0 - LG-V499  
369. LG G Pad F2 8.0 - LG-LK460  
370. LG G Pad F7.0 - LGLK430  
371. LG G Pad F 8.0 2nd Gen - LG-AK495  
372. LG G Pad F 8.0 2nd Gen - LG-UK495  
373. LG G Pad II 10.1 FHD - LG-V940  
374. LG G Pad II 10.1 FHD - LG-V940n  
375. LG G Pad II 8.0LTE - LG-V497  
376. LG G Pad II 8.3 - LG-P815L  
377. LG G Pad III 10.1 FHD LTE - LG-P755L  
378. LG G Pad III 10.1 FHD LTE - LG-V755  
379. LG G Pad III 8.0 - LG-V522  
380. LG G Pad III 8.0 FHD - LG-V525  
381. LG G Pad III 8.0 FHD - LG-V525S1  
382. LG G Pad III 8.0 FHD - LG-V525S3  
383. LG G Pad IV 8.0 - LG-V533  
384. LG G Pad IV 8.0 FHD LTE - LG-P530L  
385. LG G Pad X 8.0 - LG-V521  
386. LG G Pad X 8.3 - VK815  
387. LG G Pad X2 8.0 PLUS - LG-V530  
388. LG G Pad X II 10.1 - LGUK750  
389. LG G Pad X 8.0 - LG-V520  
390. LG G Stylo - LG-H634  
391. LG G Stylo - LGLS770  
392. LG G Stylo - LG-H630D  
393. LG G Stylo - LG-H630  
394. LG G Stylo - LG-H631  
395. LG G Stylo - LG-H631MX  
396. LG G Stylo - LG-H635  
397. LG G Stylo - LG-H635A  
398. LG G Stylo - LG-H636  
399. LG G Stylo - LGMS631  
400. LG G Vista - LG-D631  
401. LG G Vista 2 - LG-H740  
402. LG G2 - LG-D800  
403. LG G2 - LG-D801  
404. LG G2 - LG-D802  
405. LG G2 - LG-D802T  
406. LG G2 - LG-D802TR  
407. LG G2 - LG-D803  
408. LG G2 - LG-D805  
409. LG G2 - LG-D806  
410. LG G2 - LG-F320K  
411. LG G2 - LG-F320L  
412. LG G2 - LG-F320S  
413. LG G2 - LG-LS980  
414. LG G2 - VS980 4G  
415. LG G3 - AS985  
416. LG G3 - LG-AS990  
417. LG G3 - LG-D850  
418. LG G3 - LG-D851  
419. LG G3 - LG-D852  
420. LG G3 - LG-D852G  
421. LG G3 - LG-D855  
422. LG G3 - LG-D856  
423. LG G3 - LG-D857  
424. LG G3 - LG-D858  
425. LG G3 - LG-D858HK  
426. LG G3 - LG-D859  
427. LG G3 - LG-F400K  
428. LG G3 - LG-F400L  
429. LG G3 - LG-F400S  
430. LG G3 - LGL24  
431. LG G3 - LGLS990  
432. LG G3 - LGUS990  
433. LG G3 - LGV31  
434. LG G3 - VS985 4G  
435. LG G3 A - LG-F410S  
436. LG G3 Cat.6 - LG-F460K  
437. LG G3 Cat.6 - LG-F460L  
438. LG G3 Cat.6 - LG-F460S  
439. LG G4 - AS986  
440. LG G4 - LG-AS811  
441. LG G4 - LG-AS991  
442. LG G4 - LG-F500K  
443. LG G4 - LG-F500L  
444. LG G4 - LG-F500S  
445. LG G4 - LG-H810  
446. LG G4 - LG-H811  
447. LG G4 - LG-H812  
448. LG G4 - LG-H815  
449. LG G4 - LG-H818  
450. LG G4 - LG-H819  
451. LG G4 - LGLS991  
452. LG G4 - LGUS991  
453. LG G4 - LGV32  
454. LG G4 - VS986  
455. LG G4 Beat - LG-H736  
456. LG G4 Beat - LG-H735  
457. LG G4 Stylus - LG-H540  
458. LG G4 Stylus - LG-H542  
459. LG G4 vigor - LG-H731  
460. LG G4c - LG-H525  
461. LG G4c - LG-H525n  
462. LG G4s - LG-H734

463. LG G5 - LG-F700K  
464. LG G5 - LG-F700L  
465. LG G5 - LG-F700S  
466. LG G5 - LG-H820  
467. LG G5 - LG-H820PR  
468. LG G5 - LG-H830  
469. LG G5 - LG-H831  
470. LG G5 - LG-H850  
471. LG G5 - LG-H858  
472. LG G5 - LG-H860  
473. LG G5 - LG-H868  
474. LG G5 - LGAS992  
475. LG G5 - LGLS992  
476. LG G5 - LGUS992  
477. LG G5 - RS988  
478. LG G5 - VS987  
479. LG G5 SE - LG-H840  
480. LG G5 SE - LG-H845  
481. LG G5 SE - LG-H848  
482. LG G6 - LG-AS993  
483. LG G6 - LG-H870  
484. LG G6 - LG-H870AR  
485. LG G6 - LG-H870DS  
486. LG G6 - LG-H870I  
487. LG G6 - LG-H870S  
488. LG G6 - LG-H871  
489. LG G6 - LG-H872  
490. LG G6 - LG-H872PR  
491. LG G6 - LG-H873  
492. LG G6 - LG-LS993  
493. LG G6 - LGM-G600K  
494. LG G6 - LGM-G600L  
495. LG G6 - LGM-G600S  
496. LG G6 - LGUS997  
497. LG G6 - VS988  
498. LG GRACE LTE - LGL59BL  
499. LG Gentle - LG-F660L  
500. LG Gpad X 10.1 - LG-V930  
501. LG Gx - LG-F310L  
502. LG Gx - LG-F310LR  
503. LG Harmony - LG-M257  
504. LG Joy - LG-H220  
505. LG Joy - LG-H222  
506. LG Joy - LG-H221  
507. LG Joy - LG-H221AR  
508. LG K10 - LG-K425  
509. LG K10 - LG-K428  
510. LG K10 - LGMS428  
511. LG K10 - LG-K420  
512. LG K10 - LG-F670K  
513. LG K10 - LG-F670L  
514. LG K10 - LG-F670S  
515. LG K10 - LG-K420  
516. LG K10 - LG-K410  
517. LG K10 (2017) - LG-M257PR  
518. LG K10 (2017) - LG-M250  
519. LG K10 (2017) - LG-M250  
520. LG K10 LTE - LG-K420PR  
521. LG K10 LTE - LG-K430  
522. LG K10 LTE - LG-K430  
523. LG K10 Power - LG-M320  
524. LG K20 - LG-M255  
525. LG K20 Plus - LG-TP260  
526. LG K20 Plus - LGMP260  
527. LG K20 V - VS501  
528. LG K3 - LGL48VL  
529. LG K3 - LGLS450  
530. LG K3 LTE - LG-K100  
531. LG K3 LTE - LG-K100  
532. LG K4 - LG-K120GT  
533. LG K4 - LG-K121  
534. LG K4 - VS425  
535. LG K4 - LG-M160  
536. LG K4 LTE - LG-K120  
537. LG K4 LTE - LG-K130  
538. LG K4/K7 (2017) - LG-X230  
539. LG K4/K7 (2017) - LG-X230YK  
540. LG K5 - LG-X220  
541. LG K7 - LG-AS330  
542. LG K7 - LG-K330  
543. LG K7 - LGMS330  
544. LG K7 - LG-X210  
545. LG K8 - LG-M210  
546. LG K8 - LGAS375  
547. LG K8 - LGUS375  
548. LG K8 - RS500  
549. LG K8 - LG-K350  
550. LG K8 (2017) - LGUS215  
551. LG K8 (2017) - LG-M200  
552. LG K8 (2017) - LG-X240  
553. LG K8 (2017) Dual - LG-M200  
554. LG K8 LTE - LG-K350  
555. LG K8 V - VS500  
556. LG K8 V - VS500PP  
557. LG L39C - LGL39C  
558. LG LEON LTE - LG-H345  
559. LG Lancet - VS820  
560. LG Leon - LG-H320  
561. LG Leon - LG-H324  
562. LG Leon - LG-H326  
563. LG Leon 4G LTE - LG-H340  
564. LG Leon 4G LTE - LG-H340AR  
565. LG Leon 4G LTE - LG-H340GT  
566. LG Leon 4G LTE - LG-H343  
567. LG Leon 4G LTE - LGMS345  
568. LG Leon 4G LTE - LG-H342  
569. LG Leon 4G LTE - LG-H340n  
570. LG Leon TV - LG-H326  
571. LG Logos - LGUS550  
572. LG Lucid - VS840 4G  
573. LG Lucid - VS840PP  
574. LG Lucid 2 - VS870 4G  
575. LG Lucid 3 - VS876  
576. LG M1 - LG-K332  
577. LG Mach - LG-LS860  
578. LG Magna - LG-H500  
579. LG Magna - LG-T540  
580. LG Magna - LG-H502  
581. LG Magna LTE - LG-H520  
582. LG Max - LG-X155  
583. LG Max - LG-X160  
584. LG Max - LG-X165g  
585. LG Motion 4G - LG-MS770  
586. LG OPTIMUS M+ - LG-MS695

587. LG OPTIMUS ZIP - LGL75C  
588. LG Optimus 3D - LG-P920  
589. LG Optimus 3D - LG-P925g  
590. LG Optimus 3D - LG-SU760  
591. LG Optimus ELITE - LG-VM696  
592. LG Optimus Elite - LG Optimus Elite  
593. LG Optimus Elite - LG-LS696  
594. LG Optimus F3Q - LG-D520  
595. LG Optimus F7 - LG-AS780  
596. LG Optimus F7 - LG-LG870  
597. LG Optimus F7 - LG-US780  
598. LG Optimus G - LG-E970  
599. LG Optimus G - LG-E971  
600. LG Optimus G - LG-E973  
601. LG Optimus G - L-01E  
602. LG Optimus G - LGL21  
603. LG Optimus G - LG-E975  
604. LG Optimus G - LG-E975K  
605. LG Optimus G - LG-E975T  
606. LG Optimus G - LG-E976  
607. LG Optimus G - LG-E977  
608. LG Optimus G - LG-E987  
609. LG Optimus G - LG-F180K  
610. LG Optimus G - LG-F180S  
611. LG Optimus G - LG-F180L  
612. LG Optimus G - LG-LS970  
613. LG Optimus G Pro - LG-E980  
614. LG Optimus G Pro - LG-E980h  
615. LG Optimus G Pro - LG-E981h  
616. LG Optimus G Pro - LG-E986  
617. LG Optimus G Pro - LG-E988  
618. LG Optimus G Pro - LG-E989  
619. LG Optimus G Pro - LG-F240K  
620. LG Optimus G Pro - LG-F240S  
621. LG Optimus G Pro - LG-F240L  
622. LG Optimus HUB - LG-E510  
623. LG Optimus HUB - LG-E510  
624. LG Optimus HUB - LG-E510  
625. LG Optimus HUB - LG-E510  
626. LG Optimus HUB - LG-E510  
627. LG Optimus HUB - LG-E510  
628. LG Optimus HUB - LG-E510  
629. LG Optimus L1II - LG-E410  
630. LG Optimus L1II - LG-E410B  
631. LG Optimus L1II - LG-E410c  
632. LG Optimus L1II - LG-E410f  
633. LG Optimus L1II - LG-E410g  
634. LG Optimus L1II - LG-E410i  
635. LG Optimus L1II - LG-E411f  
636. LG Optimus L1II - LG-E411g  
637. LG Optimus L1II - LG-E415f  
638. LG Optimus L1II - LG-E415g  
639. LG Optimus L1II - LG-E420  
640. LG Optimus L1II - LG-E420f  
641. LG Optimus L1II - LG-E475f  
642. LG Optimus L3 - LG-E400  
643. LG Optimus L3 - LG-E400R  
644. LG Optimus L3 - LG-E400b  
645. LG Optimus L3 - LG-E400f  
646. LG Optimus L3 - LG-E400g  
647. LG Optimus L3 - LG-L38C  
648. LG Optimus L3 - LGL35G  
649. LG Optimus L3 - LG-E400  
650. LG Optimus L3 Dual - LG-E405  
651. LG Optimus L3 Dual - LG-E405f  
652. LG Optimus L3 II - LG-E435  
653. LG Optimus L3 II - LG-E435f  
654. LG Optimus L3 II - LG-E435g  
655. LG Optimus L3 II - LG-E435k  
656. LG Optimus L3 II - LG-E425  
657. LG Optimus L3 II - LG-E425c  
658. LG Optimus L3 II - LG-E425f  
659. LG Optimus L3 II - LG-E425g  
660. LG Optimus L3 II - LG-E425j  
661. LG Optimus L3 II - LG-E430  
662. LG Optimus L3 II - LG-E431g  
663. LG Optimus L4 II - LG-E440  
664. LG Optimus L4 II - LG-E440f  
665. LG Optimus L4 II - LG-E440g  
666. LG Optimus L4 II - LG-E465f  
667. LG Optimus L4 II - LG-E465g  
668. LG Optimus L4 II Dual - LG-E445  
669. LG Optimus L4 II Dual - LG-E467f  
670. LG Optimus L4 II Tri - LG-E470f  
671. LG Optimus L5 Dual - LG-E615  
672. LG Optimus L5 Dual - LG-E615f  
673. LG Optimus L5 II - LG-E455  
674. LG Optimus L5 II - LG-E455f  
675. LG Optimus L5 II - LG-E455g  
676. LG Optimus L5 II - LG-E460  
677. LG Optimus L5 II - LG-E460f  
678. LG Optimus L5 II - LG-E450  
679. LG Optimus L5 II - LG-E450B  
680. LG Optimus L5 II - LG-E450f  
681. LG Optimus L5 II - LG-E450g  
682. LG Optimus L5 II - LG-E450j  
683. LG Optimus L5 II - LG-E451g  
684. LG Optimus L5 II - LG-E460  
685. LG Optimus L7 - LG-P700  
686. LG Optimus L7 - LG-P705  
687. LG Optimus L7 - LG-P705f  
688. LG Optimus L7 - LG-P705g  
689. LG Optimus L7 - LG-P708g  
690. LG Optimus L7 - LG-T280  
691. LG Optimus L7 - LGL96G  
692. LG Optimus L7 - LG-P715  
693. LG Optimus L7 II - LG-P710  
694. LG Optimus L7 II - LG-P712  
695. LG Optimus L7 II - LG-P713  
696. LG Optimus L7 II - LG-P713GO  
697. LG Optimus L7 II - LG-P713TR  
698. LG Optimus L7 II - LG-P714  
699. LG Optimus L7II - LG-P715  
700. LG Optimus L7II - LG-P716  
701. LG Optimus L9 - LG-D700  
702. LG Optimus L9 - LG-P760  
703. LG Optimus L9 - LG-P765  
704. LG Optimus L9 - LG-P768  
705. LG Optimus L9 - LG-P769  
706. LG Optimus L9 - LG-P778  
707. LG Optimus L9 - LGMS769  
708. LG Optimus L9 (NFC) - LG-P760  
709. LG Optimus L9 II - LG-D605  
710. LG Optimus LTE Tag - LG-AS840



711. LG Optimus LTE Tag - LG-F120K  
712. LG Optimus LTE Tag - LG-F120L  
713. LG Optimus LTE Tag - LG-F120S  
714. LG Optimus LTE Tag - LG-F120K  
715. LG Optimus LTE Tag - LG-F120S  
716. LG Optimus LTE2 - LG-F160K  
717. LG Optimus LTE2 - LG-F160S  
718. LG Optimus LTE2 - LG-F160L  
719. LG Optimus LTE2 - LG-F160LV  
720. LG Optimus LTE3 - LG-F260S  
721. LG Optimus One - LG-P500  
722. LG Optimus One - LG-P500h  
723. LG Optimus One - LG-P503  
724. LG Optimus One - LG-P504  
725. LG Optimus One - LG-P505  
726. LG Optimus One - LG-P505CH  
727. LG Optimus One - LG-P505R  
728. LG Optimus One - LG-P506  
729. LG Optimus One - LG-P509  
730. LG Optimus Regard - LG-LW770  
731. LG Optimus Select - LG-AS730  
732. LG Optimus Zone 2 - VS415PP  
733. LG Pecan - LG-P350  
734. LG Pecan - LG-P350f  
735. LG Pecan - LG-P350g  
736. LG Phoenix 2 - LG-K371  
737. LG Power - LGL22C  
738. LG Prime II - LG-X170fTV  
739. LG Prime II - LG-X170g  
740. LG Prime Plus 4G - LG-H522  
741. LG Q6 - LG-M700  
742. LG Q6 - LG-M700  
743. LG Q6 - LG-M703  
744. LG Q6 - LG-US700  
745. LG Q6 - LGM-X600K  
746. LG Q6 - LGM-X600L  
747. LG Q6 - LGM-X600S  
748. LG RAY - LG-X190  
749. LG Rebel - LGL43AL  
750. LG Rebel - LGL44VL  
751. LG Revolution - VS910 4G  
752. LG SUNSET - LGL33L  
753. LG Smart Folder - LGM-X100S  
754. LG Spectrum - VS920 4G  
755. LG Spirit - LG-H420  
756. LG Spirit 4G LTE - LG-H440n  
757. LG Spirit LTE - LG-H440  
758. LG Spirit LTE - LG-H440AR  
759. LG Stylo 2 - LG-K540  
760. LG Stylo 2 - LGL81AL  
761. LG Stylo 2 - LGL82VL  
762. LG Stylo 2 - LGLS775  
763. LG Stylo 2 Plus - LG-K550  
764. LG Stylo 2 Plus - LG-K557  
765. LG Stylo 2 Plus - LGMS550  
766. LG Stylo 3 Plus - LG-M470  
767. LG Stylo 3 Plus - LG-M470F  
768. LG Stylo 3 Plus - LG-TP450  
769. LG Stylo 3 Plus - LGMP450  
770. LG Stylo3 - LG-M430  
771. LG Stylo3 - LGL83BL  
772. LG Stylo3 - LGL84VL  
773. LG Stylo3 - LG-LS777  
774. LG Stylus 2 - LG-F720K  
775. LG Stylus 2 - LG-F720L  
776. LG Stylus 2 - LG-F720S  
777. LG Stylus 2 - LG-K520  
778. LG Stylus2 - LG-K520  
779. LG Stylus2 4G - LG-K530  
780. LG Stylus2 4G - LG-K535  
781. LG Stylus2 Plus - LG-K535  
782. LG Stylus2 Plus - LG-K535n  
783. LG Stylus3 - LG-M400  
784. LG Stylus3 - LG-M400  
785. LG Thrill 4G - LG-P925  
786. LG Treasure - LGL51AL  
787. LG Treasure - LGL52VL  
788. LG Tribute 2 - LGLS665  
789. LG Tribute 5 - LGLS675  
790. LG U - LG-F820L  
791. LG Venice - LG-LG730  
792. LG Viper 4G LTE - LG-LS840  
793. LG Volt - LG-H422  
794. LG Volt - LGLS740  
795. LG Volt 4G - LG-H442  
796. LG Volt II - LGLS751  
797. LG Volt LTE - LG-F540K  
798. LG Volt LTE - LG-F540L  
799. LG Volt LTE - LG-F540S  
800. LG Volt S - LG-F640S  
801. LG Watch Sport - LG Watch Sport  
802. LG Watch Style - LG Watch Style  
803. LG Watch Urbane - LG Watch Urbane  
804. LG Watch Urbane 2nd Edition LTE - LG Watch Urbane  
805. LG Wine Smart - LG-H410  
806. LG Wine Smart Jazz - LG-F610K  
807. LG Wine Smart Jazz - LG-F610S  
808. LG X Screen - LGK500J  
809. LG X Skin - LG-F740L  
810. LG X Style - LG-K200  
811. LG X Style - LGL53BL  
812. LG X Style - LGL56VL  
813. LG X Style - LGLS676  
814. LG X Venture - LG-US701  
815. LG X Venture - LG-H700  
816. LG X Venture - LG-M710  
817. LG X Venture - LG-M710ds  
818. LG X cam - LG-F690L  
819. LG X cam - LG-F690S  
820. LG X cam - LG-K580  
821. LG X cam - LG-K580  
822. LG X cam - LG-K580Y  
823. LG X charge - LG-M322  
824. LG X charge - LG-M327  
825. LG X max - LG-K240  
826. LG X power - LG-K210  
827. LG X power - LG-K212  
828. LG X power - LG-K450  
829. LG X power - LGUS610  
830. LG X power - LG-F750K  
831. LG X power - LG-K220  
832. LG X power - LGLS755  
833. LG X power - LG-K220  
834. LG X screen - LG-F650K

835. LG X screen - LG-F650L  
836. LG X screen - LG-F650S  
837. LG X screen - LG-K500  
838. LG X screen - LGS02  
839. LG X screen - LG-K500  
840. LG X screen - LG-K500n  
841. LG X300 - LGM-K120K  
842. LG X300 - LGM-K120L  
843. LG X300 - LGM-K120S  
844. LG X400 - LGM-K121K  
845. LG X400 - LGM-K121L  
846. LG X400 - LGM-K121S  
847. LG X400 - LGM-X301K  
848. LG X400 - LGM-X301L  
849. LG X400 - LGM-X301S  
850. LG X400 - LGM-X401L  
851. LG X400 - LGM-X401S  
852. LG X5 - LG-F770S  
853. LG X500 - LG-M320  
854. LG X500 - LGM-X320K  
855. LG X500 - LGM-X320L  
856. LG X500 - LGM-X320S  
857. LG ZONE - LG-X180g  
858. LG Zero - LG-H650  
859. LG optimus it L-05D - L-05D  
860. LG optimus it L-05E - L-05E  
861. LG-AS876 - AS876  
862. LG-D150 - LG-D150  
863. LG-D157f - LG-D157f  
864. LG-E985T - LG-E985  
865. LG-E985T - LG-E985T  
866. LGL22 - LGL22  
867. Marquee - L-07C  
868. Marquee - LG-LG855  
869. Marquee - LG-LS855  
870. Marquee - LG-P970  
871. My touch 4G - LG-E739  
872. Nexus 4 - Nexus 4  
873. Nexus 5 - Nexus 5  
874. Nexus 5X - Nexus 5X  
875. Optiimus Black - LG-P970  
876. Optimus EX - LG-SU880  
877. Optimus LTE - LG-P870  
878. Optimus 2 - LG-AS680  
879. Optimus 2X - LG-P990  
880. Optimus 2X - LG-P990H  
881. Optimus 2X - LG-P990h  
882. Optimus 2X - LG-P990  
883. Optimus 2X - LG-P990  
884. Optimus 2X - LG-P990  
885. Optimus 2X - LG-P990hN  
886. Optimus 2X - LG-P999  
887. Optimus 2X - LG-P990  
888. Optimus 2X - LG-SU660  
889. Optimus 2X - LG-SU660  
890. Optimus 2X - LG-SU660  
891. Optimus 3D - LG-SU760  
892. Optimus 3D - LG-P920  
893. Optimus 3D - LG-P920  
894. Optimus 3D - LG-P920  
895. Optimus 3D - LG-P920h  
896. Optimus 3D - LG-SU760  
897. Optimus 3D Cube - LG-SU870  
898. Optimus 3D MAX - LG-P720  
899. Optimus 3D MAX - LG-P720h  
900. Optimus 3D MAX - LG-P725  
901. Optimus 3D MAX - LG-SU870  
902. Optimus 4X HD - LG-P880  
903. Optimus 4X HD - LG-P880g  
904. Optimus Big - LG-LU6800  
905. Optimus Big - LG-LU6800  
906. Optimus Black - LGL85C  
907. Optimus Black - LG-KU5900  
908. Optimus Black - LG-P970  
909. Optimus Black - LG-P970h  
910. Optimus Black - LG-P970  
911. Optimus Black - LG-P970  
912. Optimus Black - LG-P970g  
913. Optimus Black - LG-P970h  
914. Optimus Black - LG-P970h  
915. Optimus Black - LG-P970  
916. Optimus Black - LG-P970  
917. Optimus Black - LG-P970  
918. Optimus Black - LG-KU5900  
919. Optimus Black - LG-P970  
920. Optimus Black - LG-P970g  
921. Optimus Black - LG-P970h  
922. Optimus Chat - LG-C550  
923. Optimus Chat - LG-C555  
924. Optimus Core - LGL86C  
925. Optimus EX - IS11LG  
926. Optimus EX - LG-SU880  
927. Optimus Exceed 2 - LG-VS450PP  
928. Optimus F3 - LG-LS720  
929. Optimus F3 - LG-P655H  
930. Optimus F3 - LG-P655K  
931. Optimus F3 - LG-P659  
932. Optimus F3 - LG-P659H  
933. Optimus F3 - LGL25L  
934. Optimus F3 - LGMS659  
935. Optimus F5 - LG-P870h  
936. Optimus F5 - LG-P875  
937. Optimus F5 - LG-P875h  
938. Optimus F5 - AS870 4G  
939. Optimus F6 - LG-D500  
940. Optimus F6 - LG-D505  
941. Optimus F6 - LGMS500  
942. Optimus Fuel - LGL34C  
943. Optimus G Pro - L-04E  
944. Optimus GJ - LG-E975w  
945. Optimus GK - LG-F220K  
946. Optimus Hub - LG-C800  
947. Optimus Hub - LG-C800G  
948. Optimus Hub - LG-E510  
949. Optimus Hub - LG-E510f  
950. Optimus Hub - LG-E510g  
951. Optimus Hub - LG-E510g  
952. Optimus Hub - LG-E510g  
953. Optimus Hub - LG-E510f  
954. Optimus Hub - LG-E510g  
955. Optimus Hub - LG-E510g  
956. Optimus Hub - LG-E510f  
957. Optimus Hub - LG-E510  
958. Optimus Hub - LG-E510g

959. Optimus Hub - LG-E510f  
960. Optimus Hub - LG-E510  
961. Optimus Hub - LG-E510g  
962. Optimus Hub - LG-E510g  
963. Optimus Hub - LG-E510f  
964. Optimus L40 - LG-D160  
965. Optimus L40 - LG-D165  
966. Optimus L40 - LG-D165AR  
967. Optimus L40 - LG-D170  
968. Optimus L40 - LG-D175f  
969. Optimus L40 - LG-D180f  
970. Optimus L5 - LG-E610  
971. Optimus L5 - LG-E610v  
972. Optimus L5 - LG-E612  
973. Optimus L5 - LG-E612f  
974. Optimus L5 - LG-E612g  
975. Optimus L5 - LG-E617G  
976. Optimus L5 - LG-L40G  
977. Optimus L7II - LG-P716  
978. Optimus LIFE - L-02E  
979. Optimus LTE - L-01D  
980. Optimus LTE - LG-SU640  
981. Optimus LTE - LG-LU6200  
982. Optimus LTE - LG-P936  
983. Optimus LTE - LG-P930  
984. Optimus LTE - LG-P935  
985. Optimus Mach - LG-LU3000  
986. Optimus Mach - LG-LU3000  
987. Optimus Mach - LG-LU3000  
988. Optimus Net - LG-P690b  
989. Optimus Net - LG-P690  
990. Optimus Net - LG-P690  
991. Optimus Net - LGL45C  
992. Optimus Net Dual - LG-P698  
993. Optimus Net Dual - LG-P698  
994. Optimus Net Dual - LG-P698  
995. Optimus Net Dual - LG-P698f  
996. Optimus Net Dual - LG-P698  
997. Optimus One - LG-KU3700  
998. Optimus One - LG-LU3700  
999. Optimus One - LG-SU370  
1000. Optimus One - LG-SU370  
1001. Optimus One - LG-KU3700  
1002. Optimus One - LG-LU3700  
1003. Optimus One - LG-CX670  
1004. Optimus One - LG-LW690  
1005. Optimus One - LG-MS690  
1006. Optimus One - LG-US670  
1007. Optimus One - LS670  
1008. Optimus One - VM670  
1009. Optimus One - Vortex  
1010. Optimus One - thunderc  
1011. Optimus PAD LTE - LG-LU8300  
1012. Optimus Pad - L-06C  
1013. Optimus Pad - LG-V900  
1014. Optimus Pad - LG-V900  
1015. Optimus Pad - LG-V901  
1016. Optimus Pad - LG-V901  
1017. Optimus Pad - LG-V901  
1018. Optimus Pad - LG-V905R  
1019. Optimus Pad - LG-V909  
1020. Optimus Pad - LG-V909  
1021. Optimus Plus - LG-AS695  
1022. Optimus Pro - LG-C660  
1023. Optimus Pro - LG-C660R  
1024. Optimus Pro - LG-C660h  
1025. Optimus Q - LGL55C  
1026. Optimus Q2 - LG-LU6500  
1027. Optimus Q2 - LG-LU6500  
1028. Optimus Slider - LG-VM701  
1029. Optimus Sol - LG-E730  
1030. Optimus Sol - LG-E730f  
1031. Optimus Spirit - LG-P690f  
1032. Optimus Spirit - LG-P690  
1033. Optimus Vu - LG-F100L  
1034. Optimus Vu - LG-F100L  
1035. Optimus Vu - LG-F100S  
1036. Optimus Vu - L-06DJOJO  
1037. Optimus Vu - LG-F100L  
1038. Optimus Vu - LG-F100S  
1039. Optimus Vu - LG-F100S  
1040. Optimus Vu - LG-P895  
1041. Optimus Vu - LG-P895qb  
1042. Optimus Vu2 - LG-F200K  
1043. Optimus Vu2 - LG-F200S  
1044. Optimus Vu2 - LG-F200L  
1045. Optimus Vu2 - LG-F200LS  
1046. Optimus Vu: - L-06D  
1047. Optimus Z - SU950  
1048. Optimus Zone - LG-VS410PP  
1049. Optimus chat - L-04C  
1050. PRADA 3.0 - L-02D  
1051. PRADA 3.0 - LG-KU5400  
1052. PRADA 3.0 - LG-LU5400  
1053. PRADA 3.0 - LG-P940  
1054. PRADA 3.0 - LG-P940h  
1055. PRADA 3.0 - LG-SU540  
1056. PecanV - LG-P355  
1057. Phoenix 3 - LG-M150  
1058. Premier - LGL61AL  
1059. Premier - LGL62VL  
1060. Q8 - LG-H970  
1061. Q8 - LGM-X800K  
1062. Q8 - LGM-X800L  
1063. Qua phone PX - LGV33  
1064. Qua tab PX - LGT31  
1065. Qua tab PZ - LGT32  
1066. Rebel 3 - LGL158VL  
1067. Rebel 3 - LGL58VL  
1068. Shine Plus with Google - LG-C710h  
1069. Smart Dios V8700 - ref\_SCTF  
1070. Spectrum - VS920 4G  
1071. Spectrum 2 - VS930 4G  
1072. Spirit 4G - LG-MS870  
1073. Splendor - LG-US730  
1074. Spray - 402LG  
1075. Spree - LG-K120  
1076. Stylo 2 V - VS835  
1077. Swift - GT540  
1078. Swift - GT540GO  
1079. Swift - GT540R  
1080. Swift - GT540f  
1081. TBD - LG-F520K  
1082. Thrill 4G - LG-P925



1083. Thrill 4G - LG-P925  
1084. V10 - LG-F600K  
1085. V10 - LG-F600L  
1086. V10 - LG-F600S  
1087. V10 - LG-H900  
1088. V10 - LG-H900PR  
1089. V10 - LG-H901  
1090. V10 - LG-H960  
1091. V10 - LG-H961AN  
1092. V10 - LG-H961N  
1093. V10 - LG-H961S  
1094. V10 - LG-H962  
1095. V10 - LG-H968  
1096. V10 - RS987  
1097. V10 - VS990  
1098. V20 - LG-F800K  
1099. V20 - LG-F800L  
1100. V20 - LG-F800S  
1101. V20 - LG-H910  
1102. V20 - LG-H910PR  
1103. V20 - LG-H915  
1104. V20 - LG-H918  
1105. V20 - LG-H990  
1106. V20 - LG-LS997  
1107. V20 - LG-US996  
1108. V20 - LGV34  
1109. V20 - VS995  
1110. V20 PRO - L-01J  
1111. V30 - LG-H930  
1112. V30 - LG-H931  
1113. V30 - LG-H932  
1114. V30 - LG-H932PR  
1115. V30 - LG-H933  
1116. V30 - LG-LS998  
1117. V30 - LG-US998  
1118. V30 - LGM-V300K  
1119. V30 - LGM-V300L  
1120. V30 - LGM-V300S  
1121. V30 - VS996  
1122. VU3 - LG-F300K  
1123. VU3 - LG-F300L  
1124. VU3 - LG-F300S  
1125. Wine Smart - LGS01  
1126. Wine Smart - LG-D486  
1127. Wine Smart - LG-F480K  
1128. Wine Smart - LG-F480L  
1129. Wine Smart - LG-F480S  
1130. Wine Smart 3G - LG-T480K  
1131. Wine Smart 3G - LG-T480S  
1132. X Mach - LG-K600  
1133. X charge - LG-SP320  
1134. Y25 - LGL15G  
1135. Y25 - LGL16C  
1136. Zone3 - VS425PP

## **LGU+**

1. TV G - TI320-DU
2. U+ tv UHD - ST940I-UP
3. U+ tv woofer - LAP250U
4. U+ tv woofer 1.5 - LAP255U
5. U+tv UHD2 - S60UPI
6. U+tv soundbar - S60UPA

7. WA-U420D - WA-U420D

## **LIAONING YIYATONG**

1. DISNEY\_Tablet\_PC - DS2310-70LP
2. IRULU\_MID - X10

## **LINSAY**

1. F-7HD2CORE / F-7HD4CORE / F-10HD2CORE / F-10XHD4CORE - LINSAY  
F-7HD2CORE/F-7HD4CORE/F-10HD2CORE/F-10XHD4  
CORE

## **LT Electronics**

1. LT\_C2100 - LT\_C2100
2. LT\_S9\_NOTE - LT\_S9\_NOTE

## **LUVVO**

1. 001 - Luvo 001
2. 001L - LUVVO 001L

## **LUXYA**

1. MID704DC Tablet / Bitmore Tab770 - MID704DC

## **Laiq**

1. GLAM - LAIQ Glam
2. Glow - Glow
3. STARTRAIL 8 - STARTRAIL 8

## **Lanix**

1. ILIUM L1000 - ILIUM L1000
2. ILIUM L1000 - Ilium\_L1000
3. ILIUM L200 - ILIUM L200
4. ILIUM L820 - Ilium L820
5. ILIUM L900 - ILIUM L900
6. ILIUM L950 - ILIUM L950
7. ILIUM L950 - Ilium\_L950
8. ILIUM PAD E10Si - ILIUM PAD E10Si
9. ILIUM PAD E8 V6 - ILIUM PAD E8 V6
10. ILIUM PAD I8 - ilium PAD i8 v3
11. ILIUM S670 - ILIUM S670
12. ILIUM X110 - ILIUM X110
13. Ilium L1050 - Ilium L1050
14. Ilium L1100 - ILIUM L1100
15. Ilium L1120 - Ilium L1120
16. Ilium L1200 - Ilium L1200
17. Ilium L1300 - Ilium L1300
18. Ilium L420 - Ilium L420
19. Ilium L420 - Lanix Ilium L420
20. Ilium L610 - Ilium L610
21. Ilium L620 - Ilium L620
22. Ilium L920 - Ilium L920
23. Ilium LT500 - Ilium LT500
24. Ilium LT510 - Ilium LT510
25. Ilium LT520 - Ilium LT520
26. Ilium PAD i7 - Ilium PAD i7
27. Ilium PAD i7 v2 - Ilium PAD i7 v2
28. Ilium Pad L8X - Ilium Pad L8X
29. Ilium Pad T7X - Ilium Pad T7X
30. Ilium X120 - Ilium X120



31. Ilium X120B - Ilium X120B
32. Ilium X200 - Ilium X200
33. Ilium X210 - Ilium X210
34. Ilium X220 - Ilium X220
35. Ilium X260 - Ilium X260
36. Ilium X500B - Ilium X500B
37. Ilium X510 - Ilium X510
38. Ilium X520 - Ilium X520
39. Ilium X710 - Ilium X710
40. Ilium\_L1100 - ILIUM L1100
41. Ilium\_S130 - Ilium S130
42. Ilium\_S130 - Ilium\_S130
43. Ilium\_S520 - ILIUM S520
44. Ilium L910 - Ilium L910
45. X100 - ILIUM\_X100
46. X400 - ILIUM\_X400
47. ilium PAD E9 - ilium PAD E9
48. ilium PAD E7 - ilium PAD E7
49. ilium PAD E8 - ilium PAD E8
50. ilium PAD E9 - ilium Pad E9
51. ilium PAD i7 - Ilium\_PAD\_i7
52. ilium Pad E7 - ilium\_Pad\_E7
53. ilium\_S106 - Ilium S106
54. Ilium Pad L8 - Ilium Pad L8

## Lark

1. Cumulus 5 HD - Cumulus\_5\_HD
2. Cumulus 5.5 HD - Cumulus\_5.5\_HD
3. Cumulus 6 HD - Cumulus\_6\_HD
4. Impress\_Noda - Impress\_Noda
5. PHABLET 7 - PHABLET 7
6. Ultimate X4 10.1 3G IPS - Ultimate X4 10.1 3G IPS
7. Ultimate X4 8s 3G - Ultimate X4 8s 3G

## Lava

1. A3 - LAVA\_A3
2. A3\_mini - A3\_mini
3. A44 - LAVA\_A44
4. A50 - A50
5. A52 - A52
6. A55 - A55
7. A67 - A67
8. A68 - A68
9. A71 - A71
10. A72 - A72
11. A73 - A73
12. A76Plus - A76Plus
13. A76plus - A76Plus
14. A77 - A77
15. A79 - A79
16. A82 - A82
17. A89 - Lava A89
18. A97 - A97
19. A97 - A97 IPS
20. A97 2GB - A97 2GB
21. A97 2GB Plus - A97 2GB PLUS
22. ERA 1X - era1X
23. ERA 1X - era1Xpro
24. Era 2X 3GB - Era 2X 3GB
25. Era 4G - era\_4G
26. Flair P3 - P3

27. Flair S1 - S1
28. Iris 505 - iris505
29. Iris820 - iris820
30. P7 - P7
31. P7 Plus - P7plus
32. P7plus - P7plus
33. Pixel V1 - PixelV1
34. Pixel V1 - PixelV1
35. R1 - LAVA\_R1
36. R2 - R2
37. V2 3GB - V23GB
38. V2s - V2s
39. V2s - V2s M
40. V5 - LAVA V5
41. V5 - V5
42. X10 - LavaX10
43. X10 - X10
44. X11 - X11
45. X12 - X12
46. X17 - X17
47. X19 - X19
48. X28 - X28
49. X28 Plus - X28 Plus
50. X28plus - X28 Plus
51. X3 - X3
52. X38 - X38
53. X38 2GB - X38 2GB
54. X41 - X41
55. X41Plus - X41 Plus
56. X46 - X46
57. X50 - X50
58. X50 Plus - X50 Plus
59. X81 - X81
60. XOLO ERA 3X - era3x
61. XOLO LT900 - LT900
62. XOLO One HD - XOLO One HD
63. XOLO era 4K - era 4K
64. Xolo Era 2X - Era 2X
65. Xolo Era X - era\_X
66. Xolo era 2 - era 2
67. Z10 - Z10
68. Z25 - Z25
69. Z60 - Z60
70. Z70 - Z70
71. Z80 - Z80
72. Z90 - Z90
73. iris 821 - iris821
74. iris 880 - iris880
75. iris Fuel F2 - Fuel F2
76. iris atom - A1
77. iris atom 3 - A3
78. iris30 - iris30
79. iris40 - iris40
80. iris50 - iris50
81. iris512 - iris512
82. iris515 - iris515
83. iris53 - iris53
84. iris560 - iris560
85. iris565 - iris565
86. iris60 - iris60
87. iris605 - iris605
88. iris702 - iris702

89. iris80 - iris80
90. iris870 - iris870

## Lazer

1. MD1005 Tablet - MD1005
2. MID9526CM - S952
3. MW-7615P - MW-7615P
4. MW6617 - MW6617
5. MY1306P - MY1306P
6. X4508 - X4508

## Le

1. LeTV X40 - X4-40

## Le Pan

1. TC1010 - Le Pan TC1010
2. TC1020 - Le Pan TC1020
3. TC802A - Le Pan TC802A

## LeTV

1. Le 2 - Le X520
2. Le 2 - Le X526
3. Le 2 - Le X527
4. Le Max - Le Max
5. Le X507 - Le X507
6. Le X507 - Le X509
7. Le X509 - Le X509
8. Le1 - x600
9. Max3-65 - Max3-65
10. Super TV X3-55 Pro - X3-55 Pro
11. uMax85 - uMax85
12. x600 - X600

## Lechpol

1. LIVE 4 KM0438 - LIVE4\_KM0438
2. LIVE 4 KM0439 - KrugerMatz\_LIVE4
3. LIVE 4 KM0439 - LIVE4\_KM0439
4. MOVE 6 mini - MOVE\_6\_mini

## Leeco

1. Le Max2 - Le X820
2. Le Max2 - Le X821
3. Le Max2 - Le X829
4. Le Pro3 - LEX725
5. Le Pro3 - LEX727
6. Le S3 - Le X522
7. Le s2 - Le X520
8. LePro3 - LEX725
9. LePro3 - LEX727
10. LeoPro3 - LEX725
11. X Serials(X43 Pro, X55, X65) - X4-55

## Lenovo

1. 18382AU - ThinkPad Tablet
2. A1\_07 - A1\_07
3. A2109A - IdeaTabA2109A
4. A2207A-H - IdeaTabA2207A-H
5. A278t - Lenovo A278t
6. A288t - Lenovo A288t

7. A298t - Lenovo A298t
8. A30t - A30t
9. A530\_msm7627a\_alps - Lenovo A530
10. A560e\_msm7627a - LNV-Lenovo\_A560e
11. A580 - Lenovo A580
12. A600e\_msm8625 - LNV-Lenovo A600e
13. A60plus - Lenovo A60+
14. A630 - Lenovo A630
15. A660 - Lenovo A660
16. A668t - Lenovo A668t
17. A690 - Lenovo A690
18. A700e - Lenovo A700e
19. A710e\_msm7627a - Lenovo A710e
20. A780\_msm7627a - Lenovo A780
21. A789 - Lenovo A789
22. A798t - Lenovo A798t
23. A800 - Lenovo A800
24. Android - Lenovo A60+
25. K1 - K1
26. K2110A-F - IdeaTab K2110A-F
27. LIFETAB\_S9512 - LIFETAB\_S9512
28. Lenovo\_S2 - Lenovo S2-38AH0
29. MD\_LIFETAB\_P9516 - MD\_LIFETAB\_P9516
30. P700i - Lenovo P700i
31. P770 - Lenovo P770
32. S2005A-H - S2005A-H
33. S2109A - IdeaTabS2109A-F
34. S560 - Lenovo S560
35. S880i - Lenovo S880i
36. S890 - Lenovo S890
37. S899t - Lenovo S899t
38. S920\_ROW - Lenovo S920
39. S920\_ROW - Lenovo S920\_ROW
40. SmartTabII7 - SmartTabII7
41. T702T - A66t
42. a2\_3g\_data - IdeaTab A2107A-H
43. a2\_wifi - IdeaTab A2107A-F
44. a2\_wifi\_row - IdeaTab A2107A-F
45. a326 - Lenovo A326
46. a360 - Lenovo A360
47. a370 - Lenovo A370
48. a500plus - Lenovo A500+
49. a520\_gray - Lenovo A520GRAY
50. a59wg - Lenovo A500
51. a59wg - Lenovo A500+
52. a60\_campus - Lenovo A60
53. a60id\_tel - Lenovo A60
54. a60os - Lenovo A60
55. a60tw - Lenovo A60
56. a65 - Lenovo A65
57. a65\_ph\_id\_vn - Lenovo A65
58. a65cu - Lenovo A65
59. amazon\_w - Lenovo A1-32AB0
60. apollo\_td - Lenovo S2-38AT0
61. apollo\_wg - Lenovo S2-38AH0
62. apollohd\_w - Lenovo K2
63. apollozero\_w - Lenovo S760
64. aruba - Lenovo A765e
65. austin - Lenovo A300
66. ideatv\_S31 - ideatv S31
67. lenovo13\_td - Lenovo A366t
68. lenovo15\_td\_ics - Lenovo A698t

69. lenovo73\_cu - Lenovo A60
70. lenovo73\_gb - Lenovo A520
71. lenovo73\_gb - Lenovo P70
72. lenovo75\_a2\_att\_ics - A2107A-H
73. lenovo75\_a2\_ics - IdeaTab A2107A-H
74. lenovo75\_cu\_gb - Lenovo A750
75. lenovo75\_cu\_ics - Lenovo A750
76. mflid\_pr2 - Lenovo K800
77. mi\_350 - Spice Mi-350
78. msm7627\_ea95 - Lenovo A390e
79. msm7627\_surf - A68e
80. msm7627\_surf - Lenovo A68e
81. msm7627a - LNV-Lenovo A790e
82. msm7627a\_ha99 - Lenovo A780
83. msm8660\_surf - IdeaTab S2007A-F
84. msm8660\_surf - IdeaTab S2007A-H
85. msm8660\_surf - IdeaTab S2010A-D
86. msm8660\_surf - IdeaTab S2010A-F
87. msm8660\_surf - IdeaTab S2010A-H
88. msm8960 - IdeaTabS2110AF
89. msm8960 - IdeaTabS2110AH
90. msm8960 - SmartTabII10
91. p700 - Lenovo P700
92. p700\_ph - Lenovo P700
93. s880 - Lenovo S880
94. s880\_row - Lenovo S880
95. sanpaolo - IdeaTabV2007A
96. santiago - IdeaTabV2010A
97. santiago - IdeaTabV2010A-W
98. sicily - Lenovo S696
99. stuttgart\_row - Lenovo K860
100. ventana - K1
101. \t Lenovo YOGA Laptop with Android - Lenovo YB-Q501F
102. 32A3 40A3 43A3 49A3 - LenovoTV 32A3
103. 55E82,49E82,50U3A,58U3A,70UD30A,60UD30A,80U D30A,65UR30A - AQUOS 50U3A
104. 55E82,49E82,50U3A,58U3A,70UD30A,60UD30A,80U D30A,65UR30A - AQUOS 65UR30A
105. 55E82,49E82,50U3A,58U3A,70UD30A,60UD30A,80U D30A,65UR30A - AQUOS 70UD30A
106. 55E82,49E82,50U3A,58U3A,70UD30A,60UD30A,80U D30A,65UR30A - AQUOS 70UG30A
107. 55E82,49E82,50U3A,58U3A,70UD30A,60UD30A,80U D30A,65UR30A - AQUOS 70XU30A
108. 55E82,49E82,50U3A,58U3A,70UD30A,60UD30A,80U D30A,65UR30A - LenovoTV 49E82
109. 55E82,49E82,50U3A,58U3A,70UD30A,60UD30A,80U D30A,65UR30A - LenovoTV 55E82
110. 60K72 - ideatv K72
111. A10 - IdeaPadA10
112. A10-70LC - Lenovo TAB 2 A10-70LC
113. A1000 - Lenovo A1000
114. A1000 - IdeaTabA1000-F
115. A1000-G - IdeaTabA1000-G
116. A1000L - IdeaTabA1000L-F
117. A1000m - Lenovo A1000m
118. A1010 - Lenovo A1010a20
119. A1900 - Lenovo A1900
120. A2010-a - Lenovo A2010-a
121. A2010I36 - Lenovo A2010I36
122. A2016a40 - Lenovo A2016a40
123. A2016b30 - Lenovo A2016b30
124. A2016b31 - Lenovo A2016b31
125. A2020a40 - Lenovo A2020a40
126. A2020a40 - Lenovo A2020a40
127. A208t - Lenovo A208t
128. A2105 - Lenovo\_A2105
129. A2107A - A2107A-H
130. A218t - Lenovo A218t
131. A228t - Lenovo A228t
132. A238t - Lenovo A238t
133. A2580 - Lenovo A2580
134. A269 - Lenovo A269
135. A269i - Lenovo A269i
136. A278t - Lenovo A278t
137. A2800 - Lenovo A2800-d
138. A2860 - Lenovo A2860
139. A3000 - Lenovo A3000-H
140. A300t - Lenovo A300t
141. A305E - LNV-Lenovo A305e
142. A305E - Lenovo A305e
143. A308t - Lenovo A308t
144. A316 - Lenovo A316
145. A316i - Lenovo A316i
146. A318t - Lenovo A318t
147. A319 - Lenovo A319
148. A31910t30 - Lenovo A3910t30
149. A320t - Lenovo A320t
150. A328 - Lenovo A328
151. A328t - Lenovo A328t
152. A3300 - LenovoA3300-H
153. A3300 - Lenovo A3300-T
154. A3300-GV - LenovoA3300-GV
155. A3300-HV - Lenovo A3300-HV
156. A330e - Lenovo A330e
157. A338t - Lenovo A338t
158. A3500 - Lenovo A3500
159. A3500 - Lenovo A3500-HV
160. A3500-F - EveryPad2
161. A3500-F - Lenovo A3500-F
162. A3500-FL - Lenovo A3500-FL
163. A3500-H - Lenovo A3500-H
164. A355e - Lenovo A355e
165. A358t - Lenovo A358t
166. A3600-D - Lenovo A3600-d
167. A3600u - Lenovo A3600u
168. A360e - Lenovo A360e
169. A360t - Lenovo A360t
170. A368t - Lenovo A368t
171. A369 - Lenovo A369
172. A369i - Lenovo A369i
173. A370e - LNV-Lenovo A370e
174. A375e - LNV-Lenovo A375e
175. A376 - Lenovo A376
176. A378t - Lenovo A378t
177. A3800-D - Lenovo A3800-d
178. A380e - LNV-Lenovo A380e
179. A380t - Lenovo A380t
180. A385e - LNV-Lenovo A385e
181. A3860 - Lenovo A3580
182. A3860 - Lenovo A3860
183. A388t - Lenovo A388t
184. A390 - Lenovo A390



185. A390 - Lenovo A390\_ROW  
186. A3900 - Lenovo A3900  
187. A390t - Lenovo A390t  
188. A395e - LNV-Lenovo A395e  
189. A396 - Lenovo A396  
190. A396 - Lenovo A396\_TY  
191. A398t - Lenovo A398t  
192. A398t+ - Lenovo A398t+  
193. A399 - Lenovo A399  
194. A5000 - Lenovo A5000  
195. A505e - LNV-Lenovo A505e  
196. A516 - Lenovo A516  
197. A516 - Lenovo A516  
198. A526 - Lenovo A526  
199. A529 - Lenovo A529  
200. A536 - Lenovo A536  
201. A5500 - Lenovo A5500  
202. A5500-F - Lenovo A5500-F  
203. A5500-H - Lenovo A5500-H  
204. A5500-HV - Lenovo A5500-HV  
205. A560 - Lenovo A560  
206. A560 - LNV-Lenovo A560  
207. A5800-D - Lenovo A5800-D  
208. A588t - LenovoA588t  
209. A6000 - Lenovo A6000  
210. A6000-l - Lenovo A6000-l  
211. A6010 - Lenovo A6010  
212. A606 - Lenovo A606  
213. A616 - Lenovo A616  
214. A628t - Lenovo A628t  
215. A630 - LNV-Lenovo A630e  
216. A656 - Lenovo A656  
217. A658T - Lenovo A658t  
218. A6600 - Lenovo A6600d40  
219. A6600 Plus - Lenovo A6600a40  
220. A670t - Lenovo A670t  
221. A678t - Lenovo A678t  
222. A680 - Lenovo A680  
223. A680 - Lenovo A680\_ROW  
224. A6800 - Lenovo A6800  
225. A688t - Lenovo A688t  
226. A690e - LNV-Lenovo A690e  
227. A7-30GC - Lenovo TAB 2 A7-30GC  
228. A7-30H - Lenovo TAB 2 A7-30D  
229. A7-30H - Lenovo TAB 2 A7-30H  
230. A7-60HC - Lenovo A7-60HC  
231. A7000 - Lenovo A7000-a  
232. A7000 Plus - Lenovo A7000-a  
233. A706 - Lenovo A706  
234. A706\_ROW - Lenovo A706\_ROW  
235. A720e - Lenovo A720e  
236. A750e - Lenovo A750e  
237. A760 - Lenovo A760  
238. A7600 - Lenovo A7600  
239. A7600 - Lenovo A7600-m  
240. A7600 - Lenovo A7600  
241. A7600-F - Lenovo A7600-F  
242. A7600-H - Lenovo A7600-H  
243. A7600-HV - Lenovo A7600-HV  
244. A766 - Lenovo A766  
245. A768t - Lenovo A768t  
246. A7700 - A7700  
247. A7700 - Lenovo A7700  
248. A770e - Lenovo A770e  
249. A780e - LNV-Lenovo A780e  
250. A785e - LNV-Lenovo A785e  
251. A788t - Lenovo A788t  
252. A8-50 - Lenovo TAB 2 A8-50L  
253. A8-50 - Lenovo 2 A8-50LC  
254. A8-50 - Lenovo TAB 2 A8-50LC  
255. A805e - Lenovo A805e  
256. A806 - Lenovo A806  
257. A808t - Lenovo A808t  
258. A808t-i - Lenovo A808t-i  
259. A816 - Lenovo A5100  
260. A816 - Lenovo A816  
261. A820 - Lenovo A820  
262. A820e - Lenovo A820e  
263. A820t - Lenovo A820t  
264. A828 - Lenovo A858  
265. A828t - Lenovo A828t  
266. A830 - Lenovo A830  
267. A850 - Lenovo A850  
268. A850 - Lenovo A850  
269. A850+ - Lenovo A850+  
270. A858t - Lenovo A858t  
271. A859 - Lenovo A859  
272. A860e - Lenovo A860e  
273. A889 - Lenovo A889  
274. A890e - Lenovo A890e  
275. A916 - Lenovo A916  
276. A936 - Lenovo A936  
277. A938t - Lenovo A938t  
278. B6000-F - Lenovo B6000-F  
279. B6000-H - Lenovo B6000-H  
280. B6000-HV - Lenovo B6000-HV  
281. B8000-F - Lenovo B8000-F  
282. B8000-H - Lenovo B8000-H  
283. B8080 - Lenovo B8080-F  
284. B8080-H - Lenovo B8080-H  
285. B8080-HV - Lenovo B8080-HV  
286. E4002 - MEDION E4002  
287. EveryPad - EveryPad  
288. EveryPad - IdeaTab A3000-F  
289. EveryPad2 - EveryPad2  
290. IdeaTV - ideatv K91  
291. IdeaTab A1000 - LenovoA1000L-F  
292. IdeaTab A1010 - IdeaTabA1010-T  
293. IdeaTab A1020 - IdeaTabA1020-T  
294. IdeaTab A3000 - IdeaTab A3000-H  
295. IdeaTab A3000 - Vodafone Smart Tab III 7  
296. IdeaTab A5000 - IdeaTabA5000-E  
297. IdeaTab S6000 - IdeaTab S6000-F  
298. IdeaTab S6000 - IdeaTab S6000-H  
299. IdeaTab S6000 - Vodafone Smart Tab III 10  
300. Indigo - ThinkPad Tablet  
301. K1 - K1  
302. K10e70 - Lenovo K10e70  
303. K3 Note - Lenovo K50a40  
304. K3 Note - Lenovo K50-t3s  
305. K3 Note - Lenovo K50-T5  
306. K3 Note - Lenovo K50-t5  
307. K30-E - Lenovo K30-E  
308. K30-T - Lenovo K30-T



309. K30-TM - Lenovo K30-TM  
310. K30-W - Lenovo K30-W  
311. K32 - Lenovo K32c36  
312. K32c30 - Lenovo K32c30  
313. K5 - Lenovo A6020a40  
314. K5 - Lenovo A6020a41  
315. K5 - Lenovo A6020I36  
316. K5 - Lenovo A6020I37  
317. K5 Note - Lenovo A7020a40  
318. K5 Note - Lenovo A7020a48  
319. K5 Note - Lenovo K52e78  
320. K5 Note - Lenovo K52t58  
321. K5 Plus - Lenovo A6020a46  
322. K50 - Lenovo K50-t5  
323. K50 - Lenovo K50-t3s  
324. K50-T5 - Lenovo K50-t5  
325. K52t38 - Lenovo K52t38  
326. K52t38 - Lenovo k52t38  
327. K800 - Lenovo K800  
328. K80M - Lenovo K80M  
329. K860 - Lenovo K860  
330. K860i - Lenovo K860i  
331. K900 - Lenovo K900  
332. K900 - Lenovo K900\_ROW  
333. K910 - Lenovo K910  
334. K910L - Lenovo K910L  
335. K910e - LNV-Lenovo K910e  
336. K910e - Lenovo K910e  
337. K920/VIBE Z2 - Lenovo K920  
338. K920/VIBE Z2 Pro - Lenovo K920  
339. LIFETAB E10310 - LIFETAB\_E10310  
340. LIFETAB E7310 - LIFETAB\_E7310  
341. LIFETAB E7310 - LIFETAB\_E7312  
342. Lenovo - Lenovo A708t  
343. Lenovo - Lenovo A880  
344. Lenovo - Lenovo PB1-770P  
345. Lenovo A3300 - LenovoA3300-GV  
346. Lenovo A3300 - LenovoA3300-HV  
347. Lenovo K8 - Lenovo K  
348. Lenovo K8 - Lenovo K8  
349. Lenovo K8 Note - Lenovo K8 Note  
350. Lenovo K8 Note - XT1902-3  
351. Lenovo K8 Plus - Lenovo K  
352. Lenovo K8 Plus - Lenovo K8 Plus  
353. Lenovo N Series Chromebook - Braswell Chrome OS Device  
354. Lenovo N300 - Lenovo N300  
355. Lenovo S820 - Lenovo S820  
356. Lenovo TAB - Lenovo TB-8803F  
357. Lenovo TAB 7 - Lenovo TB-7504F  
358. Lenovo TAB 7 - Lenovo TB-7504N  
359. Lenovo TAB 7 - Lenovo TB-7504X  
360. Lenovo Tab 7 Essential - Lenovo TB-7304I  
361. Lenovo Tab 7 Essential - Lenovo TB-7304I  
362. Lenovo Tab 7 Essential - Lenovo TB-7304N  
363. Lenovo Tab 7 Essential - Lenovo TB-7304X  
364. Lenovo Tab4 10 Plus - TB-X704A  
365. Lenovo X2-CU/VIBE X2 - Lenovo X2-CU  
366. Lenovo YOGA A12 - Lenovo YB-Q501L  
367. LenovoTAB2 A7-30DC - Lenovo TAB 2 A7-30DC  
368. LenovoTB-8704V - TB-8704V  
369. LenovoTB-X304F/Lenovo TAB4 - Lenovo TB-X304F  
370. LenovoTB-X304F/Lenovo TAB4 - TB-X304F  
371. LenovoTB-X704F/Lenovo TAB4 10 Plus - Lenovo TB-X704F  
372. LenovoTV 40S9;LenovoTV 50S9;AQUOS 40U1;AQUOS 50U1AQUOS 58U1; AQUOS 60LX765A - AQUOS 58U1  
373. LenovoTV 40S9;LenovoTV 50S9;AQUOS 40U1;AQUOS 50U1AQUOS 58U1; AQUOS 60LX765A - AQUOS 60LX765A  
374. LenovoTV 40S9;LenovoTV 50S9;AQUOS 40U1;AQUOS 50U1AQUOS 58U1; AQUOS 60LX765A - AQUOS 60UE20A  
375. LenovoTV 40S9;LenovoTV 50S9;AQUOS 40U1;AQUOS 50U1AQUOS 58U1; AQUOS 60LX765A - LenovoTV 40S9  
376. LenovoTV 40S9;LenovoTV 50S9;AQUOS 40U1;AQUOS 50U1AQUOS 58U1; AQUOS 60LX765A - LenovoTV 58S9  
377. LenovoTV 50S52;AQUOS LCD-50S1A - AQUOS 50S1  
378. LenovoTV 50S52;AQUOS LCD-50S1A - LenovoTV 50S52  
379. Lenovo S960 - Lenovo S960  
380. Moto E3 - XT1700  
381. Moto E3 Power - XT1706  
382. Motorola M - XT1663  
383. Motorola Moto M - XT1662  
384. N300 - Lenovo N300  
385. N308 - Lenovo N308  
386. NEC PC-TE507FAW - PC-TE507FAW  
387. NEC PC-TS508FAM - NEC PC-TS508FAM  
388. NEC PC-TS508FAM - PC-TS508FAM  
389. P1 - Lenovo P1a41  
390. P1 - Lenovo P1a42  
391. P1 - Lenovo P1c72  
392. P1 - Lenovo P1c58  
393. P2 - Lenovo P2a42  
394. P2 - Lenovo P2c72  
395. P70 - Lenovo P70-A  
396. P70 - Lenovo P70-t  
397. P780 - Lenovo P780  
398. P780 - Lenovo P780  
399. P780 - Lenovo P780\_ROW  
400. P90 - Lenovo P90  
401. PB1-750M/Lenovo PHAB - Lenovo PB1-750M  
402. PB1-770M/Lenovo PHAB Plus - EveryPad3  
403. PB1-770M/Lenovo PHAB Plus - Lenovo PB1-770M  
404. PB1-770N - Lenovo PB1-770N  
405. PB2 - Lenovo PB2-650M  
406. PB2 plus - Lenovo PB2-670M  
407. PB2-650Y - Lenovo PB2-650Y  
408. PC-TE510HAW - PC-TE510HAW  
409. PHAB 2 - Lenovo PB2-650N  
410. PHAB 2 Plus - Lenovo PB2-670N  
411. PHAB 2 Plus - Lenovo PB2-670Y  
412. PHAB2 Pro - Lenovo PB2-690M  
413. PHAB2 Pro - Lenovo PB2-690N  
414. PHAB2 Pro - Lenovo PB2-690Y  
415. S1 - Lenovo S1a40  
416. S1La40 - Lenovo S1La40  
417. S5000 - Lenovo S5000-F  
418. S5000 - Lenovo S5000-H  
419. S580 - Lenovo S580  
420. S60 - Lenovo S60-a

421. S60 - Lenovo S60-t  
422. S60 - Lenovo S60-w  
423. S6000L - Lenovo S6000L-F  
424. S61 - ideatv S61  
425. S650 - Lenovo S650  
426. S650\_ROW - Lenovo S650  
427. S658t - Lenovo S658t  
428. S660 - Lenovo S660  
429. S668t - Lenovo S668t  
430. S680 - Lenovo S680  
431. S686 - Lenovo S686  
432. S720 - Lenovo S720  
433. S750 - Lenovo S750  
434. S810t - Lenovo S810t  
435. S820 - Lenovo S820  
436. S820 - Lenovo S820  
437. S820 - Lenovo S820  
438. S820 - Lenovo S820\_ROW  
439. S820e - Lenovo S820e  
440. S850 - Lenovo S850  
441. S850e - Lenovo S850e  
442. S850t - Lenovo S850t  
443. S856 - Lenovo S856  
444. S856 - Lenovo S856  
445. S856 - Lenovo S856  
446. S856 - Lenovo S856  
447. S858t - Lenovo S858t  
448. S860 - Lenovo S860  
449. S860e - Lenovo S860e  
450. S868 - Lenovo S868t  
451. S870e - LNV-Lenovo S870e  
452. S870e - Lenovo S870e  
453. S898t - Lenovo S898t  
454. S898t+ - Lenovo S898t+  
455. S90 - Lenovo S90-e  
456. S90-A - Lenovo S90-A  
457. S90-L - Lenovo S90-L  
458. S90-T - Lenovo S90-t  
459. S90-U - Lenovo S90-u  
460. S920 - Lenovo S920  
461. S930 - Lenovo S930  
462. S930\_ROW - Lenovo S930  
463. S938t - Lenovo S938t  
464. S939 - Lenovo S939  
465. S960 - Lenovo S960  
466. S960 - Lenovo S960  
467. S968t - Lenovo S968t  
468. Softbank 501LV - 501LV  
469. TAB 10 - Lenovo TB-X103F  
470. TAB 2 A10 - Lenovo TAB 2 A10-70F  
471. TAB 2 A10 - Lenovo TAB 2 A10-70L  
472. TAB 2 A10 - Lenovo TAB 2 A10-70LC  
473. TAB 2 A7-10F - Tab2A7-10F  
474. TAB 2 A7-20F - Tab2A7-20F  
475. TAB 2 A7-30F - Lenovo TAB 2 A7-30F  
476. TAB 2 A7-30HC - Lenovo 2 A7-30HC  
477. TAB 2 A7-30HC - Lenovo TAB 2 A7-30HC  
478. TAB 2 A7-30TC - Lenovo 2 A7-30TC  
479. TAB 2 A8-50F - Lenovo 2 A8-50F  
480. TAB 2 A8-50F - Lenovo TAB 2 A8-50F  
481. TAB 3 850F - Lenovo TB3-850F  
482. TAB 3 850M - Lenovo TB3-850M  
483. TAB A10-80HC - TAB A10-80HC  
484. TAB S8-50F - Lenovo TAB S8-50F  
485. TAB S8-50L - Lenovo TAB S8-50L  
486. TAB S8-50LC - Lenovo S8-50LC  
487. TAB S8-50LC - Lenovo TAB S8-50LC  
488. TAB3 7 Plus - Lenovo TB-7703F  
489. TAB3 7 Plus - Lenovo TB-7703N  
490. TAB3 7 Plus - Lenovo TB-7703X  
491. TAB3 730F - Lenovo TB3-730F  
492. TAB3 730M - Lenovo TB3-730M  
493. TAB3 730X - Lenovo TB3-730X  
494. TAB3 8 Plus - Lenovo TB-8703R  
495. TAB3 X70L - Lenovo TB3-X70L  
496. TAB3 X70N - Lenovo TB3-X70N  
497. TAB4 10 - Lenovo TB-X304L  
498. TAB4 10 - Lenovo TB-X304N  
499. TAB4 10 - TB-X304N  
500. TAB4 10 - Lenovo TB-X304X  
501. TAB4 10 Plus - Lenovo TB-X704L  
502. TAB4 10 Plus - Lenovo TB-X704N  
503. TAB4 10 Plus - TB-X704V  
504. TAB4 10 Plus - Lenovo TB-X704Y  
505. TAB4 8 - Lenovo TB-8504F  
506. TAB4 8 - Lenovo TB-8504L  
507. TAB4 8 - Lenovo TB-8504N  
508. TAB4 8 - Lenovo TB-8504X  
509. TB-8604F - Lenovo TB-8604F  
510. TB-8704F - Lenovo TB-8704F  
511. TB-8704N - Lenovo TB-8704N  
512. TB-8704X - Lenovo TB-8704X  
513. TB-8804F - Lenovo TB-8804F  
514. TB-8X04F - Lenovo TB-8X04F  
515. TB2-X30F - Lenovo TB2-X30F  
516. TB2-X30F - Lenovo TB2-X30F\_HFT  
517. TB2-X30F - Lenovo TB2-X30F\_JLC  
518. TB2-X30F - Lenovo TB2-X30F\_SCP  
519. TB2-X30F - Lenovo TB2-X30F\_UK  
520. TB2-X30F - Lenovo TB2-X30F\_YZA  
521. TB2-X30L - Lenovo TB2-X30L  
522. TB2-X30M - Lenovo TB2-X30M  
523. TB2-X30M - Lenovo TB2-X30M\_PRC\_YZ\_A  
524. TB3 8 Plus - Lenovo TB-8703F  
525. TB3 8 Plus - Lenovo TB-8703N  
526. TB3 8 Plus - Lenovo TB-8703X  
527. TB3-601LV - 601LV  
528. TB3-602LV - 602LV  
529. TB3-710F - Lenovo TB3-710F  
530. TB3-710I - Lenovo TB3-710I  
531. TB3-X70F - Lenovo TB3-X70F  
532. Tab 7 Essential - Lenovo TB-7304F  
533. Tab 7 Essential - Lenovo TB-7304F  
534. ThinkPad 11e Chromebook 3rd Gen - ThinkPad 11e Chromebook 3rd Gen (Yoga/Clamshell)  
535. ThinkVision28 - ThinkVision28  
536. Thinkpad 11e Chromebook (4th Gen)/Lenovo Thinkpad Yoga 11e Chromebook (4th Gen) - Lenovo Thinkpad 11e Chromebook (4th Gen)/Lenovo Thinkpad Yoga 11e Chromebook (4th Gen)  
537. Thinkpad Stack projector - M123  
538. VIBE K10 - Lenovo K10a40  
539. VIBE K6 - Lenovo K33a48  
540. VIBE K6 - Lenovo K33b36

541. VIBE K6 - Lenovo K33b37  
 542. VIBE K6 Note - Lenovo K53a48  
 543. VIBE K6 Note - Lenovo K53b36  
 544. VIBE K6 Note - Lenovo K53b37  
 545. VIBE K6 Power - Lenovo K33a42  
 546. VIBE X3 Lite - Lenovo A7010a48  
 547. VIBE X3 Lite - Lenovo K51c78  
 548. VIBE X3 Lite - Lenovo K51c78  
 549. X2 - Lenovo X2-AP  
 550. X2 - Lenovo X2-EU  
 551. X2 Pro - Lenovo X2Pt5  
 552. X2 Pro - VIBE X2Pt5  
 553. X2-TO/VIBE X2 - Lenovo X2-TO  
 554. X2-TR/VIBE X2 - Lenovo X2-TR  
 555. X3a40 - Lenovo X3a40  
 556. X3c50 - Lenovo X3c50  
 557. X3c70 - Lenovo X3c70  
 558. YB1-X90L/YOGA BOOK - Lenovo YB1-X90L  
 559. YOGA A12 - Lenovo YB-Q501F  
 560. YOGA BOOK - Lenovo YB1-X90F  
 561. YOGA BOOK - Lenovo YB1-X90L  
 562. YOGA Laptop with Android - Lenovo YB-Q501F  
 563. YOGA Laptop with Android - Lenovo YB-Q501L  
 564. YOGA Tablet Pro-1050L/Yoga Tablet 2 - YOGA Tablet 2-1050L  
 565. YOGA Tablet Pro-1050LC/Yoga Tablet 2 - YOGA Tablet 2-1050LC  
 566. YOGA Tablet Pro-1380F/Yoga Tablet 2 Pro - YOGA Tablet 2 Pro-1380F  
 567. YOGA Tablet Pro-1380L/Yoga Tablet 2 Pro - YOGA Tablet 2 Pro-1380L  
 568. YOGA Tablet Pro-830L/Yoga Tablet 2 - YOGA Tablet 2-830L  
 569. YOGA Tablet Pro-830LC/Yoga Tablet 2 - YOGA Tablet 2-830LC  
 570. YT3-850F/Lenovo YOGATab3 - Lenovo YT3-850F  
 571. YT3-850L/Lenovo YOGATab3 - Lenovo YT3-850L  
 572. YT3-850M/Lenovo YOGATab3 - Lenovo YT3-850M  
 573. YT3-X50F/Yoga3 Tablet - Lenovo YT3-X50F  
 574. YT3-X50L/Yoga3 Tablet - Lenovo YT3-X50L  
 575. YT3-X50M/Yoga3 Tablet - Lenovo YT3-X50M  
 576. YT3-X90F/YOGA3 Tablet Pro - Lenovo YT3-X90F  
 577. YT3-X90L/YOGA3 Tablet Pro - Lenovo YT3-X90L  
 578. YT3-X90X/YOGA3 Tablet Pro - Lenovo YT3-X90X  
 579. YT3-X90Y/YOGA3 Tablet Pro - Lenovo YT3-X90Y  
 580. YT3-X90Z/YOGA3 Tablet Pro - Lenovo YT3-X90Z  
 581. Yoga TAB3 Plus - Lenovo YT-X703F  
 582. Yoga TAB3 Plus - Lenovo YT-X703L  
 583. Yoga TAB3 Plus - Lenovo YT-X703X  
 584. YogaTablet2 -1050F - YOGA Tablet 2-1050F  
 585. YogaTbalet2-830F - YOGA Tablet 2-830F  
 586. Z2 - Lenovo Z2  
 587. Z2 - Lenovo Z2  
 588. Z2w - Lenovo Z2w  
 589. Z90/VIBE Shot - Lenovo Z90  
 590. Z90/VIBE Shot - Lenovo Z90-7  
 591. Z90/VIBE Shot - Lenovo Z90-3  
 592. Z90a40/VIBE Shot - Lenovo Z90a40  
 593. ideatv S52 - ideatv S52  
 594. ideatvK82 60LX750A 52LX750A 46LX750A 60LX850A 70LX850A 80LX850A - ideatv K82

## Lexibook

1. Fluo - MFC145FR1
2. Fluo XL - MFC191FR2
3. Fluo XL Premium Edition - MFC510FR1
4. LexiTab 10" - MFC512FR
5. LexiTab 10" - MFC511DE
6. LexiTab 10" - MFC511EN
7. LexiTab 10" - MFC511FR
8. LexiTab 7" - MFC147FR
9. LexiTab 7" - MFC146DE
10. LexiTab 7" - MFC146EN
11. LexiTab 7" - MFC146FR
12. LexiTab 7" - MFC146ES
13. MFC191 - S952
14. Playdroid - LBOX500

## Lgcns

1. LPT\_200AR - LPT\_200AR
2. LPT\_201AR - LPT\_201AR

## LifeWatch

1. V , FGL-00004 - LifeWatch V

## LinkNet

1. SH960C-LN - SH960C-LN
2. ST950I-LN - ST950I-LN
3. Smart Box HD - SH940C-LN

## Listo

1. WEBPAD1002 - WEBPAD1002

## Logic Instrument

1. FieldBook E1 - FieldBook\_E1
2. Fieldbook F1 - Logic Instrument Fieldbook F1
3. Fieldbook F53 - Logic Instrument Fieldbook F53
4. Fieldbook K80 - Logic Instrument Fieldbook K80

## Logic Mobility

1. LOGIC\_L5D - LOGIC\_L5D

## Logicom

1. B bot 50 - B BOT 50
2. B bot 550 - B BOT 550
3. C bot tab 70 - C Bot Tab 70
4. Connect503 - Connect503
5. E1052GP - E1052GP
6. E350 - E350
7. E400 - E400
8. E852GP - E852GP
9. ID bot 53 - ID bot 53
10. ID bot 553 - IDbot553
11. ID bot 553+ - IDbot553PLUS
12. IDbot53plus - ID bot 53+
13. L-EGANT ONE-R - L-EGANTONE-R
14. L-EGANT ONE - L-EGANTONE
15. L-EMENT 403 - L-EMENT\_403
16. L-EMENT 505 - L-EMENT 505
17. L-EMENT 553 - L-EMENT 553



18. L-EMENT TAB 1040 - L-EMENT\_TAB1040
19. L-EMENT TAB 741 - L-EMENT 741
20. L-EMENT TAB 742 - L-EMENT 742
21. L-EMENT TAB 744 - L-ement\_Tab\_744
22. L-EMENT TAB 744P - L-ementTab744P
23. L-EMENT350 - L-EMENT350
24. L-EMENT400 - L-EMENT 400
25. L-EMENT500 - L-EMENT500L
26. L-EMENT501 - L-EMENT501
27. L-EMENT550 - L-EMENT550
28. L-EMENT551 - L-EMENT551
29. L-EMENTTAB1042 - L-EMENT\_TAB1042BTK
30. L-EMENT\_TAB1040\_BT - L-EMENT\_TAB1040\_BT
31. L-ITE 400M - L-ITE 400M
32. L-ITE 502 PLUS - L-ITE 502 PLUS
33. L-ITE 504 HD - L-ITE 504 HD
34. L-ITE 506 HD - L-ITE 506 HD
35. L-ITE 506R HD - L-ITE 506R HD
36. L-ITE Tab 870 LTE - L-ITE Tab 870 LTE
37. L-ITE402 - L-ITE 402
38. L-ITE452 - L-ITE 452
39. L-ITE502 - L-ITE 502
40. L-ITE552 - L-ITE 552
41. L-IXIR TAB 1041 - L-IXIR1041
42. L-IXIR TAB 1046HD - L-IXIR\_TAB\_1046\_HD
43. L-IXIR TAB 701 3G - L-IXIR\_TAB\_701\_3G
44. L-IXIR TAB 840 - L-IXIR\_TAB\_840
45. L-ite\_Tab1060 - L-ite\_Tab1060
46. L743 - L-EMENT743
47. LEMENT TAB 740 - L-EMENT 740
48. LEMENTTAB1042 - L-EMENT\_TAB1042
49. LEMENTTAB901 - LEMENT\_TAB901
50. L\_IXIR\_TAB\_1047HD - L\_IXIR\_TAB\_1047HD
51. LiteTab760 - LiteTab760
52. Logikids - Logikids\_2
53. Logikids 3 - Logikids\_3
54. M bot 51 - M bot 51
55. M bot 551 - M BOT 551
56. M bot 60 - M bot 60
57. M bot Tab 103 - M bot Tab 103
58. M bot Tab 1150 - M\_bot\_tab\_1150
59. M bot Tab 71 - M\_bot\_tab\_71
60. M bot tab 100 - M BOT TAB 100
61. M bot tab 101 - M BOT TAB 101
62. M bot tab 70 - M BOT TAB 70
63. M\_bot\_52 - M bot 52
64. POWER bot - POWER BOT
65. S1052 - S1052
66. S450 - S450
67. S504 - Connect 5
68. S504 - S504
69. S732 - S732
70. S7842 - S7842
71. S952 - S952
72. VRBOT552 - VR BOT 552
73. VRBOT552PLUS - VR BOT 552 PLUS
74. Volt-R - Volt-R

## Logitech

1. Revue - Revue

## Louis Vuitton

1. Tambour Horizon - Tambour

## Lumigon

1. T2 - T2
2. T2 HD - T2HD
3. T3 - Lumigon\_T3

## Lyf

1. LS-4004 - LS-4004
2. LS-4006 - LYF\_LS-4006
3. LS-4503 - LS-4503
4. LS-4505 - LS-4505
5. LS-4508 - LS-4508
6. LS-4510 - LS-4510
7. LS-4511 - LS-4511
8. LS-4512 - LS-4512
9. LS-5002 - LS-5002
10. LS-5004 - LS-5004
11. LS-5008 - LS-5008
12. LS-5009 - LS-5009
13. LS-5013 - LS-5013
14. LS-5016 - LS-5016
15. LS-5018 - LS-5018
16. LS-5020 - LS-5020
17. LS-5021 - LS-5021
18. LS-5027 - LS-5027
19. LS-5201 - LS-5201
20. LS-5503 - LS-5503
21. LS-5504 - LS-5504
22. LS-6001 - LS-6001
23. LT-8001 - LT-8001
24. LT-8001 IRIS - LT-8001 IRIS
25. WATER F1 - LS-5505

## M4tel

1. M4 SS4450 - M4 SS4450
2. M4 SS4450B - M4 SS4450B
3. M4 SS4451 - M4 SS4451
4. M4 SS4452 - M4 SS4452
5. M4 SS4453 - M4 SS4453
6. M4 SS4453-R - M4-SS4453-R
7. M4 SS4455 - M4 SS4455
8. M4 SS4456 - M4 SS4456
9. M4 SS4457 - M4 SS4457
10. M4 SS4458 - M4 SS4458
11. M4 SS4458-R - M4-SS4458-R
12. M4-SS4457-R - M4 SS4457-R

## MG Series

1. Any 302 - TR10CS2

## MG series

1. Any 302 - TR10CS1
2. Any 302 - TR10CS2
3. Any 302 - TR10CS2
4. Any 303 - TR10CD2
5. Any 303 - TR10CD2



## MJS

1. T2702 - T2702

## MPman

1. MPDC1006 - MPDC1006
2. MPDC706 - MPDC706

## MSI

1. Primo73 - Primo73
2. Primo76 - Primo76
3. Primo81 - Primo 81
4. Primo81 - Primo81
5. Primo81 - Primo81

## MTC

1. 982 - MTC 982
2. Vodafone Smart mini - MTC 970H

## MTN Group

1. 5982C3 - MTN-TBW5982C3
2. 8978P - MTN-8978P
3. MTN Sm@rt L840 - MTN Sm@rt L840
4. MTN Sm@rt L860 - MTN Sm@rt L860
5. MTN Sm@rt L860 - MTN-L860
6. MTN Smart S730 - MTN-S730
7. MTN Smart S735 - MTN-S735
8. MTN Smart S810 - MTN-S810
9. MTN Steppa 2 LTE - MTN Steppa 2 LTE
10. S620 - MTN-S620
11. S720i - MTN-S720i
12. Sm@rt Mini S630 - MTN-S630

## MTN-E70

1. MTN-E70 - MTN-E70

## MTT

1. Master - M.T.T. Master
2. Smart Fun - M.T.T. Smart Fun

## Mach Speed

1. xtreme - X-treme Play Tab

## MachSpeed (Apollo Brands)

1. STR-9.6-Tablet - STR-9.6-Tablet
2. Trio Stealth\_10 Tablet - Trio Stealth\_10
3. Trio Stealth\_8 Tablet - Trio Stealth\_8
4. Trio Stealth\_9 Tablet - Trio Stealth\_9
5. TrioStealth-7 - TrioStealth-7

## Mad Catz

1. M.O.J.O. - Mad Catz M.O.J.O.

## Manta

1. MSP4507 - MSP4507

## Marshall

1. London - London

## Masstel

1. LT52 - Masstel LT52
2. Masstel Tab7 - Masstel Tab7
3. Masstel Tab8 - Masstel Tab8
4. Masstel\_Tab10 - Masstel Tab10

## Maxcom

1. MS514 - MS514
2. MS553 - MS553

## MeanIT

1. meanIT C80C81 - meanIT\_C80C81
2. meanIT\_C10C11 - meanIT\_C10C11

## Mecer

1. 101P51C - 101P51C
2. 101P51D - 101P51D
3. 800P31C - 800P31C
4. 800P71D - 800P71D
5. M785P - M785P
6. MF716 - MF716
7. TEI11011 - TEI11011MST
8. TF10EA2 - TF10EA2

## Medion

1. E1050X - E1050X
2. E1051X - E1051X
3. E4502 - MEDION E4502
4. E4506 - MEDION E4506
5. E5004 - MEDION E5004
6. E5005 - B5060
7. E5006/P5006 - B5032
8. E5504 - MEDION B5530
9. E691X - E691X
10. E731x - LIFETAB\_E731X
11. LIFETAB E10316 - BOSCH\_E10316
12. LIFETAB E10316 - LIFETAB\_E10316
13. LIFETAB E10320 - LIFETAB\_E10320
14. LIFETAB E10320 - MICROSTAR\_E10319
15. LIFETAB E723X - LIFETAB\_E723X
16. LIFETAB E7313 - LIFETAB\_E7313
17. LIFETAB E7316 - LIFETAB\_E7316
18. LIFETAB E7316 - LIFETAB\_S7316
19. LIFETAB E732X - LIFETAB\_E732X
20. LIFETAB E732X - LIFETAB\_E733X
21. LIFETAB E732X - LIFETAB\_S733X
22. LIFETAB P1034X - LIFETAB\_P1034X
23. LIFETAB P733x - LIFETAB\_P733X
24. LIFETAB P831X - LIFETAB\_P831X
25. LIFETAB P831X - LIFETAB\_P831X.2
26. LIFETAB P891X - LIFETAB\_P891X
27. LIFETAB P970X - LIFETAB\_P970X
28. LIFETAB S1032X - S1032X
29. LIFETAB S1033X - LIFETAB\_S1033X
30. LIFETAB S1034X - LIFETAB\_S1034X
31. LIFETAB S785X - LIFETAB\_S785X

32. LIFETAB S786x - LIFETAB\_S786X
33. LIFETAB S831X - LIFETAB\_S831X
34. LIFETAB\_S1036X - LIFETAB\_S1036X
35. Lifetab P9514 - LIFETAB\_P9514
36. Media Base P740X - P740X
37. P1032X - P1032X
38. P1035X - P1035X
39. P1050X - P1040X
40. P1050X - P1050X
41. P4501 - P4501
42. P5004 - MEDION P5004
43. P5005 - MEDION P5005
44. P5015 - MEDION P5015
45. P850X - P850X
46. P851X - P851X
47. S1035X - S1035X
48. S5004 - MEDION S5004
49. S5504 - B5531
50. S7322 - LIFETAB\_S732X
51. X1030x - X1030X
52. X1031X - X1031X
53. X5520 - B5532
54. X6001 - MEDION X6001
55. microstar E10319 - E10319

## MegaFon

1. Login 3 - MegaFon Login 3
2. MFLogin3T - MFLogin3T
3. MFLoginPh - MFLoginPh
4. MS4B - ALCATEL ONE TOUCH 7030R
5. MS4B - ALCATEL ONE TOUCH 7030Y
6. MS4B - MS4B
7. MT3A - MT3A

## Megahouse

1. CP-D403 - CP-D403

## Meitu

1. M4 - Meitu M4
2. M6 - MP1503
3. Maya - MP1603
4. V4 - Meitu V4
5. V4s - Meitu V4s
6. Victoria - MP1602

## Meizu

1. M6 - M6
2. M6 Note - M6 Note
3. PRO 7 - PRO 7
4. PRO 7 Plus - PRO 7 Plus

## Memorex

1. MTAB-07530A - MTAB-07530A
2. MTAB-0753AK - MTAB-07535AK
3. MTAB-08530A - MTAB-08530A
4. MTAB-09541AB - MTAB-09541AB

## Micromax

1. A110 - Micromax A110

2. A111 - A111
3. A116 - A116
4. A240 - A240
5. A27 - A27
6. A44 - A44
7. A45 - A45
8. A50 - Micromax A50
9. A54 - A54
10. A56 - Micromax A56
11. A57 - A57
12. A57 - Micromax A57
13. A62 - Micromax A62
14. A72 - Micromax A72
15. A73 - A73
16. A73 - Micromax A73
17. A75 - A75
18. A78 - A78
19. A84 - A84
20. A87 - A87
21. A87 - Micromax A87
22. A88 - A88
23. A89 - A89
24. A91 - A91
25. A91 - Micromax A91
26. BOLT - A068
27. BOLT - Micromax A069
28. BOLT - Micromax A24
29. BOLT - Micromax A34
30. BOLT - Micromax A67
31. BOLT - Micromax A69
32. BOLT - Micromax A69
33. BOLT - Micromax Q332
34. BOLT - Micromax Q338
35. Bolt - Micromax A064
36. Bolt - Micromax A065
37. Bolt - Micromax A066
38. Bolt - Micromax A067
39. Bolt - Micromax A082
40. Bolt - A35
41. Bolt - Micromax A79
42. Bolt - Micromax A82
43. Bolt - Micromax AD3520
44. Bolt - Micromax AD4500
45. Bolt - Micromax\_D200
46. Bolt - Micromax D303
47. Bolt - Micromax D304
48. Bolt - Micromax D305
49. Bolt - Micromax D320
50. Bolt - Micromax D321
51. Bolt - Micromax D333
52. Bolt - Micromax D340
53. Bolt - Micromax Q3001
54. Bolt - Micromax Q301
55. Bolt - Micromax Q303
56. Bolt - Micromax Q323
57. Bolt - Micromax Q324
58. Bolt - Micromax Q325
59. Bolt - Micromax Q326
60. Bolt - Micromax Q331
61. Bolt - Micromax Q333
62. Bolt - Micromax Q335
63. Bolt - Micromax Q336

64. Bolt - Micromax Q341
65. Bolt - Micromax Q346
66. Bolt - Micromax Q381
67. Bolt - Micromax Q383
68. Bolt - Micromax S300
69. Bolt - Micromax S301
70. Bolt - Micromax S302
71. Bolt Juice - Micromax Q3551
72. Bolt Pace - Micromax Q402
73. Bolt Q3301 - Micromax Q3301
74. Bolt Selfie - Micromax Q424
75. Bolt Supreme 4 - Micromax Q352
76. CANVAS 2 COLOURS - Micromax A120
77. CANVAS 2 PLUS - A110Q
78. CANVAS 2 PLUS - Micromax A110Q
79. CANVAS 4 - A210
80. CANVAS 4 - A210
81. CANVAS BEAT - Micromax A114R
82. CANVAS BLAZE - MT500
83. CANVAS DOODLE 3 - Micromax A102
84. CANVAS DUET - Micromax AE90
85. CANVAS DUET 2 - Micromax EG111
86. CANVAS ELANZA 2 - Micromax A121
87. CANVAS ENGAGE - Micromax A091
88. CANVAS ENTICE - Micromax A105
89. CANVAS GOLD - Micromax A300
90. CANVAS KNIGHT - Micromax A350
91. CANVAS KNIGHT - Micromax A350
92. CANVAS MAGNUS - Micromax A117
93. CANVAS POWER - Micromax A96
94. CANVAS TUBE - Micromax A118R
95. CANVAS TURBO - A250
96. CANVAS TURBO - A250
97. CANVAS TURBO MINI - Micromax A200
98. CANVAS UNITE 2 - Micromax A106
99. Canvas 2 - Micromax Q4310
100. Canvas 4+ - Micromax A315
101. Canvas 5 - Micromax E481
102. Canvas 5 Lite - Micromax Q463
103. Canvas 6 - Micromax E485
104. Canvas 6 Pro - Micromax E484
105. Canvas A1 - Micromax AQ4501
106. Canvas A1 - Micromax AQ4502
107. Canvas AMAZE - Micromax Q395
108. Canvas Blaze - Micromax Q400
109. Canvas Blaze 4G Plus - Micromax Q414
110. Canvas Doodle4 - Micromax Q391
111. Canvas Evok - Micromax E483
112. Canvas FIRE4G - Micromax Q411
113. Canvas Fire - Micromax A093
114. Canvas Fire - Micromax A104
115. Canvas Fire 4G - Micromax Q462
116. Canvas Fire 5 - Micromax Q386
117. Canvas Fire 6 - Micromax Q428
118. Canvas Fire3 - Micromax A096
119. Canvas Fire4 - Micromax A107
120. Canvas Fun - Micromax A76
121. Canvas HD Plus - Micromax A190
122. Canvas Hue - Micromax AQ5000
123. Canvas Hue 2 - Micromax A316
124. Canvas Infinity - Micromax HS2
125. Canvas Juice - Micromax A77
126. Canvas Juice 3+ - Micromax Q394
127. Canvas Juice 4 - Micromax Q382
128. Canvas Juice 4G - Micromax Q461
129. Canvas Juice 6 - Micromax Q398
130. Canvas Juice2 - Micromax AQ5001
131. Canvas Juice3 - Micromax Q392
132. Canvas Knight Cameo - Micromax A290
133. Canvas Knight2 - Micromax E471
134. Canvas L - Micromax A108
135. Canvas Magnus - Micromax A117
136. Canvas Magnus HD - Micromax Q421
137. Canvas Mega - Micromax E353
138. Canvas Mega - Micromax Q417
139. Canvas Mega 2 - Micromax Q426
140. Canvas Nitro - Micromax A310
141. Canvas Nitro - Micromax A311
142. Canvas Nitro2 - Micromax E311
143. Canvas Pace 4G - Micromax Q416
144. Canvas Pace Mlni - Micromax Q401
145. Canvas Pep - Micromax Q370
146. Canvas Pep - Micromax Q371
147. Canvas Pep - Micromax Q375
148. Canvas Play - Micromax Q355
149. Canvas Play 4G - Micromax Q412
150. Canvas Play4G - Micromax Q469
151. Canvas Pulse - Micromax E451
152. Canvas SPARK2 - Micromax Q334
153. Canvas Selfie - Micromax A255
154. Canvas Selfie 4 - Micromax Q349
155. Canvas Selfie Lens - Micromax Q345
156. Canvas Space 2 - Micromax Q480
157. Canvas Space 2+ - Micromax Q479
158. Canvas Spark - Micromax Q380
159. Canvas Spark 2 Plus - Micromax Q350
160. Canvas Spark 3 - Micromax Q380N
161. Canvas Spark 3 - Micromax Q385
162. Canvas Spark 4G - Micromax Q4201
163. Canvas Tab - MicromaxF666
164. Canvas Tab - MicromaxP480
165. Canvas Tab - P480
166. Canvas Tab - Micromax P681
167. Canvas Tab - Micromax P690
168. Canvas Tab - Micromax P701
169. Canvas Tab - MicromaxP702
170. Canvas Tab - P70221
171. Canvas Tab - MicromaxP802
172. Canvas Tab - Micromax P810
173. Canvas Tabby - P469
174. Canvas Turbo - Micromax A250
175. Canvas Unite 4 - Micromax Q427
176. Canvas Unite 4 Pro - Micromax Q465
177. Canvas XL2 - Micromax A109
178. Canvas Xpress - Micromax A99
179. Canvas Xpress 2 - Micromax E314
180. Canvas Xpress 4g - Micromax Q413
181. Canvas tab - Micromax P290
182. Canvas tab - P470
183. Canvas tab - Micromax P666
184. Canvas tab - MicromaxP680
185. Doodle 4 - Micromax Q491
186. Dual 4 - Micromax E4816
187. EVOK DUAL NOTE - Micromax E4815

188. Evok Dual Note - Micromax E4817
189. Evok Note - Micromax E453
190. Evok Power - Micromax Q4260
191. MAD - Micromax A94
192. Micromax Bharat 4 - Micromax Q440
193. Micromax Canvas 1 - Micromax C1
194. Micromax Canvas Music M1 - Micromax Q4261
195. Micromax Selfie 2 - Micromax Q4311
196. Micromax Selfie 2 Note - Micromax Q4601
197. Micromax Spark 4G Prime(2017) - Micromax Q452
198. Nitro 3 - Micromax E352
199. Nitro 4G - Micromax E455
200. P275 - P275
201. P300 - P300
202. Q327 - Micromax Q327
203. Q350R - Micromax Q350R
204. Q354 - Micromax Q354
205. SUPREME BOLT - Micromax Q300
206. Selfie 2 - Micromax Q340
207. Selfie 3 - Micromax E460
208. Selfie 3 - Micromax Q348
209. Sliver 5 - Micromax Q450
210. Spark 4G(2017) - Micromax Q409
211. UNITE - Micromax A092
212. Unite 3 - Micromax Q379
213. Unite2 - Micromax A106
214. Unite3 - Micromax Q372
215. Vdeo 1 - Micromax Q4001
216. Vdeo 2 - Micromax Q4101
217. Vdeo 3 - Micromax Q4202
218. Vdeo 4 - Micromax Q4251
219. Vdeo 5 - Micromax Q4220
220. Xpress 2 - Micromax E313
221. YUNIQUE - YU4711
222. YUREKA S - YU5200
223. YUREKA S - YU5551
224. Yunique 2 Plus - YU5012
225. Yuphoria - YU5010
226. Yutopia - YU5050

### **Microtech**

1. e-tab\_style\_rev.3 - e-tab\_style\_REV3

### **MiiA**

1. MT-733G - MT-733G
2. MiiA - TA10CA1

### **Mint**

1. Clover - M4CR
2. Clover - M4CRD
3. M4 - M4
4. M5 - M5

### **Mio Tab**

1. MioTab - MioTab 2016
2. MioTab2017 - MioTab2017

### **Miophone**

1. Mio Phone - Mio Phone 2016
2. Mio Phone - MioPhone2017

### **Misfit**

1. Misfit Vapor / Fossil Q Control - Vapor

### **Mito**

1. A10 - MITO A10
2. A10 - MITO\_A10
3. MITO\_A19\_1GB - MITO\_A19\_1GB
4. MITO\_A19\_2GB - MITO\_A19\_2GB

### **Mobicell**

1. 4U - 4U
2. ARC - ARC
3. Air - Air
4. BERRY - BERRY
5. CHERRY - CHERRY
6. COSMO - COSMO
7. Candy - Candy
8. DANDY - DANDY
9. ECHO - ECHO
10. FEVER - FEVER
11. FRIO - FRIO
12. HERO X - HERO\_X
13. Icon - Icon
14. METRO2 - MOBICEL METRO2
15. Matrix - Matrix
16. Mobicel - Sonic
17. Mobicel - Venus
18. Mobicel GEM - GEM
19. Mobicel ICE - ICE
20. Mobicel\_R1 - Mobicel\_R1
21. NEO - NEO
22. ONYX - ONYX
23. PLAY - PLAY
24. PLUM - PLUM
25. PURE - PURE
26. PURE MINI - PURE MINI
27. PURE\_PLUS - PURE PLUS
28. R3 - R3
29. R4 - R4
30. REBEL - REBEL
31. RUSH - RUSH
32. Retro - Retro
33. SHIFT - SHIFT
34. SWITCH - SWITCH
35. Samba - Samba
36. TRIP - TRIP
37. Trendy - TREDNY
38. Trendy - TRENDY
39. Trendy Plus - TRENDY PLUS
40. U2 - U2
41. ZEN - ZEN
42. ZOOM - ZOOM

### **MobiiStar**

1. LAI YUNA 1 - mobiistar LAI YUNA 1
2. LAI Z1 4G - mobiistar LAI Z1 4G
3. LAI Z2 - mobiistar LAI\_Z2
4. LAI Zoro 3 - mobiistar LAI ZORO 3
5. LAI Zumbo S 2017 - Zumbo\_S\_2017
6. LAI Zumbo S 2017 Lite - Zumbo\_S\_2017\_Lite



7. ZORO 4G - mobiistar\_ZORO\_4G
8. ZUMBO J2 - Mobiistar\_Zumbo\_J2
9. ZUMBO S2 - mobiistar\_Zumbo S2
10. ZUMBO\_S2\_Dual - mobiistar\_ZUMBO S2 Dual

## MobileTeleSystem

1. MTC SMART Surf 4G - MTC\_SMART\_Surf\_4G
2. SMART Race2 4G - SMART\_Race2\_4G
3. SMART Start 2 - MTC\_SMART\_Start\_2
4. SMART Turbo 4G - SMART\_Turbo\_4G
5. SMART\_Sprint\_4G - MTC SMART Sprint 4G
6. Smart Surf2 4G - SMART Surf2 4G

## Mobily

1. MDB342X - MDB342X

## Mobiola

1. Gaia - MS55L1
2. MS50L1 - MS50L1

## Mobistel

1. Cynus E7 - Cynus E7
2. Cynus F10 - Cynus\_F10
3. Cynus F9 4G - Cynus\_F9\_4G
4. Cynus T6 - Cynus T6
5. Cynus\_E8 - Cynus\_E8

## Mobiwire

1. Ahiga - Ahiga
2. Chenoa - Chenoa
3. Cygnus - Cygnus
4. Cygnus - Cygnus45
5. Cygnus mini - Cygnus mini
6. Cygnus mini - Cygnus\_mini
7. H - Halona
8. HALONA - Halona
9. Halona - Halona
10. Kaya - KAYA
11. Kiona - Kiona
12. Kohana - Kohana
13. Kosumi - Kosumi
14. Kwanita - KWANITA
15. Pegasus - Pegasus
16. S4040 - S4040
17. STARSHINE 5 - STARSHINE5
18. STARSHINE 5 - STARSHINE\_5
19. STARSHINE 5 - Smart\_A25
20. STARXTREM 5 - STARXTREM5
21. Tala - Tala
22. Telenor SmartPlus - Telenor\_SmartPlus
23. V.40 - V.40
24. V.45 - V.45S
25. VSN V.45 - V.45

## Modecom

1. FreeTAB 10.1 Silver - FreeTAB 10.1 Silver
2. FreeTAB 8015 IPS X4 LTE - FreeTAB 8015 IPS X4
3. Xino Z46 X4+ - Xino Z46 X4+

## Mohu

1. MH-CHANNELS - MH-CHANNELS

## Monster

1. M10 - M10

## Montblanc

1. SUMMIT - MB SUMMIT
2. Summit - MB SUMMIT

## Most Computers

1. Revo You - RevoYou

## Motorola

1. A853 - Milestone
2. ArgonSpin - XT550
3. Graham - MZ505
4. TAHITI - MT620
5. Triumph - MOTWX435KT
6. XT311 - XT311
7. XT316 - XT316
8. XT317 - XT317
9. XT319 - XT319
10. XT530 - XT530
11. XT531 - XT531
12. XT532 - XT532
13. argonspin\_umts - XT550
14. cdma\_kronos - MB612
15. cdma\_pax - XT603
16. cdma\_solana - MILESTONE3
17. cdma\_spyder - DROID RAZR
18. cdma\_spyder - IS12M
19. cdma\_spyder - Motorola RAZR MAXX
20. cdma\_targa - DROID BIONIC
21. cg\_tita2 - XT800+
22. choi - XT711
23. choles - XT701
24. destino - i867
25. dominoq\_umts - XT316
26. edison - MB865
27. edison - ME865
28. fawnridge - i940
29. fleming - MZ607
30. fleming - MZ608
31. fleming - MZ609
32. fleming - XOOM 2 ME
33. graham\_wifi - MZ505
34. iDEN - Motorola\_i1
35. morr - MB200
36. pasteur - MZ616
37. pasteur - MZ617
38. pasteur - XOOM 2
39. qilin - XT806
40. scorpion\_mini\_u - XT905
41. smq\_u - XT905
42. swordfish - XT882
43. tinq\_umts - XT560
44. ttu\_skt - XT800W
45. umts\_begonia - MB610
46. umts\_begonia - MB611

47. umts\_elway - MB632
48. umts\_elway - ME632
49. umts\_hubble - MZ605
50. umts\_kobe - MB520
51. umts\_lucky - A1680
52. umts\_sage - MB508
53. umts\_solana - ME863
54. umts\_solana - XT860
55. umts\_spyder - XT910
56. umts\_spyder - XT910K
57. umts\_spyder - XT910S
58. umts\_venus2 - XT610
59. wifi\_hubble - MZ604
60. zepp - MB501
61. Atrix - MB860
62. Atrix - MB861
63. Atrix - ME860
64. Atrix HD - MB886
65. Backflip - MB300
66. Backflip - ME600
67. CLIQ - MB200
68. CLIQ - morrison
69. Charm - MB502
70. Citrus - WX442
71. Citrus - WX445
72. Citrus - XT301
73. Cliq-XT - MB501
74. Cliq-XT - ME501
75. DROID MAXX 2 - XT1021
76. DROID MAXX 2 - XT1565
77. DROID RAZR HD - DROID RAZR HD
78. DROID RAZR HD - RAZR HD
79. DROID RAZR HD - XT925
80. DROID RAZR M - XT907
81. DROID RAZR i - XT890
82. DROID Turbo 2 - XT1585
83. DROID4 - DROID4
84. Defy - MB525
85. Defy - MB526
86. Defy - ME525
87. Defy - ME525+
88. Defy - unknown
89. Defy Mini - XT320
90. Defy Mini - XT321
91. Defy Mini - XT320
92. Defy Mini - XT321
93. Defy Pro - XT560
94. Devour - Devour
95. Devour - calgary
96. Droid - A854
97. Droid - Droid
98. Droid - A853
99. Droid - Milestone
100. Droid - XT701
101. Droid - XT702
102. Droid - XT720
103. Droid - umts
104. Droid 3 - DROID3
105. Droid 4 - DROID4
106. Droid Bionic - DROID BIONIC
107. Droid II - A955
108. Droid II - DROID2
109. Droid II - DROID2 GLOBAL
110. Droid MAXX - XT1080
111. Droid Mini - XT1030
112. Droid Pro - DROID PRO
113. Droid Pro - DROID Pro
114. Droid Pro - Milestone PLUS
115. Droid Pro - XT610
116. Droid RAZR - XT910
117. Droid Razr M - 201M
118. Droid Turbo - XT1250
119. Droid Turbo - XT1254
120. Droid Ultra - XT1080
121. Droid X - DROIDX
122. Droid X - MB810
123. Droid X - ME811
124. Droid X - Milestone X
125. Droid X - MotoroiX
126. Droid X2 - DROID X2
127. Droid X2 - Milestone X2
128. ELECTRIFY 2 - XT881
129. Electrify M - XT901
130. Flipout - MB511
131. Flipout - ME511
132. Flipout - MotoMB511
133. Glam XT800 - XT800
134. HS1 - Motorola\_HS1
135. Iron Rock - XT627
136. Master Touch - XT621
137. Master Touch XT621 - XT621
138. Milestone2 - A953
139. Milestone2 - ME722
140. Milestone2 - MotoA953
141. Moto 360 - Moto 360
142. Moto 360 (2nd Gen) - Moto 360
143. Moto 360 (2nd Gen) - Moto 360
144. Moto 360 Sport - Moto 360
145. Moto C - Moto C
146. Moto C - XT1754
147. Moto C - XT1755
148. Moto C - Moto C
149. Moto C Plus - Moto C Plus
150. Moto C Plus - Moto C Plus
151. Moto C Plus - Moto C Plus
152. Moto C Plus - Moto C Plus
153. Moto Defy XT - XT535
154. Moto Defy XT - XT555C
155. Moto Defy XT - XT556
156. Moto Defy XT - XT557
157. Moto Defy XT - XT535
158. Moto E (1st Gen) - XT1019
159. Moto E (1st Gen) - XT830C
160. Moto E (1st Gen) - XT1025
161. Moto E (1st Gen) - XT1021
162. Moto E (1st Gen) - XT1023
163. Moto E (1st Gen) - XT1022
164. Moto E (2nd Gen) - MotoE2
165. Moto E (2nd Gen) - XT0000
166. Moto E (2nd Gen) - MotoE2
167. Moto E (2nd Gen) - XT1021
168. Moto E (4) - Moto E (4)
169. Moto E (4) - Moto E (4)
170. Moto E (4) - Moto E (4)

171. Moto E (4) - Moto E (4)  
172. Moto E (4) - Moto E (4)  
173. Moto E (4) Plus - Moto E (4) Plus  
174. Moto E (4) Plus - Moto E (4) Plus  
175. Moto E (4) Plus - Moto E (4) Plus  
176. Moto E with 4G LTE (2nd Gen) - MotoE2  
177. Moto E with 4G LTE (2nd Gen) - MotoE2(4G-LTE)  
178. Moto E with 4G LTE (2nd Gen) - XT1526  
179. Moto E with 4G LTE (2nd Gen) - XT1528  
180. Moto E with 4G LTE (2nd Gen) - XT15280  
181. Moto E with 4G LTE (2nd Gen) - MotoE2(4G-LTE)  
182. Moto E with 4G LTE (2nd Gen) - MotoE2(4G-LTE)  
183. Moto E with 4G LTE (2nd Gen) - MotoE2(4G-LTE)  
184. Moto E4 - Moto E (4)  
185. Moto G (1st Gen) - XT1028  
186. Moto G (1st Gen) - XT1031  
187. Moto G (1st Gen) - XT937C  
188. Moto G (1st Gen) - XT1002  
189. Moto G (1st Gen) - XT1003  
190. Moto G (1st Gen) - XT1008  
191. Moto G (1st Gen) - XT1032  
192. Moto G (1st Gen) - XT1034  
193. Moto G (1st Gen) - XT939G  
194. Moto G (1st Gen) - XT1033  
195. Moto G (2nd Gen) - XT1069  
196. Moto G (2nd Gen) - titan\_retbr\_dstv  
197. Moto G (2nd Gen) - XT1063  
198. Moto G (2nd Gen) - XT1064  
199. Moto G (2nd Gen) - XT1068  
200. Moto G (2nd Gen) - titan\_niibr\_ds  
201. Moto G (3rd Gen) - MotoG3  
202. Moto G (3rd Gen) - MotoG3  
203. Moto G (3rd Gen) - MotoG3  
204. Moto G (3rd Gen) - MotoG3  
205. Moto G (3rd Gen) - MotoG3  
206. Moto G (3rd Gen) - MotoG3  
207. Moto G (4) Play - Moto G Play  
208. Moto G (5) - Moto G (5)  
209. Moto G (5) Plus - Moto G (4)  
210. Moto G (5) Plus - Moto G (5) Plus  
211. Moto G (5S) - Moto G (5S)  
212. Moto G (5S) - XT1799-1  
213. Moto G (5S) - Moto G (5S)  
214. Moto G (5S) - XT1799-2  
215. Moto G (5S) Plus - Moto G (5S) Plus  
216. Moto G (5S) Plus - Moto G (4)  
217. Moto G (5S) Plus - Moto G (5S) Plus  
218. Moto G (5S) Plus - Moto G (4)  
219. Moto G (5S) Plus - Moto G (5S) Plus  
220. Moto G (5th Gen) - Moto G (5)  
221. Moto G Google Play edition - XT1032  
222. Moto G Plus (5th Gen) - Moto G (5) Plus  
223. Moto G Plus (5th Gen) - Moto G (5) Plus  
224. Moto G Turbo Edition - MotoG3  
225. Moto G Turbo Edition - MotoG3-TE  
226. Moto G with 4G LTE (1st Gen) - XT1039  
227. Moto G with 4G LTE (1st Gen) - XT1040  
228. Moto G with 4G LTE (1st Gen) - XT1042  
229. Moto G with 4G LTE (1st Gen) - XT1045  
230. Moto G with 4G LTE (2nd Gen) - XT1072  
231. Moto G with 4G LTE (2nd Gen) - XT1077  
232. Moto G with 4G LTE (2nd Gen) - XT1079  
233. Moto G with 4G LTE (2nd Gen) - XT1063  
234. Moto G with 4G LTE (2nd Gen) - XT1078  
235. Moto G(4) - Moto G (4)  
236. Moto G(4) - Moto G (4)  
237. Moto G(4) Plus - Moto G (4)  
238. Moto G4 Play - Moto G Play  
239. Moto G4 Play - XT1609  
240. Moto G4 Play - Moto G Play  
241. Moto MAXX - XT1225  
242. Moto Turbo - XT1225  
243. Moto X (1st Gen) - XT1049  
244. Moto X (1st Gen) - XT1050  
245. Moto X (1st Gen) - XT1052  
246. Moto X (1st Gen) - XT1053  
247. Moto X (1st Gen) - XT1055  
248. Moto X (1st Gen) - XT1056  
249. Moto X (1st Gen) - XT1058  
250. Moto X (1st Gen) - XT1060  
251. Moto X (2nd Gen) - XT1085  
252. Moto X (2nd Gen) - XT1092  
253. Moto X (2nd Gen) - XT1093  
254. Moto X (2nd Gen) - XT1094  
255. Moto X (2nd Gen) - XT1095  
256. Moto X (2nd Gen) - XT1096  
257. Moto X (2nd Gen) - XT1097  
258. Moto X (2nd Gen) - XT1098  
259. Moto X (4) - XT1789-05  
260. Moto X (4) - moto x4  
261. Moto X (4) - moto x4  
262. Moto X Force - XT1580  
263. Moto X Force - XT1580  
264. Moto X Force - XT1581  
265. Moto X Play - Moto X Play  
266. Moto X Play - XT1021  
267. Moto X Play - XT1562  
268. Moto X Play - XT1563  
269. Moto X Play - XT1564  
270. Moto X Play - Moto X Play  
271. Moto X Play - XT1021  
272. Moto X Play - XT1562  
273. Moto X Play - XT1563  
274. Moto X Pro (China) - Moto X Pro  
275. Moto X Pure Edition - XT1575  
276. Moto X Style - XT1572  
277. Moto X Style - XT1570  
278. Moto X Style - XT1572  
279. Moto Z - XT1650  
280. Moto Z - XT1650-05  
281. Moto Z (2) Force - Moto Z (2)  
282. Moto Z (2) Force - XT1789-05  
283. Moto Z (2) Play - Moto Z2 Play  
284. Moto Z (2) Play - XT1710-02  
285. Moto Z (2) Play - XT1710-08  
286. Moto Z (2) Play - XT1710-11  
287. Moto Z Droid - XT1650  
288. Moto Z Play - XT1563  
289. Moto Z Play - XT1635-02  
290. Moto Z Play - XT1635-03  
291. Moto Z Play Droid - XT1635-01  
292. Motoluxe - XT611  
293. Motoluxe - XT615  
294. Motoluxe - XT682

295. Motoluxe - XT615
296. Motoluxe - XT685
297. Motoluxe - Motorola MOT-XT681
298. Motoluxe - XT687
299. Motoluxe - XT626
300. Motoluxe - XT627
301. Motoroi - Milestone XT720
302. Motoroi - Motorola XT720
303. Motoroi - XT720
304. Motosmart - XT389
305. Motosmart - XT390
306. Motosmart - XT389
307. Motosmart - XT390
308. Motosmart - XT303
309. Motosmart - XT305
310. Nexus 6 - Nexus 6
311. Opus One - Motorola Titanium
312. Opus One - Titanium
313. Photon - XT897
314. Photon - XT897S
315. Photon 4G - ISW11M
316. Photon 4G - MB855
317. Photon 4G - Motorola Electrify
318. Quench XT3 - Motorola-XT502
319. RAZR D1 - XT914
320. RAZR D1 - XT915
321. RAZR D1 - XT916
322. RAZR D1 - XT918
323. RAZR D3 - XT919
324. RAZR D3 - XT920
325. RAZR HD - DROID RAZR HD
326. RAZR HD - RAZR HD
327. RAZR M - XT907
328. RAZR M - 201M
329. RAZR i - XT890
330. Razr V - XT885
331. Razr V - XT886
332. Spice - XT300
333. XOOM - Xoom
334. XOOM - MZ601
335. XOOM - MZ601
336. XOOM - MZ605
337. XOOM - MZ604
338. XOOM - MZ606
339. XOOM - Xoom
340. XOOM 2 - MZ609
341. XOOM 2 - MZ617
342. XT605 - XT605
343. XT627 - XT627

### Motorola Solutions

1. LEX F10 - LEX F10
2. LEX L10g - LEX L10g
3. LEX L10ig - LEX L10ig
4. TC55 - TC55
5. TC55CH - TC55CH

### Movado

1. Boss Touch / TH 24/7 YOU - BOSS Touch
2. Boss Touch / TH 24/7 YOU - TH 24/7 YOU
3. Movado Connect - Movado Connect

### Movitelco Trade

1. mtt L509 - MTT\_L509

### Moxee Technologies

1. X1 - X1
2. X10 - X10
3. X100 - X100

### Multilaser

1. M10A - M10A
2. M7I-3G - M7I-3G
3. M7I-3G - ML01-M7S-Quad-Core
4. M7s Dual Core - M7s Dual ML03
5. M7s Quad Core - ML01-M7S-Quad-Core
6. M9-3G - M9-3G
7. M9-3G-2 - M9-3G\_2
8. MS40S - MS40S
9. MS40s - MS40S
10. MS45 - MS45
11. MS45S - MS45S
12. MS45S - MS45S\_A6
13. MS50 - MS50
14. MS50L - MS50L
15. MS50M - MS50M
16. MS50S - MS50S
17. MS50\_4G - MS50\_4G
18. MS55 - MS55
19. MS55M - MS55M
20. MS60 - MS60
21. MS70 - MS70
22. Ms5 - MS5
23. Ms6 - MS6

### My Go

1. GoTab GBT10 - GoTab\_GBT10

### MyPhone (PL)

1. C-Smart pix - C-Smart\_pix
2. Cube LTE - CUBE\_LTE
3. Hammer AXE PRO - Hammer AXE Pro
4. Hammer\_Active - Hammer Active
5. Hykker MyTab10 - Hykker\_MyTab10
6. MyPhone Go! - myPhone Go
7. myPhone - Q\_Smart\_BE
8. myPhone C-Smart Glam - C-Smart\_Glam
9. myPhone C-Smart IIIS - C-Smart IIIS
10. myPhone Fun 5 - FUN5
11. myPhone HAMMER ENERGY - HAMMER\_ENERGY
12. myPhone Hammer Energy - Hammer Energy
13. myPhone Luna II - LUNA\_II
14. myPhone MAGNUS - MAGNUS
15. myPhone PRIME PLUS - Prime\_Plus
16. myPhone Pocket - Pocket
17. myPhone Q-Smart Elite - Q-Smart\_Elite
18. myPhone Q-Smart Plus - Q-Smart\_Plus
19. myPhone\_Fun5 - Fun5

### Myphone

1. CUBE - myPhone Cube



2. Hammer AXE M LTE - HAMMER\_AXE\_M\_LTE
3. Iron 2 - IRON\_2
4. Iron 2 - IRON\_2
5. My phone PRIME PLUS - Prime\_Plus
6. UNO - MyPhone UNO
7. brown 1 - brown 1
8. my28S - MyPhone my28S
9. my28S DTV - MyPhone my28S DTV
10. my28S Smart - my28S Smart
11. my71 DTV - MyPhone my71 DTV
12. my72 DTV - MyPhone my72 DTV
13. my73 DTV - MyPhone my73 DTV
14. my75 DTV - MyPhone my75 DTV
15. my76 DTV - MyPhone\_my76 DTV
16. my77 DTV - MyPhone my77 DTV
17. my81 DTV - MyPhone my81 DTV
18. my85 DTV - MyPhone my85 DTV
19. my86 DTV - MyPhone\_my86\_DTV
20. my87 DTV - MyPhone my87 DTV
21. my88 DTV - MyPhone my88 DTV
22. my89 DTV - MyPhone my89 DTV
23. my91 DTV - MyPhone my91 DTV
24. my92 DTV - MyPhone my92 DTV
25. my93 DTV - MyPhone my93 DTV
26. my95 DTV - MyPhone my95 DTV
27. my96 DTV - MyPhone my96 DTV
28. myA3 - MY803
29. myA5 - MY805
30. myA6\_DTV - MY806
31. myA7\_DTV - myA7 DTV

## Myria

1. 3G MY8300 - 3G
2. Classic MY8301 - Classic
3. Cozy MY8302 - Cozy
4. Cozy MY8302 - Cozy
5. Fancy - Fancy
6. Myria 4G MY8303 - 4G
7. Myria Giant MY8304 - Giant
8. Myria Grand 4G - Myria\_Grand\_4G
9. Myria Wide 2 - Myria\_Wide\_2
10. Myria Wide 4G - Myria\_Wide\_4G

## NASCO

1. Allure\_Plus - NASCO\_Allure\_Plus
2. Magic - Magic

## NAXA

1. NID-7011 - NID-7011
2. NID\_7010 - NID\_7010

## NEC

1. 101T MEDIAS - NEC-101T
2. AGT10 - N8730-411
3. AGT10 - N8730-41101
4. AGT10 - N8730-41102
5. AGT10 D000-000039-001 - NEC-STR
6. CASIO G\zOne Commando 4G LTE - C811 4G
7. Casio G\zOne Commando - C771
8. Disney Mobile on docomoN-03E - N-03E

9. G\z One IS11CA - IS11CA
10. G\zOne TYPE-L CAL21 - CAL21
11. GzOne CA-201L - CA-201L
12. LaVieTab PC-TE508BAW - PC-TE508BAW
13. LaVieTab PC-TE508S1W/LaVieTab PC-TE508S1L - LaVieTab PC-TE508S1
14. LaVieTab PC-TE510S1L - LaVieTab PC-TE510S1
15. LifeTouch B - D000-000013-101
16. LifeTouch B - D000-000018-001
17. LifeTouch B - D000-000018-002
18. LifeTouch B - D000-000018-003
19. LifeTouch B - D000-000018-004
20. LifeTouch B - D000-000018-101
21. LifeTouch B - D000-000018-102
22. LifeTouch B - D000-000018-104
23. LifeTouch B - D000-000019-002
24. LifeTouch B - D000-000019-001
25. LifeTouch B - LTB-HS
26. LifeTouch L - LT-TLA
27. LifeTouch L - NEC-STR
28. LifeTouch L - NEC-STR
29. LifeTouch L - LT-TLA
30. LifeTouch L - LT-TLA
31. LifeTouch L D000-000035-001 - NEC-STR
32. LifeTouch L D000-000035-002 - NEC-STR
33. LifeTouch Note - D000-000010-N
34. LifeTouch Note - D000-000011-N
35. LifeTouch Note - LT-NA7
36. LifeTouch Note - LT-NA7F
37. LifeTouch S - D000-000001-B01
38. LifeTouch S - D000-000001-B02
39. LifeTouch S - D000-000001-C01
40. LifeTouch S - D000-000001-K01
41. LifeTouch S - D000-000001-R01
42. LifeTouch S - D000-000001-R02
43. LifeTouch S - D000-000001-R03
44. LifeTouch S - D000-000001-R04
45. LifeTouch S - D000-000001-S00
46. LifeTouch S - D000-000001-S01
47. LifeTouch S - D000-000001-S05
48. LifeTouch S - D000-000001-S25
49. LifeTouch S - D000-000001-S85
50. LifeTouch S - D000-000007-D01
51. LifeTouch W - D000-000002-W01
52. LifeTouch W - D000-000002-W02
53. LifeTouch W - D000-000002-001
54. MEDIAS X N-06E - N-06E
55. MEDIAS BR IS11N - IS11N
56. MEDIAS CH 101N - 101N
57. MEDIAS ES N-05D - N-05D
58. MEDIAS LTE N-04D - N-04D
59. MEDIAS N-04C - N-04C
60. MEDIAS NE-202 - NE-202
61. MEDIAS NEC-101S - NEC-101S
62. MEDIAS NEC-101S - NEC-101S
63. MEDIAS NEC-102 - NEC-102
64. MEDIAS PP N-01D - N-01D
65. MEDIAS TAB N-06D - N-06D
66. MEDIAS TAB UL N-08D - N-08D
67. MEDIAS U N-02E - N-02E
68. MEDIAS U NE-103T - NE-103T
69. MEDIAS W N-05E - N-05E

70. MEDIAS WP N-06C - N-06C
71. MEDIAS X N-04E - N-04E
72. MEDIAS X N-07D - N-07D
73. NE-201 - NEC-NE-201A1A
74. NEC909e - NEC909e
75. PC- TS507N1S - LaVieTab PC-TS507N1S
76. PC-508T1W - PC-TS508T1W
77. PC-708T1W - PC-TS708T1W
78. PC-TE307N1W - PC-TE307N1W
79. PC-TE508HAW - PC-TE508HAW
80. PC-TE510N1B - LaVieTab PC-TE510N1B

## NESO

1. N810 i7 - N810 i7

## NGM Italia SRL

1. Danamic Now - Now
2. Dynamic Racing 3 - Dynamic Racing 3
3. Dynamic\_Stylo - NGM\_Dynamic\_Stylo
4. E407 - E407
5. E451 - E451
6. E505 Plus - E505plus
7. E506plus - E506plus
8. E553 - E553
9. Endurance - ForwardEndurance
10. ForwardZero - ForwardZero
11. Forward\_Prime - Forward\_Prime
12. Infinity - Infinity
13. LIFE - Life
14. M500 - NGM M500
15. M502 - M502
16. NGM Youcolor E400 - E400
17. NGM Youcolor E450 - E450
18. NGM Youcolor E501 - E501
19. NGM Youcolor E505 - E505
20. NGM Youcolor E506 - E506
21. NGM Youcolor E507 - E507
22. P503 - NGM P503
23. P508 - P508
24. P509 - P509
25. P550 - NGM P550
26. P551 - P551
27. P552 - P552
28. Ruby - Forward Ruby
29. Ruby - ForwardRuby
30. Smart5 - Smart5
31. Smart5.5 - Smart5.5
32. Smart5.5Plus - Smart5.5Plus32GB
33. Smart5Plus - Smart5Plus

## NVIDIA

1. SHIELD Android TV - SHIELD Android TV
2. SHIELD Android TV - SHIELD Console
3. SHIELD TV - SHIELD Android TV
4. SHIELD Tablet - SHIELD Tablet
5. Shield - SHIELD
6. TegraNote - Tegra Note 7
7. TegraNote - TegraNote-P1640
8. TegraNote - TegraNote-Premium
9. TegraNote - Tegra Note 7

## NYX Mobile

1. A1 - NYX\_A1
2. BLINK - BLiNK
3. GLAM - GLAM
4. HIT - NYX\_HIT
5. KiN - KiN
6. NOBA - NOBA
7. REX - Rex
8. SENSE - SENSE
9. SHADE - NYX\_SHADE

## Nabi

1. 2 Tablet - NABI2-NV7A
2. 2S Tablet - SNB02-NV7A
3. American Girl Tablet - NBTY07SMKG
4. Barbie Tablet - NBTY07SMKG
5. Big Tab HD 20" - DMTAB-NV20A
6. Big Tab HD 24" - DMTAB-NV24A
7. DreamTab HD8 Tablet - DMTAB-IN08A
8. DreamTab HD8 Tablet - DMTAB-NV08B
9. Fisher Price Learning Tablet - NBF07PMKG
10. Hot Wheels Tablet - NBTY07SMKG
11. TOY 7 - NBTY07SMKG

## NanoTech

1. Nuvola NP-1 - Nuvola NP-1

## Navitel

1. Navitel T700 3G Navi - NAVITEL T700 3G NAVI
2. T500 3G - T500 3G

## Navon

1. D455 - D455
2. D504 - D504
3. F552 - NAVON F552
4. IQ7 - IQ7
5. Infinity - Navon\_Infinity
6. M505 - M505\_4G
7. Platinum 10 3G - Platinum 10 3G
8. Platinum 10 3G - Platinum\_10\_3G\_V2
9. Predator 10 - Predator 10
10. Predator 3G - Predator 3G
11. S450 - S450
12. Supreme Fine - Supreme\_Fine
13. Supreme Fine Mini - Supreme\_Fine\_Mini
14. Supreme Fine Plus - Supreme\_Fine\_Plus
15. Supreme Pro - Supreme\_Pro
16. T400 - T400
17. T400 3G - T400 3G 2017
18. T452 - T452
19. T503 - T503

## Ncredible

1. NV8 - NV8
2. NV8-HD - NV8

## Neffos

1. C5 - Neffos C5
2. C5 Max - Neffos C5 Max

3. C5L - TP601A
4. C5L - TP601B
5. C5L - TP601C
6. C5L - TP601E
7. X1 - Neffos X1
8. X1 Lite - Neffos X1 Lite
9. X1 Max - Neffos X1 Max
10. Y5 - Neffos Y5
11. Y50 - Neffos Y50
12. Y5L - Neffos Y5L
13. Y5L - Neffos Y5L

## Neostra

1. Neostra-R10 - Neostra-R10
2. Neostra-R10C - Neostra-R10C
3. Neostra-R7 - Neostra-R7

## Netgear

1. NeoTVPrime - GTV100

## New Balance

1. Run IQ - NB RunIQ

## Nexian

1. journey one - Mi438S

## Next Learning

1. Nexttab N3 - N3

## Nextbase

1. GoPlayer - NBCGGP01

## Nextbit

1. Robin - Robin

## Nextbook

1. M-MP7NB3G - M-MP7NB3G
2. NX16A10132S - NX16A10132S
3. NX16A11264 - NX16A11264
4. NX16A8116K - NX16A8116K
5. NX700QC - NX700QC
6. NX785QC - NX785QC
7. NX785QC8G - NX785QC8G
8. NXA101LTE116 - NXA101LTE116
9. NXA116QC164 - NXA116QC164
10. NXA8LTE116 - NXA8LTE116
11. NXA8QC116 - NXA8QC116

## Nextel

1. V.35 - Nextel V.35
2. V.45 - NII Nextel
3. V.45 - V.45

## Nikon

1. COOLPIX - COOLPIX S800c
2. COOLPIX S810c - COOLPIX S810c

## Nixon

1. The Mission - The Mission

## Njoy

1. Arcas 7 - nJoy\_Arcas\_7
2. Chronos 10 - Chronos\_10
3. Kali 8 - Kali\_8
4. Tityos 10 - nJoy\_Tityos\_10
5. Turnus 8 - nJoy\_Turnus\_8
6. nJoy Theia 10 - Theia\_10

## Nobis

1. NB07 - NB07
2. NB09 - NB09
3. NB1022 - NB1022
4. NB7022S - NB7022S
5. NB7850S - NB7850S

## Noblex

1. Go Action - N551
2. Go Urban - N503
3. NBX-T1014N - TA10CA2
4. NBX-T7014 - NBX-T7014

## Nokia

1. N1 - N1
2. Nokia 3 - TA-1020
3. Nokia 3 - TA-1028
4. Nokia 3 - TA-1032
5. Nokia 3 - TA-1038
6. Nokia 5 - TA-1024
7. Nokia 5 - TA-1027
8. Nokia 5 - TA-1044
9. Nokia 5 - TA-1053
10. Nokia 6 - TA-1000
11. Nokia 6 - TA-1003
12. Nokia 6 - TA-1021
13. Nokia 6 - TA-1025
14. Nokia 6 - TA-1033
15. Nokia 6 - TA-1039
16. Nokia 7 - TA-1041
17. Nokia 8 - TA-1004
18. Nokia 8 - TA-1012
19. Nokia 8 - TA-1052

## Nomi

1. i5032 - i5032
2. Nomi C070011 - Nomi C070011
3. Nomi C080010 - Nomi C080010 Libra2
4. Nomi C101010 - C101010 Ultra2
5. Nomi i5013 - i5013
6. Nomi i5050 - i5050
7. Nomi i5510 - i5510
8. Nomi i5532 - i5532
9. Nomi i6030 - Nomi i6030
10. i5012 - i5012

## Nous

1. NS5002 - NS5002
2. NS5502 - NS5502

## NuAns

1. NEO [Reloaded] - NEO [Reloaded]

## Nubia

1. NX401 - NX401
2. NX501 - NX501
3. NX503A - NX503A

## Nuu

1. A1 - NUU\_A1
2. A3 - NUU\_A3
3. A3L - NUU\_A3L
4. A4L - N5001L
5. M2 - NUU\_M2
6. M3 - NUU\_M3
7. N4L - N4L
8. N5L - N5L
9. X4 - X4
10. X5 - NUU\_X5
11. Z8 - Z8

## Nuvision

1. TM101A530L - TM101A530L
2. TM101A540N - TM101A540N
3. TM101A730M - TM101A730M
4. TM106A510L - TM106A510L
5. TM1088 - CT1000
6. TM1088 - Endeavour101
7. TM1088 - TM1088
8. TM1088 - WEBPAD1002
9. TM700A520L - TM700A520L
10. TM785M3 - TM785M3
11. TM800A510L - TM800A510L
12. TM800A550L - TM800A550L
13. TM800A730M - TM800A730M
14. TM800A740M - TM800A740M

## ODYS

1. PACE 10 - PACE10
2. XELIO\_HD10 - XELIO\_HD10

## Obi

1. MV1 - OBI MV1
2. MV1 - Obi MV1
3. OBJ SJ1.5 - SJ1-5

## Oceusnetworks

1. XiphosTMD - Xiphos(R)TMD

## Odys

1. UNO X10 - UNO X10
2. UNO X8 - UNO\_X8

## Oioo

1. Model 2 - Model 2
2. Model 3 - Model 3

## Olive Oil

1. CT4 - Octopus A83 CT4
2. OliveOil Model 3 - CT3

## Olivetti

1. Graphos A10 - Graphos A10
2. OP110 - OP110

## Ollee

1. XT080 - XT080

## OnePlus

1. 2 - ONE A2003
2. 3 - ONEPLUS A3000
3. One - A0001
4. One - One
5. OnePlus - ONE E1003
6. OnePlus2 - ONE A2003
7. OnePlus3 - ONEPLUS A3000
8. OnePlus3T - ONEPLUS A3000
9. OnePlus5 - ONEPLUS A5000
10. X - ONE E1003

## Onkyo

1. DP-CMX1 - DP-CMX1
2. DP-X1 - DP-X1
3. DP-X1A - DP-X1A

## OpenPeak

1. CIUS-7 - CIUS-7
2. CIUS-7-AT - CIUS-7-AT
3. cius - cius

## Oppo

1. 1100 - 1100
2. 1105 - 1105
3. 1107 - 1107
4. 1201 - 1201
5. 1206 - 1206
6. 3000 - 3000
7. 3001 - 3001
8. 3005 - 3005
9. 3006 - 3006
10. 3007 - 3007
11. 3008 - 3008
12. A11 - A11
13. A11f - A11f
14. A11t - A11t
15. A11w - A11w
16. A13t - A31t
17. A1601 - A1601
18. A1601 - A1601fw
19. A1601fw - A1601fw
20. A1603 - A1603



21. A31 - A31
22. A31c - A31c
23. A31u - A31u
24. A33 - A33
25. A33f - A33f
26. A33f - A33fw
27. A33fw - A33fw
28. A33m - OPPO A33m
29. A33t - A33t
30. A33w - A33w
31. A35 - OPPO A35
32. A37 - OPPO A37
33. A37 - OPPO A37m
34. A37f - A37f
35. A37f - A37fw
36. A37fw - A37fw
37. A37fw - A37fw
38. A37fw-International - A37f
39. A37m - OPPO A37m
40. A37t - OPPO A37t
41. A37tm - OPPO A37tm
42. A39 - OPPO A39
43. A39m - OPPO A39m
44. A39t - OPPO A39t
45. A39tm - OPPO A39tm
46. A51 - A51
47. A51 - Lava A51
48. A51f - A51f
49. A51fa - A51f
50. A51kc - A51kc
51. A51w - A51w
52. A53 - OPPO A53
53. A53f - A53f
54. A53fw - A53fw
55. A53m - OPPO A53m
56. A53w - A53w
57. A57 - OPPO A57
58. A57 - OPPO A57t
59. A57t - OPPO A57t
60. A59 - OPPO A59
61. A59 - OPPO A59m
62. A59m - OPPO A59m
63. A59st - OPPO A59st
64. A59t - OPPO A59t
65. A59tm - OPPO A59tm
66. A77 - OPPO A77
67. A77 - OPPO A77t
68. CHP1705 - CPH1705fw
69. CPH1605 - CPH1605
70. CPH1605 - OPPO CPH1605
71. CPH1605fw - CPH1605fw
72. CPH1609 - CPH1609
73. CPH1609fw - CPH1609fw
74. CPH1613 - CPH1613
75. CPH1613 - CPH1613fw
76. CPH1701 - CPH1701
77. CPH1701 - CPH1701fw
78. CPH1705 - CPH1705
79. CPH1707 - CPH1707
80. CPH1707 - CPH1707fw
81. CPH1715 - CPH1715
82. CPH1717 - CPH1717
83. F1f - F1f
84. F1f - F1fw
85. F1f - F1w
86. F1fw - F1f
87. F1fw - F1fw
88. F1w - F1f
89. F1w - F1w
90. Find 5 - X909
91. Find5 - X909
92. Find5 - X909T
93. N1 - N1
94. N1 mimi - N5111
95. N1 mimi - N5116
96. N1T - N1T
97. N1W - N1W
98. N3 - N5206
99. N3 - N5207
100. N3 - N5209
101. N5110 - N5110
102. N5117 - N5117
103. R1001 - R1001
104. R1001 - R1001
105. R1011 - R1011
106. R1011w - R1011
107. R11 - OPPO R11
108. R11 - OPPO R11t
109. R11 Plus - OPPO R11 Plus
110. R11 Plusk - OPPO R11 Plusk
111. R11 Pluskt - OPPO R11 Pluskt
112. R11 Plust - OPPO R11 Plust
113. R2001 - R2001
114. R2010 - R2010
115. R2017 - R2017
116. R5 - R8106
117. R5 - R8107
118. R5 - R8109
119. R6006 - R6006
120. R6007 - R6007
121. R7 - OPPO R7
122. R7 - R7
123. R7 Lite - R7kf
124. R7 Plus - R7Plus
125. R7 Plusf - R7plusf
126. R7 Plusm - R7Plusm
127. R7005 - R7005
128. R7007 - R7007
129. R7Plusf - R7plusf
130. R7Plust - R7Plust
131. R7c - R7c
132. R7f - R7f
133. R7g - R7g
134. R7kc - R7kc
135. R7kf - R7kf
136. R7kt - R7kt
137. R7s - OPPO R7s
138. R7s - R7s
139. R7s Plus - OPPO R7sPlus
140. R7sf - R7sf
141. R7sfg - R7sf
142. R7sm - R7sm
143. R7st - R7st
144. R7t - R7t

145. R8000 - R8000  
146. R8001 - R8001  
147. R8006 - R8006  
148. R8007 - R8007  
149. R809T - R809T  
150. R8106 - R8106  
151. R815 - R815  
152. R815T - R815T  
153. R815W - R815W  
154. R819 - R819  
155. R819T - R819T  
156. R820 - R820  
157. R8200 - R8200  
158. R8201 - R8201  
159. R8205 - R8205  
160. R8206 - R8206  
161. R8207 - R8207  
162. R821 - R821  
163. R821T - R821T  
164. R823T - R823T  
165. R827 - R827  
166. R827T - R827T  
167. R829 - R829  
168. R829T - R829T  
169. R830 - R830  
170. R830S - R830S  
171. R831 - R831  
172. R831 - R831T  
173. R831K - R831K  
174. R831L - R831L  
175. R831S - R831S  
176. R831T - R831T  
177. R833T - R833T  
178. R850 - R850  
179. R9 - OPPO R9  
180. R9 - OPPO R9km  
181. R9 - OPPO R9m  
182. R9 - OPPO R9tm  
183. R9 Plus - OPPO R9 Plusm A  
184. R9 Plus - OPPO R9 Plustm A  
185. R9 Plus A - OPPO R9 Plus A  
186. R9Plus - X9079  
187. R9PlusA - OPPO R9 Plusm A  
188. R9PlusA - OPPO R9 Plustm A  
189. R9Plusm A - OPPO R9 Plusm A  
190. R9PlustA - OPPO R9 Plust A  
191. R9Plustm A - OPPO R9 Plustm A  
192. R9k - OPPO R9k  
193. R9k - OPPO R9km  
194. R9k - OPPO R9m  
195. R9k - OPPO R9tm  
196. R9km - OPPO R9km  
197. R9m - OPPO R9m  
198. R9s - CPH1607  
199. R9s - CPH1607fw  
200. R9s - OPPO R9s  
201. R9s Plus - CPH1611  
202. R9s Plus - OPPO R9s Plus  
203. R9s Plus - OPPO R9s Plust  
204. R9s Plus - OPPO R9sPlus  
205. R9sk - OPPO R9sk  
206. R9sk - OPPO R9skt

207. R9st - OPPO R9st  
208. R9t - OPPO R9t  
209. R9tm - OPPO R9tm  
210. U3 - U3  
211. U707 - U707  
212. U707T - U707T  
213. U708 - U708  
214. Ulike2 - U705W  
215. Ulike2 - U705T  
216. X9000 - X9000  
217. X9006 - X9006  
218. X9007 - X9007  
219. X9009 - X9009  
220. X9009fw - X9009fw  
221. X9070 - X9070  
222. X9076 - X9076  
223. X9077 - X9077  
224. X9077 - X9077  
225. X9079 - X9079  
226. X909 - X909  
227. X909 - X909  
228. X909 - X909T

## Opticon

1. H-27 - H-27

## Oraimo

1. R401 - oraimo R401  
2. R402 - oraimo R402  
3. oraimo R401S - oraimo R401S

## Orange

1. ALCATEL PIXI 4 (5) - Orange-Rise51  
2. ALCATEL PIXI 4 (5) - Orange-Rise51B  
3. Dive 30 - Orange Dive 30  
4. Dive 30 - ZTE Blade A410  
5. Dive 50 - Orange Dive 50  
6. Dive 50 Dual - Dive 50 Dual  
7. Dive 71 - Orange Dive 71  
8. Dive72 - Orange-Dive72  
9. Dive\_70 - SCL-L01  
10. Doro 8042 - Doro 8042  
11. Five - OrangeFive  
12. Luno - Luno  
13. NOS Roya - NOS Roya  
14. Neva 80 - Orange Neva 80  
15. Nura - Orange Nura  
16. Nura2 - Nura 2  
17. Rise 30 - Orange Rise 30  
18. Rise 40 - Orange Rise 40  
19. Rise 50 - Rise50  
20. Rise30 - Orange-Rise30  
21. Rise31 - Orange-Rise31  
22. Rise32 - Orange Rise32  
23. Rise51 - Orange-Rise51  
24. Rise52 - Orange-Rise52  
25. Roya - Orange Roya  
26. Sego - Orange Sego  
27. Zilo - Zilo  
28. idol S - Orange Niva

## Orbic

1. R370H - R370L

## Other

1. AD681H - Smartfren Andromax AD681H
2. FJL21 - FJL21
3. T31 - Panasonic T31
4. hws7721g - MediaPad 7 Youth 2
5. -

## Oukitel

1. C6 Pro - C6 Pro
2. K10000 Pro - K10000 Pro
3. K10000\_Max - K10000 Max
4. K6000 Plus - K6000 Plus
5. U20\_Plus - U20\_Plus

## OwnMobile

1. FUN VALUE 4G - FUN VALUE 4G
2. OWN Smart 2 - SMART\_O2
3. SMART 8 - Smart8
4. Smart Plus Lte - SMART PLUS LTE

## Oysters

1. T72HM3G - T72HM3G
2. T72HMs 3G - T72HMs\_3G

## PC Smart

1. PCSGOB10MVA-A - PCSGOB10MVA-A
2. PCSGOB10SF-A - PCSGOB10SF-A
3. PTSGOB8 - PC\_Smart\_PTSGOB8

## PCD Argentina

1. PCD508 - PCD508
2. PCD509 - PCD509

## POC

1. POC2 - POC2

## Packard Bell

1. PB1009 - PB1009
2. T1000 - T1000

## Panasonic

1. H580VT\_A - JT-H580VT
2. H581VT\_A - JT-H581VT
3. P-08D - P-08D
4. Iaputa - P-07C
5. 003P - 003P
6. 101P - 101P
7. 102P - 102P
8. 43DX400C - DX01C
9. 48AX600C - 48AX600C
10. 55AX600C - 55AX600C
11. 55DX600C - TH-55DX600C
12. AS650C - AS650C
13. AX600C - AX600C

14. Altus 18 - Altus 18
15. Altus 24 - Altus 24
16. Boukenkun-reciever - VW\_RCBKK1
17. EB-4063-X - EB-4063-X
18. ELUGA - dL1
19. ELUGA A - Panasonic ELUGA A
20. ELUGA A3 - ELUGA\_A3
21. ELUGA A3 Pro - ELUGA\_A3\_Pro
22. ELUGA A4 - ELUGA A4
23. ELUGA I - Panasonic ELUGA I
24. ELUGA I2 Activ - ELUGA\_I2\_Activ
25. ELUGA I3 Mega - ELUGA I3 Mega
26. ELUGA I4 - ELUGA I4
27. ELUGA I5 - ELUGA\_I5
28. ELUGA I9 - Eluga I9
29. ELUGA L 4G - Panasonic ELUGA L 4G
30. ELUGA P - P-03E
31. ELUGA PURE - Panasonic\_ELUGA\_Pure
32. ELUGA Power - P-07D
33. ELUGA Prim - ELUGA Prim
34. ELUGA Ray 500 - ELUGA Ray 500
35. ELUGA Ray 700 - Eluga\_Ray\_700
36. ELUGA S - Panasonic ELUGA S
37. ELUGA S Mini - Panasonic ELUGA S Mini
38. ELUGA Turbo - ELUGA Turbo
39. ELUGA U - Panasonic ELUGA U
40. ELUGA U2 - Panasonic ELUGA U2
41. ELUGA V - P-06D
42. ELUGA WE - Panasonic ELUGA WE
43. ELUGA X - P-02E
44. ELUGA dL1 - Panasonic\_dL1
45. EX00C - EX00C
46. EX01C - EX01C
47. EX02C - EX02C
48. Eco11 v2 - Eco11 v2
49. Eco12 v3 - Eco v3
50. Eco9 v1 - Eco9 v1
51. Eco9 v2 - Eco9 v2
52. Elite 11 - Elite
53. Elite 11 - Elite 11
54. Elite 12 - Elite
55. Elite 12 v3 - Elitev3
56. Elite 16 - Elite
57. Elite 18 - Elite
58. Elite13 v3 - Elitev3
59. Elitev3a - Elite v3a
60. Eluga A2 - Eluga\_A2
61. Eluga Arc - Panasonic ELUGA Arc
62. Eluga Arc 2 - Eluga\_Arc\_2
63. Eluga I2 - ELUGA\_I2
64. Eluga I3 - Panasonic\_Eluga\_I3
65. Eluga Icon 2 - Panasonic ELUGA Icon 2
66. Eluga Klik - Eluga Klik
67. Eluga Mark 2 - Eluga\_Mark\_2
68. Eluga Pulse - ELUGA\_Pulse
69. Eluga Pulse X - ELUGA\_Pulse\_X
70. Eluga Ray - ELUGA Ray
71. Eluga Ray Max - ELUGA Ray Max
72. Eluga Ray X - ELUGA Ray X
73. Eluga Tapp - Panasonic ELUGA Tapp
74. Eluga Z - Panasonic ELUGA Z
75. Eluga\_Note - ELUGA Note

76. FZ-A1 - FZ-A1B  
77. FZ-A1B - FZ-A1B  
78. FZ-A2A - FZ-A2A  
79. FZ-B2 - FZ-B2B  
80. FZ-B2D - FZ-B2D  
81. FZ-N1 - FZ-N1  
82. FZ-N1 - FZ-N1  
83. FZ-N1 - FZ-N1  
84. FZ-N1 - FZ-N1  
85. FZ-N1 - FZ-N1  
86. FZ-N1 - FZ-N1  
87. FZ-N1 - FZ-N1  
88. FZ-N1 - FZ-N1  
89. FZ-N1VUCL - FZ-N1  
90. FZ-X1 - FZ-N1  
91. FZ-X1 - FZ-X1  
92. FZ-X1 - FZ-X1  
93. FZ-X1 - FZ-X1  
94. HDPSEB v2 - HD PSEB v2  
95. JT-B1 - JT-B1  
96. KX-PRXA10 - Panasonic KX-PRXA10  
97. KX-PRXA15 - Panasonic KX-PRXA15  
98. LUMIX CM1 - DMC-CM1  
99. P-01D - P-01D  
100. P-02D - P-02D  
101. P-04D - P-04D  
102. P-05D - P-05D  
103. P-07C - P-07C  
104. P11 - Panasonic P11  
105. P31 - Panasonic P31  
106. P41 - Panasonic P41  
107. P41 HD - Panasonic P41HD  
108. P51 - Panasonic P51  
109. P55 - Panasonic P55  
110. P55 Max - P55 Max  
111. P55 Novo - Panasonic P55 Novo  
112. P55 Novo - P55 Novo 4G  
113. P61 - Panasonic P61  
114. P61 - Panasonic\_P61  
115. P66 - P66  
116. P71 - P71  
117. P75 - Panasonic P75  
118. P77 - Panasonic P77  
119. P81 - Panasonic P81  
120. P85 - Panasonic P85  
121. P88 - P88  
122. P9 - P9  
123. P91 - P91  
124. P99 - Panasonic P99  
125. Panasonic P100 - Panasonic P100  
126. SDU - 9 inch SDU  
127. SDU - SDU  
128. SM17 - Smart Monitor 17  
129. SV-ME1000 - Panasonic SV-ME1000  
130. SmartTVBox - SMARTTVBOX  
131. T11 - Panasonic T11  
132. T21 - Panasonic T21  
133. T30 - Panasonic T30  
134. T31 - Panasonic T31  
135. T33 - Panasonic T33  
136. T40 - Panasonic T40  
137. T41 - Panasonic T41

138. T44 - Panasonic T44  
139. T44 Lite - Panasonic T44 Lite  
140. T9 - Panasonic T9  
141. TAB-A01 - TAB-A01-SD  
142. TAB-A02 - TAB-A02-SD  
143. TH-49DX400C - DX00C  
144. TH-55DR600C - TH55DR600C  
145. TH-55DX700C - TH\_55DX700C  
146. TH-65DR800C - TH-65DR800C  
147. TH-65DX400C - TH\_65DX400C  
148. Translation device - WA-P7  
149. UN-MT300 - Panasonic UN-MT300  
150. UN-W700 - Panasonic UN-W700  
151. VHS v2 - Video Handset  
152. VTSH v1 - VTSH v1  
153. WSCU - WSCU3

## Pantech

1. ADR910L - ADR910L  
2. ADR930L - ADR930L  
3. AT1 - IM-T100K  
4. Apache - ADR8995  
5. Burst - PantechP9070  
6. Crossover - PantechP8000  
7. EF33S - IM-A760S  
8. EF34K - IM-A770K  
9. EF35L - IM-A780L  
10. Element - PantechP4100  
11. Flex - PantechP8010  
12. IM-100GN - IM-100GN  
13. IM-100K - IM-100K  
14. IM-100S - IM-100S  
15. IM-810K - IM-A810K  
16. IM-840SP - IM-A840SP  
17. IM-A730S - IM-A730S  
18. IM-A740S - IM-A740S  
19. IM-A760S - IM-A760S  
20. IM-A770K - IM-A770K  
21. IM-A775C - IM-A775C  
22. IM-A780L - IM-A780L  
23. IM-A800S - IM-A800S  
24. IM-A810K - IM-A810K  
25. IM-A810S - IM-A810S  
26. IM-A830K - IM-A830K  
27. IM-A830KE - IM-A830KE  
28. IM-A830L - IM-A830L  
29. IM-A830S - IM-A830S  
30. IM-A840S - IM-A840S  
31. IM-A850K - IM-A850K  
32. IM-A850L - IM-A850L  
33. IM-A850S - IM-A850S  
34. IM-A860K - IM-A860K  
35. IM-A860L - IM-A860L  
36. IM-A860S - IM-A860S  
37. IM-A870K - IM-A870K  
38. IM-A870L - IM-A870L  
39. IM-A870S - IM-A870S  
40. IM-A880S - IM-A880S  
41. IM-A910K - IM-A910K  
42. IM-A910L - IM-A910L  
43. IM-A910S - IM-A910S  
44. IM-A920S - IM-A920S



45. IM-A940K - IM-A940K
46. Izar - SKY IM-A630K
47. MIRACH\_J - EIS01PT
48. MIRACH\_J - IS11PT
49. Mirach - IM-A690L
50. Mirach - IM-A690S
51. Mirach A - IM-A750K
52. P9090 - PantechP9090
53. PLANET - PLANET
54. PTL21 - PTL21
55. Pocket - PantechP9060
56. SIRIUS - IS06
57. Sirius - SKY IM-A600S
58. V955 - Pantech V955
59. VEGA RACER - IM-A770K
60. VEGA RACER - IM-A780L
61. VEGA Secret Note - IM-A890K
62. VEGA Secret Note - IM-A890L
63. VEGA Secret Note - IM-A890S
64. VEGA Secret UP - IM-A900S
65. VEGA Secret UP - IM-A900K
66. VEGA Secret UP - IM-A900L
67. VEGA Secret UP - IM-A900S
68. VEGA Secret UP - IM-A900K
69. VEGA Secret UP - IM-A900L
70. Vega - SKY IM-A650S
71. Vega LTE M - IM-A820L
72. Vega X - IM-A720L
73. Vega X - IM-A710K
74. ef14lv - IM-A725L
75. v950 - Pantech V950
76. v955 - Pantech V955
- QM152E
5. 4K & Full HD Slim LED TV powered by Android - QM152E
6. 4K LED TV powered by Android - TPM171E
7. 4K Razor Slim LED TV powered by Android TV - QM151E
8. 4K Razor Slim OLED TV powered by Android TV - QM161E
9. 4K UHD Razor Slim LED TV powered by Android - QV151E
10. 4K Ultra Slim LED TV powered by Android - QM163E
11. Android 2014 - AND1E
12. E1027 - E1027
13. FHD Ultra Slim LED TV Powered by Android - QM164E
14. HMP8100/93 - HMP8100\_ATV\_93
15. HMP8100/98 - HMP8100\_ATV\_INT
16. PHILIPS - TLE722G
17. PHP-S221C4AFD - G3SMNTS22
18. PHP-S231C4AFD - G3SMNTS23
19. PI2000 - PI2000
20. PI2010 - PI2010
21. PI2011 - PI2011
22. PI3100/51 - PI3100
23. PI3100/58 - PI3100
24. PI3100/93 - PI3100-93
25. PI3100/98 - PI3100
26. PI3100Z3/93 - PI3100Z3\_93
27. PI3105 - PI3105
28. PI3106 - PI3106
29. PI3110 - PI3110
30. PI3205G - PI3205G
31. PI3210G - PI3210G
32. PI3900 - PI3900-93
33. PI3900/51 - PI3900
34. PI3900/58 - PI3900
35. PI3900/98 - PI3900
36. PI3910 - PI3910
37. PI4010G - PI4010G
38. PI7100/93 - PI7100\_93
39. Philips S310X - Philips S310X
40. Philips S318 - Philips S318
41. Philips S329 - Philips S329
42. Philips V787 - Philips Xenium V787
43. Philips X596 - Philips X596
44. Philips X598 - Philips X598
45. Philips X818 - Philips X818
46. Philips S398 - Philips S398
47. S221C3A - G2SMNT
48. S308 - Philips S308
49. S309 - Philips S309
50. S326 - Philips\_S326
51. S327 - Philips S327
52. S337 - Philips S337
53. S337 - Philips S337
54. S337 - Philips S337
55. T8 PI7000 - PI7000
56. V377 - Philips V377
57. V387 - Philips V387
58. V526 - Philips V526
59. V787 - Philips Xenium V787
60. W337 - W337
61. W3500 - Philips\_W3500

## Partner

1. Batman - S70PCI
2. OT-310 - OT-310

## Pavapro

1. PavaPro7bk - Pavapro7bk
2. Pavapro10 - Pavapro10bk

## Pegatron

1. Duke3G - Android Tablet PC
2. DukeWifi - Android Tablet PC
3. TabletPC - Android Tablet PC
4. MaxiIQ - MaxiIQ
5. Olipad - chagall
6. chagall - Chagall 10.1 WiFi
7. chagall - E-Tab 4G
8. chagall - chagall

## Philco

1. PTB7PAP\_PT7B7PAB\_PT7B7PAR - PTB7PAP\_PT7B7PAB\_PT7B7PAR

## Philips

1. Philips\_GGC3 - SA3CNT
2. Philips\_PI5000 - Philips\_PI5000
3. SA2CNTxx - Philips GoGear Connect
4. 4K & Full HD Slim LED TV powered by Android -

62. W3568 - Philips W3568
63. W3620 - W3620
64. W6500 - W6500
65. W6610 - Philips W6610
66. W6620 - W6620
67. W8510 - Philips W8510
68. W8555 - Philips W8555
69. X586 - Philips\_X586
70. X586 - Philips\_X586
71. X588 - Philips X588
72. X818 - Philips X818
73. X818 - Philips X818
74. X818 - Philips X818
75. Xenium S386 - Philips S386
76. Xenium V377 - Philips V377

## Pioneer

1. B.PRO - jupiter
2. B.PRO - jupiter
3. CyberNavi - jupiter
4. CyberNavi - jupiter
5. CyberNavi - jupiter
6. CyberNavi - jupiter
7. CyberNavi - jupiter
8. CyberNavi - jupiter
9. CyberNavi - jupiter
10. Navigation - jupiter
11. Navigation - jupiter
12. R1 - R1
13. XDP-100R - XDP-100R
14. XDP-300R - XDP-300R

## Pixela

1. KSTB5043 - KSTB5043

## Plaisio

1. A2 - Turbo-X\_A2
2. Calltab 7 - Calltab7inch
3. Calltab2GB10.1" - Calltab2GB10
4. CalltabII 10.1 - Calltab10.1
5. Coral II - Turbo-X Coral II
6. G320 - G320
7. Hive V 3G - Hive V 3G
8. Hive V 3G - Hive V 3G
9. I4G - TURBOX\_I4G
10. Lithium Ion - Turbo-X\_e3
11. Rainbow II 3G 8" - RainbowII 3G
12. RainbowIII3G - RainbowIII3G
13. Rubik-II - RubikII7
14. Rubik10.1"II - Rubik 10.1 II
15. RubikII 10" - Rubik 10.1 II
16. Rubik\_10\_III - Rubik\_10\_III
17. Turbo-X Twister - QUAD-CORE A33 inet
18. Turbo-X s2 - s2
19. Turbo-X\_epsilon - Turbo-X\_epsilon
20. Turbo-X\_pi\_4G - Turbo-X\_pi\_4G
21. Turbo-X\_z - Turbo-X\_z
22. Turbox\_A3 - Turbox\_A3
23. Turbox\_S3 - Turbox\_S3
24. lamda - Turbo-X lamda

## Plus4

1. Q-Touch - Q-Touch

## Plusone

1. FREETEL Priori3S - FTU152A
2. FREETEL SAMURAI KIWAMI 2 - FTJ162B
3. FREETEL Samurai Rei - FTJ161B
4. FTJ152C - FTJ152C
5. FTJ161A - FTJ161A
6. FTU152D - FTU152D
7. Fun + - FTU161G
8. Fun + - Fun +
9. Ice 2 - FTJ161E-VN
10. Ice 2 - FTE161E
11. Ice 2 - ICE2
12. Kiwami - FTJ152D
13. Priori 3 - FTJ152A
14. Priori3S - FTJ152B
15. Smart HD - Smart\_HD

## PointMobile

1. PM66 - PM66
2. PM70 - PM70
3. PM80 - PM80

## Polar

1. M600 - Polar M600

## Polaris

1. Condroid\_X7 - Condroid\_X7

## Polaroid

1. A/S10 - A/S10
2. A/S7 - A/S7
3. A/S8 - A/S8
4. A6 - A6
5. A7X\_PTAB735X - A7X\_PTAB735X
6. A7\_PTAB735 - HS-7DTB39
7. A9x/PTAB935x - A9x/PTAB935x
8. Cosmo L - P5026A
9. Cosmo P5s - P5046A
10. Cosmo Z - P5047A
11. Infinite - MID 1324
12. K7 - K7/PTAB782
13. L9 - L9
14. MID1028 - MID1028
15. MID4X07 - MID4X07
16. MID4X10 - MID4X10
17. P10/Q10/PTAB1040/PTAB1041 - P10/Q10/PTAB1040/PTAB1041
18. P1000 - P1000
19. P1001 - P1001
20. P4526A - P4526A
21. P5006A - P5006A
22. P5526A - P5526A
23. P7/Q7/PTAB740/PTAB741 - P7/Q7/PTAB740/PTAB741
24. P791 - P791
25. P9/Q9/PTAB940/PTAB941 - P9/Q9/PTAB940/PTAB941
26. P900 - P900/Q900

27. P901 - P901
28. PMID7102DC - PMID7102DC
29. PRO5023PW - PRO5023PW
30. PRO5043 - PRO5043
31. PRO5044PEE01 - PRO5044PEE01
32. PRO5544PEE01 - PRO5544PEE01
33. PRO5584PHE01 - PRO5584PHE01
34. PTAB1051-PTAB1055 - PTAB1051\_PTAB1055
35. PTAB751 - PTAB751
36. Phantom 5 - PRO5023
37. SIGMA 5 - SIGMA-5
38. SOHO - SOHO
39. V45M - CARBON\_PRO4543
40. V7 - V7

## Polytron

1. P500 - P500
2. POLYTRON R2509 - POLYTRON R2509
3. POLYTRON R2509SE - POLYTRON R2509SE

## Porsche

1. Rear Seat Entertainment - Porsche Rear Seat Entertainment

## Positivo

1. 8MA-A - 8MA-A 3G
2. AB10PGN - AB10PGN
3. AB7 - YPY\_AB7D
4. AB7D - YPY\_AB7DC
5. BGH 7Di-A - Positivo BGH 7Di-A
6. BGH Y200 - Positivo BGH Y200
7. BGH Y230 - Y230
8. First - First
9. Life - S421 Positivo Life
10. Mini - Positivo Mini
11. Mini - Positivo Mini TE
12. Next - Positivo Next
13. OCTA - OCTA
14. One - Positivo One
15. One - S420
16. S380 - S380
17. S430 Positivo Twist Mini - S430 Positivo Twist Mini
18. S440 - S440
19. S450 - S450
20. S480 - S480
21. S550 - S550
22. SX1000 - Positivo SX1000
23. Selfie - S455
24. Stilo T725 - Stilo T725
25. T1060 - T1060
26. T1060 - T1060B
27. T1060 - T1060C
28. T1075 - Positivo T1075
29. T701 TV - T701
30. T705 - T705
31. T705 - T705/T708
32. T705 - T705K
33. T710 - Positivo T710
34. T715 - Stilo T715
35. T730 - Positivo Stilo T730 Kids
36. T750 - Positivo T750

37. Twist - Positivo Twist M
38. Twist - Positivo Twist S
39. Twist 4G - Positivo Twist 4G
40. Twist Max - Twist Max
41. Twist Mini - Twist Mini
42. Twist XL - Twist XL
43. Union US2070 - Positivo US2070
44. X400 - X400
45. YPY 10 3G - YPY\_10FTA
46. YPY AB7 - Positivo Ypy AB7E
47. YPY AB7 - Positivo Ypy AB7EC
48. YPY S400 - YPY\_S400
49. YPY7 3G - Positivo Ypy 7 - TB07FTA
50. YPY7 3G - Ypy 7 - TB07FTA
51. YPY7 3G - YPY\_07FTA
52. YPY7 wifi - Positivo Ypy 7 - TB07STA
53. YPY7 wifi - Ypy 7 - TB07STA
54. YPY7 wifi - YPY\_07STA
55. Ypy 07FTB - POSITIVO TABLET YPY 07FTB PM BELM
56. Ypy 07FTB - YPY\_07FTB
57. Ypy 07FTBF - YPY\_07FTBF
58. Ypy 07STB - YPY\_07STB
59. Ypy 07STBF - YPY\_07STBF
60. Ypy 10FTB - YPY\_10FTB
61. Ypy 10FTBF - YPY\_10FTBF
62. Ypy 10STB - YPY\_10STB
63. Ypy 10STBF - YPY\_10STBF
64. Ypy AB10 - YPY\_AB10D
65. Ypy AB10D - YPY\_AB10DC
66. Ypy AB10DP - YPY\_AB10DP
67. Ypy AB10E - Positivo Ypy AB10E
68. Ypy AB10E - Positivo Ypy AB10EC
69. Ypy AB10H - Positivo Ypy AB10H
70. Ypy AB10i - Ypy AB10i
71. Ypy AB7F - Positivo Ypy AB7F
72. Ypy AB7F - T720
73. Ypy AB7K - YPY\_AB7K
74. Ypy Kids - Positivo Ypy L700 Kids
75. Ypy Kids - Positivo Ypy L700+ Kids
76. Ypy L1000 - Positivo Ypy L1000
77. Ypy L1000 - Positivo Ypy L1000F
78. Ypy L1050 - Positivo Ypy L1050
79. Ypy L1050 - Positivo Ypy L1050F
80. Ypy L1050E - Positivo Ypy L1050E
81. Ypy L700 - Positivo Ypy L700
82. Ypy L700 - Positivo Ypy L700 Ed. Especial
83. Ypy L700 - Positivo Ypy L700+
84. Ypy Mini - Positivo BGH Mini
85. Ypy S350 - YPY\_S350
86. Ypy S350p - YPY\_S350\_PLUS
87. Ypy S405 - YPY\_S405
88. Ypy S450 - YPY\_S450
89. Ypy S460 - YPY\_S460
90. Ypy S500 - YPY\_S500
91. Ypy TQ7 - YPY\_TQ7
92. mini I - Positivo BGH Y300
93. mini I - Positivo Mini I
94. quattro - quattro

## Positivo BGH

1. BGH Y100 - Positivo BGH Y100
2. BGH Y210 - Positivo BGH 7Di-A

3. BGH Y210 - Positivo BGH Y210
4. BGH Y400 - Y400
5. BGH Y700 - Positivo BGH Y700
6. BGH Y710 kids - Positivo BGH Y710 KIDS
7. Positivo BGH +Simple - Positivo BGH +Simple
8. Y1000 - Y1000
9. Ypy - L701 TV
10. Ypy - Positivo BGH Ypy L700
11. Ypy Kids - Positivo BGH Ypy L700 Kids

## Premio

1. P520 - P520
2. P540 - P540
3. PREMIO P450 - P450
4. Premio P610 - P610
5. Premio P620 - P620

## Prestige

1. 7G - Prestige 7G
2. ELITE10Q - Elite10Q
3. ELITE7Q - Elite7Q
4. ELITE8Q - ELITE8Q
5. ELITE8QS - Elite8QS
6. ELITE9Q - ELITE9Q
7. PRO10D - PRO10D
8. PRO7DS - PRO7DS
9. PRO8D - PRO8D
10. PRO9D - PRO9D

## Prestigio

1. GV7790 - GV7790
2. Grace - PSP7557
3. Grace 3118 3G - PMT3118\_3G
4. Grace X3 - PSP3455DUO
5. Grace X5 - PSP5470DUO
6. Grace X7 - PSP7505DUO
7. MT3237\_3G - PMT3237\_3G
8. MULTIPAD WIZE 3027 - PMT3027\_Wi
9. MULTIPAD WIZE 3108 3G - PMT3108\_3G
10. MULTIPAD WIZE 3111 - PMT3111\_Wi
11. MULTIPAD WIZE 3121 - PMT3121\_Wi
12. MULTIPAD WIZE 3308 3G - PMT3308\_3G
13. MULTIPAD WIZE 3331 3G - PMT3331\_3G
14. MULTIPAD WIZE 3341 3G - PMT3341\_3G
15. MULTIPAD WIZE 3787 3G - PMT3787\_3G
16. MultiPad Thunder 7.0i - PMT3377\_Wi
17. MultiPad Wize 3009 - PMT3009\_Wi\_C
18. MultiPad Wize 3017 - PMT3017\_Wi
19. MultiPad Wize 3018 - PMT3018\_Wi
20. MultiPad Wize 3037 3G - PMT3037\_3G
21. MultiPad Wize 3038 3G - PMT3038\_3G
22. MultiPhone 5453 DUO - PSP5453DUO
23. MultiPhone 5455 DUO - PSP5455DUO
24. MultiPhone 5504 DUO - PSP5504DUO
25. MultiPhone 5505 DUO - PSP5505DUO
26. MultiPhone 5517 DUO - PSP5517DUO
27. Multipad Wize 3407 4G - PMT3407\_4G
28. Multipad Wize 3408 4G - PMT3408\_4G
29. Multipad Wize 3508 4G - PMT3508\_4G
30. Multipad Wize 3757 3G - PMT3757\_3G
31. Multiphone 5508 DUO - PSP5508DUO

32. Muze A3 - PSP3452DUO
33. PGPS7795 - PGPS7795
34. PMT3008\_Wi - PMT3008\_Wi\_C
35. PMT3011\_3G - PMT3011\_3G
36. PMT3021\_3G - PMT3021\_3G
37. PMT3031\_3G - PMT3031\_3G
38. PMT3047\_3G - PMT3047\_3G
39. PMT3057\_3G - PMT3057\_3G
40. PMT3067\_3G - PMT3067\_3G
41. PMT3077\_Wi - PMT3077\_Wi
42. PMT3087\_3G - PMT3087\_3G
43. PMT3101\_4G - PMT3101\_4G
44. PMT3137\_3G - PMT3137\_3G
45. PMT3157\_3G - PMT3157\_3G
46. PMT3157\_4G - PMT3157\_4G
47. PMT3177\_3G - PMT3177\_3G
48. PMT3201\_4G - PMT3201\_4G
49. PMT3208\_3G - PMT3208\_3G
50. PMT3257\_4G - PMT3257\_4G
51. PMT3277\_3G - PMT3277\_3G
52. PMT3287\_3G - PMT3287\_3G
53. PMT3301\_4G - PMT3301\_4G
54. PMT3351\_3G - PMT3351\_3G
55. PMT3418\_4G - PMT3418\_4G
56. PMT3437\_3G - PMT3437\_3G
57. PMT3507\_4G - PMT3507\_4G
58. PMT3607\_4G - PMT3607\_4G
59. PMT3608\_4G - PMT3608\_4G
60. PMT3677\_Wi - PMT3677\_Wi
61. PMT3767\_3G - PMT3767\_3G
62. PMT3777\_3G - PMT3777\_3G
63. PMT3797\_3G - PMT3797\_3G
64. PMT5001\_3G - PMT5001\_3G
65. PMT5002\_Wi - PMT5002\_Wi
66. PMT5008\_3G - PMT5008\_3G
67. PMT5011\_3G - PMT5011\_3G
68. PMT5018\_3G - PMT5018\_3G
69. PMT5021\_3G - PMT5021\_3G
70. PMT5287\_4G - PMT5287\_4G
71. PMT5487\_3G - PMT5487\_3G
72. PMT5587\_Wi - PMT5587\_Wi
73. PMT5777\_3G - PMT5777\_3G
74. PMT5877C - PMT5877C
75. PMT5887\_3G - PMT5887\_3G
76. PMT7008\_4G - PMT7008\_4G
77. PMT7077\_3G - PMT7077\_3G
78. PMT7177\_3G - PMT7177\_3G
79. PMT7287C3G - PMT7287C3G
80. PMT7287\_3G - PMT7287\_3G
81. PMT7787\_3G - PMT7787\_3G
82. PSP3403DUO - PSP3403DUO
83. PSP3404DUO - PSP3404DUO
84. PSP3405DUO - PSP3405DUO
85. PSP3413DUO - PSP3413DUO
86. PSP3423DUO - PSP3423DUO
87. PSP3450DUO - PSP3450DUO
88. PSP3456DUO - PSP3456DUO
89. PSP3457DUO - PSP3457DUO
90. PSP3458DUO - PSP3458DUO
91. PSP3459DUO - PSP3459DUO
92. PSP3468DUO - PSP3468DUO
93. PSP3502DUO - PSP3502DUO



94. PSP3503DUO - PSP3503DUO
95. PSP3504DUO - PSP3504DUO
96. PSP3505DUO - PSP3505DUO
97. PSP3506DUO - PSP3506DUO
98. PSP3507DUO - PSP3507DUO
99. PSP3508DUO - PSP3508DUO
100. PSP3510DUO - PSP3510DUO
101. PSP3511DUO - PSP3511DUO
102. PSP3512 - PSP3512DUO
103. PSP3516DUO - PSP3516DUO
104. PSP3517DUO - PSP3517DUO
105. PSP3518DUO - PSP3518DUO
106. PSP3527DUO - PSP3527DUO
107. PSP3528DUO - PSP3528DUO
108. PSP3530DUO - PSP3530DUO
109. PSP3531DUO - PSP3531DUO
110. PSP3533DUO - PSP3533DUO
111. PSP3537DUO - PSP3537DUO
112. PSP3551 - PSP3551DUO
113. PSP3552DUO - PSP3552DUO
114. PSP5047DUO - PSP5047DUO
115. PSP5307DUO - PSP5307DUO
116. PSP5454DUO - PSP5454DUO
117. PSP5457DUO - PSP5457DUO
118. PSP5502DUO - PSP5502DUO
119. PSP5506DUO - PSP5506DUO
120. PSP5507DUO - PSP5507DUO
121. PSP5509DUO - PSP5509DUO
122. PSP5512DUO - PSP5512DUO
123. PSP5516DUO - PSP5516DUO
124. PSP5519DUO - PSP5519DUO
125. PSP5530DUO - PSP5530DUO
126. PSP5531 - PSP5531DUO
127. PSP5550DUO - PSP5550DUO
128. PSP5551DUO - PSP5551DUO
129. PSP5552DUO - PSP5552DUO
130. PSP7501DUO - PSP7501DUO
131. PSP7511DUO - PSP7511DUO
132. PSP7530DUO - PSP7530DUO
133. PSP7550DUO - PSP7550DUO
134. PSP7551DUO - PSP7551DUO
135. PSP7552DUO - PSP7552DUO
136. WIZE A3 - PSP3453DUO
137. Wize 3131 3G - PMT3131\_3G
138. Wize 3147 3G - PMT3147\_3G
139. Wize 3401 3G - PMT3401\_3G

## Proscan

1. PLT1065G - PLT1065G
2. PLT1077G(1GB/8GB) - PLT1077G
3. PLT1077G\_16G - PLT1077G\_16G
4. PLT7100G - PLT7100G
5. PLT7109G - PLT7109G
6. PLT7130G - PLT7130G
7. PLT7602G - PLT7602G
8. PLT7649G - PLT7649G
9. PLT7650G - PLT7650G
10. PLT7770G - PLT7770G
11. PLT7803G - PLT7803G
12. PLT7804G - PLT7804G
13. PLT8235G Tablet - PLT8235G
14. PLT8802G - PLT8802G

15. PLT9602G - PLT9602G
16. PLT9606G - PLT9606G
17. PLT9609G - PLT9609G
18. PLT9649G - PLT9649G
19. PLT9650G - PLT9650G
20. PLT9999G - PLT9999G

## Protab

1. PTBPT5QCB7 - PTBPT5QCB7

## QLA

1. C600 - C600

## QMobile

1. A1 - Noir A1
2. A1 lite - Noir A1 lite
3. CS1 - QMobile CS1
4. CS1 Plus - QMobile CS1 Plus
5. Dual One - QMobile Dual One
6. E1 - E1
7. E1 - QMobile E1
8. E2 - E2 Noir
9. E3 Dual - E3 Dual
10. E8 - E8
11. ENERGY X1 - QMobile ENERGY X1
12. ENERGY X2 - QMobile ENERGY X2
13. Evok Power - QMobile Evok Power
14. Evok Power Lite - QMobile Evok Power Lite
15. J1 - QMobile J1
16. J2 - QMobile J2
17. J5 - J5
18. J7 - J7
19. J7 PRO - J7 PRO
20. JS10 - JAZZX JS10
21. JazzX JS7 PRO - JazzX JS7 PRO
22. KING KONG MAX - KING KONG MAX
23. L20 - QMobile L20
24. LT300 - LT300
25. LT500 PRO - LT500 PRO
26. LT550 - QMobile LT550
27. LT600 PRO - QMobile\_LT600\_PRO
28. LT650 - LT650
29. LT680 - LT680
30. LT700 - LT700
31. LT700 PRO - LT700 PRO
32. M350 Pro - M350 Pro
33. M6 - M6
34. M6 Lite - M6 Lite
35. NOIR A3 - QMobile A3
36. NOIR A6 - QMobile A6
37. Noir S9 - QMobile Noir S9
38. Pakistan - QMobile A1
39. Q Infinity - Q Infinity
40. QNote - QMobile QNote
41. S1 Lite - QMobile S1 Lite
42. S1 PRO - QMobile S1 PRO
43. S2 Plus - QMobile S2 Plus
44. S2 Pro - S2 Pro
45. S4 - S4
46. S6 - QMobile S6
47. S6 PLUS - QMobile S6 PLUS

48. S6S - QMobile S6S
49. S8 - S8
50. S9 - S9
51. V100 - V100
52. V500 - V500
53. W70 - W70
54. W80 - W80
55. X1S - Noir X1S
56. X32 - QMobile X32
57. X32 - QMobile X32
58. X32 Power - QMobile X32 Power
59. X33 - QMobile X33
60. X36 - QMobile X36
61. X700 PRO - QMobile X700 PRO
62. X700 PRO II - QMobile X700 PRO II
63. X700 PRO Lite - QMobile X700 PRO Lite
64. X75 - X75
65. Z10 - QMobile Z10
66. Z12 - Z12
67. Z12 PRO - Z12 PRO
68. Z14 - Z14
69. Z9 Plus - Z9 Plus
70. i2 POWER - QMobile i2 POWER
71. i2 PRO - QMobile i2 PRO
72. i5.5 - QMobile i5.5
73. i6 Metal 2017 - QMobile i6 Metal 2017
74. i6 Metal HD - i6 Metal HD
75. i6 Metal ONE - QMobile i6 Metal ONE
76. i6 Metal One - QMobile i6 Metal ONE
77. i7i PRO - QMobile i7i PRO

## QOOQ

1. QOOQV3 - QOOQ

## Qilive

1. Q.3778 - Q.3778
2. W55 - W55

## Quanta

1. Nirvana\_Tablet - Nirvana\_Tablet
2. infinity\_g - INFINITY G NK2
3. nk1 - IGS-1000
4. nk1 - TA1013
5. ventana - NK1\_111018\_002\_HC
6. ventana - Q10
7. CT2200 - CT2200
8. FT103 - FT103
9. True Beyond 4G - TRUE BEYOND 4G
10. VSD220 - VSD220

## Quantum

1. FLY - Quantum Fly
2. Go - Quantum Go
3. Go - Quantum Go
4. Go 2 - GO 2
5. MUV - Quantum MUV
6. MUV 3G - MUV
7. MUV 3G - MUV 3G
8. MUV PRO - Quantum MUV PRO
9. MUV UP - Quantum MUV UP

10. Muv - MUV
11. Muv - Quantum MUV
12. QSPT-1952 - QT-195W-aa2
13. Sky - Sky
14. Twist Neo - twist neo
15. You - Quantum You
16. You - You
17. You L - You L
18. i9i - QMobile I9i

## RCA

1. 10 Viking II - RCT6603W47M7
2. 10 Viking II Pro - RCT6603W87M7
3. 10 Viking Pro - RCT6303W87DK
4. 10 Viking Pro - RCT6303W87M
5. 10 Viking Pro - RCT6303W87M7
6. 10 Viking Pro - RCT6K03W13
7. 11 Galileo Pro - RCT6513W87
8. 11 Maven Pro - RCT6213W87DK
9. 7 Mercury - RCT6673W23M
10. 7 Mercury - RCT6673W43M
11. 7 Voyager - RCT6873W42
12. 7 Voyager II - RCT6773W22B
13. 7 Voyager II - RCT6773W22BM
14. Atlas 10 - RCT6703W12
15. BNT-710 - BNT-710
16. DAA730R / RCA DAA738R - DAA730R
17. DAA730R / RCA DAA738R - DAA738R
18. Mercury 7 - CT9973W43M
19. Pro10 Edition II - RCT6203W46L
20. Pro12 - RCT6223W87
21. RCA RCT6213W22 - RCT6213W22
22. RCA RCT6213W23 - RCT6213W23
23. RCA RCT6213W24 - RCT6213W24
24. RCA RCT6703W13 - RCT6703W13
25. RCA RCT6S03W12 - RCT6S03W12
26. RCA RCT6S03W14 - RCT6S03W14
27. RCS13101T - RCS13101T
28. RCT6002W46 - RCT6002W46
29. RCT6077W2 - RCT6077W2
30. RCT6077W22 - RCT6077W22
31. RCT6103W46 - RCT6103W46
32. RCT6203W46 - RCT6203W46
33. RCT6223W97 - RCT6223W97
34. RCT6272W23 - RCT6272W23
35. RCT6273W26 - RCT6273W26
36. RCT6283W27 - RCT6283W27
37. RCT6293W23 - RCT6293W23
38. RCT6378W2 - RCT6378W2
39. RCT6573W23 - RCT6573W23
40. RCT6603W47 - RCT6603W47DK
41. RCT6672W23 - RCT6672W23
42. RCT6673W-V1 - RCT6673W-V1
43. RCT6691W3 - RCT6691W3
44. RCT6773W22 - RCT6773W22
45. RCT6773W42B - RCT6773W42B
46. RCT6873W42M - RCT6873W42M
47. RCT6973W43 - RCT6973W43
48. RCT6973W43M - RCT6973W43M
49. Voyager Pro - RCT6873W42M\_F7
50. XLD Series - XLDRCV1

## REACH

1. Q882 - Q882

## Rainbow

1. WIKO - RAINBOW

## Razer

1. Forge TV - Forge
2. Razer Phone - Phone
3. Razer phone - Phone

## Reeder

1. A8i Q2 - A8i-Q2
2. M7 Plus - M7Plus
3. P10 - P10
4. P10S - P10S
5. P10SE - P10SE
6. P9C - P9C
7. T8 - reeder\_T8
8. reeder P12 - P12

## Reliance

1. FL7008 - FL7008
2. LS-4008 - LS-4008
3. LS-5506 - LS-5506
4. LS-5512 - LS-5512
5. MCM3000 - IPSetTopBox
6. Orbic RC505L-RW - RC505L-RW
7. RC500L - RC500L
8. RC501L - RC501L
9. Smartphone JS LS-5010 - LS-5010

## Revo

1. Pearl - Pearl
2. Power - Power

## Revtel

1. R45 - R45

## Royaltek

1. FGAD - FGAD

## Ruggear

1. CP250 - cp250\_gts
2. DEWALT MD501 - DeWalt MD501
3. IMO S - IMO\_S
4. RG730 - RugGear RG730

## Ruio

1. RUIO i7c Tablet - i7c
2. S4 - RUIO\_S4

## SAKAISIO

1. FP-U320-711-WIFI - FP-U320-711-WIFI
2. FP-U320-711-WWAN - FP-U320-711-WWAN

## SED Wireless

1. GPH-650R - GPH-650R

## SELECLINE

1. MID7526CM - NID\_7010
2. MID\_9526CM - S952

## SFR

1. G8800 - SFR-G8800
2. STARADDICT 4 - STARADDICT 4
3. STARXTREM3 - STARXTREM3
4. Star Shine II - STARSHINE II
5. Star Trail 5 - STARTRAIL5
6. Star Trail 6 - STARTRAIL6
7. Star Trail III - StarTrail III

## SK Broadband

1. B tv smart - BHX-S100
2. B tv smart - BKO-S200

## SK Telesys

1. K4 - SK-S170
2. msm8255\_k5 - SK-S150
3. qsd8250\_s1 - SK-S100
4. AN200 - AN200
5. EG68BE - EG668
6. EG978TW - EG978
7. EG980 - EG980
8. Fly - Fly
9. ITP-E410W - ITP-E410W
10. ITP-R208W - ITP-R208W
11. Ice-Phone Forever - Ice-Phone Forever
12. K2401 - S201
13. S150 - S150
14. T720 - Clear
15. UTA200 - UTA200
16. WA966 - WA966
17. WA978 - WA978
18. icube-830 - icube-830

## SOSMART

1. T5 - SOSMART\_T5

## SPC Mobile

1. L50 - L50
2. L51 BLITZ - L51
3. L51 PRO - L51 Pro
4. L52 PRO - L52 Pro
5. L52 STEEL+ - L52

## STF Mobile

1. AERIAL - AERIAL
2. AERIAL PLUS - AERIAL PLUS
3. DUO - DUO
4. Fractal - Fractal
5. HK-914581 - HK-914581
6. IO - IO
7. Joy Pro - Joy Pro

8. NATIVO - NATIVO
9. Origins Pro - Origins Pro

## STK(Santok)

1. Hero X - STK\_Hero\_X
2. SYNC 5C - STK\_Sync\_5c
3. Storm 2e Plus - Storm 2e Plus
4. Storm 2e Pluz - Storm 2e Pluz
5. Storm 3 - STK Storm 3
6. Sync 5e - STK\_Sync\_5e
7. Sync 5z - STK Sync 5z
8. Transporter 1 - STK\_Transporter\_1

## Saltillo

1. CF10 - CF10

## Samsung

1. GT-I5510M - GT-I5510M
2. GT-I5510T - GT-I5510T
3. GT-I5800L - GT-I5800L
4. GT-N7000B - GT-N7000B
5. GT-P7300B - GT-P7300B
6. GT-P7320T - GT-P7320T
7. GT-P7500M - GT-P7500M
8. GT-P7500R - GT-P7500R
9. GT-P7500V - GT-P7500V
10. GT-S5698 - GT-S5698
11. GT-S5820 - GT-S5820
12. GT-S5830V - GT-S5830V
13. SCH-I339 - SCH-I339
14. SCH-I405U - SCH-I405U
15. SCH-I509U - SCH-I509U
16. SCH-I519 - SCH-I519
17. SCH-I559 - SCH-I559
18. SCH-I559 - SCH-i559
19. SCH-I639 - SCH-I639
20. SCH-I659 - SCH-I659
21. SCH-I699 - SCH-I699
22. SCH-I779 - SCH-I779
23. SCH-I919U - SCH-I919U
24. SCH-W899 - SCH-W899
25. SCH-W999 - SCH-W999
26. SCH-i809 - SCH-i809
27. SCH-i919 - SCH-i919
28. SGH-I987 - SGH-I987
29. SGH\_T939 - Behold II
30. SHV-E150S - SHV-E150S
31. SHW-M115S - SHW-M115S
32. SHW-M135K - SHW-M135K
33. SHW-M135L - SHW-M135L
34. SHW-M340D - SHW-M340D
35. SHW-M340K - SHW-M340K
36. SHW-M460D - SHW-M460D
37. amazingtrf - SGH-S730G
38. aruba3gchn - GT-I8262D
39. espressorfcmcc - GT-P3108
40. gd1ltektt - EK-KC120K
41. godivaltevw - SCH-I425
42. ironcmcc - GT-B9388
43. m0grandectc - SCH-W2013
44. m0grandectc - SCH-W9913

45. p4noterfskt - SHW-M480S
46. stunnerltespr - SPH-L500
47. superiorchn - GT-I9260
48. \t Galaxy A7(2016) - SM-A710XZ
49. Absolute - GT-B9120
50. Acclaim - SCH-R880
51. Admire - SCH-R720
52. Amazing - SGH-S730M
53. Baffin - SHV-E270L
54. Captivate Glide - SAMSUNG-SGH-I927
55. Captivate Glide - SGH-I927
56. China Telecom - SCH-I699I
57. Chromebook 3 - Samsung Chromebook 3
58. Chromebook Plus - Samsung Chromebook Plus
59. Chromebook Plus - kevin
60. Chromebook Pro - Samsung Chromebook Pro
61. Chromebook Pro - caroline
62. Conquer - SPH-D600
63. DoubleTime - SAMSUNG-SGH-I857
64. Droid Charge - SCH-I510
65. Elite - SM-G1600
66. Elite - SM-G1650
67. Europa - GT-I5500B
68. Europa - GT-I5500L
69. Europa - GT-I5500M
70. Europa - GT-I5503T
71. Europa - GT-I5510L
72. Exhibit - SGH-T759
73. GALAXY Camera - EK-GC100
74. Galaxy (China) - GT-B9062
75. Galaxy 070 - YP-GI2
76. Galaxy A - SHW-M100S
77. Galaxy A - archer
78. Galaxy A3 - SM-A300H
79. Galaxy A3 - SM-A300F
80. Galaxy A3 - SM-A300M
81. Galaxy A3 - SM-A300XZ
82. Galaxy A3 - SM-A300YZ
83. Galaxy A3 - SM-A3000
84. Galaxy A3 - SM-A300X
85. Galaxy A3 - SM-A3009
86. Galaxy A3 - SM-A300G
87. Galaxy A3 - SM-A300F
88. Galaxy A3 - SM-A3000
89. Galaxy A3 - SM-A300YZ
90. Galaxy A3 - SM-A300FU
91. Galaxy A3 - SM-A300XU
92. Galaxy A3 - SM-A300Y
93. Galaxy A3 (2017) - SM-A320Y
94. Galaxy A3(2016) - SM-A310F
95. Galaxy A3(2016) - SM-A310M
96. Galaxy A3(2016) - SM-A310X
97. Galaxy A3(2016) - SM-A310Y
98. Galaxy A3(2016) - SM-A310NO
99. Galaxy A3(2017) - SM-A320F
100. Galaxy A3(2017) - SM-A320FL
101. Galaxy A3(2017) - SM-A320X
102. Galaxy A5 - SM-A500H
103. Galaxy A5 - SM-A500F
104. Galaxy A5 - SM-A500G
105. Galaxy A5 - SM-A500M
106. Galaxy A5 - SM-A500XZ



107. Galaxy A5 - SM-A5000  
108. Galaxy A5 - SM-A500X  
109. Galaxy A5 - SM-A5009  
110. Galaxy A5 - SM-A5000  
111. Galaxy A5 - SM-A500YZ  
112. Galaxy A5 - SM-A500FU  
113. Galaxy A5 - SM-A500Y  
114. Galaxy A5 - SM-A500W  
115. Galaxy A5 - SM-A500K  
116. Galaxy A5 - SM-A500L  
117. Galaxy A5 - SM-A500F1  
118. Galaxy A5 - SM-A500S  
119. Galaxy A5(2016) - SM-A510F  
120. Galaxy A5(2016) - SM-A510M  
121. Galaxy A5(2016) - SM-A510X  
122. Galaxy A5(2016) - SM-A510Y  
123. Galaxy A5(2016) - SM-A5108  
124. Galaxy A5(2016) - SM-A510K  
125. Galaxy A5(2016) - SM-A510L  
126. Galaxy A5(2016) - SM-A510S  
127. Galaxy A5(2016) - SM-A510Y  
128. Galaxy A5(2016) - SM-A5100  
129. Galaxy A5(2016) - SM-A5100X  
130. Galaxy A5(2016) - SM-A510XZ  
131. Galaxy A5(2017) - SM-A520F  
132. Galaxy A5(2017) - SM-A520X  
133. Galaxy A5(2017) - SM-A520W  
134. Galaxy A5(2017) - SM-A520K  
135. Galaxy A5(2017) - SM-A520L  
136. Galaxy A5(2017) - SM-A520S  
137. Galaxy A5x(2016) - SM-A510Y  
138. Galaxy A7 - SM-A700H  
139. Galaxy A7 - SM-A700F  
140. Galaxy A7 - SM-A700FD  
141. Galaxy A7 - SM-A700X  
142. Galaxy A7 - SM-A7000  
143. Galaxy A7 - SM-A700YD  
144. Galaxy A7 - SM-A7009  
145. Galaxy A7 - SM-A700K  
146. Galaxy A7 - SM-A700L  
147. Galaxy A7 - SM-A700S  
148. Galaxy A7(2016) - SM-A710F  
149. Galaxy A7(2016) - SM-A710M  
150. Galaxy A7(2016) - SM-A710X  
151. Galaxy A7(2016) - SM-A7108  
152. Galaxy A7(2016) - SM-A710K  
153. Galaxy A7(2016) - SM-A710L  
154. Galaxy A7(2016) - SM-A710S  
155. Galaxy A7(2016) - SM-A710Y  
156. Galaxy A7(2016) - SM-A7100  
157. Galaxy A7(2017) - SM-A720F  
158. Galaxy A7(2017) - SM-A720S  
159. Galaxy A8 - SCV32  
160. Galaxy A8 - SM-A800F  
161. Galaxy A8 - SM-A800YZ  
162. Galaxy A8 - SM-A800S  
163. Galaxy A8 - SM-A800I  
164. Galaxy A8 - SM-A800IZ  
165. Galaxy A8 - SM-A8000  
166. Galaxy A8 - SM-A800X  
167. Galaxy A8(2016) - SM-A810F  
168. Galaxy A8(2016) - SM-A810YZ  
169. Galaxy A8(2016) - SM-A810S  
170. Galaxy A9 Pro - SM-A9100  
171. Galaxy A9 Pro - SM-A910F  
172. Galaxy A9(2016) - SM-A9000  
173. Galaxy Ace - GT-S5830  
174. Galaxy Ace - GT-S5830B  
175. Galaxy Ace - GT-S5830C  
176. Galaxy Ace - GT-S5830D  
177. Galaxy Ace - GT-S5830F  
178. Galaxy Ace - GT-S5830G  
179. Galaxy Ace - GT-S5830L  
180. Galaxy Ace - GT-S5830M  
181. Galaxy Ace - GT-S5830T  
182. Galaxy Ace - GT-S5830i  
183. Galaxy Ace - GT-S5831i  
184. Galaxy Ace - GT-S5838  
185. Galaxy Ace - GT-S5839i  
186. Galaxy Ace - GT-S6358  
187. Galaxy Ace - SCH-I619  
188. Galaxy Ace - SHW-M240S  
189. Galaxy Ace - SM-G310R5  
190. Galaxy Ace - SM-G357M  
191. Galaxy Ace 4 - SM-G313HU  
192. Galaxy Ace 4 - SM-G313HY  
193. Galaxy Ace 4 - SM-G313M  
194. Galaxy Ace 4 - SM-G313MY  
195. Galaxy Ace 4 Lite - SM-G313U  
196. Galaxy Ace Advance - GT-S6800  
197. Galaxy Ace Duos - GT-S6352  
198. Galaxy Ace Duos - GT-S6802  
199. Galaxy Ace Duos - GT-S6802B  
200. Galaxy Ace Duos - SCH-i579  
201. Galaxy Ace Duos - SCH-I589  
202. Galaxy Ace Duos - SCH-i589  
203. Galaxy Ace Duos - SCH-i579  
204. Galaxy Ace Duos - SCH-i589  
205. Galaxy Ace Plus - GT-S7500  
206. Galaxy Ace Plus - GT-S7500L  
207. Galaxy Ace Plus - GT-S7500T  
208. Galaxy Ace Plus - GT-S7500W  
209. Galaxy Ace Plus - GT-S7508  
210. Galaxy Ace Q - SGH-I827D  
211. Galaxy Ace Style - SM-S765C  
212. Galaxy Ace Style - SM-S766C  
213. Galaxy Ace Style - SM-G310HN  
214. Galaxy Ace Style - SM-G357FZ  
215. Galaxy Ace2 - GT-I8160  
216. Galaxy Ace2 - GT-I8160L  
217. Galaxy Ace2 - GT-I8160P  
218. Galaxy Ace2 X - GT-S7560  
219. Galaxy Ace2 X - GT-S7560M  
220. Galaxy Ace3 - GT-S7270  
221. Galaxy Ace3 - GT-S7270L  
222. Galaxy Ace3 - SCH-I679  
223. Galaxy Ace3 - GT-S7278  
224. Galaxy Ace3 - GT-S7272  
225. Galaxy Ace3 - GT-S7275  
226. Galaxy Ace3 - GT-S7275B  
227. Galaxy Ace3 - GT-S7275R  
228. Galaxy Ace3 - GT-S7275T  
229. Galaxy Ace3 - GT-S7275Y  
230. Galaxy Ace3 Duos - GT-S7272C

231. Galaxy Ace3 Duos - GT-S7278U  
232. Galaxy Ace3 Duos TV - GT-S7273T  
233. Galaxy Ace4 - SM-G313ML  
234. Galaxy Ace4 - SM-G316H  
235. Galaxy Ace4 - SM-G316HU  
236. Galaxy Ace4 - SM-G316M  
237. Galaxy Ace4 - SM-G316MY  
238. Galaxy Ace4 - SM-G313F  
239. Galaxy Ace4 - SM-G313MU  
240. Galaxy Ace4 - SM-G313HN  
241. Galaxy Ace4 Lite - SM-G3139D  
242. Galaxy Ace4 Lite - SM-G313H  
243. Galaxy Ace4 Lite - SM-G316U  
244. Galaxy Ace4 Lite - SM-G318H  
245. Galaxy Ace4 Lite - SM-G318ML  
246. Galaxy Ace4 Lite - SM-G318HZ  
247. Galaxy Ace4 Lite - SM-G318MZ  
248. Galaxy Ace4 Neo - SM-G316ML  
249. Galaxy Active neo - SC-01H  
250. Galaxy Admire - SCH-R820  
251. Galaxy Admire 2 - SCH-R830C  
252. Galaxy Alpha - SM-G850F  
253. Galaxy Alpha - SM-G850FQ  
254. Galaxy Alpha - SM-G850M  
255. Galaxy Alpha - SM-G850X  
256. Galaxy Alpha - SM-G850Y  
257. Galaxy Alpha - SAMSUNG-SM-G850A  
258. Galaxy Alpha - SM-G850W  
259. Galaxy Alpha - SM-G8508S  
260. Galaxy Alpha - SM-G850K  
261. Galaxy Alpha - SM-G850L  
262. Galaxy Alpha - SM-G850S  
263. Galaxy Amp - SAMSUNG-SGH-I407  
264. Galaxy Apollo - GT-I5800  
265. Galaxy Apollo - GT-I5800L  
266. Galaxy Apollo - GT-I5800D  
267. Galaxy Apollo - GT-I5801  
268. Galaxy Appeal - SAMSUNG-SGH-I827  
269. Galaxy Attain - SCH-R920  
270. Galaxy Avant - SM-G386T  
271. Galaxy Axiom - SCH-R830  
272. Galaxy Beam - GT-I8250  
273. Galaxy Beam - GT-I8530  
274. Galaxy C5 - SM-C5000  
275. Galaxy C5 - SM-C500X  
276. Galaxy C5 - SM-C5000  
277. Galaxy C5 Pro - SM-C5010  
278. Galaxy C5 Pro - SM-C5018  
279. Galaxy C7 - SM-C7000  
280. Galaxy C7 - SM-C700X  
281. Galaxy C7 - SM-C701X  
282. Galaxy C7 Pro - SM-C701F  
283. Galaxy C7 Pro - SM-C7010  
284. Galaxy C7 Pro - SM-C7018  
285. Galaxy C8 - SM-C7100  
286. Galaxy C8 - SM-C710X  
287. Galaxy C8 - SM-C7108  
288. Galaxy C9 Pro - SM-C900F  
289. Galaxy C9 Pro - SM-C900Y  
290. Galaxy C9 Pro - SM-C9000  
291. Galaxy C9 Pro - SM-C9008  
292. Galaxy C9 Pro - SM-C900X  
293. Galaxy Camera - EK-GC100  
294. Galaxy Camera - SAMSUNG-EK-GC100  
295. Galaxy Camera - EK-GC100  
296. Galaxy Camera - EK-KC100K  
297. Galaxy Camera - EK-KC120L  
298. Galaxy Camera - EK-KC120S  
299. Galaxy Camera - EK-GC120  
300. Galaxy Camera - EK-KC100S  
301. Galaxy Camera - EK-GC110  
302. Galaxy Camera - EK-GC110  
303. Galaxy Camera - EK-GN100  
304. Galaxy Camera - EK-GN120  
305. Galaxy Camera 2 - EK-GC200  
306. Galaxy Centura - SCH-S738C  
307. Galaxy Chat - GT-B5330  
308. Galaxy Chat - GT-B5330B  
309. Galaxy Chat - GT-B5330L  
310. Galaxy Core - SM-G386T1  
311. Galaxy Core - SM-G386W  
312. Galaxy Core - GT-I8262  
313. Galaxy Core - GT-I8260  
314. Galaxy Core - GT-I8260L  
315. Galaxy Core 2 - SM-G355H  
316. Galaxy Core Advance - GT-I8580  
317. Galaxy Core Advance - SHW-M570S  
318. Galaxy Core LTE - SM-G386F  
319. Galaxy Core LTE - SM-G3518  
320. Galaxy Core Lite - SM-G3586V  
321. Galaxy Core Lite - SM-G3589W  
322. Galaxy Core Max - SM-G5108  
323. Galaxy Core Max Duos - SM-G5108Q  
324. Galaxy Core Plus - SM-G350  
325. Galaxy Core Plus - SM-G3502  
326. Galaxy Core Plus - SM-G3502L  
327. Galaxy Core Plus - SM-G3502T  
328. Galaxy Core Plus - SM-G350L  
329. Galaxy Core Plus - SM-G350M  
330. Galaxy Core Prime - SM-G360H  
331. Galaxy Core Prime - SM-G360HU  
332. Galaxy Core Prime - SM-G360F  
333. Galaxy Core Prime - SM-G360FY  
334. Galaxy Core Prime - SM-G360M  
335. Galaxy Core Prime - SAMSUNG-SM-G360AZ  
336. Galaxy Core Prime - SM-G360R6  
337. Galaxy Core Prime - SM-G360P  
338. Galaxy Core Prime - SM-S820L  
339. Galaxy Core Prime - SM-G360V  
340. Galaxy Core Prime - SM-G361H  
341. Galaxy Core Prime - SM-G361HU  
342. Galaxy Core Prime - SM-G361F  
343. Galaxy Core Prime - SM-G361M  
344. Galaxy Core Prime - SM-G360T1  
345. Galaxy Core Prime - SM-G360T  
346. Galaxy Core Prime - SM-G3606  
347. Galaxy Core Prime - SM-G3608  
348. Galaxy Core Prime - SM-G3609  
349. Galaxy Core Prime - SM-G360GY  
350. Galaxy Core Safe - GT-I8260E  
351. Galaxy Core Safe - SHW-M580D  
352. Galaxy Core Safe - SHW-M585D  
353. Galaxy Core2 - SM-G355H  
354. Galaxy Core2 - SM-G355HQ

355. Galaxy Core2 - SM-G355M  
356. Galaxy Core2 - SM-G3556D  
357. Galaxy Core2 - SM-G3558  
358. Galaxy Core2 - SM-G3559  
359. Galaxy Core2 - SM-G355HN  
360. Galaxy Discover - SCH-R740C  
361. Galaxy Discover - SCH-S735C  
362. Galaxy Duos - GT-I8268  
363. Galaxy E5 - SM-E500H  
364. Galaxy E5 - SM-E500F  
365. Galaxy E5 - SM-E500M  
366. Galaxy E5 - SM-S978L  
367. Galaxy E5 - SM-E500YZ  
368. Galaxy E7 - SM-E700H  
369. Galaxy E7 - SM-E700F  
370. Galaxy E7 - SM-E700M  
371. Galaxy E7 - SM-E7000  
372. Galaxy E7 - SM-E7009  
373. Galaxy E7 - SM-E7000  
374. Galaxy Elite - SM-G165N  
375. Galaxy Elite - SM-G160N  
376. Galaxy Europa - GT-I5500  
377. Galaxy Europa - GT-I5503  
378. Galaxy Europa - GT-I5508  
379. Galaxy Europa - GT-I5510  
380. Galaxy Exhibit - SGH-T599N  
381. Galaxy Exhibit - SGH-T599  
382. Galaxy Exhibit - SGH-T599V  
383. Galaxy Exhibit2 - SGH-T679  
384. Galaxy Exhilarate - SAMSUNG-SGH-I577  
385. Galaxy Express - SAMSUNG-SGH-I437  
386. Galaxy Express - SAMSUNG-SGH-I437P  
387. Galaxy Express - GT-I8730  
388. Galaxy Express - GT-I8730T  
389. Galaxy Express - SAMSUNG-SGH-I437Z  
390. Galaxy Express2 - SM-G3815  
391. Galaxy Fame - SCH-I629  
392. Galaxy Fame - GT-S6810  
393. Galaxy Fame - GT-S6810B  
394. Galaxy Fame - GT-S6810E  
395. Galaxy Fame - GT-S6810L  
396. Galaxy Fame - GT-S6812i  
397. Galaxy Fame - GT-S6818  
398. Galaxy Fame - GT-S6818V  
399. Galaxy Fame - GT-S6812  
400. Galaxy Fame - GT-S6812B  
401. Galaxy Fame - GT-S6790N  
402. Galaxy Fame - GT-S6810M  
403. Galaxy Fame - GT-S6810P  
404. Galaxy Fame - GT-S6790  
405. Galaxy Fame - GT-S6790E  
406. Galaxy Fame - GT-S6790L  
407. Galaxy Fame - GT-S6812C  
408. Galaxy Fame Lite Duos - GT-S6792L  
409. Galaxy Feel - SC-04J  
410. Galaxy Fit - GT-S5670  
411. Galaxy Fit - GT-S5670B  
412. Galaxy Fit - GT-S5670L  
413. Galaxy Folder - SM-G155S  
414. Galaxy Folder - SM-G150NK  
415. Galaxy Folder - SM-G150N0  
416. Galaxy Folder - SM-G150NL  
417. Galaxy Folder - SM-G150NS  
418. Galaxy Fresh - GT-S7390  
419. Galaxy Fresh - GT-S7390E  
420. Galaxy Fresh - GT-S7390G  
421. Galaxy Gio - GT-S5660  
422. Galaxy Gio - GT-S5660B  
423. Galaxy Gio - GT-S5660L  
424. Galaxy Gio - GT-S5660M  
425. Galaxy Gio - GT-S5660V  
426. Galaxy Gio - SCH-i569  
427. Galaxy Gio - SHW-M290K  
428. Galaxy Gio - SHW-M290S  
429. Galaxy Go Prime - SAMSUNG-SM-G530A  
430. Galaxy Golden - GT-I9230  
431. Galaxy Golden - GT-I9235  
432. Galaxy Golden - SHV-E400K  
433. Galaxy Golden - SHV-E400S  
434. Galaxy Golden 2 - SM-W2015  
435. Galaxy Grand - SCH-I879  
436. Galaxy Grand - GT-I9128  
437. Galaxy Grand - GT-I9128V  
438. Galaxy Grand - SHV-E270K  
439. Galaxy Grand - SHV-E270S  
440. Galaxy Grand - GT-I9118  
441. Galaxy Grand - GT-I9080E  
442. Galaxy Grand - GT-I9080L  
443. Galaxy Grand - SHV-E275K  
444. Galaxy Grand - SHV-E275S  
445. Galaxy Grand - GT-I9128E  
446. Galaxy Grand - GT-I9128I  
447. Galaxy Grand Duos - GT-I9082  
448. Galaxy Grand Duos - GT-I9082L  
449. Galaxy Grand Max - SM-G7202  
450. Galaxy Grand Max - SM-G7200  
451. Galaxy Grand Max - SM-G720AX  
452. Galaxy Grand Neo - GT-I9060  
453. Galaxy Grand Neo - GT-I9060L  
454. Galaxy Grand Neo - GT-I9082C  
455. Galaxy Grand Neo - GT-I9063T  
456. Galaxy Grand Neo - GT-I9168  
457. Galaxy Grand Neo - GT-I9168I  
458. Galaxy Grand Neo Plus - GT-I9060C  
459. Galaxy Grand Neo Plus - GT-I9060I  
460. Galaxy Grand Neo Plus - GT-I9060M  
461. Galaxy Grand Neo+ - SCH-I879E  
462. Galaxy Grand Prime - SM-G530H  
463. Galaxy Grand Prime - SM-G530BT  
464. Galaxy Grand Prime - SM-G5306W  
465. Galaxy Grand Prime - SM-G5308W  
466. Galaxy Grand Prime - SM-G530F  
467. Galaxy Grand Prime - SM-G530M  
468. Galaxy Grand Prime - SM-G5309W  
469. Galaxy Grand Prime - SM-G5308W  
470. Galaxy Grand Prime - SM-G530MU  
471. Galaxy Grand Prime - SM-G530Y  
472. Galaxy Grand Prime - SM-G530H  
473. Galaxy Grand Prime - SM-G530R7  
474. Galaxy Grand Prime - gprimelteacg  
475. Galaxy Grand Prime - SM-G530W  
476. Galaxy Grand Prime - SM-G530T1  
477. Galaxy Grand Prime - SM-G530P  
478. Galaxy Grand Prime - SM-S920L



479. Galaxy Grand Prime - SM-G530T  
480. Galaxy Grand Prime - SM-G530R4  
481. Galaxy Grand Prime - SM-G530FZ  
482. Galaxy Grand Prime - SAMSUNG-SM-G530AZ  
483. Galaxy Grand Prime - SM-G531H  
484. Galaxy Grand Prime - SM-G531BT  
485. Galaxy Grand Prime - SM-G531F  
486. Galaxy Grand Prime - SM-G531M  
487. Galaxy Grand Prime - SM-G531Y  
488. Galaxy Grand duos - GT-I9082i  
489. Galaxy Grand-Max - SM-G720N0  
490. Galaxy Grand2 - SM-G7102  
491. Galaxy Grand2 - SM-G7106  
492. Galaxy Grand2 - SM-G7108  
493. Galaxy Grand2 - SM-G7109  
494. Galaxy Grand2 - SM-G7102T  
495. Galaxy Grand2 - SM-G710  
496. Galaxy Grand2 - SM-G7105  
497. Galaxy Grand2 - SM-G7105H  
498. Galaxy Grand2 - SM-G7105L  
499. Galaxy Grand2 - SM-G710K  
500. Galaxy Grand2 - SM-G710L  
501. Galaxy Grand2 - SM-G710S  
502. Galaxy Indulge - SCH-R910  
503. Galaxy Indulge - SCH-R915  
504. Galaxy Infinite - SCH-I759  
505. Galaxy J - SGH-N075T  
506. Galaxy J1 - SM-J100H  
507. Galaxy J1 - SM-J100ML  
508. Galaxy J1 - SM-S777C  
509. Galaxy J1 - SM-J100F  
510. Galaxy J1 - SM-J100G  
511. Galaxy J1 - SM-J100M  
512. Galaxy J1 - SM-J100FN  
513. Galaxy J1 - SM-J100MU  
514. Galaxy J1 - SM-J100Y  
515. Galaxy J1 - SM-J100VPP  
516. Galaxy J1 - SM-J120F  
517. Galaxy J1 - SM-J120FN  
518. Galaxy J1 - SM-J120M  
519. Galaxy J1 - SAMSUNG-SM-J120AZ  
520. Galaxy J1 - SAMSUNG-SM-J120A  
521. Galaxy J1 - SM-J120W  
522. Galaxy J1 - SM-J120P  
523. Galaxy J1 - SM-S120VL  
524. Galaxy J1 Ace - SM-J110F  
525. Galaxy J1 Ace - SM-J110G  
526. Galaxy J1 Ace - SM-J110M  
527. Galaxy J1 Ace - SM-J111F  
528. Galaxy J1 Ace - SM-J111M  
529. Galaxy J1 Ace - SM-J110H  
530. Galaxy J1 Ace - SM-J110L  
531. Galaxy J1 Mini - SM-J105B  
532. Galaxy J1 Mini - SM-J105H  
533. Galaxy J1 Mini - SM-J105B  
534. Galaxy J1 Mini - SM-J105H  
535. Galaxy J1 Mini - SM-J105F  
536. Galaxy J1 Mini - SM-J105M  
537. Galaxy J1 Mini - SM-J105Y  
538. Galaxy J1 Mini Prime - SM-J106B  
539. Galaxy J1 Mini Prime - SM-J106H  
540. Galaxy J1 Mini Prime - SM-J106B  
541. Galaxy J1 Mini Prime - SM-J106M  
542. Galaxy J1(2016) - SM-J120H  
543. Galaxy J1(2016) - SM-J120G  
544. Galaxy J1(2016) - SM-J120ZN  
545. Galaxy J2 - SM-J200H  
546. Galaxy J2 - SM-J200F  
547. Galaxy J2 - SM-J200G  
548. Galaxy J2 - SM-J200GU  
549. Galaxy J2 - SM-J200M  
550. Galaxy J2 - SM-J200Y  
551. Galaxy J2 - SM-J200BT  
552. Galaxy J2 Prime - SM-G532G  
553. Galaxy J2 Prime - SM-G532M  
554. Galaxy J2(2016) - SM-J210F  
555. Galaxy J2(2016) - SM-J210F  
556. Galaxy J3 - SM-J3109  
557. Galaxy J3 - SM-J320P  
558. Galaxy J3 - SM-J327U  
559. Galaxy J3 - SM-J320H  
560. Galaxy J3 Pop - SAMSUNG-SM-J326AZ  
561. Galaxy J3 Pop - SAMSUNG-SM-J327AZ  
562. Galaxy J3 Pop - SAMSUNG-SM-J327A  
563. Galaxy J3 Pop - SM-J327W  
564. Galaxy J3 Pop - SM-S337TL  
565. Galaxy J3 Pop - SM-J327R7  
566. Galaxy J3 Pop - SM-J327R6  
567. Galaxy J3 Pop - SM-J327P  
568. Galaxy J3 Pop - SM-S327VL  
569. Galaxy J3 Pop - SM-J327R4  
570. Galaxy J3 Pop - SM-J327V  
571. Galaxy J3 Pop - SM-J327VPP  
572. Galaxy J3 Prime - SM-J327T1  
573. Galaxy J3 Prime - SM-J327T  
574. Galaxy J3 Pro - SM-J3119S  
575. Galaxy J3 Pro - SM-J3110  
576. Galaxy J3 Pro - SM-J3119  
577. Galaxy J3 Pro - SM-J330G  
578. Galaxy J3(2016) - SM-J320N0  
579. Galaxy J3(2016) - SM-S320VL  
580. Galaxy J3(2016) - SM-J320Y  
581. Galaxy J3(2016) - SM-J320YZ  
582. Galaxy J3(2016) - SM-J320R4  
583. Galaxy J3(2016) - SM-J320V  
584. Galaxy J3(2016) - SM-J320VPP  
585. Galaxy J3(2016) - SM-J320ZN  
586. Galaxy J3(2016) - SM-J320F  
587. Galaxy J3(2016) - SM-J320G  
588. Galaxy J3(2016) - SM-J320M  
589. Galaxy J3(2016) - SAMSUNG-SM-J320AZ  
590. Galaxy J3(2016) - SAMSUNG-SM-J321AZ  
591. Galaxy J3(2016) - SAMSUNG-SM-J320A  
592. Galaxy J3(2016) - SM-J320W8  
593. Galaxy J3(2016) - SM-J320FN  
594. Galaxy J3(2017) - SM-J330F  
595. Galaxy J3(2017) - SM-J330FN  
596. Galaxy J3(2017) - SM-J330N  
597. Galaxy J3(2017) - SM-J330L  
598. Galaxy J3(2017) - SM-J330O  
599. Galaxy J3(2017) - SM-J3308  
600. Galaxy J5 - SM-J500H  
601. Galaxy J5 - SM-J5007  
602. Galaxy J5 - SM-J500F



603. Galaxy J5 - SM-J500G  
604. Galaxy J5 - SM-J500M  
605. Galaxy J5 - SM-J5008  
606. Galaxy J5 - SM-J500N  
607. Galaxy J5 - SM-J500FN  
608. Galaxy J5 - SM-J500Y  
609. Galaxy J5 Prime - SM-G570F  
610. Galaxy J5 Prime - SM-G570M  
611. Galaxy J5 Prime - SM-G570Y  
612. Galaxy J5 Prime - SM-G570F  
613. Galaxy J5 Prime - SM-G5700  
614. Galaxy J5 Pro - SM-J530Y  
615. Galaxy J5 Pro - SM-J530YM  
616. Galaxy J5(2016) - SM-J510H  
617. Galaxy J5(2016) - SM-J5108  
618. Galaxy J5(2016) - SM-J510F  
619. Galaxy J5(2016) - SM-J510FN  
620. Galaxy J5(2016) - SM-J510FQ  
621. Galaxy J5(2016) - SM-J510GN  
622. Galaxy J5(2016) - SM-J510MN  
623. Galaxy J5(2016) - SM-J510UN  
624. Galaxy J5(2016) - SM-J510K  
625. Galaxy J5(2016) - SM-J510L  
626. Galaxy J5(2016) - SM-J510S  
627. Galaxy J5(2017) - SM-J530F  
628. Galaxy J5(2017) - SM-J530FM  
629. Galaxy J5(2017) - SM-J530G  
630. Galaxy J5(2017) - SM-J530GM  
631. Galaxy J5(2017) - SM-J530K  
632. Galaxy J5(2017) - SM-J530L  
633. Galaxy J5(2017) - SM-J530S  
634. Galaxy J7 - SM-J700K  
635. Galaxy J7 - SM-J700H  
636. Galaxy J7 - SM-J700F  
637. Galaxy J7 - SM-J700M  
638. Galaxy J7 - SM-J7008  
639. Galaxy J7 Max - SM-G615F  
640. Galaxy J7 Neo - SM-J701F  
641. Galaxy J7 Neo - SM-J701M  
642. Galaxy J7 Neo - SM-J701MT  
643. Galaxy J7 Pop - SAMSUNG-SM-J727AZ  
644. Galaxy J7 Pop - SAMSUNG-SM-J727A  
645. Galaxy J7 Pop - SM-J727S  
646. Galaxy J7 Pop - SM-S737TL  
647. Galaxy J7 Pop - SM-J727U  
648. Galaxy J7 Pop - SM-J727P  
649. Galaxy J7 Pop - SM-J727R4  
650. Galaxy J7 Pop - SM-J727V  
651. Galaxy J7 Pop - SM-J727VPP  
652. Galaxy J7 Pop - SM-S727VL  
653. Galaxy J7 Prime - SM-J727T1  
654. Galaxy J7 Prime - SM-J727T  
655. Galaxy J7 Prime - SM-G610F  
656. Galaxy J7 Prime - SM-G610M  
657. Galaxy J7 Prime - SM-G610Y  
658. Galaxy J7 Prime - SM-G6100  
659. Galaxy J7 Pro - SM-J730G  
660. Galaxy J7 Pro - SM-J730GM  
661. Galaxy J7(2015) - SM-J700P  
662. Galaxy J7(2016) - SM-J700T1  
663. Galaxy J7(2016) - SM-J700T  
664. Galaxy J7(2016) - SM-J710F  
665. Galaxy J7(2016) - SM-J710FQ  
666. Galaxy J7(2016) - SM-J710GN  
667. Galaxy J7(2016) - SM-J710MN  
668. Galaxy J7(2016) - SM-J7108  
669. Galaxy J7(2016) - SM-J710K  
670. Galaxy J7(2016) - SM-J7109  
671. Galaxy J7(2017) - SM-J730F  
672. Galaxy J7(2017) - SM-J730FM  
673. Galaxy J7(2017) - SM-J730G  
674. Galaxy J7(2017) - SM-J730GM  
675. Galaxy J7(2017) - SM-J730K  
676. Galaxy J7+ - SM-C710F  
677. Galaxy K - SHW-M130K  
678. Galaxy K Zoom - SM-C111  
679. Galaxy K Zoom - SM-C111M  
680. Galaxy K Zoom - SM-C115  
681. Galaxy K Zoom - SM-C115M  
682. Galaxy K Zoom - SM-C115W  
683. Galaxy K Zoom - SM-C115L  
684. Galaxy M Pro2 - GT-B7810  
685. Galaxy M Style - SHW-M340L  
686. Galaxy M Style - SHW-M340S  
687. Galaxy M Style - GT-I8258  
688. Galaxy Mega 2 - SM-G750H  
689. Galaxy Mega 5.8 - GT-I9152  
690. Galaxy Mega 5.8 - SCH-P709  
691. Galaxy Mega 5.8 - GT-I9150  
692. Galaxy Mega 5.8 - GT-I9158  
693. Galaxy Mega 6.3 - GT-I9200  
694. Galaxy Mega 6.3 - GT-I9208  
695. Galaxy Mega 6.3 - SCH-P729  
696. Galaxy Mega 6.3 - GT-I9205  
697. Galaxy Mega 6.3 - SGH-M819N  
698. Galaxy Mega 6.3 - SAMSUNG-SGH-I527  
699. Galaxy Mega 6.3 - SGH-I527M  
700. Galaxy Mega 6.3 - SHV-E310K  
701. Galaxy Mega 6.3 - SHV-E310L  
702. Galaxy Mega 6.3 - SHV-E310S  
703. Galaxy Mega 6.3 - SPH-L600  
704. Galaxy Mega 6.3 - SCH-R960  
705. Galaxy Mega Plus - GT-I9152P  
706. Galaxy Mega Plus - GT-I9158P  
707. Galaxy Mega Plus - GT-I9158V  
708. Galaxy Mega2 - SM-G750F  
709. Galaxy Mega2 - SAMSUNG-SM-G750A  
710. Galaxy Mega2 - SM-G750H  
711. Galaxy Mega2 - SM-G7508Q  
712. Galaxy Mega2 - SM-G7508Q  
713. Galaxy Mini - GT-S5570  
714. Galaxy Mini - GT-S5570B  
715. Galaxy Mini - GT-S5570I  
716. Galaxy Mini - GT-S5570L  
717. Galaxy Mini - GT-S5578  
718. Galaxy Mini - SGH-T499  
719. Galaxy Mini - SGH-T499V  
720. Galaxy Mini - SGH-T499Y  
721. Galaxy Mini2 - GT-S6500  
722. Galaxy Mini2 - GT-S6500D  
723. Galaxy Mini2 - GT-S6500L  
724. Galaxy Mini2 - GT-S6500T  
725. Galaxy Music - GT-S6010  
726. Galaxy Music - GT-S6010L

727. Galaxy Music Duos - GT-S6012  
728. Galaxy Music Duos - GT-S6012B  
729. Galaxy NX - EK-GN120  
730. Galaxy NX - EK-GN120A  
731. Galaxy NX - EK-GN120A  
732. Galaxy Neo - SHW-M220L  
733. Galaxy Nexus - Galaxy Nexus  
734. Galaxy Nexus - Galaxy X  
735. Galaxy Nexus - Galaxy Nexus  
736. Galaxy Nexus - Galaxy Nexus  
737. Galaxy Note - GT-I9220  
738. Galaxy Note - GT-I9228  
739. Galaxy Note - GT-N7000  
740. Galaxy Note - GT-N7005  
741. Galaxy Note - SC-05D  
742. Galaxy Note - SCH-i889  
743. Galaxy Note - SAMSUNG-SGH-I717  
744. Galaxy Note - SGH-I717  
745. Galaxy Note - SGH-I717D  
746. Galaxy Note - SGH-I717M  
747. Galaxy Note - SGH-I717R  
748. Galaxy Note - SGH-T879  
749. Galaxy Note - SHV-E160K  
750. Galaxy Note - SHV-E160L  
751. Galaxy Note - SHV-E160S  
752. Galaxy Note 10.1 - SM-P601  
753. Galaxy Note 10.1 - SM-P602  
754. Galaxy Note 10.1 - SM-P605K  
755. Galaxy Note 10.1 - SM-P605L  
756. Galaxy Note 10.1 - SM-P605S  
757. Galaxy Note 10.1 - GT-N8020  
758. Galaxy Note 10.1 - SHV-E230K  
759. Galaxy Note 10.1 - SHV-E230L  
760. Galaxy Note 10.1 - SHV-E230S  
761. Galaxy Note 10.1 - SPH-P600  
762. Galaxy Note 10.1 - SCH-I925U  
763. Galaxy Note 10.1 - SCH-I925  
764. Galaxy Note 10.1 - GT-N8000  
765. Galaxy Note 10.1 - GT-N8005  
766. Galaxy Note 10.1 - SHW-M480K  
767. Galaxy Note 10.1 - GT-N8013  
768. Galaxy Note 10.1 - SHW-M486W  
769. Galaxy Note 10.1 - SHW-M480W  
770. Galaxy Note 10.1 - SHW-M485W  
771. Galaxy Note 10.1 - GT-N8010  
772. Galaxy Note 10.1 2014 Edition - SM-P601  
773. Galaxy Note 10.1 2014 Edition - SM-P605  
774. Galaxy Note 10.1 2014 Edition - SM-P605M  
775. Galaxy Note 10.1 2014 Edition - SM-P607T  
776. Galaxy Note 10.1 2014 Edition - SM-P605V  
777. Galaxy Note 10.1 2014 Edition - SM-P600  
778. Galaxy Note 10.1 2014 Edition - SM-P600  
779. Galaxy Note 10.1 2014 Edition - SM-P600  
780. Galaxy Note 8.0 - GT-N5100  
781. Galaxy Note 8.0 - GT-N5105  
782. Galaxy Note 8.0 - GT-N5120  
783. Galaxy Note 8.0 - SAMSUNG-SGH-I467  
784. Galaxy Note 8.0 - SGH-I467M  
785. Galaxy Note 8.0 - GT-N5110  
786. Galaxy Note 8.0 - SHW-M500W  
787. Galaxy Note Edge - SC-01G  
788. Galaxy Note Edge - SCL24  
789. Galaxy Note Edge - SM-N915K  
790. Galaxy Note Edge - SM-N915L  
791. Galaxy Note Edge - SM-N915S  
792. Galaxy Note Edge - SM-N9150  
793. Galaxy Note Edge - SM-N915F  
794. Galaxy Note Edge - SM-N915FY  
795. Galaxy Note Edge - SM-N915G  
796. Galaxy Note Edge - SM-N915X  
797. Galaxy Note Edge - SAMSUNG-SM-N915A  
798. Galaxy Note Edge - SM-N915W8  
799. Galaxy Note Edge - SM-N9150  
800. Galaxy Note Edge - SM-N915P  
801. Galaxy Note Edge - SM-N915T  
802. Galaxy Note Edge - SM-N915T3  
803. Galaxy Note Edge - SM-N915R4  
804. Galaxy Note Edge - SM-N915V  
805. Galaxy Note Fan Edition - SM-N935F  
806. Galaxy Note Fan Edition - SM-N935K  
807. Galaxy Note Fan Edition - SM-N935L  
808. Galaxy Note Fan Edition - SM-N935S  
809. Galaxy Note II - SAMSUNG-SGH-I317  
810. Galaxy Note Pro 12.2 - SM-P901  
811. Galaxy Note Pro 12.2 - SM-P900  
812. Galaxy Note Pro 12.2 - SM-P900  
813. Galaxy Note Pro 12.2 - SM-P905  
814. Galaxy Note Pro 12.2 - SM-P905M  
815. Galaxy Note Pro 12.2 - SAMSUNG-SM-P907A  
816. Galaxy Note Pro 12.2 - SM-P905F0  
817. Galaxy Note Pro 12.2 - SM-P905V  
818. Galaxy Note2 - SC-02E  
819. Galaxy Note2 - GT-N7100  
820. Galaxy Note2 - GT-N7100T  
821. Galaxy Note2 - GT-N7100  
822. Galaxy Note2 - GT-N7102  
823. Galaxy Note2 - GT-N7102i  
824. Galaxy Note2 - GT-N7108  
825. Galaxy Note2 - SCH-N719  
826. Galaxy Note2 - GT-N7102  
827. Galaxy Note2 - GT-N7102i  
828. Galaxy Note2 - GT-N7105  
829. Galaxy Note2 - GT-N7105T  
830. Galaxy Note2 - SAMSUNG-SGH-I317  
831. Galaxy Note2 - SGH-I317M  
832. Galaxy Note2 - SGH-T889V  
833. Galaxy Note2 - GT-N7108D  
834. Galaxy Note2 - SC-02E  
835. Galaxy Note2 - SHV-E250K  
836. Galaxy Note2 - SHV-E250L  
837. Galaxy Note2 - SHV-E250S  
838. Galaxy Note2 - SPH-L900  
839. Galaxy Note2 - SGH-T889  
840. Galaxy Note2 - SCH-R950  
841. Galaxy Note2 - SCH-I605  
842. Galaxy Note3 - SC-01F  
843. Galaxy Note3 - SC-02F  
844. Galaxy Note3 - SCL22  
845. Galaxy Note3 - SM-N900  
846. Galaxy Note3 - SM-N9000Q  
847. Galaxy Note3 - SM-N9005  
848. Galaxy Note3 - SM-N9006  
849. Galaxy Note3 - SM-N9007  
850. Galaxy Note3 - SM-N9008V

851. Galaxy Note3 - SM-N9009  
852. Galaxy Note3 - SM-N900U  
853. Galaxy Note3 - SAMSUNG-SM-N900A  
854. Galaxy Note3 - SM-N900W8  
855. Galaxy Note3 - SM-N900K  
856. Galaxy Note3 - SM-N900L  
857. Galaxy Note3 - SM-N900S  
858. Galaxy Note3 - SM-N900P  
859. Galaxy Note3 - SM-N900T  
860. Galaxy Note3 - SM-N900R4  
861. Galaxy Note3 - SM-N900V  
862. Galaxy Note3 - SM-N9007  
863. Galaxy Note3 Duos - SM-N9002  
864. Galaxy Note3 Duos - SM-N9008  
865. Galaxy Note3 Neo - SM-N750K  
866. Galaxy Note3 Neo - SM-N750L  
867. Galaxy Note3 Neo - SM-N750S  
868. Galaxy Note3 Neo - SM-N750  
869. Galaxy Note3 Neo - SM-N7500Q  
870. Galaxy Note3 Neo - SM-N7502  
871. Galaxy Note3 Neo - SM-N7505  
872. Galaxy Note3 Neo - SM-N7505L  
873. Galaxy Note3 Neo - SM-N7507  
874. Galaxy Note4 - SM-N916K  
875. Galaxy Note4 - SM-N916L  
876. Galaxy Note4 - SM-N916S  
877. Galaxy Note4 - SM-N910H  
878. Galaxy Note4 - SM-N910C  
879. Galaxy Note4 - SM-N910K  
880. Galaxy Note4 - SM-N910L  
881. Galaxy Note4 - SM-N910S  
882. Galaxy Note4 - SM-N910U  
883. Galaxy Note4 - SM-N910F  
884. Galaxy Note4 - SM-N910G  
885. Galaxy Note4 - SM-N910X  
886. Galaxy Note4 - SAMSUNG-SM-N910A  
887. Galaxy Note4 - SM-N910F  
888. Galaxy Note4 - SM-N910W8  
889. Galaxy Note4 - SM-N9100  
890. Galaxy Note4 - SM-N9106W  
891. Galaxy Note4 - SM-N9108V  
892. Galaxy Note4 - SM-N9109W  
893. Galaxy Note4 - SM-N9100  
894. Galaxy Note4 - SM-N910P  
895. Galaxy Note4 - SM-N910T  
896. Galaxy Note4 - SM-N910T2  
897. Galaxy Note4 - SM-N910T3  
898. Galaxy Note4 - SM-N910R4  
899. Galaxy Note4 - SM-N910V  
900. Galaxy Note5 - SM-N9208  
901. Galaxy Note5 - SM-N920C  
902. Galaxy Note5 - SM-N920F  
903. Galaxy Note5 - SM-N920G  
904. Galaxy Note5 - SM-N920I  
905. Galaxy Note5 - SM-N920X  
906. Galaxy Note5 - SM-N920R7  
907. Galaxy Note5 - SAMSUNG-SM-N920A  
908. Galaxy Note5 - SM-N920W8  
909. Galaxy Note5 - SM-N9200  
910. Galaxy Note5 - SM-N9208  
911. Galaxy Note5 - SM-N9200  
912. Galaxy Note5 - SM-N920K  
913. Galaxy Note5 - SM-N920L  
914. Galaxy Note5 - SM-N920R6  
915. Galaxy Note5 - SM-N920S  
916. Galaxy Note5 - SM-N920P  
917. Galaxy Note5 - SM-N920T  
918. Galaxy Note5 - SM-N920R4  
919. Galaxy Note5 - SM-N920V  
920. Galaxy Note7 - SC-01J  
921. Galaxy Note7 - SCV34  
922. Galaxy Note7 - SM-N930F  
923. Galaxy Note7 - SM-N930X  
924. Galaxy Note7 - SM-N930K  
925. Galaxy Note7 - SM-N930L  
926. Galaxy Note7 - SM-N930S  
927. Galaxy Note7 - SM-N930R7  
928. Galaxy Note7 - SAMSUNG-SM-N930A  
929. Galaxy Note7 - SM-N930W8  
930. Galaxy Note7 - SM-N9300  
931. Galaxy Note7 - SGH-N037  
932. Galaxy Note7 - SM-N930R6  
933. Galaxy Note7 - SM-N930P  
934. Galaxy Note7 - SM-N930VL  
935. Galaxy Note7 - SM-N930T  
936. Galaxy Note7 - SM-N930U  
937. Galaxy Note7 - SM-N930R4  
938. Galaxy Note7 - SM-N930V  
939. Galaxy Note8 - SC-01K  
940. Galaxy Note8 - SCV37  
941. Galaxy Note8 - SM-N950F  
942. Galaxy Note8 - SM-N950N  
943. Galaxy Note8 - SM-N950U  
944. Galaxy Note8 - SM-N9500  
945. Galaxy Note8 - SM-N9508  
946. Galaxy Note8 - SM-N950W  
947. Galaxy Note8 - SM-N950U1  
948. Galaxy On Max - SM-G615FU  
949. Galaxy On Nxt - SM-G610F  
950. Galaxy On5 - SM-G550FY  
951. Galaxy On5 - SM-G5500  
952. Galaxy On5 - SM-G550FY  
953. Galaxy On5 - SM-G550T1  
954. Galaxy On5 - SM-S550TL  
955. Galaxy On5 - SM-G550T  
956. Galaxy On5 - SM-G550T2  
957. Galaxy On5(2016) - SM-G5520  
958. Galaxy On5(2016) - SM-G5528  
959. Galaxy On5(2016) - SM-G5510  
960. Galaxy On5(2016) - SM-G5700  
961. Galaxy On7 - SM-G600FY  
962. Galaxy On7 - SM-G6000  
963. Galaxy On7 - SM-G600F  
964. Galaxy On7 Pro - SM-G600FY  
965. Galaxy On7(2016) - SM-G610K  
966. Galaxy On7(2016) - SM-G610L  
967. Galaxy On7(2016) - SM-G610S  
968. Galaxy On7(2016) - SM-G6100  
969. Galaxy On8 - SM-J710FN  
970. Galaxy Player - YP-GB70  
971. Galaxy Player 3.6 - YP-GS1  
972. Galaxy Player 4 - YP-GB1  
973. Galaxy Player 4.0 - YP-G1  
974. Galaxy Player 4.2 - YP-G11



975. Galaxy Player 5 - YP-G70  
976. Galaxy Player 5.8 - YP-GP1  
977. Galaxy Player 5.8 - YP-GP1  
978. Galaxy Player 5.8 - YP-GP1  
979. Galaxy Player 50 - YP-G50  
980. Galaxy Pocket - GT-S5300  
981. Galaxy Pocket - GT-S5300B  
982. Galaxy Pocket - GT-S5300L  
983. Galaxy Pocket - GT-S5302  
984. Galaxy Pocket - GT-S5302B  
985. Galaxy Pocket - GT-S5301  
986. Galaxy Pocket - GT-S5303  
987. Galaxy Pocket Neo - GT-S5312  
988. Galaxy Pocket Neo - GT-S5312B  
989. Galaxy Pocket Neo - GT-S5312L  
990. Galaxy Pocket Neo - GT-S5310  
991. Galaxy Pocket Neo - GT-S5310B  
992. Galaxy Pocket Neo - GT-S5310E  
993. Galaxy Pocket Neo - GT-S5310G  
994. Galaxy Pocket Neo - GT-S5310L  
995. Galaxy Pocket Neo - GT-S5310T  
996. Galaxy Pocket Neo - GT-S5310I  
997. Galaxy Pocket Neo - GT-S5310N  
998. Galaxy Pocket Neo - GT-S5312C  
999. Galaxy Pocket Neo - GT-S5312M  
1000. Galaxy Pocket Neo - SAMSUNG-SGH-I747Z  
1001. Galaxy Pocket Plus - GT-S5301  
1002. Galaxy Pocket Plus - GT-S5301B  
1003. Galaxy Pocket Plus - GT-S5301L  
1004. Galaxy Pocket SS - GT-S5310C  
1005. Galaxy Pocket SS - GT-S5310M  
1006. Galaxy Pocket2 - SM-G110B  
1007. Galaxy Pocket2 - SM-G110M  
1008. Galaxy Pocket2 - SM-G110H  
1009. Galaxy Pop - SHV-E220S  
1010. Galaxy Pop (CDMA) - SCH-i559  
1011. Galaxy Precedent - SCH-M828C  
1012. Galaxy Premier - GT-I9260  
1013. Galaxy Premier - GT-I9268  
1014. Galaxy Prevail - SPH-M820-BST  
1015. Galaxy Prevail2 - SPH-M840  
1016. Galaxy Pro - GT-B7510  
1017. Galaxy Pro - GT-B7510B  
1018. Galaxy Pro - GT-B7510L  
1019. Galaxy Proclaim - SCH-S720C  
1020. Galaxy Q - SGH-T589  
1021. Galaxy Q - SGH-T589R  
1022. Galaxy Q - SGH-T589W  
1023. Galaxy R-Style - SHV-E170K  
1024. Galaxy R-Style - SHV-E170L  
1025. Galaxy R-Style - SHV-E170S  
1026. Galaxy Reverb - SPH-M950  
1027. Galaxy Round - SM-G910S  
1028. Galaxy Rugby - SGH-I547C  
1029. Galaxy Rugby Pro - SAMSUNG-SGH-I547  
1030. Galaxy Rush - SPH-M830  
1031. Galaxy S - GT-I9000  
1032. Galaxy S - GT-I9000B  
1033. Galaxy S - GT-I9000M  
1034. Galaxy S - GT-I9000T  
1035. Galaxy S - GT-I9003  
1036. Galaxy S - GT-I9003L  
1037. Galaxy S - GT-I9008L  
1038. Galaxy S - GT-I9010  
1039. Galaxy S - GT-I9018  
1040. Galaxy S - GT-I9050  
1041. Galaxy S - SC-02B  
1042. Galaxy S - SCH-I500  
1043. Galaxy S - SCH-S950C  
1044. Galaxy S - SCH-i909  
1045. Galaxy S - SAMSUNG-SGH-I897  
1046. Galaxy S - SGH-T959V  
1047. Galaxy S - SGH-T959W  
1048. Galaxy S - SHW-M110S  
1049. Galaxy S - SHW-M190S  
1050. Galaxy S - SPH-D700  
1051. Galaxy S - GT-S7275  
1052. Galaxy S Advance - GT-I9070  
1053. Galaxy S Advance - GT-I9070P  
1054. Galaxy S Aviator - SCH-R930  
1055. Galaxy S Blaze - SGH-T769  
1056. Galaxy S BlazeQ - SGH-T699  
1057. Galaxy S Captivate - SAMSUNG-SGH-I896  
1058. Galaxy S Captivate - SGH-I896  
1059. Galaxy S Continuum - SCH-I400  
1060. Galaxy S DUOS - GT-S7562  
1061. Galaxy S DUOS - GT-S7562L  
1062. Galaxy S Duos - GT-S7562  
1063. Galaxy S Duos - GT-S7562  
1064. Galaxy S Duos - GT-S7568  
1065. Galaxy S Duos2 - GT-S7582  
1066. Galaxy S Duos2 - GT-S7582L  
1067. Galaxy S Duos3 - SM-G313HZ  
1068. Galaxy S Epic - SPH-D700  
1069. Galaxy S Fascinate - SGH-T959P  
1070. Galaxy S Glide - SAMSUNG-SGH-I927R  
1071. Galaxy S Lightray - SCH-R940  
1072. Galaxy S Plus - GT-I9001  
1073. Galaxy S Stratosphere - SCH-I405  
1074. Galaxy S Vibrant - SGH-T959  
1075. Galaxy S Vibrant - SGH-T959D  
1076. Galaxy S duos - GT-S7566  
1077. Galaxy S2 - GT-I9100  
1078. Galaxy S2 - GT-I9100M  
1079. Galaxy S2 - GT-I9100P  
1080. Galaxy S2 - GT-I9100T  
1081. Galaxy S2 - GT-I9103  
1082. Galaxy S2 - GT-I9108  
1083. Galaxy S2 - GT-I9210T  
1084. Galaxy S2 - SC-02C  
1085. Galaxy S2 - SCH-R760X  
1086. Galaxy S2 - SAMSUNG-SGH-I777  
1087. Galaxy S2 - SGH-S959G  
1088. Galaxy S2 - SGH-T989  
1089. Galaxy S2 - SHV-E110S  
1090. Galaxy S2 - SHW-M250K  
1091. Galaxy S2 - SHW-M250L  
1092. Galaxy S2 - SHW-M250S  
1093. Galaxy S2 - GT-I9108  
1094. Galaxy S2 Duos - SCH-i929  
1095. Galaxy S2 Duos TV - GT-S7273T  
1096. Galaxy S2 Epic - SCH-R760  
1097. Galaxy S2 Epic - SPH-D710  
1098. Galaxy S2 Epic - SPH-D710BST



1099. Galaxy S2 Epic - SPH-D710VMUB  
1100. Galaxy S2 HD LTE - SGH-I757M  
1101. Galaxy S2 HD LTE - SHV-E120K  
1102. Galaxy S2 HD LTE - SHV-E120L  
1103. Galaxy S2 HD LTE - SHV-E120S  
1104. Galaxy S2 LTE - GT-I9210  
1105. Galaxy S2 LTE - SC-03D  
1106. Galaxy S2 LTE - SGH-I727R  
1107. Galaxy S2 Plus - GT-I9100G  
1108. Galaxy S2 Plus - GT-I9105  
1109. Galaxy S2 Plus - GT-I9105P  
1110. Galaxy S2 Skyrocket - SAMSUNG-SGH-I727  
1111. Galaxy S2 Skyrocket - SGH-I727  
1112. Galaxy S2 Wimax - ISW11SC  
1113. Galaxy S2 X - SGH-T989D  
1114. Galaxy S3 - SC-03E  
1115. Galaxy S3 - SGH-I748  
1116. Galaxy S3 - SHV-E210K  
1117. Galaxy S3 - SHV-E210L  
1118. Galaxy S3 - SHV-E210S  
1119. Galaxy S3 - SAMSUNG-SGH-I747  
1120. Galaxy S3 - SGH-I747M  
1121. Galaxy S3 - SGH-T999V  
1122. Galaxy S3 - SCH-R530C  
1123. Galaxy S3 - Gravity  
1124. Galaxy S3 - SC-06D  
1125. Galaxy S3 - SGH-T999N  
1126. Galaxy S3 - SPH-L710T  
1127. Galaxy S3 - SGH-T999L  
1128. Galaxy S3 - SCH-R530M  
1129. Galaxy S3 - SCH-L710  
1130. Galaxy S3 - SPH-L710  
1131. Galaxy S3 - SCH-S960L  
1132. Galaxy S3 - SCH-S968C  
1133. Galaxy S3 - SGH-T999  
1134. Galaxy S3 - SCH-R530U  
1135. Galaxy S3 - SPH-L710  
1136. Galaxy S3 - SCH-I535  
1137. Galaxy S3 - SCH-I535PP  
1138. Galaxy S3 - SCH-R530X  
1139. Galaxy S3 - GT-I9300  
1140. Galaxy S3 - GT-I9300T  
1141. Galaxy S3 - SCH-I939  
1142. Galaxy S3 - GT-I9300  
1143. Galaxy S3 - GT-I9308  
1144. Galaxy S3 - SCH-I939  
1145. Galaxy S3 - SCH-I939D  
1146. Galaxy S3 - SHW-M440S  
1147. Galaxy S3 - GT-I9305  
1148. Galaxy S3 - GT-I9305N  
1149. Galaxy S3 - GT-I9305T  
1150. Galaxy S3 - GravityQuad  
1151. Galaxy S3 - SC-03E  
1152. Galaxy S3 Duos - GT-I8262B  
1153. Galaxy S3 Mini - GT-I8190  
1154. Galaxy S3 Mini - GT-I8190L  
1155. Galaxy S3 Mini - GT-I8190N  
1156. Galaxy S3 Mini - GT-I8190T  
1157. Galaxy S3 Mini - SAMSUNG-SM-G730A  
1158. Galaxy S3 Mini - SM-G730W8  
1159. Galaxy S3 Mini - SM-G730V  
1160. Galaxy S3 Mini - GT-I8200L  
1161. Galaxy S3 Mini Value Edition - GT-I8200N  
1162. Galaxy S3 Mini Value Edition - GT-I8200  
1163. Galaxy S3 Mini Value Edition - GT-I8200Q  
1164. Galaxy S3 Neo - GT-I9300I  
1165. Galaxy S3 Neo - GT-I9301I  
1166. Galaxy S3 Neo - GT-I9301Q  
1167. Galaxy S3 Neo - GT-I9300I  
1168. Galaxy S3 Neo - GT-I9300I  
1169. Galaxy S3 Neo - GT-I9300I  
1170. Galaxy S3 Neo Plus - GT-I9300I  
1171. Galaxy S3 Neo Plus - GT-I9308I  
1172. Galaxy S3 Progre - SCL21  
1173. Galaxy S3 Slim - SM-G3812B  
1174. Galaxy S4 - SC-04E  
1175. Galaxy S4 - GT-I9500  
1176. Galaxy S4 - SCH-I959  
1177. Galaxy S4 - SHV-E300K  
1178. Galaxy S4 - SHV-E300L  
1179. Galaxy S4 - SHV-E300S  
1180. Galaxy S4 - GT-I9505  
1181. Galaxy S4 - GT-I9508  
1182. Galaxy S4 - GT-I9508C  
1183. Galaxy S4 - SGH-M919N  
1184. Galaxy S4 - SAMSUNG-SGH-I337Z  
1185. Galaxy S4 - SAMSUNG-SGH-I337  
1186. Galaxy S4 - SGH-I337M  
1187. Galaxy S4 - SGH-M919V  
1188. Galaxy S4 - SCH-R970C  
1189. Galaxy S4 - SCH-R970X  
1190. Galaxy S4 - SCH-I545L  
1191. Galaxy S4 - SPH-L720T  
1192. Galaxy S4 - SPH-L720  
1193. Galaxy S4 - SM-S975L  
1194. Galaxy S4 - SGH-S970G  
1195. Galaxy S4 - SGH-M919  
1196. Galaxy S4 - SCH-R970  
1197. Galaxy S4 - SCH-I545  
1198. Galaxy S4 - SCH-I545PP  
1199. Galaxy S4 - GT-I9507  
1200. Galaxy S4 - GT-I9507V  
1201. Galaxy S4 - GT-I9515  
1202. Galaxy S4 - GT-I9515L  
1203. Galaxy S4 - GT-I9505X  
1204. Galaxy S4 - GT-I9508V  
1205. Galaxy S4 - GT-I9506  
1206. Galaxy S4 - SHV-E330K  
1207. Galaxy S4 - SHV-E330L  
1208. Galaxy S4 Active - GT-I9295  
1209. Galaxy S4 Active - SAMSUNG-SGH-I537  
1210. Galaxy S4 Active - SGH-I537  
1211. Galaxy S4 Active - SHV-E470S  
1212. Galaxy S4 Duos - GT-I9502  
1213. Galaxy S4 Google Play Edition - GT-I9505G  
1214. Galaxy S4 LTE-A - SHV-E330S  
1215. Galaxy S4 Mini - GT-I9190  
1216. Galaxy S4 Mini - GT-I9192  
1217. Galaxy S4 Mini - GT-I9195  
1218. Galaxy S4 Mini - GT-I9195L  
1219. Galaxy S4 Mini - GT-I9195T  
1220. Galaxy S4 Mini - GT-I9195X  
1221. Galaxy S4 Mini - GT-I9197  
1222. Galaxy S4 Mini - SGH-I257M

1223. Galaxy S4 Mini - SHV-E370K  
1224. Galaxy S4 Mini - SHV-E370D  
1225. Galaxy S4 Mini - SCH-I435L  
1226. Galaxy S4 Mini - SPH-L520  
1227. Galaxy S4 Mini - SCH-R890  
1228. Galaxy S4 Mini - SCH-I435  
1229. Galaxy S4 Mini - GT-I9192I  
1230. Galaxy S4 Mini - GT-I9195I  
1231. Galaxy S4 Mini - SAMSUNG-SGH-I257  
1232. Galaxy S4 Zoom - SM-C101  
1233. Galaxy S4 Zoom - SAMSUNG-SM-C105A  
1234. Galaxy S4 Zoom - SM-C105K  
1235. Galaxy S4 Zoom - SM-C105L  
1236. Galaxy S4 Zoom - SM-C105S  
1237. Galaxy S4 Zoom - SM-C105  
1238. Galaxy S5 - SC-04F  
1239. Galaxy S5 - SCL23  
1240. Galaxy S5 - SM-G900H  
1241. Galaxy S5 - SM-G9008W  
1242. Galaxy S5 - SM-G9009W  
1243. Galaxy S5 - SM-G900F  
1244. Galaxy S5 - SM-G900FQ  
1245. Galaxy S5 - SM-G900I  
1246. Galaxy S5 - SM-G900M  
1247. Galaxy S5 - SM-G900MD  
1248. Galaxy S5 - SM-G900T1  
1249. Galaxy S5 - SM-G900T4  
1250. Galaxy S5 - SM-G900R7  
1251. Galaxy S5 - SAMSUNG-SM-G900AZ  
1252. Galaxy S5 - SAMSUNG-SM-G900A  
1253. Galaxy S5 - SM-G900W8  
1254. Galaxy S5 - SM-G9006W  
1255. Galaxy S5 - SM-G900K  
1256. Galaxy S5 - SM-G900L  
1257. Galaxy S5 - SM-G900R6  
1258. Galaxy S5 - SM-G900S  
1259. Galaxy S5 - SM-G900P  
1260. Galaxy S5 - SM-S903VL  
1261. Galaxy S5 - SM-G900T  
1262. Galaxy S5 - SM-G900T3  
1263. Galaxy S5 - SM-G900R4  
1264. Galaxy S5 - SM-G900V  
1265. Galaxy S5 - SM-G900X  
1266. Galaxy S5 - SM-G906K  
1267. Galaxy S5 - SM-G906L  
1268. Galaxy S5 - SM-G906S  
1269. Galaxy S5 Active - SC-02G  
1270. Galaxy S5 Active - SM-G870F0  
1271. Galaxy S5 Active - SM-G870F  
1272. Galaxy S5 Active - SAMSUNG-SM-G870A  
1273. Galaxy S5 Active - SM-G870W  
1274. Galaxy S5 Dual SIM - SM-G900FD  
1275. Galaxy S5 Google Play Edition - SM-G900FG  
1276. Galaxy S5 K Sport - SM-G860P  
1277. Galaxy S5 LTE-A - SM-G901F  
1278. Galaxy S5 Mini - SM-G800H  
1279. Galaxy S5 Mini - SM-G800F  
1280. Galaxy S5 Mini - SM-G800Y  
1281. Galaxy S5 Mini - SM-G800R4  
1282. Galaxy S5 Neo - SM-G903F  
1283. Galaxy S5 Neo - SM-G903M  
1284. Galaxy S5 Neo - SM-G903W  
1285. Galaxy S5 mini - SM-G800HQ  
1286. Galaxy S5 mini - SM-G800M  
1287. Galaxy S5 mini - SAMSUNG-SM-G800A  
1288. Galaxy S5 mini - SM-G800X  
1289. Galaxy S5 mini LTE - SM-G800Y  
1290. Galaxy S6 - SC-05G  
1291. Galaxy S6 - SM-G920F  
1292. Galaxy S6 - SM-G920I  
1293. Galaxy S6 - SM-G920X  
1294. Galaxy S6 - SM-G920R7  
1295. Galaxy S6 - SAMSUNG-SM-G920AZ  
1296. Galaxy S6 - SAMSUNG-SM-G920A  
1297. Galaxy S6 - SM-G920W8  
1298. Galaxy S6 - SM-G9200  
1299. Galaxy S6 - SM-G9208  
1300. Galaxy S6 - SM-G9209  
1301. Galaxy S6 - SM-G920K  
1302. Galaxy S6 - SM-G920L  
1303. Galaxy S6 - SM-G920R6  
1304. Galaxy S6 - SM-G920T1  
1305. Galaxy S6 - SM-G920S  
1306. Galaxy S6 - SM-G920P  
1307. Galaxy S6 - SM-S906L  
1308. Galaxy S6 - SM-S907VL  
1309. Galaxy S6 - SM-G920T  
1310. Galaxy S6 - SM-G920R4  
1311. Galaxy S6 - SM-G920V  
1312. Galaxy S6 Active - SAMSUNG-SM-G890A  
1313. Galaxy S6 Edge - 404SC  
1314. Galaxy S6 Edge - SC-04G  
1315. Galaxy S6 Edge - SCV31  
1316. Galaxy S6 Edge - SM-G925F  
1317. Galaxy S6 Edge - SM-G925I  
1318. Galaxy S6 Edge - SM-G925X  
1319. Galaxy S6 Edge - SM-G925R7  
1320. Galaxy S6 Edge - SAMSUNG-SM-G925A  
1321. Galaxy S6 Edge - SM-G925W8  
1322. Galaxy S6 Edge - SM-G9250  
1323. Galaxy S6 Edge - SM-G925K  
1324. Galaxy S6 Edge - SM-G925L  
1325. Galaxy S6 Edge - SM-G925R6  
1326. Galaxy S6 Edge - SM-G925S  
1327. Galaxy S6 Edge - SM-G925P  
1328. Galaxy S6 Edge - SM-G925T  
1329. Galaxy S6 Edge - SM-G925R4  
1330. Galaxy S6 Edge - SM-G925V  
1331. Galaxy S6 Edge+ - SM-G9287  
1332. Galaxy S6 Edge+ - SM-G9287C  
1333. Galaxy S6 Edge+ - SM-G928C  
1334. Galaxy S6 Edge+ - SM-G928F  
1335. Galaxy S6 Edge+ - SM-G928G  
1336. Galaxy S6 Edge+ - SM-G928I  
1337. Galaxy S6 Edge+ - SM-G928X  
1338. Galaxy S6 Edge+ - SAMSUNG-SM-G928A  
1339. Galaxy S6 Edge+ - SM-G928W8  
1340. Galaxy S6 Edge+ - SM-G9280  
1341. Galaxy S6 Edge+ - SM-G928K  
1342. Galaxy S6 Edge+ - SM-G928N0  
1343. Galaxy S6 Edge+ - SM-G928L  
1344. Galaxy S6 Edge+ - SM-G928S  
1345. Galaxy S6 Edge+ - SM-G928P  
1346. Galaxy S6 Edge+ - SM-G928T

1347. Galaxy S6 Edge+ - SM-G928R4  
1348. Galaxy S6 Edge+ - SM-G928V  
1349. Galaxy S7 - SM-G930F  
1350. Galaxy S7 - SM-G930X  
1351. Galaxy S7 - SM-G930W8  
1352. Galaxy S7 - SM-G930K  
1353. Galaxy S7 - SM-G930L  
1354. Galaxy S7 - SM-G930S  
1355. Galaxy S7 - SM-G930R7  
1356. Galaxy S7 - SAMSUNG-SM-G930AZ  
1357. Galaxy S7 - SAMSUNG-SM-G930A  
1358. Galaxy S7 - SM-G930VC  
1359. Galaxy S7 - SM-G9300  
1360. Galaxy S7 - SM-G9308  
1361. Galaxy S7 - SM-G930R6  
1362. Galaxy S7 - SM-G930T1  
1363. Galaxy S7 - SM-G930P  
1364. Galaxy S7 - SM-G930VL  
1365. Galaxy S7 - SM-G930T  
1366. Galaxy S7 - SM-G930U  
1367. Galaxy S7 - SM-G930R4  
1368. Galaxy S7 - SM-G930V  
1369. Galaxy S7 Active - SAMSUNG-SM-G891A  
1370. Galaxy S7 Edge - SC-02H  
1371. Galaxy S7 Edge - SCV33  
1372. Galaxy S7 Edge - SM-G935F  
1373. Galaxy S7 Edge - SM-G935X  
1374. Galaxy S7 Edge - SM-G935W8  
1375. Galaxy S7 Edge - SM-G935K  
1376. Galaxy S7 Edge - SM-G935L  
1377. Galaxy S7 Edge - SM-G935S  
1378. Galaxy S7 Edge - SAMSUNG-SM-G935A  
1379. Galaxy S7 Edge - SM-G935VC  
1380. Galaxy S7 Edge - SM-G9350  
1381. Galaxy S7 Edge - SM-G935P  
1382. Galaxy S7 Edge - SM-G935T  
1383. Galaxy S7 Edge - SM-G935U  
1384. Galaxy S7 Edge - SM-G935R4  
1385. Galaxy S7 Edge - SM-G935V  
1386. Galaxy S8 - SC-02J  
1387. Galaxy S8 - SCV36  
1388. Galaxy S8 - SM-G950F  
1389. Galaxy S8 - SM-G950N  
1390. Galaxy S8 - SM-G950W  
1391. Galaxy S8 - SM-G9500  
1392. Galaxy S8 - SM-G9508  
1393. Galaxy S8 - SM-G950U  
1394. Galaxy S8 - SM-G950U1  
1395. Galaxy S8 Active - SM-G892A  
1396. Galaxy S8+ - SC-03J  
1397. Galaxy S8+ - SCV35  
1398. Galaxy S8+ - SM-G955F  
1399. Galaxy S8+ - SM-G955N  
1400. Galaxy S8+ - SM-G955W  
1401. Galaxy S8+ - SM-G9550  
1402. Galaxy S8+ - SM-G955U  
1403. Galaxy S8+ - SM-G955U1  
1404. Galaxy Spica - GT-I5700L  
1405. Galaxy Spica - GT-I5700L  
1406. Galaxy Spica - GT-I5700R  
1407. Galaxy Spica - GT-I5700L  
1408. Galaxy Spica - GT-I5700  
1409. Galaxy Spica - GT-I5700L  
1410. Galaxy Spica - GT-I5700R  
1411. Galaxy Spica - GT-I5700  
1412. Galaxy Star - GT-S5282  
1413. Galaxy Star - GT-S5280  
1414. Galaxy Star Plus - GT-S7262  
1415. Galaxy Star Trios - GT-S5283B  
1416. Galaxy Star2 Plus - SM-G350E  
1417. Galaxy Stellar - SCH-I200  
1418. Galaxy Stellar - SCH-I200PP  
1419. Galaxy Stratosphere2 - SCH-I415  
1420. Galaxy Style Duos - SCH-I829  
1421. Galaxy TAB3 Lite - SM-T116IR  
1422. Galaxy Tab - GT-P1000  
1423. Galaxy Tab - GT-P1000L  
1424. Galaxy Tab - GT-P1000M  
1425. Galaxy Tab - GT-P1000N  
1426. Galaxy Tab - GT-P1000R  
1427. Galaxy Tab - GT-P1000T  
1428. Galaxy Tab - GT-P1010  
1429. Galaxy Tab - GT-P1013  
1430. Galaxy Tab - SC-01C  
1431. Galaxy Tab - SCH-I800  
1432. Galaxy Tab - SGH-T849  
1433. Galaxy Tab - SHW-M180K  
1434. Galaxy Tab - SHW-M180L  
1435. Galaxy Tab - SHW-M180S  
1436. Galaxy Tab - SHW-M180W  
1437. Galaxy Tab - SMT-i9100  
1438. Galaxy Tab 10.1 - GT-P7500  
1439. Galaxy Tab 10.1 - GT-P7500D  
1440. Galaxy Tab 10.1 - GT-P7503  
1441. Galaxy Tab 10.1 - GT-P7510  
1442. Galaxy Tab 10.1 - SC-01D  
1443. Galaxy Tab 10.1 - SCH-I905  
1444. Galaxy Tab 10.1 - SGH-T859  
1445. Galaxy Tab 10.1 - SHW-M300W  
1446. Galaxy Tab 10.1 - SHW-M380K  
1447. Galaxy Tab 10.1 - SHW-M380S  
1448. Galaxy Tab 10.1 - SHW-M380W  
1449. Galaxy Tab 10.1 N - GT-P7501  
1450. Galaxy Tab 10.1 N - GT-P7511  
1451. Galaxy Tab 10.1 v - GT-P7100  
1452. Galaxy Tab 3 Lite - SM-T116IR  
1453. Galaxy Tab 3V 7.0 - SM-T116NY  
1454. Galaxy Tab 4 8.0 - SM-T330X  
1455. Galaxy Tab 4 8.0 - SM-T330  
1456. Galaxy Tab 4 Active - SM-T365  
1457. Galaxy Tab 4 Active - SM-T365Y  
1458. Galaxy Tab 7.0 - SPH-P100  
1459. Galaxy Tab 7.0 Plus - GT-P6200  
1460. Galaxy Tab 7.0 Plus - GT-P6200L  
1461. Galaxy Tab 7.0 Plus - GT-P6201  
1462. Galaxy Tab 7.0 Plus - GT-P6210  
1463. Galaxy Tab 7.0 Plus - GT-P6211  
1464. Galaxy Tab 7.0 Plus - SC-02D  
1465. Galaxy Tab 7.0 Plus - SGH-T869  
1466. Galaxy Tab 7.0 Plus - SHW-M430W  
1467. Galaxy Tab 7.7 - GT-P6800  
1468. Galaxy Tab 7.7 - GT-P6810  
1469. Galaxy Tab 7.7 - SCH-I815  
1470. Galaxy Tab 7.7 Plus - SC-01E



1471. Galaxy Tab 8.9 - GT-P7300  
1472. Galaxy Tab 8.9 - GT-P7310  
1473. Galaxy Tab 8.9 - GT-P7320  
1474. Galaxy Tab 8.9 - SCH-P739  
1475. Galaxy Tab 8.9 - SAMSUNG-SGH-I957  
1476. Galaxy Tab 8.9 - SAMSUNG-SGH-I957D  
1477. Galaxy Tab 8.9 - SGH-I957D  
1478. Galaxy Tab 8.9 - SAMSUNG-SGH-I957M  
1479. Galaxy Tab 8.9 - SGH-I957M  
1480. Galaxy Tab 8.9 - SAMSUNG-SGH-I957R  
1481. Galaxy Tab 8.9 - SGH-I957R  
1482. Galaxy Tab 8.9 - SHV-E140K  
1483. Galaxy Tab 8.9 - SHV-E140L  
1484. Galaxy Tab 8.9 - SHV-E140S  
1485. Galaxy Tab 8.9 - SHW-M305W  
1486. Galaxy Tab A 10.1 - SM-P580  
1487. Galaxy Tab A 10.1 - SM-T585  
1488. Galaxy Tab A 10.1 - SM-T585M  
1489. Galaxy Tab A 10.1 - SM-T587  
1490. Galaxy Tab A 10.1 - SM-T585C  
1491. Galaxy Tab A 10.1 - SM-T585N0  
1492. Galaxy Tab A 10.1 - SM-T580  
1493. Galaxy Tab A 10.1 - SM-T580X  
1494. Galaxy Tab A 10.1 - SM-T580  
1495. Galaxy Tab A 10.1 - SM-T580X  
1496. Galaxy Tab A 10.1(2016) - SM-P585  
1497. Galaxy Tab A 10.1(2016) - SM-P585Y  
1498. Galaxy Tab A 7.0 - SM-T285  
1499. Galaxy Tab A 7.0 - SM-T285M  
1500. Galaxy Tab A 7.0 - SM-T287  
1501. Galaxy Tab A 7.0 - SM-T285YD  
1502. Galaxy Tab A 7.0 - SM-T280  
1503. Galaxy Tab A 8.0 - SM-T355  
1504. Galaxy Tab A 8.0 - SM-T355Y  
1505. Galaxy Tab A 8.0 - SM-T355C  
1506. Galaxy Tab A 8.0 - SM-T357T  
1507. Galaxy Tab A 8.0 - SM-T350  
1508. Galaxy Tab A 8.0 - SM-T350X  
1509. Galaxy Tab A 8.0 - SM-T350  
1510. Galaxy Tab A 8.0 - SM-T350X  
1511. Galaxy Tab A 8.0 - SM-P355  
1512. Galaxy Tab A 8.0 - SM-P355M  
1513. Galaxy Tab A 8.0 - SM-P355C  
1514. Galaxy Tab A 8.0 - SM-P355Y  
1515. Galaxy Tab A 8.0 - SM-P350  
1516. Galaxy Tab A 8.0 - SM-P350  
1517. Galaxy Tab A 9.7 - SM-T555  
1518. Galaxy Tab A 9.7 - SM-T555C  
1519. Galaxy Tab A 9.7 - SM-T550  
1520. Galaxy Tab A 9.7 - SM-T550X  
1521. Galaxy Tab A 9.7 - SM-T550  
1522. Galaxy Tab A 9.7 - SM-T550X  
1523. Galaxy Tab A 9.7 - SM-P555  
1524. Galaxy Tab A 9.7 - SM-P555M  
1525. Galaxy Tab A 9.7 - SM-P555C  
1526. Galaxy Tab A 9.7 - SM-P555Y  
1527. Galaxy Tab A 9.7 - SM-P555K  
1528. Galaxy Tab A 9.7 - SM-P555L  
1529. Galaxy Tab A 9.7 - SM-P555S  
1530. Galaxy Tab A 9.7 - SM-P550  
1531. Galaxy Tab A 9.7 - SM-P550  
1532. Galaxy Tab A S 8.0 - SM-T357W  
1533. Galaxy Tab A2 8.0 - SM-T385  
1534. Galaxy Tab A2 8.0 - SM-T385M  
1535. Galaxy Tab A2 8.0 - SM-T385C  
1536. Galaxy Tab A2 8.0 - SM-T385K  
1537. Galaxy Tab A2 8.0 - SM-T385L  
1538. Galaxy Tab A2 8.0 - SM-T385S  
1539. Galaxy Tab A2 8.0 - SM-T380  
1540. Galaxy Tab A2 8.0 - SM-T380C  
1541. Galaxy Tab Active2 - SM-T395  
1542. Galaxy Tab E 8.0 - SAMSUNG-SM-T377A  
1543. Galaxy Tab E 8.0 - SM-T377W  
1544. Galaxy Tab E 8.0 - SM-T375L  
1545. Galaxy Tab E 8.0 - SM-T375S  
1546. Galaxy Tab E 8.0 - SM-T377T  
1547. Galaxy Tab E 8.0 - SM-T3777  
1548. Galaxy Tab E 8.0 - SM-T377V  
1549. Galaxy Tab E 8.0 - SM-T377P  
1550. Galaxy Tab E 8.0 - SM-T377R4  
1551. Galaxy Tab E 9.6 - SM-T561  
1552. Galaxy Tab E 9.6 - SM-T561M  
1553. Galaxy Tab E 9.6 - SM-T561Y  
1554. Galaxy Tab E 9.6 - SM-T562  
1555. Galaxy Tab E 9.6 - SM-T567V  
1556. Galaxy Tab E 9.6 - SM-T560  
1557. Galaxy Tab E 9.6 - SM-T560  
1558. Galaxy Tab E 9.6 - SM-T560NU  
1559. Galaxy Tab Plus 7.0 - SM-T116BU  
1560. Galaxy Tab Pro 10.1 - SM-T525  
1561. Galaxy Tab Pro 10.1 - SM-T520  
1562. Galaxy Tab Pro 10.1 Chef Collection - SM-T520CC  
1563. Galaxy Tab Pro 12.2 - SM-T905  
1564. Galaxy Tab Pro 12.2 - SM-T900  
1565. Galaxy Tab Pro 12.2 - SM-T900X  
1566. Galaxy Tab Pro 8.4 - SM-T325  
1567. Galaxy Tab Pro 8.4 - SM-T320  
1568. Galaxy Tab Pro 8.4 - SM-T320X  
1569. Galaxy Tab Pro 8.4 - SM-T320  
1570. Galaxy Tab Pro 8.4 - SM-T320  
1571. Galaxy Tab Pro 8.4 - SM-T320NU  
1572. Galaxy Tab Q - SM-T2519  
1573. Galaxy Tab S 10.5 - SM-T800  
1574. Galaxy Tab S 8.4 - SC-03G  
1575. Galaxy Tab S 8.4 - SM-T705  
1576. Galaxy Tab S 8.4 - SM-T705C  
1577. Galaxy Tab S 8.4 - SM-T705Y  
1578. Galaxy Tab S 8.4 - SM-T707V  
1579. Galaxy Tab S 8.4 - SM-T700  
1580. Galaxy Tab S2 8.0 - SM-T815  
1581. Galaxy Tab S2 8.0 - SM-T715  
1582. Galaxy Tab S2 8.0 - SM-T715Y  
1583. Galaxy Tab S2 8.0 - SM-T715C  
1584. Galaxy Tab S2 8.0 - SM-T715N0  
1585. Galaxy Tab S2 8.0 - SM-T719  
1586. Galaxy Tab S2 8.0 - SM-T719Y  
1587. Galaxy Tab S2 8.0 - SM-T719C  
1588. Galaxy Tab S2 8.0 - SM-T713  
1589. Galaxy Tab S2 8.0 - SM-T713  
1590. Galaxy Tab S2 8.0 - SM-T710  
1591. Galaxy Tab S2 8.0 - SM-T710X  
1592. Galaxy Tab S2 8.0 - SM-T710  
1593. Galaxy Tab S2 9.7 - SM-T815C  
1594. Galaxy Tab S2 9.7 - SM-T815Y



1595. Galaxy Tab S2 9.7 - SM-T817  
1596. Galaxy Tab S2 9.7 - SAMSUNG-SM-T817A  
1597. Galaxy Tab S2 9.7 - SM-T817W  
1598. Galaxy Tab S2 9.7 - SM-T815N0  
1599. Galaxy Tab S2 9.7 - SM-T817P  
1600. Galaxy Tab S2 9.7 - SM-T817T  
1601. Galaxy Tab S2 9.7 - SM-T817R4  
1602. Galaxy Tab S2 9.7 - SM-T817V  
1603. Galaxy Tab S2 9.7 - SM-T818  
1604. Galaxy Tab S2 9.7 - SM-T819  
1605. Galaxy Tab S2 9.7 - SM-T819Y  
1606. Galaxy Tab S2 9.7 - SAMSUNG-SM-T818A  
1607. Galaxy Tab S2 9.7 - SM-T818W  
1608. Galaxy Tab S2 9.7 - SM-T819C  
1609. Galaxy Tab S2 9.7 - SM-T818T  
1610. Galaxy Tab S2 9.7 - SM-T813  
1611. Galaxy Tab S2 9.7 - SM-T813  
1612. Galaxy Tab S2 9.7 - SM-T810  
1613. Galaxy Tab S2 9.7 - SM-T810X  
1614. Galaxy Tab S3 - SM-T825  
1615. Galaxy Tab S3 - SM-T825C  
1616. Galaxy Tab S3 - SM-T825X  
1617. Galaxy Tab S3 - SM-T827  
1618. Galaxy Tab S3 - SM-T825N0  
1619. Galaxy Tab S3 - SM-T827R4  
1620. Galaxy Tab S3 - SM-T827V  
1621. Galaxy Tab S3 - SM-T820  
1622. Galaxy Tab S3 - SM-T820X  
1623. Galaxy Tab S3 - SM-T820  
1624. Galaxy Tab2 10.1 - SAMSUNG-SGH-I497  
1625. Galaxy Tab2 10.1 - SGH-I497  
1626. Galaxy Tab2 10.1 - GT-P5100  
1627. Galaxy Tab2 10.1 - SPH-P500  
1628. Galaxy Tab2 10.1 - SGH-T779  
1629. Galaxy Tab2 10.1 - SCH-I915  
1630. Galaxy Tab2 10.1 - GT-P5110  
1631. Galaxy Tab2 10.1 - GT-P5113  
1632. Galaxy Tab2 7.0 - GT-P3100  
1633. Galaxy Tab2 7.0 - GT-P3100B  
1634. Galaxy Tab2 7.0 - GT-P3105  
1635. Galaxy Tab2 7.0 - SCH-I705  
1636. Galaxy Tab2 7.0 - SCH-i705  
1637. Galaxy Tab2 7.0 - GT-P3110  
1638. Galaxy Tab2 7.0 - GT-P3113  
1639. Galaxy Tab3 - SM-T310  
1640. Galaxy Tab3 10.1 - GT-P5200  
1641. Galaxy Tab3 10.1 - GT-P5220  
1642. Galaxy Tab3 10.1 - GT-P5210  
1643. Galaxy Tab3 10.1 - GT-P5210XD1  
1644. Galaxy Tab3 7.0 - SM-T211  
1645. Galaxy Tab3 7.0 - SM-T212  
1646. Galaxy Tab3 7.0 - SM-T211M  
1647. Galaxy Tab3 7.0 - SM-T215  
1648. Galaxy Tab3 7.0 - SAMSUNG-SM-T217A  
1649. Galaxy Tab3 7.0 - SM-T217S  
1650. Galaxy Tab3 7.0 - SM-T217T  
1651. Galaxy Tab3 7.0 - SM-T210  
1652. Galaxy Tab3 7.0 - SM-T210R  
1653. Galaxy Tab3 7.0 - SM-T210L  
1654. Galaxy Tab3 8.0 - SM-T311  
1655. Galaxy Tab3 8.0 - SM-T312  
1656. Galaxy Tab3 8.0 - SM-T315  
1657. Galaxy Tab3 8.0 - SM-T315T  
1658. Galaxy Tab3 8.0 - SM-T310  
1659. Galaxy Tab3 8.0 - SM-T310X  
1660. Galaxy Tab3 8.0 - SM-T210X  
1661. Galaxy Tab3 Kids - SM-T2105  
1662. Galaxy Tab3 Lite - SM-T111  
1663. Galaxy Tab3 Lite - SM-T111M  
1664. Galaxy Tab3 Lite - SM-T110  
1665. Galaxy Tab3 Lite 7.0 - SM-T116NQ  
1666. Galaxy Tab3 Lite 7.0 - SM-T113  
1667. Galaxy Tab3 VE 7.0 - SM-T116  
1668. Galaxy Tab3V 7.0 - SM-T116NU  
1669. Galaxy Tab3V 7.0 - SM-T113NU  
1670. Galaxy Tab4 - SM-T530NN  
1671. Galaxy Tab4 10.0 - SM-T531  
1672. Galaxy Tab4 10.0 - SM-T535  
1673. Galaxy Tab4 10.0 - SAMSUNG-SM-T537A  
1674. Galaxy Tab4 10.0 - SM-T537R4  
1675. Galaxy Tab4 10.0 - SM-T537V  
1676. Galaxy Tab4 10.1 - SM-T536  
1677. Galaxy Tab4 10.1 - SM-T533  
1678. Galaxy Tab4 10.1 - SM-T530  
1679. Galaxy Tab4 10.1 - SM-T530X  
1680. Galaxy Tab4 10.1 - SM-T530  
1681. Galaxy Tab4 10.1 - SM-T530NU  
1682. Galaxy Tab4 7.0 - 403SC  
1683. Galaxy Tab4 7.0 - SM-T230NW  
1684. Galaxy Tab4 7.0 - SM-T230NW  
1685. Galaxy Tab4 7.0 - SM-T231  
1686. Galaxy Tab4 7.0 - SM-T232  
1687. Galaxy Tab4 7.0 - SM-T235  
1688. Galaxy Tab4 7.0 - SM-T235Y  
1689. Galaxy Tab4 7.0 - SM-T237P  
1690. Galaxy Tab4 7.0 - SM-T237V  
1691. Galaxy Tab4 7.0 - SM-T239  
1692. Galaxy Tab4 7.0 - SM-T2397  
1693. Galaxy Tab4 7.0 - SM-T239M  
1694. Galaxy Tab4 7.0 - SM-T239C  
1695. Galaxy Tab4 7.0 - SM-T230  
1696. Galaxy Tab4 7.0 - SM-T230NY  
1697. Galaxy Tab4 7.0 - SM-T230X  
1698. Galaxy Tab4 7.0 - SM-T230NY  
1699. Galaxy Tab4 7.0 - SM-T230NT  
1700. Galaxy Tab4 7.0 - SM-T230NU  
1701. Galaxy Tab4 7.0 - SM-T230NU  
1702. Galaxy Tab4 8.0 - SM-T331  
1703. Galaxy Tab4 8.0 - SM-T335  
1704. Galaxy Tab4 8.0 - SAMSUNG-SM-T337A  
1705. Galaxy Tab4 8.0 - SM-T335K  
1706. Galaxy Tab4 8.0 - SM-T335L  
1707. Galaxy Tab4 8.0 - SM-T337T  
1708. Galaxy Tab4 8.0 - SM-T337V  
1709. Galaxy Tab4 8.0 - SM-T330  
1710. Galaxy Tab4 8.0 - SM-T330NU  
1711. Galaxy Tab4 Active - SM-T365  
1712. Galaxy Tab4 Active - SM-T365M  
1713. Galaxy Tab4 Active - SM-T365F0  
1714. Galaxy Tab4 Active - SM-T360  
1715. Galaxy Tab4 Active - SM-T360  
1716. Galaxy Tab4 Nook 10.1 - SM-T530NU  
1717. Galaxy TabA Plus 10.1 - SM-P585M  
1718. Galaxy TabA Plus 10.1 - SM-P587

1719. Galaxy TabA Plus 10.1 - SM-P588C  
1720. Galaxy TabA Plus 10.1 - SM-P585N0  
1721. Galaxy TabA Plus 10.1 - SM-P583  
1722. Galaxy TabA Plus 10.1 - SM-T587P  
1723. Galaxy TabA Plus10.1 - SM-P580X  
1724. Galaxy TabE 8.0 - SM-T378K  
1725. Galaxy TabE 8.0 - SM-T378L  
1726. Galaxy TabE 8.0 - SM-T378S  
1727. Galaxy TabS 10.5 - SCT21  
1728. Galaxy TabS 10.5 - SM-T805K  
1729. Galaxy TabS 10.5 - SM-T805L  
1730. Galaxy TabS 10.5 - SM-T805S  
1731. Galaxy TabS 10.5 - SM-T805  
1732. Galaxy TabS 10.5 - SM-T805M  
1733. Galaxy TabS 10.5 - SM-T805Y  
1734. Galaxy TabS 10.5 - SM-T807  
1735. Galaxy TabS 10.5 - SAMSUNG-SM-T807A  
1736. Galaxy TabS 10.5 - SM-T805W  
1737. Galaxy TabS 10.5 - SM-T807P  
1738. Galaxy TabS 10.5 - SM-T807T  
1739. Galaxy TabS 10.5 - SM-T807R4  
1740. Galaxy TabS 10.5 - SM-T807V  
1741. Galaxy TabS 10.5 - SM-T800  
1742. Galaxy TabS 10.5 - SM-T800X  
1743. Galaxy TabS 10.5 - SM-T800  
1744. Galaxy TabS 8.4 - SM-T705  
1745. Galaxy TabS 8.4 - SM-T705M  
1746. Galaxy TabS 8.4 - SAMSUNG-SM-T707A  
1747. Galaxy TabS 8.4 - SM-T705W  
1748. Galaxy TabS 8.4 - SM-T700  
1749. Galaxy TabS 8.4 - SM-T700  
1750. Galaxy TabS2 9.7 - SM-T818V  
1751. Galaxy TabS3 - SM-T825  
1752. Galaxy TabS3 - SM-T825Y  
1753. Galaxy TabS3 - SM-T825C  
1754. Galaxy Tap Pro 10.1 - SM-T525  
1755. Galaxy Tap Pro 8.4 - SM-T320  
1756. Galaxy Trend - GT-S7392  
1757. Galaxy Trend - GT-S7392L  
1758. Galaxy Trend - GT-S7568I  
1759. Galaxy Trend Duos - GT-S7562i  
1760. Galaxy Trend Duos - GT-S7572  
1761. Galaxy Trend Duos - GT-S7390  
1762. Galaxy Trend Duos - GT-S7392  
1763. Galaxy Trend Duos - GT-S7562C  
1764. Galaxy Trend Lite - GT-S7390  
1765. Galaxy Trend Lite - GT-S7390L  
1766. Galaxy Trend Plus - GT-S7580  
1767. Galaxy Trend Plus - GT-S7580E  
1768. Galaxy Trend Plus - GT-S7580L  
1769. Galaxy Trend Plus - GT-S7583T  
1770. Galaxy Trend2 - GT-S7898  
1771. Galaxy Trend2 - GT-S7898I  
1772. Galaxy Trend2 - SCH-I739  
1773. Galaxy Trend3 - SM-G3502U  
1774. Galaxy Trend3 - SM-G3508  
1775. Galaxy Trend3 - SM-G3509  
1776. Galaxy Trend3 - SM-G3508I  
1777. Galaxy Trend3 - SM-G3502C  
1778. Galaxy Trend3 - SM-G3502I  
1779. Galaxy Trend3 - SM-G3508J  
1780. Galaxy Trend3 - SM-G3509I  
1781. Galaxy U - SHW-M130L  
1782. Galaxy Victory - SPH-L300  
1783. Galaxy Victory - SPH-L300  
1784. Galaxy View - SM-T677  
1785. Galaxy View - SAMSUNG-SM-T677A  
1786. Galaxy View - SM-T677V  
1787. Galaxy View - SM-T677  
1788. Galaxy View - SM-T670  
1789. Galaxy View - SM-T670  
1790. Galaxy W - GT-I8150  
1791. Galaxy W - GT-I8150B  
1792. Galaxy W - GT-I8150T  
1793. Galaxy W - SGH-T679M  
1794. Galaxy W - SM-T255S  
1795. Galaxy Wide - SM-G600S  
1796. Galaxy Win - GT-I8558  
1797. Galaxy Win - SCH-I869  
1798. Galaxy Win - GT-I8552  
1799. Galaxy Win - GT-I8552B  
1800. Galaxy Win - GT-I8550E  
1801. Galaxy Win - SHV-E500L  
1802. Galaxy Win - SHV-E500S  
1803. Galaxy Win Duos - GT-I8552  
1804. Galaxy Win Pro - SM-G3818  
1805. Galaxy Win Pro - SM-G3819  
1806. Galaxy Win Pro - SM-G3819D  
1807. Galaxy Win Pro - SM-G3812  
1808. Galaxy Win2 - SM-G360BT  
1809. Galaxy Xcover - GT-S5690  
1810. Galaxy Xcover - GT-S5690L  
1811. Galaxy Xcover - GT-S5690M  
1812. Galaxy Xcover - GT-S5690R  
1813. Galaxy Xcover2 - GT-S7710  
1814. Galaxy Xcover2 - GT-S7710L  
1815. Galaxy Xcover3 - SM-G388F  
1816. Galaxy Xcover3 - SM-G389F  
1817. Galaxy Xcover4 - SM-G390F  
1818. Galaxy Xcover4 - SM-G390Y  
1819. Galaxy Xcover4 - SM-G390W  
1820. Galaxy Y - GT-S5360  
1821. Galaxy Y - GT-S5360B  
1822. Galaxy Y - GT-S5360L  
1823. Galaxy Y - GT-S5360T  
1824. Galaxy Y - GT-S5363  
1825. Galaxy Y - GT-S5368  
1826. Galaxy Y - GT-S5369  
1827. Galaxy Y - SCH-I509  
1828. Galaxy Y - SCH-I509  
1829. Galaxy Y Duos - GT-S6102  
1830. Galaxy Y Duos - GT-S6102B  
1831. Galaxy Y Duos - GT-S6102E  
1832. Galaxy Y Plus - GT-S5303  
1833. Galaxy Y Plus - GT-S5303B  
1834. Galaxy Y Pop - GT-S6108  
1835. Galaxy Y Pro - GT-B5510  
1836. Galaxy Y Pro - GT-B5510B  
1837. Galaxy Y Pro - GT-B5510L  
1838. Galaxy Y Pro Duos - GT-B5512  
1839. Galaxy Y Pro Duos - GT-B5512B  
1840. Galaxy Y TV - GT-S5367  
1841. Galaxy Young - GT-S6312  
1842. Galaxy Young - GT-S6313T

1843. Galaxy Young - GT-S6310  
1844. Galaxy Young - GT-S6310B  
1845. Galaxy Young - GT-S6310L  
1846. Galaxy Young - GT-S6310T  
1847. Galaxy Young - GT-S6313T  
1848. Galaxy Young - GT-S6310N  
1849. Galaxy Young2 - SM-G130H  
1850. Galaxy Young2 - SM-G130M  
1851. Galaxy Young2 - SM-G130U  
1852. Galaxy Young2 - SM-G130BT  
1853. Galaxy Young2 - SM-G130E  
1854. Galaxy Young2 - SM-G130HN  
1855. Galaxy Young2 Pro - SM-G130BU  
1856. Galaxy player 70 Plus - YP-GB70D  
1857. Galaxy view - SM-T677NK  
1858. Galaxy view - SM-T677NL  
1859. Galaxy win - GT-I8550L  
1860. Galaxy-A9(2016) - SM-A9000  
1861. Garda - SGH-T399N  
1862. Garda - SGH-T399  
1863. Gear Live - Gear Live  
1864. Gem - SCH-I100  
1865. Grand Prime Plus - SM-G532F  
1866. Grand Prime Plus - SM-G532G  
1867. Grand Prime Plus - SM-G532MT  
1868. Hennessy - SCH-W789  
1869. Homesync - GT-B9150  
1870. Homesync - GT-B9150  
1871. IceTouch - YP-GH1  
1872. Illusion - SCH-I110  
1873. Infuse - SAMSUNG-SGH-I997  
1874. Infuse - SAMSUNG-SGH-I997R  
1875. J1 Mini Prime - SM-J106F  
1876. Moment - SPH-M900  
1877. Montblanc - SM-W2014  
1878. Nexus 10 - Nexus 10  
1879. Nexus S - Nexus S  
1880. Nexus S - Nexus S 4G  
1881. ProXpress M4580 - samsung-printer-tablet  
1882. Replenish - SPH-M580  
1883. Replenish - SPH-M580BST  
1884. Repp - SCH-R680  
1885. Roy VE DTV - GT-S6293T  
1886. Roy VE DTV - GT-S6293T  
1887. Rugby Smart - SAMSUNG-SGH-I847  
1888. SM G9298 - SM-G9298  
1889. SM-G9198 - SM-G9198  
1890. Sidekick - SGH-T839  
1891. Transfix - SCH-R730  
1892. Transform - SPH-M920  
1893. Transform Ultra - SPH-M930  
1894. Transform Ultra - SPH-M930BST  
1895. VinsQ - SPH-M910  
1896. VinsQ(M910) - SPH-M910  
1897. W2016 - SM-W2016  
1898. W2017 - SM-W2017  
1899. olleh - SMT-E5015

## Sansui

1. ETAB M9021G - ETAB\_M9021G
2. ETAB S7042G - ETAB\_S7042G
3. Fun - Sansui Fun

4. Go - Go
5. Sansui Play - Sansui Play
6. Switch - Sansui\_Switch
7. Tab 7" - ETAB\_I7043G
8. Tab 7" - ETAB\_I7043G
9. Tab 7" - ETAB\_I7043G\_VP3

## Sanyo

1. 55CE6139M1 - CEM1
2. Benesse - 31TL04
3. Benesse - 40TL04
4. Benesse - 41EA04
5. CEA1 - CEA1
6. CEA3 - CEA3
7. CEH1 - CEH1
8. CER2 - CER2
9. CER3 - CER3

## Schok

1. mini\_SM7216 - SM7216

## Seemahale Telecoms

1. ST5000 - ST5000

## Senseit

1. A109 - SENSEIT\_A109
2. L301 - SENSEIT\_L301
3. SENSEIT\_A247 - SENSEIT\_A247

## Senwa

1. Telcel\_LS50 - LS50
2. Telcel\_LS55 - LS55

## Sharp

1. SH7218T - SH7218T
2. SH8268U - SH8268U
3. SH8288U - SH8288U
4. SH8298U - SH8298U
5. msm7627\_surf - SH8118U
6. 306SH - 306SH
7. 401SH - 401SH
8. 507SH - 507SH
9. A01SH - A01SH
10. A1 - FS8002
11. ADS1 - SHARP-ADS1
12. AN-NP40 - AN-NP40
13. AQUOS CRYSTAL 2 - 403SH
14. AQUOS CRYSTAL X - 402SH
15. AQUOS Compact SH-02H - SH-02H
16. AQUOS EVER SH-02J - SH-02J
17. AQUOS EVER SH-04G - SH-04G
18. AQUOS K SHF31 - SHF31
19. AQUOS K SHF32 - SHF32
20. AQUOS K SHF33 - SHF33
21. AQUOS L SHV37 - SHV37\_u
22. AQUOS L2 - SH-L02
23. AQUOS M1 - FS8001
24. AQUOS P1 - P1X
25. AQUOS PAD SHT22 - SHT22



26. AQUOS PAD SH-05G - SH-05G  
27. AQUOS PAD SH-06F - SH-06F  
28. AQUOS PAD SH-08E - SH-08E  
29. AQUOS PAD SHT21 - SHT21  
30. AQUOS PHONE SERIE SHL22 - SHL22  
31. AQUOS PHONE SERIE SHL23 - SHL23  
32. AQUOS PHONE SERIE mini SHL24 - SHL24  
33. AQUOS PHONE CL IS17SH - IS17SH  
34. AQUOS PHONE EX SH-02F - SH-02F  
35. AQUOS PHONE EX SH-04E - SH-04E  
36. AQUOS PHONE IS11SH - IS11SH  
37. AQUOS PHONE IS12SH - IS12SH  
38. AQUOS PHONE IS13SH - IS13SH  
39. AQUOS PHONE IS14SH - IS14SH  
40. AQUOS PHONE SERIE ISW16SH - ISW16SH  
41. AQUOS PHONE SERIE SHL21 - SHL21  
42. AQUOS PHONE SH-01D - SH-01D  
43. AQUOS PHONE SH-06D - SH-06D  
44. AQUOS PHONE SH-12C - SH-12C  
45. AQUOS PHONE SH90B - SH90B  
46. AQUOS PHONE SL IS15SH - IS15SH  
47. AQUOS PHONE SoftBank 102SH II - SBM102SH2  
48. AQUOS PHONE SoftBank 006SH - SBM006SH  
49. AQUOS PHONE SoftBank 102SH - SBM102SH  
50. AQUOS PHONE SoftBank 103SH - SBM103SH  
51. AQUOS PHONE SoftBank 104SH - SBM104SH  
52. AQUOS PHONE THE HYBRID SoftBank 007SH - SBM007SH  
53. AQUOS PHONE THE HYBRID SoftBank 007SH J - SBM007SHJ  
54. AQUOS PHONE THE HYBRID SoftBank 101SH - SBM101SH  
55. AQUOS PHONE THE PREMIUM SoftBank 009SH - SBM009SH  
56. AQUOS PHONE WX05SH - WX05SH  
57. AQUOS PHONE Xx 206SH - SBM206SH  
58. AQUOS PHONE Xx 302SH - SBM302SH  
59. AQUOS PHONE Xx SoftBank 106SH - SBM106SH  
60. AQUOS PHONE Xx mini 303SH - SBM303SH  
61. AQUOS PHONE ZETA SH-01F - SH-01F  
62. AQUOS PHONE ZETA SH-02E - SH-02E  
63. AQUOS PHONE ZETA SH-06E - SH-06E  
64. AQUOS PHONE ZETA SH-09D - SH-09D  
65. AQUOS PHONE es WX04SH - WX04SH  
66. AQUOS PHONE f SH-13C - SH-13C  
67. AQUOS PHONE si SH-01E - SH-01E  
68. AQUOS PHONE si SH-07E - SH-07E  
69. AQUOS PHONE slider SH-02D - SH-02D  
70. AQUOS PHONE ss 205SH - SBM205SH  
71. AQUOS PHONE st SH-07D - SH-07D  
72. AQUOS PHONE sv SH-10D - SH-10D  
73. AQUOS R - 605SH  
74. AQUOS R SH-03J - SH-03J  
75. AQUOS R SHV39 - SHV39  
76. AQUOS SERIE SHL25 - SHL25  
77. AQUOS SERIE SHV32 - SHV32  
78. AQUOS SERIE SHV34 - SHV34  
79. AQUOS SERIE mini SHV31 - SHV31  
80. AQUOS SERIE mini SHV33 - SHV33  
81. AQUOS SERIE mini SHV38 - SHV38  
82. AQUOS SH-M01 - SH-M01  
83. AQUOS SH-M02 - SH-M02  
84. AQUOS SH-M02-EVA20 - SH-M02-EVA20  
85. AQUOS SH-RM02 - SH-RM02  
86. AQUOS U SHV35 - SHV35  
87. AQUOS U SHV37 - SHV37  
88. AQUOS Xx - 404SH  
89. AQUOS Xx 3 - 506SH  
90. AQUOS Xx 304SH - 304SH  
91. AQUOS Xx2 - 502SH  
92. AQUOS Xx2 mini - 503SH  
93. AQUOS Xx3 mini - 603SH  
94. AQUOS ZETA SH-01G - SH-01G  
95. AQUOS ZETA SH-01H - SH-01H  
96. AQUOS ZETA SH-03G - SH-03G  
97. AQUOS ZETA SH-04F - SH-04F  
98. AQUOS ZETA SH-04H - SH-04H  
99. AQUOS ea - 606SH  
100. AQUOS mini SH-M03 - SH-M03  
101. AQUOS sense - SHV40\_u  
102. AQUOS sense SH-01K - SH-01K  
103. AQUOS sense SHV40 - SHV40  
104. AQUOS SH-06G - SH-06G  
105. Android One S1 - S1  
106. BASIO2 SHV36 - SHV36  
107. C1 - FS8001  
108. DM009SH - DM009SH  
109. DM010SH - DM010SH  
110. DM011SH - DM011SH  
111. DM012SH - DM012SH  
112. DM013SH - DM013SH  
113. DM016SH - DM016SH  
114. Disney Mobile DM014SH - DM014SH  
115. Disney Mobile on docomo DM-01H - DM-01H  
116. Disney Mobile on docomo DM-01J - DM-01J  
117. Disney Mobile on docomo SH-02G - SH-02G  
118. Disney Mobile on docomo SH-05F - SH-05F  
119. EB-A71GJ - EB-A71GJ  
120. EB-WX1GJ/EB-W51GJ - EB-W51GJ  
121. EB-WX1GJ/EB-W51GJ - EB-WX1GJ  
122. FS8014 - FS8014  
123. GALAPAGOS SoftBank 003SH - SBM003SH  
124. GALAPAGOS SoftBank 005SH - SBM005SH  
125. HC-16TT1 - HCTT1  
126. INFOBAR A01 - INFOBAR A01  
127. INFOBAR C01 - INFOBAR C01  
128. IS01 - IS01  
129. IS03 - IS03  
130. IS05 - IS05  
131. LC-\*\*UH30U - LC-Ux30US  
132. LC-40SF466T - LC\_40FOC466T  
133. LC-42LE860H - LC-42LE860H  
134. LC-42LE860M - LC-42LE860M  
135. LC-45SF460T - LC\_45FOC460T  
136. LC-50LE570X - LC-xxLE570X  
137. LC-50LE860H - LC-50LE860H  
138. LC-50LE860M - LC-50LE860M  
139. LC-50UE1H - LC-50UE1H  
140. LC-50UE1M - LC-50UE1M  
141. LC-55LE860H - LC-55LE860H  
142. LC-55LE860M - LC-55LE860M  
143. LC-58UE1H - LC-58UE1H  
144. LC-58UE1M - LC-58UE1M  
145. LC-A11A - LC-A11A



146. LC-A1H - LC-A1H  
147. LC-LE580T - LC-LE580T  
148. LC-LE580X - LC-LE580X  
149. LC-LX565H - LC-LX565H  
150. LC-S3H-01 - LC-S3H-01  
151. LC-S4H/LC-S45H - LC-xxCAE5H  
152. LC-SU666T/LC-SU766T - LC-xxBEL6T  
153. LC-U35T - LC-U35T  
154. LC-UA6800X/LC-UA8000X - AQUOS-4KTVX17  
155. LC-US50/LC-UH50 - AQUOS-4KTVJ17  
156. LC-XU35T - LC-XU35T  
157. LC-XU930X\_830X - LC-XU930X\_830X  
158. LC-xxUE630X - LC-UE630X  
159. LCD-40SF465A - LCD\_40FOC465A  
160. LCD-40SF466A, LCD-40TX3000A, LCD-40MX3000A,  
LCD-40DS3000A, LCD-40X508A - LCD\_40FOC466A  
161. LCD-40SF468A - LCD\_40FOC468A  
162. LCD-45SF460A - LCD\_45FOC46A  
163. LCD-45SF470A - LCD\_xxSFFOC470A  
164. LCD-45SF475A - LCD\_xxSFFOC475A  
165. LCD-45T45A/LCD-45T46A/LCD-45T47A - LCD\_FOC36A  
166. LCD-45TX3000A - LCD\_45FOC3000A  
167. LCD-50MY4000A/TX4000A/50SU470A -  
LCD\_50FOC4000A  
168. LCD-60SU470A - LCD\_xxSUFOC470A  
169. LCD-60SU475A - LCD\_xxSUFOC475A  
170. LCD-LX460A - LCD-LX460A  
171. LCD-LX560A - LCD-LX560A  
172. LCD-LX565A - LCD-LX565A-B  
173. LCD-LX565A - LCD-LX565A  
174. LCD-S3A - LCD-S3A-01  
175. LCD-SU460A/LCD-SU465A - LCD-xxCAE5A-C  
176. LCD-SU560A - LCD-xxCAE5A  
177. LCD-SU870A - LCD-xxBEL8A-B  
178. LCD-TX5000A - LCD-xxCAE5A-D  
179. LCD-UF30A - LCD-UF30A  
180. LCD-V3A - LCD-V3A  
181. LCD-xxBEL6A - LCD-xxBEL6A  
182. LCD-xxBEL8A - LCD-xxBEL8A  
183. LCD-  
xxSU670A/xxMY6100A/xxSU675A/xxSU775A/xxSU87  
5A - LCD-xxDEM6A  
184. LCD-xxSX970A, LCD-xxMY9100A - LCD-xxDEM9A  
185. LCD-xxX818A, LCD-xxMY818A - LCD-xxDEM9A  
186. LC\_50FOC45H - LC\_50FOC45H  
187. LYNX 3D SH-03C - SH-03C  
188. LYNX SH-10B - SH-10B  
189. Media Tablet - EB-L76G-B  
190. PANTONE 5 SoftBank 107SH - SBM107SH  
191. PANTONE 6 SoftBank 200SH - SBM200SH  
192. Q-pot.Phone SH-04D - SH-04D  
193. RW107 - RW107  
194. RZ-E302 - RZ-E302  
195. SBM204SH - SBM204SH  
196. SC-S01 - SC-S01  
197. SH-01E Vivienne Westwood - SH-01EVW  
198. SH-01F DRAGON QUEST - SH-01FDQ  
199. SH-03F - SH-03F  
200. SH-03H - SH-03H  
201. SH-05E - SH-05E  
202. SH-06D NERV - SH-06DNERV  
203. SH-H01 - SH-H01

204. SH-M04 - SH-M04  
205. SH80F - SH80F  
206. SH8118U - SH8118U  
207. SH8128U - SH8128U  
208. SH8188U - SH8188U  
209. SH825wi - SH825Wi  
210. SHARP AQUOS S2 - FS8010  
211. SHARP AQUOS S2 Plus - FS8016  
212. SoftBank 007SH KT - SBM007SHK  
213. SoftBank 107SH B - SBM107SHB  
214. SoftBank 305SH - 305SH  
215. SoftBank AQUOS PHONE Xx 203SH - SBM203SH  
216. Star Wars mobile - SW001SH  
217. X1 - X1  
218. Yahoo! Phone SoftBank 009SH Y - SBM009SHY  
219. Z2 - FS8002  
220. Z3 - FS8009  
221. lcd\_xxbel7a\_c - LCD-xxBEL7A-C  
222. z3 - FS8009  
223. SG509SH - 509SH  
224. SR01MW - SR01MW  
225. SR02MW - SR02MW

### **SiAL**

1. Bic camera - Si01BB
2. Si01BE - Si01BE

### **Sico SmartPhone**

1. SSR1-5-8M - SSR1-5-8M
2. SSR1-5-8M - sico pro

### **Silent Circle**

1. Blackphone 2 - Blackphone 2

### **Simbans**

1. PicassoTab - PicassoTab

### **Siragon**

1. SP-5000 - Siragon SP-5000

### **Sirin**

1. LABS SOLARIN - SOLARIN
2. LABS SOLARIN - Solarin

### **Sky Devices**

1. SKY 5.0LM - SKY 5.0LM
2. SKY 5.0Pro II - SKY 5.0Pro II

### **SkyLife**

1. UHD2 - IC1110

### **Skyworth**

1. Asia - globe
2. South America - globe

### **Smartab**

1. SRF79 - SRF79
2. ST1009X - ST1009X

3. ST700 - ST700
4. ST7150 - ST7150
5. STJR700 - STJR700
6. STJR76 - STJR76

## Smartfren

1. A16C3H - Andromax A16C3H
2. A26C4H - Andromax A26C4H
3. AD688G - Smartfren Andromax AD688G
4. AD689G - Smartfren Andromax AD689G
5. Andromax AD682H - Smartfren Andromax AD682H
6. Andromax AD687G - Andromax AD687G
7. Andromax C46B2G - Andromax C46B2G
8. AndromaxNC36B1H - Smartfren Andromax NC36B1H
9. B16C2G - Andromax B16C2G
10. B16C2H - Andromax B16C2H
11. B26D2H - Andromax B26D2H
12. C2LEAD688G - Smartfren Andromax AD688G
13. EG680 - EG680
14. G36C1G - Andromax G36C1G
15. G36C1H - Andromax G36C1H
16. I46D1G - Andromax I46D1G
17. NC36B1G - Smartfren Andromax NC36B1G
18. NEWAD688G - Smartfren Andromax AD688G

## Smartron

1. Srtphone - T5524
2. tphone - T5511

## Sonimtech

1. Ex-Handy 09 - Ex-Handy 09
2. Smart-Ex 01 - Smart-Ex 01
3. XP6 - Ex-Handy 209
4. XP6 - XP6700
5. XP7 - Smart-Ex 201
6. XP7 - XP7700
7. XP7 - Smart-Ex 01
8. XP7700Z1 - Smart-Ex 01
9. XP7705 - XP7700

## Sony

1. C5503 - C5503
2. C6616 - C6616
3. SGP312 - SGP312
4. ST21i - ST21i
5. ST23i - ST23i
6. ST26i - ST26i
7. nbx02 - Sony Tablet P
8. BRAVIA 2015 - BRAVIA 2015
9. BRAVIA 4K 2015 - BRAVIA 2015
10. BRAVIA 4K 2015 - BRAVIA 4K 2015
11. BRAVIA 4K GB - BRAVIA 4K GB
12. BRAVIA Smart Stick - NSZ-GU1
13. Ericsson Live with Walkman - WT19a
14. Ericsson Live with Walkman - WT19i
15. Internet TV - Internet TV
16. Internet TV - Internet TV Box
17. NSZGS7 - NSZ-GS7/GX70
18. NW-F800 - WALKMAN
19. NW-F880 Series - WALKMAN

20. NW-Z1000 - NW-Z1000Series
21. NW-ZX1 - WALKMAN
22. NW-ZX2 - WALKMAN
23. NWZ-Z1000 - NWZ-Z1000Series
24. NWZ-ZX1 - WALKMAN
25. SmartWatch 3 - SmartWatch 3
26. Smartphone Z Ultra Google Play edition - C6806\_GPe
27. Tablet P - Sony Tablet P
28. Tablet S - Sony Tablet S
29. Xperia E1 dual - D2114
30. Xperia M - C1905
31. Xperia A - SO-04E
32. Xperia A2 - SO-04F
33. Xperia A4 - SO-04G
34. Xperia C - C2304
35. Xperia C - C2305
36. Xperia C3 - D2533
37. Xperia C3 Dual - D2502
38. Xperia C5 Ultra - E5506
39. Xperia C5 Ultra - E5553
40. Xperia C5 Ultra Dual - E5533
41. Xperia C5 Ultra Dual - E5563
42. Xperia E - C1504
43. Xperia E - C1505
44. Xperia E dual - C1604
45. Xperia E dual - C1605
46. Xperia E1 - D2004
47. Xperia E1 - D2005
48. Xperia E1 - D2114
49. Xperia E1 Dual - D2104
50. Xperia E1 Dual - D2105
51. Xperia E1 dual - D2104
52. Xperia E1 dual - D2105
53. Xperia E3 - D2202
54. Xperia E3 - D2203
55. Xperia E3 - D2206
56. Xperia E3 - D2243
57. Xperia E3 Dual - D2212
58. Xperia E4g - E2053
59. Xperia E4g Dual - E2033
60. Xperia E4g Dual - E2043
61. Xperia E5 - F3311
62. Xperia E5 - F3313
63. Xperia Go - ST27a
64. Xperia Go - ST27i
65. Xperia J - ST26a
66. Xperia J - ST26i
67. Xperia J1 Compact - D5788
68. Xperia L - C2104
69. Xperia L - C2105
70. Xperia L1 - G3311
71. Xperia L1 - G3312
72. Xperia L1 - G3313
73. Xperia M - C1904
74. Xperia M - C1905
75. Xperia M Dual - C2005
76. Xperia M dual - C2004
77. Xperia M dual - C2005
78. Xperia M2 - D2303
79. Xperia M2 - D2305
80. Xperia M2 - D2306
81. Xperia M2 Aqua - D2403

82. Xperia M2 Aqua - D2406
83. Xperia M2 Dual - D2302
84. Xperia M2 dual - D2302
85. Xperia M5 - E5603
86. Xperia M5 - E5606
87. Xperia M5 - E5653
88. Xperia M5 Dual - E5633
89. Xperia M5 Dual - E5643
90. Xperia M5 Dual - E5663
91. Xperia Miro - ST23i
92. Xperia P - LT22i
93. Xperia PLAY - R800a
94. Xperia PLAY - R800i
95. Xperia R1 - G2199
96. Xperia R1 Plus - G2299
97. Xperia S - LT26i
98. Xperia SL - LT26ii
99. Xperia SP - C5302
100. Xperia SP - C5303
101. Xperia SP - C5306
102. Xperia SP - M35h
103. Xperia SP - M35t
104. Xperia T - LT30a
105. Xperia T - LT30p
106. Xperia T2 Ultra - D5303
107. Xperia T2 Ultra - D5306
108. Xperia T2 Ultra - D5316
109. Xperia T2 Ultra - D5316N
110. Xperia T2 Ultra - D5322
111. Xperia T2 Ultra dual - D5322
112. Xperia T3 - D5102
113. Xperia T3 - D5103
114. Xperia T3 - D5106
115. Xperia TX - LT29i
116. Xperia Tablet S - SGPT12
117. Xperia Tablet S - SGPT13
118. Xperia Tablet Z - SGP311
119. Xperia Tablet Z - SGP312
120. Xperia Tablet Z - SGP321
121. Xperia Tablet Z - SGP351
122. Xperia Tipo - ST21i
123. Xperia Tipo - ST21i2
124. Xperia Touch - G1109
125. Xperia U - ST25a
126. Xperia U - ST25i
127. Xperia V - LT25i
128. Xperia X - F5121
129. Xperia X - F5122
130. Xperia X - F5121
131. Xperia X Compact - F5321
132. Xperia X Compact - SO-02J
133. Xperia X Performance - 502SO
134. Xperia X Performance - F8131
135. Xperia X Performance - F8132
136. Xperia X Performance - SO-04H
137. Xperia X Performance - SOV33
138. Xperia XA - F3111
139. Xperia XA - F3112
140. Xperia XA - F3113
141. Xperia XA - F3115
142. Xperia XA - F3116
143. Xperia XA Ultra - F3211
144. Xperia XA Ultra - F3212
145. Xperia XA Ultra - F3213
146. Xperia XA Ultra - F3215
147. Xperia XA Ultra - F3216
148. Xperia XA1 - G3112
149. Xperia XA1 - G3116
150. Xperia XA1 - G3121
151. Xperia XA1 - G3123
152. Xperia XA1 - G3125
153. Xperia XA1 Plus - G3412
154. Xperia XA1 Plus - G3416
155. Xperia XA1 Plus - G3421
156. Xperia XA1 Plus - G3423
157. Xperia XA1 Plus - G3426
158. Xperia XA1 Ultra - G3212
159. Xperia XA1 Ultra - G3221
160. Xperia XA1 Ultra - G3223
161. Xperia XA1 Ultra - G3226
162. Xperia XZ - 601SO
163. Xperia XZ - F8331
164. Xperia XZ - F8332
165. Xperia XZ - SO-01J
166. Xperia XZ - SOV34
167. Xperia XZ Premium - G8141
168. Xperia XZ Premium - G8142
169. Xperia XZ Premium - SO-04J
170. Xperia XZ1 - G8341
171. Xperia XZ1 - G8342
172. Xperia XZ1 - G8343
173. Xperia XZ1 - SO-01K
174. Xperia XZ1 Compact - G8441
175. Xperia XZ1 Compact - SO-02K
176. Xperia XZs - 602SO
177. Xperia XZs - G8231
178. Xperia XZs - G8232
179. Xperia XZs - SO-03J
180. Xperia XZs - SOV35
181. Xperia Z - C6602
182. Xperia Z - C6603
183. Xperia Z - C6606
184. Xperia Z - C6616
185. Xperia Z - L36h
186. Xperia Z - SO-02E
187. Xperia Z Ultra - C6802
188. Xperia Z Ultra - C6806
189. Xperia Z Ultra - C6833
190. Xperia Z Ultra - C6843
191. Xperia Z Ultra - SGP412
192. Xperia Z Ultra - SOL24
193. Xperia Z Ultra - XL39h
194. Xperia Z1 - C6902
195. Xperia Z1 - C6903
196. Xperia Z1 - C6906
197. Xperia Z1 - C6916
198. Xperia Z1 - C6943
199. Xperia Z1 - L39h
200. Xperia Z1 - L39t
201. Xperia Z1 - L39u
202. Xperia Z1 - SO-01F
203. Xperia Z1 - SOL23
204. Xperia Z1 Compact - D5503
205. Xperia Z1 Compact - M51w



206. Xperia Z1f - SO-02F  
207. Xperia Z2 - D6502  
208. Xperia Z2 - D6503  
209. Xperia Z2 - D6543  
210. Xperia Z2 - SO-03F  
211. Xperia Z2 Tablet - SGP511  
212. Xperia Z2 Tablet - SGP512  
213. Xperia Z2 Tablet - SGP521  
214. Xperia Z2 Tablet - SGP551  
215. Xperia Z2 Tablet - SGP561  
216. Xperia Z2 Tablet - SO-05F  
217. Xperia Z2 Tablet - SOT21  
218. Xperia Z2a - D6563  
219. Xperia Z3 - 401SO  
220. Xperia Z3 - D6603  
221. Xperia Z3 - D6616  
222. Xperia Z3 - D6643  
223. Xperia Z3 - D6646  
224. Xperia Z3 - D6653  
225. Xperia Z3 - SO-01G  
226. Xperia Z3 - SOL26  
227. Xperia Z3 - D6603  
228. Xperia Z3 Compact - D5803  
229. Xperia Z3 Compact - D5833  
230. Xperia Z3 Compact - SO-02G  
231. Xperia Z3 Compact - D5803  
232. Xperia Z3 Dual - D6633  
233. Xperia Z3 Dual - D6683  
234. Xperia Z3 Tablet Compact - SGP611  
235. Xperia Z3 Tablet Compact - SGP612  
236. Xperia Z3 Tablet Compact - SGP621  
237. Xperia Z3 Tablet Compact - SGP641  
238. Xperia Z3+ - E6553  
239. Xperia Z3+ Dual - E6533  
240. Xperia Z3v - D6708  
241. Xperia Z4 - 402SO  
242. Xperia Z4 - SO-03G  
243. Xperia Z4 - SOV31  
244. Xperia Z4 Tablet - SGP712  
245. Xperia Z4 Tablet - SGP771  
246. Xperia Z4 Tablet - SO-05G  
247. Xperia Z4 Tablet - SOT31  
248. Xperia Z4v - E6508  
249. Xperia Z5 - 501SO  
250. Xperia Z5 - E6603  
251. Xperia Z5 - E6653  
252. Xperia Z5 - SO-01H  
253. Xperia Z5 - SOV32  
254. Xperia Z5 Compact - E5803  
255. Xperia Z5 Compact - E5823  
256. Xperia Z5 Compact - SO-02H  
257. Xperia Z5 Premium - E6853  
258. Xperia Z5 Premium - E6883  
259. Xperia Z5 Premium - SO-03H  
260. Xperia Z5 Premium Dual - E6833  
261. Xperia Z5 dual - E6633  
262. Xperia Z5 dual - E6683  
263. Xperia ZL - C6502  
264. Xperia ZL - C6503  
265. Xperia ZL - C6506  
266. Xperia ZL - L35h  
267. Xperia ZL2 - SOL25

268. Xperia ZR - C5306  
269. Xperia ZR - C5502  
270. Xperia ZR - C5503  
271. Xperia acro HD - SO-03D  
272. Xperia acro S - LT26w  
273. Xperia active - ST17i  
274. Xperia arc S - LT18i  
275. Xperia go - ST27i  
276. Xperia ion - LT28h  
277. Xperia ion - LT28i  
278. Xperia mini pro - SK17a  
279. Xperia miro - ST23a  
280. Xperia miro - ST23i  
281. Xperia neo L - MT25i  
282. Xperia pro - MK16i  
283. Xperia ray - ST18i  
284. Xperia sola - MT27i  
285. Xperia tipo - ST21a  
286. Xperia tipo dual - ST21a2  
287. Xperia C4 - E5303  
288. Xperia C4 - E5306  
289. Xperia C4 - E5353  
290. Xperia C4 Dual - E5333  
291. Xperia C4 Dual - E5343  
292. Xperia C4 Dual - E5363  
293. Xperia E4 - E2104  
294. Xperia E4 - E2105  
295. Xperia E4 Dual - E2115  
296. Xperia E4 Dual - E2124  
297. Xperia E4g - E2003  
298. Xperia E4g - E2006  
299. Xperia M4 Aqua - E2303  
300. Xperia M4 Aqua - E2306  
301. Xperia M4 Aqua - E2353  
302. Xperia M4 Aqua Dual - E2312  
303. Xperia M4 Aqua Dual - E2333  
304. Xperia M4 Aqua Dual - E2363

## Sony Ericsson

1. LT15a - LT15a
2. LT18i - LT18i
3. LT22i - LT22i
4. LT26i - LT26i
5. LT28h - LT28h
6. LT28i - LT28i
7. MK16a - MK16a
8. MK16i - MK16i
9. MT11i - MT11i
10. MT15i - MT15i
11. MT27i - MT27i
12. R800x - R800x
13. SK17i - SK17i
14. ST15i - ST15i
15. ST17i - ST17i
16. ST18i - ST18i
17. WT18i - WT18i
18. WT19a - WT19a
19. WT19i - WT19i
20. Live with Walkman - WT19a
21. Live with Walkman - WT19i
22. Live with Walkman(TM) - WT19a
23. X10 Xperia Mini - E10i



24. Xperia AX - SO-01E
25. Xperia Acro - IS11S
26. Xperia Acro - SO-02C
27. Xperia Arc - LT15i
28. Xperia Arc - SO-01C
29. Xperia C - S39h
30. Xperia GX - SO-04D
31. Xperia Go - ST27a
32. Xperia Go - ST27i
33. Xperia J - ST26i
34. Xperia Neo - MT15i
35. Xperia P - LT22i
36. Xperia PLAY - R800a
37. Xperia PLAY - R800at
38. Xperia PLAY - R800i
39. Xperia PLAY - R800x
40. Xperia PLAY - SO-01D
41. Xperia Play - R800i
42. Xperia Play - Zeus
43. Xperia S - LT26i
44. Xperia S - SO-02D
45. Xperia SL - LT26ii
46. Xperia SP - M35c
47. Xperia SX - SO-05D
48. Xperia T - LT30a
49. Xperia T - LT30at
50. Xperia T - LT30p
51. Xperia TX - LT29i
52. Xperia Tablet Z - SGP311
53. Xperia Tablet Z - SGP321
54. Xperia Tablet Z - SGP341
55. Xperia Tablet Z - SO-03E
56. Xperia U - ST25i
57. Xperia UL - SOL22
58. Xperia V - LT25c
59. Xperia V - LT25i
60. Xperia VL - SOL21
61. Xperia X10 - SO-01B
62. Xperia X10 - SO-01B
63. Xperia X10 - X10i
64. Xperia X10 - X10a
65. Xperia X10 - X10i
66. Xperia X10 Mini - E10i
67. Xperia X10 Mini - E10i
68. Xperia X10 Mini Pro - U20i
69. Xperia X10 mini - E10a
70. Xperia X10 mini pro - U20a
71. Xperia X8 - E15i
72. Xperia Z - SO-02E
73. Xperia Z Ultra - C6806
74. Xperia Z1 - C6903
75. Xperia Z1 - C6906
76. Xperia Z1 - C6943
77. Xperia acro HD - IS12S
78. Xperia acro S - LT26w
79. Xperia active - ST17i
80. Xperia arc - LT15a
81. Xperia arc - LT15i
82. Xperia arc S - LT18a
83. Xperia arc S - LT18i
84. Xperia go - ST27i
85. Xperia ion - LT28at

86. Xperia ion - LT28h
87. Xperia ion - LT28i
88. Xperia live - WT19a
89. Xperia mini - S51SE
90. Xperia mini - ST15a
91. Xperia mini - ST15i
92. Xperia mini pro - SK17a
93. Xperia mini pro - SK17i
94. Xperia miro - ST23i
95. Xperia neo - MT15a
96. Xperia neo - MT15i
97. Xperia neo L - MT25i
98. Xperia neo V - MT11a
99. Xperia neo V - MT11i
100. Xperia pro - MK16a
101. Xperia pro - MK16i
102. Xperia ray - SO-03C
103. Xperia ray - ST18a
104. Xperia ray - ST18i
105. Xperia sola - MT27i
106. Xperia tipo - ST21i
107. Xperia tipo dual - ST21i2

### **Sophix\_Digix**

1. TAB-750\_G - TAB-750\_G

### **Sourcing Creation**

1. Connect 451 - Connect 451
2. Connect 504 - Connect504
3. Connect502 - Connect502
4. Connect502 - Connect502
5. Connect551 - Connect551
6. Key\TAB 1001 - Smarttab\_9701
7. ST1003S - Smart\_TAB\_1003s
8. Smart TAB 1005 - SmartTab1005
9. Smart Tab 1004XS - SmartTab\_1004\_XS
10. Smart\ Tab 1006 - SmartTab1006
11. SmartTab\_8004 - SmartTab\_8004
12. Web\Pad\_1002\_02 - Webpad\_1002\_02
13. Wooze I 5 - Wooze\_I5
14. Wooze I 5.5 Gris - Wooze\_I55
15. Wooze L - Wooze\_L
16. Wooze XL - Wooze\_XL
17. Woozel45 - Woozel45
18. sp401 - sp401
19. webpad\_7005 - Webpad\_7005

### **Southern Telecom**

1. A1000/P1003/P1010 - A1000/P1003/P1010
2. A400 - A400
3. A5 - A5
4. A500 - a500
5. A600 - A600
6. Emerson EM756 - EM756
7. M10 - M10
8. M10 - M10/Q1010
9. M11H/Q1100 - M11H/Q1100
10. Nook Tablet 7 - BNTV450
11. P709/P716 - P709/P716
12. P7100 - P7100
13. P909 - P909

14. PDT9000 - PDT9000
15. Polaroid L10/P1000 - L10
16. Polaroid M11 - M11
17. Polaroid P700/A700 - P700/A700
18. Polaroid P902/A900 - P902/A900
19. Polaroid Power P600 - P600
20. Polaroid Snap S50 - S50
21. Polaroid Snap S55 - S55
22. Polaroid Snap S60 - S60
23. ST1009 - ST1009
24. ST13 - ST13
25. ST706 - ST706
26. Smartab ST10 - ST10/ST10x
27. Smartab ST7 - ST7/ST7x
28. Streamachine - X13
29. a4 - a4

### **SpectraPrecision**

1. Ranger 5 Handheld - Ranger5
2. Ranger 8 Handheld - Ranger8
3. Ranger 8 Handheld - Ranger8
4. Spectra Ranger 5 - Ranger5

### **Spectralink**

1. 8744 - 8744
2. PIVOT 8741/8753 - 8741
3. PIVOT 8741/8753 - 8742
4. PIVOT 8741/8753 - 8753

### **Spice**

1. Dream Uno - Spice Mi-498
2. Dream Uno - Spice Mi-498H
3. F301 - Spice F301
4. K601 - Spice K601
5. Smart Flo Mi-449 - SpiceMi-449
6. Smart Flo Mi-449 - SpiceMi-449
7. Spice F302 - Spice F302
8. Spice V801 - Spice V801
9. Stellar Mi-438 - MI-438
10. Stellar Mi-506 - Spice Mi-506
11. Victor5 - Xlife-Victor5
12. Xlife-441Q - Xlife-415
13. Xlife-441Q - Xlife-441Q
14. Xlife-450Q - Xlife-450Q
15. Xlife-514Q - Xlife-514Q
16. Xlife-M44Q - Xlife-M44Q
17. Xlife-Proton 5 pro - Xlife-Proton5 Pro

### **Sprint**

1. AQT100 - AQT100
2. AQT82 - AQT82
3. HTC Bolt - 2PYB2
4. Slate 8 Tablet - AQT80

### **StarMobile**

1. UP Prime - UP Prime

### **Starlight**

1. I STAR PLUS - I\_STAR\_PLUS

### **Storex**

1. eZee\Tab7Q11-M - Tab7Q11
2. eZeeTab10D12-S - eZeeTab10D12-S
3. eZeeTab7D15-M - eZeeTab7D15-M
4. eZeeTab7D14-S - NID\_7010

### **Stream**

1. B1 - B1
2. B2s - B2s
3. FIXION - FIXION
4. Iron Pro - IRON Pro
5. PERLA - PERLA

### **Sts-tottori**

1. JR-500 - JR-500
2. JR-P2000 - JR-P2000
3. TAB-A03 - TAB-A03-SD

### **Stylo**

1. S551 - STYLO S551
2. STYLOF1 - STYLO F1
3. STYLO\_S61 - STYLO SM61 MAGIC+
4. STYLO\_S61 - STYLO SV61 VECTOR+
5. VS5502 - VS5502

### **Stylus**

1. AT703 - AT703
2. FUNDA - ETAB I1041G
3. FUNDA - ETAB\_I7041G
4. IFS100 - IFS100

### **Sugar**

1. Sugar - SUGAR

### **Sumitomo Electric Industries**

1. ST4173 - ST4173

### **Sumitomo Electric Networks**

1. dhe1100 - Hikari-iFrame/WDPF-703SE

### **Swisstone**

1. swisstone SD 510 - swisstone SD 510

### **Symphony**

1. H300 - H300
2. H400 - H400
3. H58 - H58
4. P6 PRO - P6 PRO
5. P7 - P7
6. P7 Pro - Symphony P7 PRO
7. P8 PRO - P8 PRO
8. P9 - P9
9. R100 - Symphony R100
10. R20 - R20
11. R30 - R30
12. Roar A50 - Roar\_A50
13. SYMTAB25 - SYMTAB25

14. SYMTAB60 - SYMTAB60
15. Symphony\_Z9 - Symphony Z9
16. V100 - V100
17. V110 - V110
18. V120 - V120
19. V34 - V34
20. V47 - V47
21. V65 - V65
22. V75 - V75
23. V85 - V85
24. Z10 - SYMPHONY Z10
25. ZVII - ZVII
26. ZVIII - ZVIII
27. i10 - i10
28. i10 plus - i10 plus
29. i20 - i20
30. i25 - i25
31. i50 - i50
32. i60 - i60

### **T-Mobile**

1. Telekom\_Puls - Telekom Puls

### **TA71CA5\_JP**

1. JP SA COUTO, S.A. \_MG070A2T - TA71CA5

### **TAG Heuer**

1. Connected - TAG Heuer
2. Connected Modular 41 - TAG Heuer
3. Connected Modular 45 - TAG Heuer
4. Connected Modular 45 (China) - TAG Heuer

### **TCL**

1. L55E6700UDS - movo\_la
2. LE50UHDE5692G - movo
3. Percee TV - Percee TV
4. South America - Percee TV

### **TCT (Alcatel)**

1. A556C - A556C
2. A919\_gsm - TCL A919
3. ASB-D\_T918 - ASB-D T918
4. B-GriffinPlus\_TD - ASB-D T918
5. BASE\_Varia\_gsm - BASE\_Varia
6. E928\_TD - TCL E928
7. Griffin\_TD - TCL E928
8. MOVE\_gsm - MOVE
9. MTC-962\_gsm - MTC-962
10. Martini - one touch 906
11. MegaFon\_SP-A10 - MegaFon\_SP-A10
12. ONE\_TOUCH\_928D\_gsm - ALCATEL ONE TOUCH 928D
13. ONE\_TOUCH\_983A\_gsm - ALCATEL\_one\_touch\_983A
14. ONE\_TOUCH\_983M\_gsm - ONE TOUCH 983M
15. OP070 - OP070
16. OT-906 - ALCATEL\_one\_touch\_906
17. OT-906 - ALCATEL\_one\_touch\_906Y
18. OT-913D - ALCATEL\_one\_touch\_913D
19. OT-976 - ALCATEL\_one\_touch\_976
20. OT-978 - ALCATEL\_one\_touch\_978
21. OT-979 - ALCATEL\_one\_touch\_979
22. OT-979 - ALCATEL\_one\_touch\_979\_HelloKitty
23. OT-980A\_gsm - Alcatel OT-980A
24. OT-980\_gsm - Alcatel OT-980
25. OT-980\_gsm - Alcatel OT-980A
26. OT-980\_gsm - Alcatel OT-981A
27. OT-981A\_gsm - Alcatel OT-981A
28. OT-981\_gsm - Alcatel OT-981A
29. OT\_918\_gsm - ALCATEL OT 918
30. OT\_919\_HelloKitty\_gsm - ALCATEL OT 919 HelloKitty
31. OT\_919\_gsm - ALCATEL OT 919
32. OT\_990M\_gsm - ALCATEL\_OT\_990M
33. RASPG3201\_umts - RASPG3201
34. RPSPG3201\_umts - RPSPG3201
35. SmartIII4 - Vodafone 975N
36. T20 - one touch T20
37. T60 - onetouch T60
38. TCL-A909\_A909\_gsm - TCL A909
39. TCL-S806 - TCL-S806
40. TCL\_890D\_gsm - TCL A890 2SIM
41. TCL\_A510 - TCL A510
42. TCL\_A510 - TCL\_A510
43. TCL\_A919\_umts - TCL A919
44. TCL\_A919\_umts - TCL\_W969
45. TCL\_A966\_gsm - TCL A966
46. TCL\_A968 - TCL A968
47. TCL\_A980\_gsm - TCL A980
48. TCL\_A986\_gsm - TCL A986
49. TCL\_A988\_gsm - TCL\_A988
50. TCL\_A998\_gsm - TCL A998
51. TCL\_C990\_Plus\_cdma - TCL C990+
52. TCL\_D515\_cdma - TCL D515
53. TCL\_D662\_cdma - TCL D662
54. TCL\_S800\_GSM - TCL S800
55. TCL\_W939\_gsm - TCL\_W939
56. TCL\_W969\_gsm - TCL W969
57. Vancouver\_gsm - Vancouver\_Orange
58. mercury - I-L1
59. move\_2\_gsm - move 2
60. msm7627\_ffa - Alcatel OT-980
61. msm7627\_ffa - Alcatel OT-980A
62. one\_touch\_890D\_gsm - ALCATEL one touch 890D
63. one\_touch\_890\_gsm - ALCATEL\_one\_touch\_890
64. one\_touch\_890\_gsm - Vip\_MiniDroid
65. one\_touch\_891\_gsm - ALCATEL\_one\_touch\_891
66. one\_touch\_908A\_gsm - ALCATEL\_one\_touch\_908A
67. one\_touch\_908F\_gsm - ALCATEL\_one\_touch\_908F
68. one\_touch\_908F\_gsm - ALCATEL\_one\_touch\_908F\_Orange
69. one\_touch\_908F\_gsm - Alcatel\_one\_touch\_908F
70. one\_touch\_908F\_gsm - Alcatel\_one\_touch\_908F\_Orange
71. one\_touch\_908M\_gsm - ALCATEL\_one\_touch\_908M
72. one\_touch\_908S\_gsm - ALCATEL\_one\_touch\_908S
73. one\_touch\_908\_gsm - ALCATEL ONE TOUCH 908
74. one\_touch\_909A\_gsm - ALCATEL\_one\_touch\_909A
75. one\_touch\_909B\_cdma - ALCATEL\_one\_touch\_909B
76. one\_touch\_909B\_cdma - USCC\_ALCATEL\_one\_touch\_909B
77. one\_touch\_909S\_gsm - ALCATEL\_one\_touch\_909S
78. one\_touch\_910A\_gsm - ALCATEL\_one\_touch\_910A
79. one\_touch\_910\_gsm - ALCATEL\_one\_touch\_910
80. one\_touch\_916A\_gsm - ALCATEL ONE TOUCH 916A

|  |                            |
|--|----------------------------|
| 81. one_touch_916D_gsm - ALCATEL ONE TOUCH 916D        | 142. 5054W - 5054W         |
| 82. one_touch_916_gsm - ALCATEL ONE TOUCH 916          | 143. 5054X - 5054X         |
| 83. one_touch_918M_gsm - ALCATEL_ONE_TOUCH_918M        | 144. 5056 - 5056           |
| 84. one_touch_918M_umts - ALCATEL_one_touch_918M       | 145. 5056A - 5056A         |
| 85. one_touch_918N_umts - ALCATEL_one_touch_918N       | 146. 5056D - 5056D         |
| 86. one_touch_918_gsm - ALCATEL ONE TOUCH 918          | 147. 5056E - 5056E         |
| 87. one_touch_985_gsm - ALCATEL ONE TOUCH 985          | 148. 5056E - 5056M         |
| 88. one_touch_985_gsm - Telenor Smart                  | 149. 5056G - 5056G         |
| 89. one_touch_988_cdma - ALCATEL_one_touch_988         | 150. 5056I - 5056I         |
| 90. one_touch_988_cdma -<br>USCC_ALCATEL_one_touch_988 | 151. 5056N - 5056N         |
| 91. one_touch_990A_gsm - ALCATEL ONE TOUCH 990A        | 152. 5056T - 5056T         |
| 92. one_touch_990A_gsm - ALCATEL_one_touch_990A        | 153. 5056U - 5056U         |
| 93. one_touch_990C_cdma - ALCATEL one touch 990C       | 154. 5056W - 5056W         |
| 94. one_touch_990_gsm - ALCATEL ONE TOUCH 990          | 155. 5056X - 5056X         |
| 95. one_touch_990_gsm - Alcatel one touch 990 Orange   | 156. 5065A - 5065A         |
| 96. one_touch_990_gsm - Telenor OneTouch               | 157. 5065D - 5065D         |
| 97. one_touch_991S_gsm - ALCATEL ONE TOUCH 991S        | 158. 5065N - 5065N         |
| 98. one_touch_993D_gsm - ALCATEL ONE TOUCH 993D        | 159. 5065W - 5065W         |
| 99. one_touch_995A_gsm - ALCATEL_one_touch_995A        | 160. 5065X - 5065X         |
| 100. one_touch_995C_cdma - one touch 995C+             | 161. 5070D - 5070D         |
| 101. one_touch_996_gsm - Orange_infinity_996           | 162. 5080A - 5080A         |
| 102. \t ALCATEL ONETOUCH PIXI 3 (3.5) - SoshPhone_mini | 163. 5080F - 5080F         |
| 103. \t ALCATEL ONETOUCH PIXI 3 (4.5) - 5017X          | 164. 5080Q - 5080Q         |
| 104. 4013M - 4013M                                     | 165. 5080U - 5080U         |
| 105. 4014A - 4014A                                     | 166. 5080U - ALCATEL_5080U |
| 106. 4014M - 4014M                                     | 167. 5085G - 5085G         |
| 107. 4024X - 4024X                                     | 168. 5085O - 5085O         |
| 108. 4047D - 4047D                                     | 169. 5098O - 5098O         |
| 109. 4047G - 4047G                                     | 170. 5098O - Alcatel_5098O |
| 110. 4047N - 4047N                                     | 171. 5098O - alcatel_5098O |
| 111. 4047X - 4047X                                     | 172. 5098S - 5098S         |
| 112. 4055A - 4055A                                     | 173. 5154A - 5154A         |
| 113. 4055I - 4055I                                     | 174. 6010A - 6016A         |
| 114. 4055J - 4055J                                     | 175. 6014X - 6014X         |
| 115. 4055Q - 4055Q                                     | 176. 6016D - 6016D         |
| 116. 4055T - 4055T                                     | 177. 6016E - 6016E         |
| 117. 4055U - 4055U                                     | 178. 6016X - 6016X         |
| 118. 4060W - 4060W                                     | 179. 6037B - 6037B         |
| 119. 4114E - 4114E                                     | 180. 6037K - 6037K         |
| 120. 5011A - 5011A                                     | 181. 6037Y - 6037Y         |
| 121. 5017B - 5017B                                     | 182. 6039A - 6039A         |
| 122. 5023E - 5023E                                     | 183. 6039H - 6039H         |
| 123. 5023F - 5023F                                     | 184. 6039J - 6039J         |
| 124. 5027B - 5027B                                     | 185. 6039K - 6039K         |
| 125. 5038D - 5038D                                     | 186. 6039S - 6039S         |
| 126. 5042T - 5042T                                     | 187. 6039Y - 6039Y         |
| 127. 5046S - 5046S                                     | 188. 6042D - 6042D         |
| 128. 5049S - 5049S                                     | 189. 6043A - 6043A         |
| 129. 5049W - 5049W                                     | 190. 6043D - 6043D         |
| 130. 5049Z - 5049Z                                     | 191. 6044D - 6044D         |
| 131. 5051 - 5051                                       | 192. 6055A - 6055A         |
| 132. 5051A - 5051A                                     | 193. 6055B - 6055B         |
| 133. 5051D - 5051D                                     | 194. 6055D - 6055D         |
| 134. 5051J - 5051J                                     | 195. 6055K - 6055K         |
| 135. 5051M - 5051M                                     | 196. 6055P - 6055P         |
| 136. 5051T - 5051T                                     | 197. 6060X - 6060X         |
| 137. 5051X - 5051X                                     | 198. 7040N - 7040N         |
| 138. 5054A - 5054A                                     | 199. 7040R - 7040R         |
| 139. 5054D - 5054D                                     | 200. 7040T - 7040T         |
| 140. 5054S - 5054S                                     | 201. 7045Y - 7045Y         |
| 141. 5054T - 5054T                                     | 202. 730U - J730U          |
|  | 203. 8030B - 8030B         |



204. 8030B - 8030B  
205. 8030Y - 8030Y  
206. 8050D - 8050D  
207. 8050E - 8050E  
208. 8050E - T600M  
209. 8050G - 8050G  
210. 8050X - 8050X  
211. 8053 - 8053  
212. 8054 - 8054  
213. 8055 - 8055  
214. 8056 - 8056  
215. 8057 - 8057  
216. 8057 - KR076  
217. 8062 - 8062  
218. 8063 - 8063  
219. 8070 - 8070  
220. 8079 - 8079  
221. 8080 - 8080  
222. 8262 - 8262  
223. 9001D - 9001D  
224. 9001I - 9001I  
225. 9001X - 9001X  
226. 9002A - 9002A  
227. 9002A - ALCATEL ONE TOUCH 9002A  
228. 9002W - 9002W  
229. 9002X - 9002X  
230. 9003A - 9003A  
231. 9003X - 9003X  
232. 9005X - 9005X  
233. 9006W - 9006W  
234. 9007X - 9007X  
235. 9010X - 9010X  
236. 9015B - 9015B  
237. 9015B - ALCATEL ONETOUCH POP 7 LTE  
238. 9015B - 9015B  
239. 9015B - 9015B  
240. 9015B - 9015B  
241. 9015J - 9015J  
242. 9015Q - 9015Q  
243. 9015U - 9015U  
244. 9015W - 9015W  
245. 9015W - ALCATEL ONETOUCH POP 7 LTE  
246. 9021A - 9021A  
247. 9024O - 9024O  
248. 9024W - 9024W  
249. 9025Q - 9025Q  
250. 9030G - 9030G  
251. 9030Q - 9030Q  
252. 9203A - 9203A  
253. A3 - 5046A  
254. A3 - 5046D  
255. A3 - 5046I  
256. A3 - 5046J  
257. A3 - 5046T  
258. A3 - 5046U  
259. A3 - 5046Y  
260. A3 10\'' - 9026T  
261. A3 10\'' - 9026X  
262. A3 PLUS - 5049E  
263. A3 PLUS - 5049G  
264. A3 XL - 9008A  
265. A3 XL - 9008D  
266. A3 XL - 9008I  
267. A3 XL - 9008J  
268. A3 XL - 9008N  
269. A3 XL - 9008T  
270. A3 XL - 9008U  
271. A3 XL - 9008X  
272. A3 XL - 9108A  
273. A3 XL - TCLGalaG60(9108A)  
274. A30 - 5046G  
275. A30 - A576RW  
276. A450TL - A450TL  
277. A460T - A460T  
278. A464BG - A464BG  
279. A466BG - A466BG  
280. A5 - 5085A  
281. A5 - 5085B  
282. A5 - 5085D  
283. A5 - 5085H  
284. A5 - 5085I  
285. A5 - 5085J  
286. A5 - 5085N  
287. A5 - 5085Q  
288. A5 - 5085Y  
289. A520L - A520L  
290. A521L - A521L  
291. A570BL - A570BL  
292. A571VL - A571VL  
293. A572BG - A572BG  
294. A573VC - A573VC  
295. A577VL - A577VL  
296. A621BL - A621BL  
297. A621R - A621R  
298. A622GL - A622GL  
299. A622VL - A622VL  
300. A7 - 5090A  
301. A7 - 5090I  
302. A7 - 5090Y  
303. A7 XL - 7071A  
304. A7 XL - 7071D  
305. A846L - A846L  
306. A851L - Alcatel 7030L  
307. A851L - Alcatel A851L  
308. ALCATEL 4015T - ALCATEL 4015T  
309. ALCATEL A564C - ALCATEL A564C  
310. ALCATEL A564R - ALCATEL A564R  
311. ALCATEL ONE TOUCH 4005D - ALCATEL ONE TOUCH 4005D  
312. ALCATEL ONE TOUCH 4005D - ALCATEL\_ONE\_TOUCH\_4005D  
313. ALCATEL ONE TOUCH 4010X - ALCATEL ONE TOUCH 4010A  
314. ALCATEL ONE TOUCH 4010X - ALCATEL ONE TOUCH 4010D  
315. ALCATEL ONE TOUCH 4010X - ALCATEL ONE TOUCH 4010E  
316. ALCATEL ONE TOUCH 4010X - ALCATEL ONE TOUCH 4010X  
317. ALCATEL ONE TOUCH 4010X - TCL\_J210  
318. ALCATEL ONE TOUCH 4010X - Telenor Smart 2  
319. ALCATEL ONE TOUCH 4030X - ALCATEL ONE TOUCH 4029A  
320. ALCATEL ONE TOUCH 4030X - ALCATEL ONE TOUCH

- 4030D
321. ALCATEL ONE TOUCH 4030X - ALCATEL ONE TOUCH 4030E
322. ALCATEL ONE TOUCH 4030X - ALCATEL ONE TOUCH 4030X
323. ALCATEL ONE TOUCH 4030X - ALCATEL ONE TOUCH 4030Y
324. ALCATEL ONE TOUCH 4030X - ALCATEL ONE TOUCH 4030Y\_orange
325. ALCATEL ONE TOUCH 4030X - Infinity POP
326. ALCATEL ONE TOUCH 4030X - Orange Runo
327. ALCATEL ONE TOUCH 4037N - ALCATEL ONE TOUCH 4037N
328. ALCATEL ONE TOUCH 4037N - ALCATEL ONE TOUCH 4037T
329. ALCATEL ONE TOUCH 5020D - ALCATEL ONE TOUCH 5020A
330. ALCATEL ONE TOUCH 5020D - ALCATEL ONE TOUCH 5020D
331. ALCATEL ONE TOUCH 5020D - ALCATEL ONE TOUCH 5020E
332. ALCATEL ONE TOUCH 5020D - ALCATEL ONE TOUCH 5020T
333. ALCATEL ONE TOUCH 5020D - ALCATEL ONE TOUCH 5020W
334. ALCATEL ONE TOUCH 5020D - ALCATEL ONE TOUCH 5020X
335. ALCATEL ONE TOUCH 5020D - ALCATEL ONE TOUCH 5021E
336. ALCATEL ONE TOUCH 5020D -  
ALCATEL\_ONE\_TOUCH\_5020D\_Orange
337. ALCATEL ONE TOUCH 5020D -  
ALCATEL\_ONE\_TOUCH\_5020X\_Orange
338. ALCATEL ONE TOUCH 5020D - AURUS III
339. ALCATEL ONE TOUCH 5020D - MTC 972
340. ALCATEL ONE TOUCH 5020D - Orange Kivo
341. ALCATEL ONE TOUCH 5020D - Telenor Smart Pro 2
342. ALCATEL ONE TOUCH 5020N - ALCATEL ONE TOUCH 5020N
343. ALCATEL ONE TOUCH 5035D - ALCATEL ONE TOUCH 5035A
344. ALCATEL ONE TOUCH 5035D - ALCATEL ONE TOUCH 5035D
345. ALCATEL ONE TOUCH 5035D - ALCATEL ONE TOUCH 5035E
346. ALCATEL ONE TOUCH 5035D - ALCATEL ONE TOUCH 5035X
347. ALCATEL ONE TOUCH 5035D - TCL J610
348. ALCATEL ONE TOUCH 5035D - TCL S810
349. ALCATEL ONE TOUCH 5036A - ALCATEL ONE TOUCH 5036A
350. ALCATEL ONE TOUCH 5036D - ALCATEL ONE TOUCH 5036D
351. ALCATEL ONE TOUCH 5036D - ONE TOUCH 5036X
352. ALCATEL ONE TOUCH 5036F - ALCATEL ONE TOUCH 5036F
353. ALCATEL ONE TOUCH 5036X - ALCATEL ONE TOUCH 5036X
354. ALCATEL ONE TOUCH 5037E - ALCATEL ONE TOUCH 5037E
355. ALCATEL ONE TOUCH 601 - ALCATEL ONE TOUCH 6010
356. ALCATEL ONE TOUCH 6010A - ALCATEL ONE TOUCH 6010A
357. ALCATEL ONE TOUCH 6010D - ALCATEL ONE TOUCH 6010D
358. ALCATEL ONE TOUCH 6010X - ALCATEL ONE TOUCH 6010
359. ALCATEL ONE TOUCH 6010X - ALCATEL ONE TOUCH 6010D
360. ALCATEL ONE TOUCH 6010X - ALCATEL ONE TOUCH 6010X
361. ALCATEL ONE TOUCH 6010X - ALCATEL ONE TOUCH 6010X-orange
362. ALCATEL ONE TOUCH 6010X - TCL S520
363. ALCATEL ONE TOUCH 6030A - ALCATEL ONE TOUCH 6030A
364. ALCATEL ONE TOUCH 6030D - ALCATEL ONE TOUCH 6030D
365. ALCATEL ONE TOUCH 6030N - ALCATEL ONE TOUCH 6030N
366. ALCATEL ONE TOUCH 6030X - ALCATEL ONE TOUCH 6030A
367. ALCATEL ONE TOUCH 6030X - ALCATEL ONE TOUCH 6030D
368. ALCATEL ONE TOUCH 6030X - ALCATEL ONE TOUCH 6030X
369. ALCATEL ONE TOUCH 6030X - ALCATEL ONE TOUCH 6030X-orange
370. ALCATEL ONE TOUCH 6030X -  
ALCATEL\_ONE\_TOUCH\_6030X\_Orange
371. ALCATEL ONE TOUCH 6030X - Optimus\_San\_Remo
372. ALCATEL ONE TOUCH 6030X - TCL S820
373. ALCATEL ONE TOUCH 6030X-orange - ALCATEL ONE TOUCH 6030X-orange
374. ALCATEL ONE TOUCH 6032 - ALCATEL ONE TOUCH 6032
375. ALCATEL ONE TOUCH 6032A - ALCATEL ONE TOUCH 6032A
376. ALCATEL ONE TOUCH 6032X - ALCATEL ONE TOUCH 6032X
377. ALCATEL ONE TOUCH 6033A - ALCATEL ONE TOUCH 6033A
378. ALCATEL ONE TOUCH 6033M - ALCATEL ONE TOUCH 6033M
379. ALCATEL ONE TOUCH 6033X - ALCATEL ONE TOUCH 6033M
380. ALCATEL ONE TOUCH 6033X - ALCATEL ONE TOUCH 6033X
381. ALCATEL ONE TOUCH 6033X - TCL S850
382. ALCATEL ONE TOUCH 6037B - ALCATEL ONE TOUCH 6037B
383. ALCATEL ONE TOUCH 6040A - ALCATEL ONE TOUCH 6040A
384. ALCATEL ONE TOUCH 6040D - ALCATEL ONE TOUCH 6040D
385. ALCATEL ONE TOUCH 6040D - TCL S950
386. ALCATEL ONE TOUCH 6040E - ALCATEL ONE TOUCH 6040E
387. ALCATEL ONE TOUCH 6040X - ALCATEL ONE TOUCH 6040X
388. ALCATEL ONE TOUCH 7024W - ALCATEL ONE TOUCH 7024R
389. ALCATEL ONE TOUCH 7024W - ALCATEL ONE TOUCH

- 7024W
390. ALCATEL ONE TOUCH 7024W - ALCATEL ONE TOUCH FIERCE
391. ALCATEL ONE TOUCH 7025D - ALCATEL ONE TOUCH 7025D
392. ALCATEL ONE TOUCH 7040A - ALCATEL ONE TOUCH 7040A
393. ALCATEL ONE TOUCH 7040D - ALCATEL ONE TOUCH 7040D
394. ALCATEL ONE TOUCH 7040E - ALCATEL ONE TOUCH 7040E
395. ALCATEL ONE TOUCH 7040K - ALCATEL ONE TOUCH 7040K
396. ALCATEL ONE TOUCH 7040X - ALCATEL ONE TOUCH 7040X
397. ALCATEL ONE TOUCH 7041D - ALCATEL ONE TOUCH 7041D
398. ALCATEL ONE TOUCH 7041X - ALCATEL ONE TOUCH 7041X
399. ALCATEL ONE TOUCH 7042A - ALCATEL ONE TOUCH 7042A
400. ALCATEL ONE TOUCH 7042D - ALCATEL ONE TOUCH 7042D
401. ALCATEL ONE TOUCH 7042E - ALCATEL ONE TOUCH 7042E
402. ALCATEL ONE TOUCH 7047D - ALCATEL ONE TOUCH 7047D
403. ALCATEL ONE TOUCH 7047E - ALCATEL ONE TOUCH 7047E
404. ALCATEL ONE TOUCH 7047X - ALCATEL ONE TOUCH 7047X
405. ALCATEL ONE TOUCH 8008D - ALCATEL ONE TOUCH 8008D
406. ALCATEL ONE TOUCH 8008D - ALCATEL ONE TOUCH 8008X
407. ALCATEL ONE TOUCH 8008D - Orange Infinity 8008X
408. ALCATEL ONE TOUCH 8020A - ALCATEL ONE TOUCH 8020A
409. ALCATEL ONE TOUCH 8020D - ALCATEL ONE TOUCH 8020D
410. ALCATEL ONE TOUCH 8020E - ALCATEL ONE TOUCH 8020E
411. ALCATEL ONE TOUCH 8020X - ALCATEL ONE TOUCH 8020X
412. ALCATEL ONE TOUCH 903 -  
ALCATEL\_ONE\_TOUCH\_903
413. ALCATEL ONE TOUCH 903 - ALCATEL\_one\_touch\_903
414. ALCATEL ONE TOUCH 903 - ALCATEL ONE TOUCH 903D
415. ALCATEL ONE TOUCH 903 - ALCATEL ONE TOUCH 903
416. ALCATEL ONE TOUCH 903 -  
ALCATEL\_ONE\_TOUCH\_903
417. ALCATEL ONE TOUCH 903A - ALCATEL ONE TOUCH 903A
418. ALCATEL ONE TOUCH 903D - ALCATEL ONE TOUCH 903D
419. ALCATEL ONE TOUCH 918 - ALCATEL ONE TOUCH 918
420. ALCATEL ONE TOUCH 918 - ALCATEL one touch 918
421. ALCATEL ONE TOUCH 918 - ALCATEL\_one\_touch\_918
422. ALCATEL ONE TOUCH 918 -  
Alcatel\_one\_touch\_918\_Orange
423. ALCATEL ONE TOUCH 918A - ALCATEL ONE TOUCH 918A
424. ALCATEL ONE TOUCH 918A -  
ALCATEL\_one\_touch\_918A
425. ALCATEL ONE TOUCH 918D - ALCATEL ONE TOUCH 918D
426. ALCATEL ONE TOUCH 918D - ALCATEL ONE TOUCH 918D
427. ALCATEL ONE TOUCH 918N - ALCATEL ONE TOUCH 918N
428. ALCATEL ONE TOUCH 918N - ALCATEL ONE TOUCH 918N
429. ALCATEL ONE TOUCH 918S - ALCATEL ONE TOUCH 918S
430. ALCATEL ONE TOUCH 922 - ALCATEL ONE TOUCH 922
431. ALCATEL ONE TOUCH 930D - ALCATEL ONE TOUCH 930D
432. ALCATEL ONE TOUCH 930D - ALCATEL ONE TOUCH 930N
433. ALCATEL ONE TOUCH 985 - ALCATEL ONE TOUCH 985
434. ALCATEL ONE TOUCH 985 -  
ALCATEL\_ONE\_TOUCH\_985
435. ALCATEL ONE TOUCH 985 - ALCATEL\_one\_touch\_985
436. ALCATEL ONE TOUCH 985 - Telenor\_One\_Touch\_C
437. ALCATEL ONE TOUCH 985D - ALCATEL ONE TOUCH 985D
438. ALCATEL ONE TOUCH 985N - ALCATEL ONE TOUCH 985N
439. ALCATEL ONE TOUCH 991 - ALCATEL ONE TOUCH 991D
440. ALCATEL ONE TOUCH 991 - ALCATEL ONE TOUCH 991
441. ALCATEL ONE TOUCH 991 - ALCATEL\_one\_touch\_991
442. ALCATEL ONE TOUCH 991 - Telenor\_Smart\_Pro
443. ALCATEL ONE TOUCH 991 - ALCATEL ONE TOUCH 991
444. ALCATEL ONE TOUCH 991A - ALCATEL ONE TOUCH 991A
445. ALCATEL ONE TOUCH 991D - ALCATEL ONE TOUCH 991D
446. ALCATEL ONE TOUCH 991D - ALCATEL ONE TOUCH 991D
447. ALCATEL ONE TOUCH 991T - ALCATEL ONE TOUCH 991T
448. ALCATEL ONE TOUCH 992D - ALCATEL ONE TOUCH 992
449. ALCATEL ONE TOUCH 992D - ALCATEL ONE TOUCH 992D
450. ALCATEL ONE TOUCH 992D - TCL S500
451. ALCATEL ONE TOUCH 992D - TCL S600
452. ALCATEL ONE TOUCH 995 - ALCATEL\_one\_touch\_995
453. ALCATEL ONE TOUCH 995 - Optimus\_Madrid
454. ALCATEL ONE TOUCH 995 - Telenor\_Smart\_HD
455. ALCATEL ONE TOUCH 995A -  
ALCATEL\_one\_touch\_995A
456. ALCATEL ONE TOUCH 997D - ALCATEL ONE TOUCH 997
457. ALCATEL ONE TOUCH 997D - ALCATEL ONE TOUCH 997D



458. ALCATEL ONE TOUCH 997D - BASE\_Lutea\_3  
459. ALCATEL ONE TOUCH 997D - TCL S710  
460. ALCATEL ONE TOUCH 997D - TCL S800  
461. ALCATEL ONE TOUCH D668 - ALCATEL ONE TOUCH D668  
462. ALCATEL ONE TOUCH D668 - TCL D668  
463. ALCATEL ONE TOUCH D668 - TCL-D668  
464. ALCATEL ONE TOUCH Fierce - ALCATEL ONE TOUCH 7024N  
465. ALCATEL ONE TOUCH Fierce - ALCATEL ONE TOUCH 7024W  
466. ALCATEL ONE TOUCH Fierce - ALCATEL ONE TOUCH Fierce  
467. ALCATEL ONE TOUCH P310A - ALCATEL ONE TOUCH P310A  
468. ALCATEL ONE TOUCH P320A - ALCATEL ONE TOUCH P320A  
469. ALCATEL ONE TOUCH P321 - ALCATEL ONE TOUCH P321  
470. ALCATEL ONE TOUCH918N - ALCATEL ONE TOUCH 918N  
471. ALCATEL ONETOUCH 4037R - ALCATEL ONE TOUCH 4037R  
472. ALCATEL ONETOUCH 4037R - ALCATEL ONETOUCH 4037R  
473. ALCATEL ONETOUCH 6032 - ALCATEL ONETOUCH 6032  
474. ALCATEL ONETOUCH 6032A - ALCATEL ONETOUCH 6032A  
475. ALCATEL ONETOUCH 6032X - ALCATEL ONETOUCH 6032X  
476. ALCATEL ONETOUCH 6043D - ALCATEL ONETOUCH 6043D  
477. ALCATEL ONETOUCH Flash Plus - ALCATEL ONETOUCH Flash Plus  
478. ALCATEL ONETOUCH IDOL 3 (5.5) - 6045B  
479. ALCATEL ONETOUCH IDOL 3 (5.5) - 6045F  
480. ALCATEL ONETOUCH IDOL 3 (5.5) - 6045I  
481. ALCATEL ONETOUCH IDOL 3 (5.5) - 6045K  
482. ALCATEL ONETOUCH IDOL 3 (5.5) - 6045Y  
483. ALCATEL ONETOUCH IDOL 3 (5.5) - TCL i806  
484. ALCATEL ONETOUCH P310A - ALCATEL ONE TOUCH P310A  
485. ALCATEL ONETOUCH P310A - ALCATEL ONETOUCH P310A  
486. ALCATEL ONETOUCH PIXI 3 (3.5) - 4009A  
487. ALCATEL ONETOUCH PIXI 3 (3.5) - 4009D  
488. ALCATEL ONETOUCH PIXI 3 (3.5) - 4009E  
489. ALCATEL ONETOUCH PIXI 3 (3.5) - 4009F  
490. ALCATEL ONETOUCH PIXI 3 (3.5) - 4009K  
491. ALCATEL ONETOUCH PIXI 3 (3.5) - 4009M  
492. ALCATEL ONETOUCH PIXI 3 (3.5) - 4009S  
493. ALCATEL ONETOUCH PIXI 3 (3.5) - 4009X  
494. ALCATEL ONETOUCH PIXI 3 (4.5) - 5017A  
495. ALCATEL ONETOUCH PIXI 3 (4.5) - 5017D  
496. ALCATEL ONETOUCH PIXI 3 (4.5) - 5017E  
497. ALCATEL ONETOUCH PIXI 3 (4.5) - 5019D  
498. ALCATEL ONETOUCH PIXI 4 (4) - 4034A  
499. ALCATEL ONETOUCH PIXI 4 (4) - 4034D  
500. ALCATEL ONETOUCH PIXI 4 (4) - 4034E  
501. ALCATEL ONETOUCH PIXI 4 (4) - 4034F  
502. ALCATEL ONETOUCH PIXI 4 (4) - 4034G  
503. ALCATEL ONETOUCH PIXI 4 (4) - 4034X  
504. ALCATEL ONETOUCH PIXI 4 (4) - Alcatel\_4034F  
505. ALCATEL ONETOUCH PIXI 4 (4) - DIGICEL DL 1 lite  
506. ALCATEL ONETOUCH PIXI 3 (4.5) - 5017O  
507. ALCATEL ONETOUCH POP 3 (5) - 5015A  
508. ALCATEL ONETOUCH POP 3 (5) - 5015D  
509. ALCATEL ONETOUCH POP 3 (5) - 5015E  
510. ALCATEL ONETOUCH POP 3 (5) - 5015X  
511. ALCATEL ONETOUCH POP 3 (5) - 5016A  
512. ALCATEL ONETOUCH POP 3 (5) - 5016J  
513. ALCATEL ONETOUCH POP 3 (5) - 5116J  
514. ALCATEL ONETOUCH POP 3 (5.5) - 5025D  
515. ALCATEL ONETOUCH POP 3 (5.5) - 5025E  
516. ALCATEL ONETOUCH POP 3 (5.5) - 5025G  
517. ALCATEL ONETOUCH POP 3 (5.5) - 5025X  
518. ALCATEL ONETOUCH POP 3 (5.5) - DIGICEL DL1000  
519. ALCATEL ONETOUCH POP 3 (5.5) - S4035 3G  
520. ALCATEL ONETOUCH POP D3 - ALCATEL ONETOUCH POP D3  
521. ALCATEL ONETOUCH Victory - Alcatel 7046T  
522. ALCATEL PIXI 4 (5) - 5041D  
523. ALCATEL PIXI 4 (5) - 5045A  
524. ALCATEL PIXI 4 (5) - 5045D  
525. ALCATEL PIXI 4 (5) - 5045F  
526. ALCATEL PIXI 4 (5) - 5045G  
527. ALCATEL PIXI 4 (5) - 5045I  
528. ALCATEL PIXI 4 (5) - 5045J  
529. ALCATEL PIXI 4 (5) - 5045T  
530. ALCATEL PIXI 4 (5) - 5045X  
531. ALCATEL PIXI 4 (5) - 5045Y  
532. ALCATEL PIXI 4 (5) - 5145A  
533. ALCATEL PIXI 4 (5) - DIGICELDL1  
534. ALCATEL one touch 986+ - ALCATEL one touch 986+  
535. ALCATEL one touch 990C+ - ALCATEL one touch 990C+  
536. ALCATEL one touch J320 - ALCATEL one touch J320  
537. ALCATEL\_4034A - ALCATEL\_4034A  
538. ALCATEL\_6055K - ALCATEL\_6055K  
539. ALCATEL\_ONETOUCH\_7053D - 7053D  
540. ALCATEL\_ONETOUCH\_7053D - ALCATEL\_ONETOUCH\_7053D  
541. ALCATEL\_ONE\_TOUCH\_4027A - ALCATEL ONE TOUCH 4027A  
542. ALCATEL\_ONE\_TOUCH\_5037A - ALCATEL ONE TOUCH 5037A  
543. ALCATEL\_ONE\_TOUCH\_5037X - ALCATEL ONE TOUCH 5037X  
544. ALCATEL\_ONE\_TOUCH\_6010X\_Orange - ALCATEL\_ONE\_TOUCH\_6010X\_Orange  
545. ALCATEL\_ONE\_TOUCH\_6030X\_Orange - ALCATEL\_ONE\_TOUCH\_6030X\_Orange  
546. ALCATEL\_ONE\_TOUCH\_7047A - ALCATEL ONE TOUCH 7047A  
547. ALCATEL\_ONE\_TOUCH\_903 - ALCATEL\_ONE\_TOUCH\_903  
548. ALCATEL\_ONE\_TOUCH\_903 - ALCATEL\_ONE\_TOUCH\_903  
549. ALCATEL\_ONE\_TOUCH\_991\_Orange - ALCATEL\_ONE\_TOUCH\_991\_Orange  
550. ALCATEL\_ONE\_TOUCH\_P310X - ALCATEL ONE TOUCH P310X  
551. ALCATEL\_ONE\_TOUCH\_P320X - ALCATEL ONE TOUCH



P320X

552. ALCATEL\_one\_touch\_918D -  
ALCATEL\_one\_touch\_918D

553. ALCATEL\_one\_touch\_991 - ALCATEL\_one\_touch\_991

554. ALCATEL\_one\_touch\_991 - ALCATEL\_one\_touch\_991

555. ALCATEL\_one\_touch\_995 - ALCATEL\_one\_touch\_995

556. ALCATEL\_one\_touch\_995 - RPSPE4301

557. ALCATEL\_one\_touch\_995 - Telenor\_One\_Touch\_S

558. ALCATEL\_one\_touch\_995 - Telenor\_Smart\_HD

559. ALCATEL\_one\_touch\_995A -  
ALCATEL\_one\_touch\_995A

560. ALCATEL\_one\_touch\_995S -  
ALCATEL\_one\_touch\_995S

561. ALOO 6032 - ALOO 6032

562. AM-H100 - AM-H100

563. ATEL ONE TOUCH 995 - ALCATEL\_one\_touch\_995

564. Alcatel Raven LTE - A574BL

565. Alcatel one touch 985 - ALCATEL\_one\_touch\_985

566. Alcatel9007T - Alcatel9007T

567. Alcatel\_4060A - Alcatel\_4060A

568. Alcatel\_5045A - Alcatel\_5045A

569. Alcatel\_5054O - Alcatel\_5054O

570. Alcatel\_5056O - Alcatel\_5056O

571. Alcatel\_5085C - Alcatel\_5085C

572. Alcatel\_5098O - Alcatel\_5098O

573. Alcatel\_6055U - Alcatel\_6055U

574. Alcatel\_6055U - Alcatel\_6055U

575. Alcatel\_6060C - Alcatel\_6060C

576. Alcatel\_7049D - Alcatel\_7049D

577. Alcatel\_9001X - Alcatel\_9001X

578. Alcatel\_9026S - Alcatel\_9026S

579. Alcatel\_one\_touch\_918\_Orange -  
Alcatel\_one\_touch\_918\_Orange

580. Boost View 5.0 - Boost View 5.0

581. D819 - D819

582. D820 - D820

583. D820X - D820X

584. DL900 - DL900

585. DLGICELDL1 plus - DIGICELDL1plus

586. E500 - E500

587. ELEMENT5 - Alcatel\_5044R

588. EVO7 - MTC 1065

589. EVO7 - onetouch EVO7

590. EVO7 - starTIM tab 7

591. FL03 - FL03

592. Flash Plus 2 - FL02

593. Flash2\_7049D - Flash2\_7049D

594. Go PLAY - 7048A

595. Go PLAY - 7048S

596. Go PLAY - 7048W

597. Go PLAY - 7048X

598. Hero2C - 7055A

599. I216A - I216A

600. I216X - I216X

601. I220 - I220

602. I221 - I221

603. IDOL 2 S - 6050Y

604. IDOL 2 S - ALCATEL ONE TOUCH 6050Y

605. IDOL 2 S - Idol2S\_Orange

606. IDOL 2 S - 6050A

607. IDOL 2 S - 6050F

608. IDOL 2 S - 6050W

609. IDOL 2 S - 6050Y

610. IDOL 2 S - ALCATEL ONE TOUCH 6050Y

611. IDOL 2 S - ALCATEL ONETOUCH 6050A

612. IDOL 2 S - OWN S5030

613. IDOL 2 S - TCL S830U

614. IDOL 2 S - TCL S838M

615. IDOL 4S - 6070K

616. IDOL 4S - 60700

617. IDOL 5 - 6058A

618. IDOL 5 - 6058D

619. IDOL 5 - 6058X

620. IDOL 5S - 6060S

621. Idol S - ALCATEL ONE TOUCH 6035L

622. Idol S - BS472

623. Idol S - MTC 978

624. Idol S - ALCATEL ONE TOUCH 6034L

625. Idol S - ALCATEL ONE TOUCH 6034M

626. Idol S - ALCATEL ONE TOUCH 6034R

627. Idol S - ALCATEL ONE TOUCH 6034Y

628. Idol S - San Remo 4G

629. Idol S - TCL-S850L

630. Idol X - ALCATEL ONE TOUCH 6035R

631. Idol2 MINI S - 6036A

632. Idol2 MINI S - 6036X

633. Idol2 MINI S - 6036Y

634. Juke-A554C - A554C

635. LCATEL ONETOUCH PIXI 3 (4.5) - DIGICEL DL810

636. M812C - M812C

637. MTC 960 - MTC 960

638. MTC 970 - MTC 970

639. MTC975 - MTC975

640. MegaFon\_SP-A10 - MegaFon\_SP-A10

641. Megafon Login - MegaFon\_SP-AI

642. Mirage - 5057M

643. Moov2 - move 2

644. NeXT by Maxis (B1) - VFD 500

645. NeXT by Maxis (M1) - Maxis VFD 700

646. NeXT by Maxis (M1) - VFD 700

647. NeXT by Maxis (M1) - VFD700

648. Nitro - 6045O

649. No - Alcatel\_4060O

650. ONE TOUCH 4007X - ONE TOUCH 4007A

651. ONE TOUCH 4007X - ONE TOUCH 4007D

652. ONE TOUCH 4007X - ONE TOUCH 4007E

653. ONE TOUCH 4007X - ONE TOUCH 4007X

654. ONE TOUCH 4011X - ONE TOUCH 4011X

655. ONE TOUCH 4015X - 4016D

656. ONE TOUCH 4015X - ONE TOUCH 4015A

657. ONE TOUCH 4015X - ONE TOUCH 4015D

658. ONE TOUCH 4015X - ONE TOUCH 4015N

659. ONE TOUCH 4015X - ONE TOUCH 4015X

660. ONE TOUCH 4015X - ONE TOUCH 4015X-orange

661. ONE TOUCH 4015X - ONE TOUCH 4016A

662. ONE TOUCH 4015X - Orange Yomi

663. ONE TOUCH 4033X - 4032A

664. ONE TOUCH 4033X - 4032D

665. ONE TOUCH 4033X - 4032E

666. ONE TOUCH 4033X - 4032X

667. ONE TOUCH 4033X - 4033L

668. ONE TOUCH 4033X - MS3B

669. ONE TOUCH 4033X - ONE TOUCH 4032A

670. ONE TOUCH 4033X - ONE TOUCH 4033A

671. ONE TOUCH 4033X - ONE TOUCH 4033D  
672. ONE TOUCH 4033X - ONE TOUCH 4033E  
673. ONE TOUCH 4033X - ONE TOUCH 4033X  
674. ONE TOUCH 4033X - OWN S3010  
675. ONE TOUCH 4033X - OWN S3010D  
676. ONE TOUCH 4033X - TCLJ330  
677. ONE TOUCH 6012A - ONE TOUCH 6012A  
678. ONE TOUCH 6012D - ALCATEL ONE TOUCH 6012D  
679. ONE TOUCH 6012D - ALCATEL ONE TOUCH 6012X  
680. ONE TOUCH 6012D - Mobile Sosh  
681. ONE TOUCH 6012D - ONE TOUCH 6012A  
682. ONE TOUCH 6012D - ONE TOUCH 6012D  
683. ONE TOUCH 6012D - ONE TOUCH 6012E  
684. ONE TOUCH 6012D - ONE TOUCH 6012X  
685. ONE TOUCH 6012D - ONE TOUCH IDOL MINI  
686. ONE TOUCH 6012D - Orange Covo  
687. ONE TOUCH 6012D - Orange Hiro  
688. ONE TOUCH 6012X - ONE TOUCH 6012X  
689. ONE TOUCH 8020D - ONE TOUCH 8020D  
690. ONE TOUCH 983 - ALCATEL\_one\_touch\_983  
691. ONE TOUCH 983 - ONE TOUCH 983  
692. ONE TOUCH 983 - VALENCIA  
693. ONE TOUCH 983 - ALCATEL\_one\_touch\_983  
694. ONE TOUCH C505C - ONE TOUCH C505C  
695. ONE TOUCH EVO7HD - MTC 1078  
696. ONE TOUCH EVO7HD - ONE TOUCH E710  
697. ONE TOUCH EVO7HD - ONE TOUCH EVO7HD  
698. ONE TOUCH EVO8HD - ONE TOUCH EVO7HD  
699. ONE TOUCH EVO8HD - ONE TOUCH EVO8HD  
700. ONE TOUCH SCRIBE 5 - ALCATEL ONE TOUCH 8000A  
701. ONE TOUCH SCRIBE 5 - ALCATEL ONE TOUCH 8000D  
702. ONE TOUCH SCRIBE 5 - TCL Y710  
703. ONE TOUCH T10 - GR-TB7  
704. ONE TOUCH TAB 7 - ONE TOUCH TAB 7  
705. ONE TOUCH TAB 7 - TCL TAB 7  
706. ONE TOUCH TAB 7HD - ONE TOUCH TAB 7HD  
707. ONE TOUCH TAB 8HD - ONE TOUCH TAB 8HD  
708. ONE TOUCH Ultra 960c - ONE\_TOUCH\_960C  
709. ONE TOUCH Ultra 960c - ADR3010  
710. ONE TOUCH Ultra 960c - ONE TOUCH 960C  
711. ONE TOUCH Ultra 960c - ADR3010  
712. ONE TOUCH Ultra 960c - ONE\_TOUCH\_960C  
713. ONE TOUCH Ultra 960c - ONE\_TOUCH\_960C  
714. ONETOUCH PIXI 3 (8) - 9022S  
715. ONETOUCH PIXI 3 (8) - 9022X  
716. ONETOUCH PIXI 3 (8) - Alcatel9022S  
717. ONETOUCH PIXI 3 (8) - Alcatel\_9022S  
718. ONETOUCH PIXI3(7) - 9007A  
719. ONETOUCH PIXI3(7) - 9007X  
720. ONE\_TOUCH\_P310A - ONE TOUCH P310A  
721. ONE\_TOUCH\_P310X - ALCATEL ONE TOUCH P310X  
722. OT-990C - OT-990C  
723. OWN S4010 - OWN S4010  
724. OWN S5010 - OWN S5010  
725. OWN\_S4025 - OWN\_S4025  
726. One Touch 890D - ALCATEL one touch 890D  
727. One Touch 906 - ALCATEL\_one\_touch\_906Y  
728. One Touch 908 - ALCATEL ONE TOUCH 908  
729. One Touch 908 - ALCATEL\_one\_touch\_908  
730. One Touch 908 - Alcatel\_one\_touch\_908F\_Orange  
731. One Touch 990 - ALCATEL ONE TOUCH 990  
732. One Touch 990 - ALCATEL one touch 990  
733. One Touch 990 - ALCATEL\_one\_touch\_990  
734. One Touch 990 - Alcatel one touch 908F Orange  
735. One Touch 990 - Alcatel one touch 990 Orange  
736. One Touch 990 - Los Angeles  
737. One Touch 990 - TCL A990  
738. One Touch 990 - TCL ONE TOUCH 990  
739. One Touch 990 - Telenor\_OneTouch  
740. One Touch 990 - Vodafone 958  
741. One Touch 990A - ALCATEL\_one\_touch\_990A  
742. One Touch 990S - ALCATEL\_one\_touch\_990S  
743. One Touch 990S - Alcatel one touch 990S  
744. P330X - P330X  
745. P330X\_orange - P330X\_orange  
746. P350X - P350X  
747. P360X - P360X  
748. P688L - TCL-P688L  
749. P688L - TOM007  
750. PIXI 4 (5) - 5010D  
751. PIXI 4 (5) - 5010E  
752. PIXI 4 (5) - 5010G  
753. PIXI 4 (5) - 5010S  
754. PIXI 4 (5) - 5010U  
755. PIXI 4 (5) - 5010X  
756. PIXI 5 HD - A576CC  
757. PIXI3(4) - 4003A  
758. PIXI3(4) - 4003J  
759. PIXI3(4) - 4013D  
760. PIXI3(4) - 4013E  
761. PIXI3(4) - 4013J  
762. PIXI3(4) - 4013K  
763. PIXI3(4) - 4013X  
764. PIXI3(4) - 4014E  
765. PIXI3(4) - ONE\_TOUCH\_PIXI3  
766. PIXI3(4) - ONE\_TOUCH\_PIXI3D  
767. PIXI3(4.5) - 4027A  
768. PIXI3(4.5) - 4027D  
769. PIXI3(4.5) - 4027N  
770. PIXI3(4.5) - 4027X  
771. PIXI3(4.5) - 4028A  
772. PIXI3(4.5) - 4028E  
773. PIXI3(4.5) - 4028J  
774. PIXI3(4.5) - 4028S  
775. PIXI4 (3.5) - 4017A  
776. PIXI4 (3.5) - 4017D  
777. PIXI4 (3.5) - 4017F  
778. PIXI4 (3.5) - 4017S  
779. PIXI4 (3.5) - 4017X  
780. PIXI4 - 4060S  
781. PLAY\_P1 - 4024D  
782. PLAY\_P1 - 4024E  
783. POP 2 - 5042A  
784. POP 2 - 5042D  
785. POP 2 - 5042X  
786. POP 2 (5) - 7043A  
787. POP 2 (5) - 7043K  
788. POP 2 (5) - 7043Y  
789. POP 2 (5) - 7044A  
790. POP 2 (5) - 7044X  
791. POP 4 6" 4G android - 7070I  
792. POP 4 6" 4G android - 7070Q  
793. POP 4 6" 4G android - 7070X  
794. POP 4S - 5095I

795. POP 4S - 5095K  
796. POP 4S - 5095Y  
797. POP S3 - ALCATEL A845L  
798. POP S3 - 5050A  
799. POP S3 - 5050S  
800. POP S3 - 5050X  
801. POP S3 - 5050Y  
802. POP S3 - ALCATEL ONETOUCH 5050X  
803. POP S3 - Siru  
804. POP S9 - 7050Y  
805. POP S9 - ALCATEL A995L  
806. POP S9 - STARXTREM II  
807. POP S9 - Smartphone Android by SFR STARXTREM II  
808. POP2 (4) - 4045A  
809. POP2 (4) - 4045A  
810. POP2 (4) - 4045D  
811. POP2 (4) - 4045L  
812. POP2 (4) - 4045O  
813. POP2 (4) - 4045X  
814. POP2 (4.5) - 5042G  
815. POP2 (4.5) - 5042W  
816. PandA\_m14 - PandA\_m14  
817. Pixi3-3.5 TF - A463BG  
818. Pixi3-4 TF - A460G  
819. Pixi4-4 3G Telus - A466T  
820. Pixo 7 - I211  
821. Pixo 7 - I212  
822. Pixo 7 - I213  
823. Pop4 - Pop4  
824. S4035\_4G - S4035\_4G  
825. SHINE LITE - 5080D  
826. SHINE LITE - 5080X  
827. SMART 4G 5.5 Enterprise - SMART 4G 5.5 Enterprise  
828. SMART\_PLUS - SMART\_PLUS  
829. SOL PRIME - T-1000  
830. SOL PRIME - T-1000  
831. SOLO Aspire M - SOLO Aspire M  
832. SOUL 4.5 - 5038X  
833. Smartphone Android by SFR STARADDICT II -  
Smartphone Android by SFR STARADDICT II  
834. Smartphone Android by SFR STARADDICT II -  
Smartphone\_Android\_by\_SFR\_STARADDICT\_II  
835. Sol - AM-H200  
836. Soul 3.5 - 4018A  
837. Soul 3.5 - 4018D  
838. Soul 3.5 - 4018E  
839. Soul 3.5 - 4018F  
840. Soul 3.5 - 4018M  
841. Soul 3.5 - 4018X  
842. Soul 3.5 - T4018  
843. Soul 4 - 4035A  
844. Soul 4 - 4035D  
845. Soul 4 - 4035X  
846. Soul 4 - 4035X\_Orange  
847. Soul 4 - 4035Y  
848. Soul 4 - 4036E  
849. Soul 4.5 - 5038A  
850. Soul 4.5 - 5038E  
851. Soul 4.5 - D45  
852. T10 - one touch T10  
853. T70 - T70  
854. TAB 7 DUAL CORE - TAB 7 DUAL CORE  
855. TAB 7 DUAL CORE - TAB 7 DUAL CORE  
856. TCL 302U - TCL 302U  
857. TCL 520 - TCL 520  
858. TCL 562 - 562  
859. TCL 580 - TCL 580  
860. TCL 736L - TCL-J736L  
861. TCL 738M - TCL J738M  
862. TCL 750 - TCL 750  
863. TCL 950 - TCL 950  
864. TCL A506 - TCL A506  
865. TCL A865 - TCL A865  
866. TCL A988 - ALCATEL ONE TOUCH 993D  
867. TCL A988 - ALCATEL ONE TOUCH 993  
868. TCL A988 - MTC\_968  
869. TCL C995 - TCL C995  
870. TCL D35 - TCL D35  
871. TCL D40 DUAL - TCL D40 DUAL  
872. TCL D55 - TCL D55  
873. TCL D662 - TCL D662  
874. TCL D706 - TCL D706  
875. TCL D768 - TCL D768  
876. TCL D920 - TCL D920  
877. TCL D920 - TCL-D920  
878. TCL DL750 - DL750  
879. TCL H900M - TCL H900M  
880. TCL J210C - TCL J210C  
881. TCL J210C - TCL-J210C  
882. TCL J300 - ALCATEL ONE TOUCH 5020T  
883. TCL J300 - TCL J300  
884. TCL J310 - TCL J310  
885. TCL J320 - TCL J320  
886. TCL J320C - TCL J320C  
887. TCL J320T - TCL J320T  
888. TCL J600T - TCL J600T  
889. TCL J620 - TCL J620  
890. TCL J630 - J630  
891. TCL J630T - TCL J630T  
892. TCL J720 - TCL J720  
893. TCL J726T - TCL J726T  
894. TCL J900 - TCL J900  
895. TCL J900T - TCL J900T  
896. TCL J920 - TCL J920  
897. TCL J926T - TCL J926T  
898. TCL J928 - TCL J928  
899. TCL J929L - TCL-J929L  
900. TCL J938M - TCL J938M  
901. TCL M2M - TCL M2M  
902. TCL M2U - TCL M2U  
903. TCL P301C - TCL P301C  
904. TCL P301M - TCL P301M  
905. TCL P302C - TCL P302C  
906. TCL P316L - TCL P316L  
907. TCL P331M - TCL P331M  
908. TCL P332U - TCL P332U  
909. TCL P360W - TCL P360W  
910. TCL P500M - TCL P500M  
911. TCL P502U - TCL P502U  
912. TCL P520L - TCL P520L  
913. TCL P606 - TCL P600  
914. TCL P606 - TCL P606  
915. TCL P606 - TCL P606T  
916. TCL P618L - TCL P618L



917. TCL P631M - TCL P631M  
918. TCL P689L - TCL\_P689L  
919. TCL P728M - TCL P728M  
920. TCL S300T - TCL S300T  
921. TCL S500 - TCL S500  
922. TCL S520 - TCL S520  
923. TCL S530T - TCL S530T  
924. TCL S600 - TCL S600  
925. TCL S700 - TCL S700  
926. TCL S700T - TCL S700T  
927. TCL S720 - TCL S720  
928. TCL S720T - TCL S720T  
929. TCL S725T - TCL\_S725T  
930. TCL S820 - TCL S820  
931. TCL S850 - TCL S850  
932. TCL S860 - TCL S860  
933. TCL S900 - TCL S900  
934. TCL S950 - TCL S950  
935. TCL S950T - TCL S950T  
936. TCL S960 - TCL S960  
937. TCL S960T - TCL S960T  
938. TCL T500L - TCL T500L  
939. TCL Y900 - TCL Y900  
940. TCL Y910 - TCL Y910  
941. TCL Y910T - TCL Y910T  
942. TCL i708U - TCL i708U  
943. TCL i718M - TCL i718M  
944. TCL i718M - TCL i709M  
945. TCL-550 - TCL-550  
946. TCL-J320D - TCL-J320D  
947. TCL-J900C - TCL-J900C  
948. TCL-P306C - TCL-P306C  
949. TCL\_6110A - TCL 6110A  
950. TCL\_6110A - TCL\_6110A  
951. TCL\_J636D - TCL\_J636D  
952. TCL\_J706T - TCL\_J706T  
953. TCL\_P561U - TCL\_P561U  
954. TCL\_U980 - TCL\_U980  
955. TCL\_Xess\_P17AA - TCL Xess P17AA  
956. TCL\_Xess\_P17AA\_OS - TCL Xess P17AA  
957. Telenor\_Smart - Telenor\_Smart  
958. Telenor\_Smart\_Mini - Telenor Smart Mini  
959. U3 - 4049D  
960. U3 - 4049E  
961. U3 - 4049G  
962. U3 - 4049M  
963. U3 - 4049X  
964. U5 - 5044A  
965. U5 - 5044P  
966. U5 - 5044Y  
967. U5 3G - 4047A  
968. U5 3G - 4047F  
969. U5 HD - 5047D  
970. U5 HD - 5047I  
971. U5 HD - 5047U  
972. U5 HD - 5047Y  
973. U50 - 5044G  
974. U50 - 5044S  
975. VF 860 - Vodafone Smart II  
976. Vodafone 785 - MTC 982  
977. Vodafone 861 - ALCATEL ONE TOUCH 922  
978. Vodafone 861 - Vodafone 861

979. Vodafone 985N - Vodafone 985N  
980. Vodafone Smart III - Vodafone 975  
981. Vodafone Smart III (with NFC) - Vodafone 975N  
982. X35E - X35E  
983. X50D - X50D  
984. Xess mini - TCL Xess miniC15BA  
985. Xess-mini - TCL Xess C15BA  
986. alcatel PIXI 4 (5.5) - 5012D  
987. alcatel PIXI 4 (5.5) - 5012F  
988. alcatel PIXI 4 (5.5) - 5012G  
989. alcatel U5 - 5044D  
990. alcatel U5 - 5044I  
991. alcatel U5 - 5044K  
992. alcatel U5 - 5044O  
993. alcatel U5 - 5044T  
994. freebit PandA\_m14 - freebit PandA\_m14  
995. one touch 995C+ - one touch 995C+  
996. one touch D920 - ALCATEL one touch D920  
997. one touch D920 - one touch D920  
998. one\_touch\_4030\_TLVE - ALCATEL\_one\_touch\_4030A  
999. one\_touch\_D920\_ALIQ - one touch D920  
1000. onetouch\_P689L - onetouch\_P689L  
1001. tbd - A576BL  
1002. tmn smarta8 - moche smart a8  
1003. tmn smarta8 - tmn smart a8

#### **TG&Co.**

1. TG-L800S - TG-L800S
2. TG-L900S - TG-L900S

#### **THTF**

1. TSINGHUA TONGFANG CO., LTD. - TR10CD1

#### **TIM**

1. TIM BOX - TIM\_BOX
2. TIMvision - skipper

#### **TJC**

1. Metal Tablet - Metal\_Tablet\_10

#### **TMAX**

1. TM9S775 - TM9S775

#### **TPS**

1. MTC 982o - MTC\_982O
2. SMART Sprint - SMART Sprint

#### **TSUNAMI**

1. Tablet Tsunami TSTA080D1 - MG080D1T

#### **TUNTUN English**

1. DREAM PAD - ITP-R408W

#### **TUPAD**

1. TU7\_58212\_18222 - TU7\_18222



## TaiwanMobile

1. A5C - A5C
2. A6S - A6S
3. Amazing A8 - Amazing A8
4. Amazing X3 - Amazing X3

## Takara

1. MID 107 - MID107
2. MID210 - MID210

## Technicolor

1. omap4\_WT3 - T-Hub2
2. Euskaltel - cooper
3. LMT viedtelevizijas iekrta - skipper
4. Shortcut - Shortcut

## Techpad

1. TechPad - 916
2. TechPad\_10x - TechPad\_10x
3. TechPad\_3Gx - TechPad\_3Gx
4. TechPad\_716 - 716

## Tecno

1. A7S - TECNO-A7S
2. C5 - TECNO-C5
3. C7 - TECNO-C7
4. C8 - TECNO-C8
5. C9 - TECNO-C9
6. C9S - TECNO-C9S
7. Camon CX - TECNO Camon CX
8. Camon CX Air - TECNO CX Air
9. Camon CXS - TECNO Camon CXS
10. DP10APro-SLA1 - DP10APro
11. DP7CPro-SGA1 - DP7CPro-SGA1
12. DroiPad 10 Pro - DP10APro
13. DroiPad 7C Pro - DP7CPro
14. DroiPad 7D - TECNO P701
15. DroiPad 7D ProLTE - TECNO P702
16. DroiPad 7D ProLTE - TECNO P702A
17. DroiPad 8 - DP8D
18. Droipad10 - DP10A
19. Droipad10 - TECNO DP10A
20. H5S - TECNO H5S
21. H7S - H7S
22. J5 - TECNO-J5
23. J7 - TECNO-J7
24. J8 - TECNO-J8
25. L5 - TECNO-L5
26. L8 - TECNO-L8
27. L8 Lite - TECNO L8 Lite
28. L8Plus - TECNO-L8Plus
29. L9 - TECNO L9
30. L9Plus - TECNO L9 Plus
31. M3 - TECNO M3S
32. M6S - TECNO-M6S
33. N2 - TECNO-N2
34. N2S - TECNO-N2S
35. N5S - TECNO N5S
36. N6 - TECNO-N6
37. N6S - TECNO-N6S
38. N8 - TECNO N8
39. N8 - TECNO-N8
40. N8R - TECNO-N8R
41. N8S - TECNO-N8S
42. N9 - TECNO-N9
43. N9S - TECNO-N9S
44. P5 - TECNO P5S
45. P702AS - TECNO P702AS
46. PHANTOM-Z-mini - PTM-Z-mini
47. PHANTOM5 - TECNO-PHANTOM5
48. Phantom6 - Phantom6
49. Phantom6 plus - Phantom6-Plus
50. Phantom6S - Phantom6S
51. PhonePad 3 - TECNO PhonePad 3
52. PhonePad 7 II - TECNO PP7E-DLA1
53. PhonePad 7 II - TECNO PP7E-SLA1
54. R6 - TECNO R6
55. S1 - TECNO S1
56. S1 - TECNO S1M
57. S1 Pro - TECNO S1 Pro
58. S1 Pro - TECNO S1E Pro
59. S6S - TECNO S6S
60. SPARK - TECNO K7
61. SPARK Plus - TECNO K9
62. SPARK Pro - TECNO K8
63. TECNO AX8 - TECNO AX8
64. TECNO CX Air - TECNO CX Air
65. TECNO K7 - TECNO K7
66. TECNO K9 - TECNO K9
67. TECNO L9 - TECNO L9
68. TECNO P904 - TECNO P904
69. TECNO R6 - TECNO R6
70. TECNO R6S - TECNO R6S
71. TECNO S1 Lite - TECNO S1 Lite
72. TECNO S6S - TECNO S6S
73. TECNO W5 - TECNO-W5
74. TECNO WX4 Pro S - TECNO WX4 Pro S
75. TECNO i3 - TECNO i3
76. TECNO-Y2 - TECNO-Y2
77. TECNO-Y2 - TECNO-Y3+
78. Techno L6 - TECNO-L6
79. W1 - TECNO W1
80. W2 - TECNO W2
81. W3 - TECNO-W3
82. W3 Pro - TECNO W3 Pro
83. W3LTE - TECNO-W3LTE
84. W4 - TECNO\_W4
85. W5 - TECNO-W5
86. W5 Lite - TECNO W5 Lite
87. WX3 - TECNO WX3
88. WX3F LTE - TECNO WX3F LTE
89. WX3LTE - TECNO WX3LTE
90. WX3P - TECNO WX3P
91. WX4 - TECNO WX4
92. WX4 Pro - TECNO WX4 Pro
93. Y3 - TECNO-Y3
94. Y3+ - TECNO-Y2
95. Y3+ - TECNO-Y3+
96. Y3S - TECNO-Y3S
97. Y4 - TECNO-Y4
98. Y5 - TECNO-Y5
99. Y6 - TECNO-Y6

100. i3 - TECNO i3
101. i3-Pro - TECNO i3 Pro
102. i5 - TECNO i5
103. i5-Pro - TECNO i5 Pro
104. i7 - TECNO i7

## Teknosa

1. Preo P2 - Preo\_P2

## Tekwind

1. A10A - A10A
2. TC97RA1 - TC97RA1

## Telcel

1. i50F - i50F

## Tele2

1. Maxi - Tele2\_Maxi
2. Maxi 1.1 - TELE2\_Maxi\_1\_1
3. Maxi\_Plus - Tele2\_Maxi\_Plus
4. Midi - Tele2
5. Midi 1.1 - Tele2\_Midi\_1\_1
6. Midi LTE - Tele2\_Midi\_LTE
7. Mini - Tele2\_Mini
8. Mini 1.1 - Tele2\_Mini\_1.1
9. Mini 1.1 - Tele2\_Mini\_1\_1
10. Tele 2 Maxi LTE - Tele2\_Maxi\_LTE
11. Tele2\_Midi\_2\_0 - Tele2\_Midi\_2\_0
12. Tele2fon V4 - Tele2fon v4
13. Tele2fon V5 - Tele2fon v5

## Telecable

1. tedi - Telecable ATV

## Teleepoch

1. MaxBravo - PMI920
2. U670C - U670C
3. chaser-921 - Chaser
4. Essentiel B SmartTab 1002 - SmartTAB 1002
5. U675 - U675
6. UMX U680C - U680C

## Telefunken

1. Enjoy TE1 - TE1
2. VP73\_Telefunken - VP73\_Telefunken

## Telenor

1. Infinity K - Infinity\_K
2. Infinity a2 - Infinity\_a2
3. Infinity e2 - Infinity\_e2
4. Infinity\_a - Infinity\_a
5. Infinity\_e - Infinity\_e
6. Infinity\_i - Infinity\_i
7. K530 - Telenor K530
8. N940 - Telenor N940
9. Smart - Telenor\_Smart
10. Smart II - SmartII
11. Smart plus II - SmartPlusII
12. Smart4G - Telenor\_Smart\_4G

## Telkom

1. Telkom - TVB-100

## TellyTablet

1. VM\_MD\_001 - VM\_MD\_001

## Telus

1. Pik TV Media Box - HMB2213PW22TS

## Tesco

1. Hudl 2 - Hudl 2
2. Hudl HT7S3 - Hudl HT7S3
3. Hudl HT7S3 - hudl ht7s3
4. W032I\_C3 - W032I\_C3
5. hudl 2 - Hudl 2

## Tesla

1. Tablet\_L7\_1 - Tesla L7.1
2. Tesla SP3.3 Lite - Tesla\_SP3.3 Lite
3. Tesla Smartphone 3.3 - Tesla\_SP3.3
4. Tesla Smartphone 6.3 - Tesla\_SP6.3
5. Tesla Smartphone 9.1 - Tesla\_SP9.1

## Tetratab

1. TF10EA2 - CASEBOOK\_3

## Thinpad

1. TH805 - TH805

## Thomson

1. PRIMO7 Tablet - PRIMO7
2. PRIMO8 Tablet - PRIMO8
3. TCL Percee TV - Percee TV
4. TEO10 - SPTEO10BK16
5. TLink 455 - TLINK455

## Timovi

1. Infini Lite 2 - Infini\_Lite\_2
2. Infini MX Pro - Infini MX Pro
3. Timovi Infini MX - Infini MX

## Tinhvan

1. TA80TA1 - TA80TA1

## Tobii DynaVox

1. T10+ - T10+
2. T7 - T7

## Tonino Lamborghini

1. Antares - TL66
2. Antares - Antares
3. TL99 - TL99
4. TL99G - TL99G

## Toshiba

1. WDPF-703TI - Hikari-iFrame/WDPF-703TI

2. tosebook01 - DB50
3. tostab05 - AT200
4. tostabg1 - LT170
5. A204 - A204
6. A205 - A205
7. AT10-A/AT15-A (Japan: AT503) - AT10-A
8. AT10-A/AT15-A (Japan: AT503) - AT502
9. AT10-A/AT15-A (Japan: AT503) - AT503
10. AT10-A/AT15-A (Japan: AT503) - AT503\_HEMS
11. AT100 - AT100
12. AT100 - Tostab03
13. AT10LE-A/AT15LE-A/AT10PE-A/AT15PE-A (Japan: AT703) - AT10LE-A
14. AT10LE-A/AT15LE-A/AT10PE-A/AT15PE-A (Japan: AT703) - AT10PE-A
15. AT10LE-A/AT15LE-A/AT10PE-A/AT15PE-A (Japan: AT703) - AT702
16. AT10LE-A/AT15LE-A/AT10PE-A/AT15PE-A (Japan: AT703) - AT703
17. AT400 - AT300SE
18. AT400 - AT400
19. AT7-A - AT374
20. AT7-A - AT7-A
21. AT7-B - AT374
22. AT7-B - AT7-B
23. AT7-C - A17
24. AT7-C - AT7-C
25. JP:REGZA Tablet AT570 Others:TOSHIBA AT270 - AT270
26. JP:REGZA Tablet AT570 Others:TOSHIBA AT270 - AT470
27. JP:REGZA Tablet AT570 Others:TOSHIBA AT270 - AT570
28. JPN:REGZA Tablet AT500 Other countries:TOSHIBA AT300 - AT300
29. JPN:REGZA Tablet AT500 Other countries:TOSHIBA AT300 - AT500
30. JPN:REGZA Tablet AT500 Other countries:TOSHIBA AT300 - AT500a
31. JPN:REGZA Tablet AT830 Other countries:TOSHIBA AT330 - AT330
32. JPN:REGZA Tablet AT830 Other countries:TOSHIBA AT330 - AT830
33. L4300 - I4300
34. L5450 - I5400
35. L5450 - I5450
36. L5450/L5400 - I5400
37. L5450/L5400 - I5450
38. L5450/L5400 - I5400
39. L5450/L5400 - I5450
40. L5450C - I3453
41. L5450C - I5450
42. L5450ME - I5400
43. L5450ME - I5450
44. L5550/L5551/L5552 - I5550
45. L9450 - I9450
46. Mozart - Mozart
47. STB10 - TOSPASB
48. Thrive 7 - AT1S0
49. tt300/tt301/tt302 - Mozart

## Toughshield

1. R200 - R200
2. T700\_TABLET - T700

## Trekstor

1. SurfTab ST70204-3 - SurfTab ST70204-3
2. SurfTab breeze 9.6 quad - TrekStor SurfTab breeze 9.6 quad
3. SurfTab breeze 9.6 quad 3G - TrekStor SurfTab breeze 9.6 quad 3G
4. SurfTab breeze 9.6 quad 3G - TrekStor SurfTab breeze 9.6 quad 3G
5. SurfTab xintron i 7.0 - st70408\_4
6. SurfTab xintron i 7.0 - st70408\_4\_coho
7. toline tab 7 - toline tab 7
8. toline tab 8 - toline tab 8
9. toline tab 8.9 - toline tab 8.9

## Trimble Navigation

1. MM50 - MobileMapper50\_4G
2. MM50 - TDC100\_4G
3. MM50 - MobileMapper50\_WiFi
4. MM50 - TDC100\_WiFi
5. PeopleNet ConnectedTablet - MS5
6. TD-520 - TD520
7. TDC500 Handheld - TDC500
8. TDC500 Handheld - TDC500
9. TDC800 Handheld - TDC800
10. TDC800 Handheld - TDC800
11. TDI 600 - Rugged Tablet
12. TDI 600 - TDI 600
13. Trimble ConnectedTablet - MS5

## Trio

1. 7.85 - TRIO-7.85
2. 7.85 vQ - Trio 7.85 vQ
3. AXS 3G - Trio AXS 3G
4. MINI - Trio MINI
5. MST711 - MST711
6. Stealth G4 7 - Trio-Stealth-G4-7
7. Stealth-G4-101 - Trio-Stealth G4 10.1
8. Stealth-G4-7.85 - Trio-Stealth-G4-7.85

## True

1. SMART 4G GEN C 4.0" - SMART 4G GEN C 4.0
2. SMART 4G GEN C 5.0" - SMART 4G GEN C 5.0
3. SMART 4G M1 - SMART 4G M1
4. SMART 4G M1 Plus - SMART 4G M1 Plus
5. SMART 4G Octa 5.5 - SMART 4G Octa 5.5
6. SMART TAB 4G M1 - SMART TAB 4G M1
7. SMART\_Champ\_4inch - SMART Champ 4.0

## Tunisie Telecom

1. Star Trail by TT - StarTrail TT

## Turbonet

1. ADR1776 - ADR1776
2. TN500A1 - TN500A1
3. TN500A2 - TN500A2

4. TurboTab E1 - TN800A1

## **Turk Telekom**

1. E4 - E4

## **UNOWHY**

1. Q00Q - Q00Q-V41
2. UNOWHY - SQOOL-V41

## **USA111**

1. IRULU X11 - iRULU X11
2. IRULU X9 - X9
3. Irulu X7 - X7
4. iRULU V3 - iRULU\_V3
5. iRULU V3 - iRULU\_V3
6. iRULU\_V4 - V4

## **Ubiquiti**

1. USS - USS
2. UVP - UVP
3. UVP Executive - UVP Executive
4. UVP Pro - UVP Pro
5. UVP-X - UVP-X
6. UVP-X - UVP-X

## **Ulefone**

1. Armor 2 - Armor\_2
2. MIX - MIX
3. Power 2 - Power\_2
4. S8 - Ulefone S8
5. S8 Pro - S8\_Pro
6. S8\_ - Ulefone S8

## **Umax**

1. UMAX - visionbook P55 LTE
2. VisionBook10Q - VB\_10Q\_Plus
3. VisionBook\_P55\_LTE\_Pro - VisionBook P55 LTE Pro

## **Umx(Ultimate Mobile Experience)**

1. U2VR - U2VR
2. U673C - U673C

## **Utopia**

1. UH0342 UHTABLET10.1INCH - UH0342

## **V7**

1. Zyro - V7 Zyro

## **VAIO**

1. VA-10J - JCI VA-10J
2. VPA051 - VPA051

## **VENSTAR**

1. VENSTAR2050 - VENSTAR2050

## **VIBE Z**

1. K910 - Lenovo K910

## **VSN**

1. V.35 - V.35

## **VT**

1. MB300 - SmartTV

## **Vaxcare**

1. VAX114 - VAX114

## **Venturer**

1. i7 - i7

## **VerD**

1. E1 - E1

## **Verizon Wireless**

1. Ellipsis 10 - QTAIR7
2. Ellipsis 7 - QMV7A
3. Ellipsis 7 - QMV7B
4. Ellipsis 7 (QMV7A) - QMV7A
5. Ellipsis 7 (QMV7B) - QMV7B
6. Ellipsis 8 - QTAQZ3
7. Ellipsis 8 HD - QTASUN1
8. Ellipsis 8 HD - QTASUN2
9. Ellipsis 10 HD - QTAXIA1
10. Gizmo Tab - QTASUN2
11. QTAQZ3KID - QTAQZ3KID
12. Wear24 - Wear24
13. ZenPad Z8 - P008

## **Vernee**

1. M5 - vernee\_M5
2. Thor E - Thor E
3. Thor Plus - Thor Plus

## **Verssed**

1. FW8977-ED - FW8977-ED

## **Vertex**

1. Impress Action - Impress\_Action
2. Impress Dune - Impress\_Dune
3. Impress Eagle - Impress\_Eagle
4. Impress Fortune - Impress\_Fortune
5. Impress Grip - Impress\_Grip
6. Impress Groove - Impress\_Groove
7. Impress Lightning - Impress\_Lightning
8. Impress Lion (3G) - Impress\_Lion\_3G
9. Impress Lion (4G) - Impress\_Lion\_4G
10. Impress Lotus - Impress\_Lotus
11. Impress Luck - Impress\_Luck
12. Impress Ra (4G) - Impress\_Ra
13. Impress Saturn - Impress\_Saturn
14. Impress Tor - Impress\_Tor



## Vertu

1. Aster - Aster
2. Aster T - Aster T
3. Constellation V - Constellation V
4. Constellation X - CONSTELLATION X
5. Signature Touch - Signature Touch
6. Signature Touch - Signature Touch
7. Signature Touch - Signature Touch L
8. Ti - VERTU Ti

## Verykool

1. S5019 - verykoolS5019
2. S5019 - verykools5019
3. SL5050 - verykoolSL5050
4. SL5200 - verykoolSL5200
5. SL5560 - verykoolSL5560
6. T7445 - verykoolT7445
7. s4513 - verykool Luna II S4513
8. s5007 - verykoolS5007
9. s5021 - verykool Wave Pro s5021
10. s5021 - verykoolS5021
11. s5027 - verykoolS5027
12. s5028 - verykoolS5028
13. s5034 - verykools5034
14. s5035 - verykools5035
15. s5526 - verykools5526
16. s5527 - verykools5527
17. s5528 - verykools5528
18. verykoolSL5565 - verykoolSL5565
19. verykools5205 - verykools5205

## Vestel

1. 5000 - Vestel\_5000
2. 5000 - Vestel\_5000\_Dual
3. 5000\_2gb - Vestel\_5000\_2gb
4. 5530 - Vestel\_5530
5. 5530 - Vestel\_5530\_Dual
6. Farabi - Farabi
7. Riga - Venus E3
8. S7252 - S7252
9. Teos - Venus V5
10. V TAB 7" LITE II - VTAB7LITEII
11. V TAB 7\'' LITE II - V\_TAB\_7\_LITE\_II
12. V TAB 7011 - V\_TAB\_7011
13. V TAB 7015 - V\_TAB\_7015
14. V TAB 7020 - V\_TAB\_7020
15. V TAB 7020A - V\_TAB\_7020A
16. V TAB 7025 - V\_TAB\_7025
17. V TAB 7810 - V\_TAB\_7810
18. V TAB 8010 - V\_TAB\_8010
19. V TAB 8029 - V\_TAB\_8029
20. V TAB 9.7\'' PRO - VT97PRO
21. V Tab 7010 - V Tab 7010
22. V3 5580 Dual - V3\_5580\_Dual
23. VP100+ - 10.1Myros
24. VP100+ - VP100+
25. VP73 - VP73
26. VP73 - VP73\_Hyundai
27. VP73 - VP73\_Myros
28. VP73 - VP73\_Vox
29. VP73 - VP73\_le

30. VP74 - VP74
31. VP74 - VP74-Celcus
32. VP74 - VP74-Finlux
33. VP74 - VP74-Luxor
34. VP74 - VP74-Orava
35. VP74 - VP74-Telefunken
36. VP74 - VP74-Vox
37. VSP145M - VSP145M
38. VSP250g - VSP250g
39. VSP250s - VSP250s
40. VSP355g - VSP355g
41. VSP355s - VSP355s
42. VT10E - VT10E
43. VT10E2 - S TAB 10\'' II
44. VT10E2 - V TAB 10\'' LITE
45. VT10E2 - VT10E2
46. VT785P2 - V TAB 7.85\'' LITE
47. VT785P2 - VT785P2-Celcus
48. VT785P2 - VT785P2-Cleverpad
49. VT785P2 - VT785P2-Finlux
50. VT785P2 - VT785P2-Vestel
51. VTAB 1040 - V\_TAB\_1040
52. Venus V3 5010 - Venus\_V3\_5010
53. Venus V3 5020 - Venus\_V3\_5020
54. Venus V3 5030 - Venus\_V3\_5030
55. Venus V3 5040 - Venus\_V3\_5040
56. Venus V3 5040 - Venus\_V3\_5040\_2GB
57. Venus V3 5070 - Venus\_V3\_5070
58. Venus V3 5570 - Venus\_V3\_5570
59. Venus V3 5580 - Venus\_V3\_5580
60. Venus V4 - Venus\_V4
61. Venus Z10 - Venus Z10

## ViewSonic

1. ViewPad\_IR10Q - IR10Q
2. ViewPad\_IR8Q - IR8Q
3. v350 - ViewSonic-V350
4. viewpad4 - ViewSonic-ViewPad4
5. viewpad7 - ViewPad7
6. viewpad7x - ViewPad7X
7. viewpad7x - ViewPad7x
8. Q5 - Viewphone Q5
9. VSD221 - VSD221
10. VSD231 - VSD231
11. VSD241 Smart Display - VSD241
12. VSD242 - VSD242
13. ViewPad I7M - VIEWPAD I7M
14. ViewPad IR7Q - IR7Q
15. ViewPad\_M10 - ViewPad\_M10
16. ViewPadi7Q - vsi7q\_1
17. ViewPadi7Q - vsi7q\_1\_coho
18. ViewPadi8Q - vsi8q\_1
19. ViewPadi8Q - vsi8q\_1\_coho

## Visiontouch

1. Inspire - Vision Touch Inspire
2. Life - VisionTouchLife

## Visual Land

1. Prestige Elite10QI - Elite10QI
2. Prestige Elite10QL - Elite10QL

3. Prestige Elite10QS - Elite10QS
4. Prestige Elite11Q - Elite11Q
5. Prestige Elite13Q - Elite13Q
6. Prestige Elite7QL - Elite7QL
7. Prestige Elite7QS - Elite7QS
8. Prestige Elite8QI - Elite8QI
9. Prestige Elite8QL - Elite8QL
10. Prestige Elite9QL - Elite9QL
11. Prestige Prime10ES - Prime10ES
12. Prestige Prime10SE - Prime10SE
13. Prestige Prime11E - Prime11E

## Vitsmo

1. Zero Spin - Zero\_Spin

## Vivo

1. 1601 - vivo 1601
2. 1601 - vivo 1713
3. 1609 - vivo 1609
4. PD1304DL - vivo Y13iL
5. PD1419V - vivo Y923
6. PD1612 - vivo PD1612
7. PD1612 - vivo Y67
8. V1 - vivo V1
9. V1Max - vivo Y37
10. V3 - vivo V3
11. V3 - vivo V3
12. V3Lite - vivo V3Lite
13. V3M A - vivo PD1524B
14. V3Max - vivo V3Max
15. V3Max + A - vivo V3Max+ A
16. V3Max A - vivo PD1523A
17. V5Plus - vivo V5Plus
18. X5 - vivo X5
19. X5M - vivo X5M
20. X5Max - vivo X5Max
21. X5Max S - vivo X5Max S
22. X5MaxV - vivo X5MaxV
23. X5Pro - vivo X5Pro
24. X5Pro D - vivo X5Pro D
25. X5Pro V - vivo X5Pro V
26. X6A - vivo PD1415A
27. X6D - vivo X6D
28. X6Plus A - vivo PD1515A
29. X6Plus D - vivo PD1501D
30. X6S A - vivo X6S A
31. X6SPlusA - vivo PD1515BA
32. X7 - vivo X7
33. X7Plus - vivo X7Plus
34. X9 - vivo X9
35. X9i - vivo X9i
36. Xplay5A - vivo PD1522A
37. Xplay5A - vivo Xplay5A
38. Xplay6 - vivo Xplay6
39. Y11 - vivo Y11
40. Y15 - vivo Y15
41. Y15S - vivo Y15S
42. Y21 - vivo Y21
43. Y21L - vivo Y21L
44. Y22 - vivo Y22
45. Y27 - vivo Y27

46. Y28 - vivo Y28
47. Y31 - vivo Y31
48. Y31 - vivo Y31
49. Y31L - vivo Y31L
50. Y31i - vivo 1707
51. Y31i - vivo Y31
52. Y31i - vivo Y31i
53. Y33 - vivo Y33
54. Y35 - vivo Y35
55. Y35A - vivo Y35A
56. Y51 - vivo Y51
57. Y51A - vivo Y51A
58. Y53 - vivo 1606
59. Y53L - vivo PD1628
60. Y55 - vivo 1603
61. Y55A - vivo Y55
62. Y55s - vivo 1610
63. Y66 - vivo Y66
64. Y67 - vivo Y67
65. Y937 - vivo Y937
66. vivo 1611 - vivo 1611
67. vivo 1714 - vivo 1714
68. vivo 1716 - vivo 1716
69. vivo X20 - vivo PD1709
70. vivo X20 - vivo 1721
71. vivo X20Plus - vivo PD1710
72. vivo X9Plus - vivo X9Plus
73. vivo X9s - vivo PD1616B
74. vivo X9s - vivo X9s
75. vivo X9s Plus - vivo PD1635
76. vivo X9s Plus - vivo X9s Plus
77. vivo Y65 - vivo 1719

## Viwa

1. X2 - X2

## Vizio

1. StreamPlayer - VAP430
2. VTAB1008 - VTAB1008
3. XR6M10 - XR6M10
4. XR6P10 - XR6P10

## Vodafone

1. 785 - Vodafone 785
2. 895 - VF-895N
3. Smart N8 - VFD 610
4. Smart Tab 4 - Vodafone Smart Tab 4
5. Smart Tab N8 - VFD 1300
6. Smart V8 - VFD 710
7. Smart first 7 - VFD 200
8. Smart mini 7 - VFD 300
9. Smart mini 7 dual - VFD 301
10. Smart platinum 7 - VFD 900
11. Smart prime 7 - VFD 600
12. Smart turbo 7 - VFD 500
13. Smart turbo 7 - VFD 501
14. Smart turbo 7 dual - VFD 502
15. Smart ultra 6 - Vodafone Smart ultra 6
16. Smart ultra 7 - Maxis VFD700
17. Smart ultra 7 - VFD 700
18. Smart\_Tab\_3G - Vodafone Smart Tab 3G

19. Smart\_Tab\_4G - Vodafone Smart Tab 4G
20. Tab Prime 7 - VFD 1400
21. Tab Prime 7 - VFD1400
22. Tab mini 7 - VFD 1100
23. VDF 600 - VFD 600
24. VF-1296 - Vodacom Power Tab 10
25. VF-1296 - Vodafone Tab grand 6
26. VF-1397 - VF-1397
27. VF-1497 - VF-1497
28. VF685 - VF685
29. VF695 - VF695
30. VFD 200 - VFD 200
31. Vodacom Kicka VE - VFD 100
32. Vodafone Smart E8 - VFD 510
33. Vodafone Smart E8 - VFD 511
34. Vodafone Smart E8 - VFD 512
35. Vodafone Smart E8 - VFD 513
36. Vodafone Smart mini - Vodafone 875
37. Vodafone Smart mini 7 ve - VFD 310
38. Vodafone Smart mini 7 ve dual - VFD 311

## Vonino

1. Druid\_L10 - Druid\_L10
2. Epic E8 - Epic E8
3. Epic P7 - Epic\_P7
4. Jax X - Jax X
5. Jax X A6 - Jax X
6. Jax\_X\_TM - Jax X
7. Magnet M1\_A7 - Magnet M1
8. Magnet\_M1 - Magnet M1
9. MusicPAD - MusicPAD
10. Navo QS - Navo\_QS
11. Navo S - Navo S
12. Pluri B7 - Pluri B7
13. Pluri C7 - Pluri C7
14. Pluri C8 - Pluri C8
15. Pluri M7 - Pluri\_M7
16. Pluri M7 A6 - Pluri\_M7
17. Pluri Q8 - Pluri\_Q8
18. Pluri Q8 A6 - Pluri\_Q8
19. Pluri Q8 TM - Pluri\_Q8
20. Pluri\_B7\_TM - Pluri\_B7\_TM
21. Pluri\_G7 - Pluri G7
22. Volt S - Volt S
23. Volt\_X - Volt\_X
24. Xavy G7 - Xavy G7
25. Xavy L8 A6 - Xavy\_L8
26. Xavy T7 A6 - Xavy\_T7
27. Xavy\_L8 - Xavy\_L8
28. Xavy\_T7 - Xavy\_T7
29. Xylo P - Xylo P
30. Xylo X A6 - Xylo X
31. Xylo\_X\_TM - Xylo X
32. ZUN XO - ZUN XO
33. ZUN XO A6 - ZUN XO
34. Zun X - Zun X
35. Zun X A6 - Zun X
36. Zun XS - Zun XS
37. jax\_S - Jax\_S

## Vsun

1. MARS Touch - MARS TOUCH
2. MARS Nocam - MARS NOCAM
3. MARS Note - MARS NOTE
4. MERCURY Tough - MERCURY Tough
5. SATURN Selfie - SATURN SELFIE

## Vulcan

1. Pulse 7 - VT0701A08
2. Pulse 7S - VT0702A16
3. TA10TA2 - TA10TA2
4. TA71CA1 - TA71CA1
5. TA71CA2 - TA71CA2
6. TEMPO S11 - VS4011
7. TEMPO S12 - VS5012
8. TEMPO S13 - VS5513
9. TEMPO S16 - VS5016
10. Tempo 5 - VP5004A
11. VT0702A08 - VT0702A08
12. Vulcan Rhyme 10A - VT1002A16
13. Vulcan Rhyme 10J - VT1003J16
14. Vulcan Rhyme 7C - VT0703C16
15. Vulcan VR5533 - VR5533
16. Vulcan VR6031 - VR6031
17. Vulcan VR6032 - VR6032

## W.e.

1. WETAB700DG - WETAB700DG
2. WeTab1004B - WeTab1004B

## Wacom

1. Cintiq Companion Hybrid 13HD - Cintiq Companion Hybrid 13HD

## Walton

1. LT750 - LT750
2. Primo F7s - Primo F7s
3. Primo GF6 - Primo GF6
4. Primo GH5 - Primo GH5
5. Primo GH5 mini - Primo GH5 mini
6. Primo GM2 - Primo GM2
7. Primo GM2 Plus - Primo GM2 Plus
8. Primo HM4 - Primo HM4
9. Primo NF3 - Primo NF3
10. Primo NX3 - Primo\_NX3
11. Primo NX4 - Primo NX4
12. Primo NX4 mini - Primo NX4 mini
13. Primo R4 - Primo R4
14. Primo R4 Plus - Primo R4 Plus
15. Primo RM2 mini - Primo RM2 mini
16. Primo RX5 - Primo RX5
17. Primo S5 - Primo\_S5
18. Primo S6 - Primo S6
19. Primo X4 - Primo X4
20. Primo X4 Pro - Primo X4 Pro
21. Primo ZX2 - Primo\_ZX2
22. Primo ZX2 Lite - Primo ZX2 Lite
23. Primo ZX2 mini - Primo ZX2 mini
24. Primo ZX3 - Primo ZX3
25. Primo\_RM3 - Primo RM3

## WeTek

1. Play - Play

## Weimei

1. WEIMEI NEON2 - WEIMEI\_NEON2

## Welgate

1. WA-U420D - WA-U420D

## Wenu

1. Kate - Kate

## Wiko

1. B-KOOL - B-KOOL
2. BIRDY - BIRDY
3. BLOOM - BLOOM
4. Barry - BARRY
5. CINK SLIM 2 - CINK SLIM 2
6. DARKFULL - DARKFULL
7. DARKFULL - Dream
8. DARKNIGHT - DARKNIGHT
9. DARKNIGHT - X-tremer
10. FEVER - FEVER
11. FEVER - FEVER
12. FEVER - Ridge 4G-Fever
13. FREDDY - FREDDY
14. FREDDY - FREDDY
15. GETAWAY - GETAWAY
16. GOA - GOA
17. HARRY - HARRY
18. HARRY - HARRY
19. HIGHWAY - HIGHWAY
20. HIGHWAY 4G - HIGHWAY 4G
21. HIGHWAY PURE - HIGHWAY PURE
22. HIGHWAY SIGNS - HIGHWAY SIGNS
23. HIGHWAY STAR - HIGHWAY STAR
24. IGGY - Cynus F4
25. IGGY - Golf
26. IGGY - IGGY
27. JERRY - JERRY
28. JERRY - JERRY
29. JERRY MAX - JERRY MAX
30. JERRY2 - JERRY2
31. JIMMY - JIMMY
32. K-KOOL - K-KOOL
33. K-KOOL - K-KOOL
34. KENNY - KENNY
35. KENNY - KENNY
36. KITE - KITE
37. LENNY - LENNY
38. LENNY2 - LENNY2
39. LENNY2 - LENNY2
40. LENNY3 - LENNY3
41. LENNY3 MAX - LENNY3 MAX
42. Lenny4 - Lenny4
43. Lenny4 Plus - Lenny4 Plus
44. MACARON - MACARON
45. P4903JP - P4903JP
46. PULP - PULP
47. PULP 4G - PULP 4G

48. PULP FAB - PULP FAB
49. PULP FAB - SLIDE2
50. PULP FAB 4G - PULP FAB 4G
51. RAINBOW - RAINBOW
52. RAINBOW 4G - RAINBOW 4G
53. RAINBOW JAM - RAINBOW JAM
54. RAINBOW JAM - RAINBOW JAM
55. RAINBOW JAM - RAINBOW JAM
56. RAINBOW LITE - RAINBOW LITE
57. RAINBOW LITE 4G - RAINBOW LITE 4G
58. RAINBOW LITE 4G - RAINBOW LITE 4G
59. RAINBOW LITE 4G - RAINBOW LITE 4G
60. RAINBOW LITE 4G - RAINBOW LITE 4G
61. RAINBOW LITE 4G - RAINBOW JAM 4G
62. RAINBOW UP - RAINBOW UP
63. RAINBOW UP 4G - RAINBOW UP 4G
64. RIDGE - RIDGE
65. RIDGE 4G - RIDGE 4G
66. RIDGE FAB 4G - RIDGE FAB 4G
67. ROBBY - ROBBY
68. ROBBY - ROBBY
69. ROBBY2 - ROBBY2
70. SELFY - SELFY
71. SELFY 4G - SELFY 4G
72. SLIDE - SLIDE
73. SUGAR F7 mini - SUGAR F7 mini
74. SUGAR S9 - SUGAR S9
75. SUNNY - SUNNY
76. SUNNY - SUNNY
77. SUNNY - SUNNY
78. SUNNY - SUNNY
79. SUNNY - SUNNY
80. SUNNY - SUNNY
81. SUNNY MAX - SUNNY MAX
82. SUNNY MAX - SUNNY MAX
83. SUNNY2 - SUNNY2
84. SUNSET - SUNSET
85. SUNSET2 - SUNSET2
86. Sunny2 Plus - Sunny2 Plus
87. TOMMY - TOMMY
88. TOMMY - TOMMY
89. TOMMY2 - TOMMY2
90. TOMMY2 - TOMMY2
91. TOMMY2 - TOMMY2
92. Tommy2 Plus - Tommy2 Plus
93. U FEEL - U FEEL
94. U FEEL - U FEEL
95. U FEEL - U FEEL
96. U FEEL FAB - SUGAR Y7 MAX
97. U FEEL FAB - SUGAR Y8
98. U FEEL FAB - U FEEL FAB
99. U FEEL GO - U FEEL GO
100. U FEEL LITE - U FEEL LITE
101. U FEEL LITE - U FEEL LITE
102. U FEEL PRIME - U FEEL PRIME
103. U PULSE - U PULSE
104. U PULSE LITE - U PULSE LITE
105. VIEW - View
106. View - View
107. View Prime - View Prime
108. View XL - View XL
109. WAX - WAX



110. WIM - WIM
111. WIM - WIM
112. WIM Lite - WIM Lite
113. WIM Lite - WIM Lite

## Wileyfox

1. Spark - Wileyfox Spark
2. Spark - Wileyfox Spark +
3. Spark - Wileyfox Spark X
4. Spark X - Wileyfox Spark X
5. Storm - Wileyfox Storm
6. Swift - Wileyfox Swift
7. Swift 2 - Swift 2
8. Swift 2 - Swift 2 Plus
9. Swift 2 - Swift 2 X
10. Swift 2 - Wileyfox Swift 2 Plus

## Wink

1. City S - Wink\_City\_S
2. Glory SE - Wink Glory SE
3. Share SE - Wink\_Share\_SE
4. World SE - Wink World SE

## Wintec

1. T730 - Clear
2. T730 - T730
3. T750 - Clear

## Wistron

1. DW-21(A) - DW-21(A)
2. W1011A - W1011A

## Woongjin

1. WoongjinThinkbig - BP-1001

## X-TIGI

1. V3+ - X-TIGI\_V3+
2. X\_TIGI\_A1 - X\_TIGI\_A1
3. X\_TIGI\_A1Plus - X\_TIGI\_A1Plus

## Xiaomi

1. China - MiTV
2. HM 1SC - HM 1AC
3. HM 1SC - HM 1S
4. HM 1SC - HM 1SC
5. HM 1SC - HM 1SW
6. HM 1SLTETD - 2014501
7. HM 1STD - 2014011
8. HM 2A - 2014502
9. HM 2A - HM 2A
10. HM 2LTE-BR - 2014819
11. HM 2LTE-CMCC - 2014813
12. HM 2LTE-CT - 2014812
13. HM 2LTE-CU - 2014811
14. HM 2LTE-IN - 2014818
15. HM 2LTE-SA - 2014817
16. HM NOTE 1LTETD - HM NOTE 1LTE
17. HM NOTE 1LTETD - HM NOTE 1LTETD
18. HM NOTE 1LTETD - HM NOTE 1LTEW

19. HM NOTE 1S CT - HM NOTE 1S
20. HM NOTE 1S CT - gucci
21. HM NOTE 1TD - HM NOTE 1TD
22. HM NOTE 1W - HM NOTE 1W
23. HM Note 2 - Redmi Note 2
24. Hong Mi - 2013022
25. MI 2 - MI 2
26. MI 2 - MI 2S
27. MI 2A - MI 2A
28. MI 3W - MI 3W
29. MI 4LTE - MI 4C
30. MI 4LTE - MI 4LTE
31. MI 4LTE - MI 4W
32. MI 4LTE-CT - MI 4LTE
33. MI 4s - MI 4S
34. MI 5C - MI 5C
35. MI 5C - Meri
36. MI 5X - MI 5X
37. MI 5s Plus - MI 5s Plus
38. MI MAX - MI MAX
39. MI MAX - MI MAX
40. MI MAX 2 - MI MAX 2
41. MI NOTE LTE - MI NOTE LTE
42. MI NOTE Pro - MI NOTE Pro
43. MI Note 3 - Mi Note 3
44. MI PAD - MI PAD
45. MI PAD 3 - MI PAD 3
46. MI6 - MI 6
47. MIBOXPRO - MiBOX\_PRO
48. MIPAD2 - MI PAD 2
49. MITV3S - MiTV3S
50. MITV3S-55/60 - MiTV3S
51. MITV3S-55/60 - MiTV4
52. MIX - MIX
53. MIX - lithium
54. MIX 2 - MIX 2
55. MIX 2 - Mi MIX 2
56. Mi 3 - MI 3
57. Mi 4c - Mi-4c
58. Mi 4i - Mi 4i
59. Mi 5 - MI 5
60. Mi 5s - MI 5s
61. Mi A1 - MI A1
62. Mi A1 - Mi A1
63. Mi Box - MIBOX3
64. Mi Note - MI NOTE LTE
65. Mi Note2 - Mi Note 2
66. MiBOX1S - MiBOX1S
67. MiBOX2 - MiBOX2
68. MiBOX3S - MiBOX3S
69. MiBOX\_mini - MiBOX\_mini
70. MiTV2 - MiTV2
71. Redmi - 2013023
72. Redmi 3 - Redmi 3
73. Redmi 3 - ido
74. Redmi 3S - Redmi 3S
75. Redmi 4 - Redmi 4
76. Redmi 4 Pro - Redmi 4
77. Redmi 4A - Redmi 4A
78. Redmi 4X - Redmi 4X
79. Redmi 4X - santoni
80. Redmi Note 3 - Redmi Note 3

81. Redmi Note 3 - Redmi Note 3
82. Redmi Note 3 - Redmi Note 3
83. Redmi Note 4 - Redmi Note 4
84. Redmi Note 4 - Redmi Note 4X
85. Redmi Note 4 - Redmi Note 4
86. Redmi Note 5A - Redmi Note 5A
87. Redmi Note 5A - Redmi Y1
88. Redmi Note 5A - Redmi Note 5A
89. Redmi Pro - Redmi Pro
90. TELEBEE - MIBOX3

## Xolo

1. Era 2X 2GB - Era 2X
2. Era 2X 3GB - Era 2X 3GB
3. Era3 - Era 3
4. XOLO ERA 2V - Era 2V
5. era1X - era1X

## Xplore Technologies

1. RangerX - iX101T1
2. RangerX - iX101T1-2G
3. XSLATE\_D10 - iX101B1

## YU

1. YUNICORN - YU5530
2. YUNIQUE - YU4711
3. YUPHORIA - YU5010
4. YUPHORIA - YU5010A
5. YUREKA - YU5510
6. YUREKAS - YU5200
7. Yunique 2 - YU5011
8. Yureka - AO5510
9. Yureka - YU5510
10. Yureka - YU5510A
11. Yureka - YUREKA
12. Yureka Black - YU5040
13. Yureka Black - YU5041
14. Yureka Note - YU 6000

## Yes

1. M631Y - M631Y
2. STING - STING

## Yezz

1. 5.5M - 5.5M
2. 5E - 5E

## Yota Devices

1. C9660 - C9660
2. YotaPhone2 - YD201

## Yuho

1. Y2 - YUHO\_Y2
2. Y2\_PRO - YUHO\_Y2\_PRO

## ZTE

1. BUL\_P726G - ZTE-RACER
2. D930 - D930
3. Grand-S - ZTE Grand S

4. N720 - N720
5. N720\_Micromax - Micromax A60
6. N721 - N721
7. N721 - ZTE-U N721
8. N721 - ZTE\_U N721
9. N8010\_CT - ZXY-ZTE\_N8010
10. N8010\_CT\_BL - ZXY-ZTE\_N8010
11. N8300\_CT - ZXY-ZTE N8300
12. NX501 - NX501
13. P117A11 - ZTE U807
14. P117A13 - ZTE U807N
15. P117A20qHD - ZTE U817
16. P117A30 - ZTE U935
17. P117T21 - ZTE U960E
18. P188T10 - ZTE U956
19. P188T20 - ZTE U819
20. P253A20 - ZTE V768
21. P722G - ZTE-U X876
22. P726CU - ZTE-U X850
23. P726G - ZTE-LINK
24. P726G - ZTE-RACER
25. P726G - ZTE-WAVE
26. P726N - soft stone
27. P726N - soft-stone
28. P726VV - ZTE-U X850
29. P727A - VF945
30. P729B - Orange Tactile internet 2
31. P729C - ZTE-BLADE
32. P810A10 - ZTE U880s2
33. P810A20 - ZTE U887
34. P810T01 - ZTE U791
35. P810T01 - ZTE U791(OPEN)
36. P810T02 - ZTE U793
37. P825T10 - ZTE U808
38. P825T10 - ZTE U808(OPEN)
39. QB7211 - QB7211
40. QB7211 - STARTEXT II
41. T77 - T77
42. T9 - ZTE-T T9
43. TWM\_P726G - Taiwan Mobile T2
44. U788 - ZTE U788
45. U790 - ZTE U790
46. U795 - ZTE U795
47. U805 - ZTE-T U805
48. U812 - ZTE-T U812
49. U830 - ZTE-T U830
50. U880E - ZTE U880E
51. U880F1 - ZTE U880F1
52. U880s - ZTE U880s
53. U885 - ZTE U885
54. U930HD - ZTE U930HD
55. U960s - ZTE-T U960s
56. U960s2 - ZTE U960s2
57. U960s3 - ZTE U960s3
58. V6020\_Claro - V6020\_Claro
59. V66 - V66
60. V68 - V68
61. V71A - STARTAB
62. V71A - V71B
63. V768 - ZTE V768
64. V8100\_Z55 - V8100\_Z55
65. V8200\_EE\_UK - V8200\_EE\_UK

66. V8200\_OSK - V8200-Memphis-orange-Slovakia  
67. V8300\_Z39 - V8300\_Z39  
68. V857 - ZTE-U V857  
69. V875m - ZTE-U V875m  
70. X500 - X500  
71. X500 - X500\_USA\_General  
72. X500MMB - ZTE-C X500  
73. ZTE-Grand-S - ZTE Grand S  
74. ZTE-N5 - ZTE N5  
75. ZTE-N807 - ZTE N807  
76. ZTE-N880F - ZTE N880F  
77. ZTE-N881E - ZTE N881E  
78. ZTE-N881F - ZTE N881F  
79. ZTE-N980 - ZTE N980  
80. ZTE-N988 - ZTE N988  
81. ZTE-U-V889F - ZTE-U V889F  
82. ZTE-V72A - V72A  
83. ZTE-V889F - ZTE V889F  
84. ZTE-V955 - ZTE V955  
85. ZTE-V956 - ZTE V956  
86. ZTE-V988 - ZTE Grand S  
87. ZTE-V988 - ZTE V988  
88. amigo - Android Edition Starnaute  
89. arthur - N860  
90. atlas40 - Acqua  
91. atlas40 - BLADE III  
92. atlas40 - MEDION LIFE P4012  
93. atlas40 - N880E  
94. atlas40 - ZTE G882  
95. atlas40 - ZTE N880E  
96. atlas40 - ZTE N881D  
97. atlas40 - ZTE N882E  
98. atlas40 - ZTE R22  
99. atlas40 - ZTE T22  
100. atlas40 - ZTE V880E  
101. atlas40 - ZTE V889D  
102. banana - ZTE-C N780  
103. blade - MegaFon SP-A5  
104. blade - V880  
105. blade - ZTE Libra  
106. blade - ZTE-BLADE  
107. blade2 - ATLAS W  
108. blade2 - BLADEII  
109. blade2 - Blade S  
110. blade2 - San Francisco II  
111. bladeplus - 008Z  
112. bladeplus - V881  
113. bladeplus - ZTE V881  
114. bladeplus - ZTE-U V881  
115. cardhu - ZTE-T T98  
116. crane-zte7 - K75  
117. dana - ZTE N970  
118. deepblue - ZTE N790  
119. deepblue - ZTE N790S  
120. enterprise - ZTE U5  
121. enterprise\_HK - ZTE Grand Era  
122. enterprise\_U950 - ZTE U950  
123. enterprise\_U985 - ZTE U985  
124. enterprise\_V985 - ZTE V985  
125. frosty - ZTE T82  
126. hct77\_ics2 - V865M  
127. hope - N855D  
128. hope - N855D\_PERFECTUM  
129. hope - N855D\_YM  
130. hope - ZTE N855  
131. hope - ZTE N855D  
132. hope - ZTE N855D+  
133. iliamna - ZTE T81  
134. joe - V871  
135. joe - Vodafone 945  
136. kiska - ZTE V9800  
137. mooncake2 - MTS-SP102  
138. mooncake2 - Mtag 281  
139. mooncake2 - ZTE N660  
140. msm7627a - ZTE N880F  
141. msm7627a - ZTE V889F  
142. msm7627a - ZTE-U V889F  
143. msm7630\_zteu960 - ZTE U960D  
144. msm7630\_zteu960 - ZTE-T U960  
145. nice - A21plus  
146. nice - ICE  
147. nice - KIS II  
148. nice - Orange Zali  
149. nice - Turkcell Maxi Plus 5  
150. nice - V880S  
151. nice - ZTE Kis Pro  
152. okmok - ZTE V9500  
153. p173a10 - ZTE-U V760  
154. r750 - ZTE-C R750  
155. racer2 - ARIZONA  
156. racer2 - Kyivstar Shine  
157. racer2 - RACERII  
158. racer2 - RacerII  
159. racer2 - Turkcell T11  
160. racer2 - ZTE-U V859  
161. roamer - ZTE Roamer  
162. roamer - ZTE roamer  
163. roamer - ZTE-C N760  
164. roamer2 - Dubai  
165. roamer2 - Dublin  
166. roamer2 - N788\_BASHA  
167. roamer2 - Orange Dublin  
168. roamer2 - V788D  
169. roamer2 - ZTE N788  
170. roamer2 - ZTE N789  
171. roamer2 - ZTE V788D  
172. roundtop - ZTE V9800  
173. sailboat - ZTE V875  
174. sean - N850  
175. skate - KPN Smart 200  
176. skate - MEDION LIFE P4310  
177. skate - Monte Carlo  
178. skate - Optimus Monte Carlo  
179. skate - Orange Monte Carlo  
180. skate - ZTE N960  
181. skate - ZTE Skate  
182. skate - ZTE V960  
183. skate - ZTE-SKATE  
184. skate - ZTE-Skate  
185. skate - ZTE-U V960  
186. skateplus - Skate4.3 H  
187. turies - Android Edition StarText  
188. turies - Vodafone Smart Chat  
189. turies - ZTE-Tureis

190. v9plus - BASE Tab 7.1  
191. v9plus - Light Tab 2  
192. v9plus - Light Tab 2W  
193. v9plus - MegaFon V9+  
194. v9plus - TT102  
195. v9plus - Telenor Touch Pad  
196. v9plus - V9+  
197. v9plus - V9A  
198. v9plus - V9e+  
199. v9plus - ZTE V10  
200. v9plus - ZTE V9A  
201. ventana - ZTE U970  
202. ventana\_U880F - ZTE U880F  
203. ventana\_U930 - ZTE U930  
204. warp2 - N861  
205. whistler - STARADDICT II  
206. whistler - V961  
207. whistler - ZTE Grand X  
208. whistler - ZTE V970T  
209. whistler - ZTE-Mimosa X  
210. z788 - ZTE U788+  
211. z795 - ZTE U795+  
212. zte\_v857 - ZTE-U V857  
213. 009Z - 009Z  
214. 009Z - ZTE V882  
215. 009Z - ZTE V886j  
216. 402ZT - 402ZT  
217. A1P - A1P  
218. A1R - A1  
219. A1R - A1R  
220. A2 - A2  
221. A2015 - ZTE A2015  
222. A2016 - ZTE A2016  
223. A2017 - ZTE A2017  
224. A2017G - ZTE A2017G  
225. A2017U - ZTE A2017U  
226. A2018 - ZTE A2018  
227. A880 - ZTE A880  
228. AV-ATB100 - AV-ATB100  
229. AXON 7 mini - AXON 7 mini  
230. AXON WATCH - AXON WATCH  
231. AXON WATCH - ZTE W1010  
232. Amazing A1 - Amazing A1  
233. Amazing A30 - Amazing A30  
234. Amazing A50 - Amazing A50  
235. Amazing P6 - Amazing P6  
236. Amazing X2 - Amazing X2  
237. Amazing X5s - Amazing X5s  
238. Amazing X6 - Amazing X6  
239. Amazing X7 - Amazing X7  
240. Amazing p5\_Lite - Amazing p5\_Lite  
241. Amazing\_X3s - Amazing\_X3s  
242. Amazing\_X3s\_16G - Amazing\_X3s\_16G  
243. Android edition by sfr STARADDICT - Android edition  
by sfr STARADDICT  
244. Andromax G46D1Z - Andromax G46D1Z  
245. Avea inTouch 2 - Avea inTouch 2  
246. Avea inTouch 4 - Avea inTouch 4  
247. Avea inTouch 4 - ZTE Blade V220  
248. B2015 - ZTE B2015  
249. B2016 - ZTE B2016  
250. B2017G - ZTE B2017G

251. B2017G - ZTE B2017G  
252. B2017G - ZTE B2017G  
253. B760E - B760E  
254. B760E - B760H  
255. B790 - ZTE B790  
256. B860AV2 - B860AV2  
257. B860H - B860H  
258. B860H - B860H V1.0  
259. B860H - B860H V1.1  
260. B880 - ZTE B880  
261. B880 - ZTE B880  
262. BA510 - ZTE BA510  
263. BA520 - ZTE BA520  
264. BA601 - ZTE BA601  
265. BA602 - ZTE BA602  
266. BA602T - ZTE BA602T  
267. BA603 - ZTE BA603  
268. BA610C - ZTE BA610C  
269. BA610T - ZTE BA610T  
270. BA610T - ZTE BA610T  
271. BA611C - ZTE BA611C  
272. BA611T - ZTE BA611T  
273. BA611T - ZTE BA611T  
274. BA910 - ZTE BA910  
275. BA910 - ZTE BA910  
276. BA910T - ZTE BA910T  
277. BASE Lutea 2 - BASE Lutea 2  
278. BGH Joy X5 - BGH Joy X5  
279. BLADE - ZTE-BLADE  
280. BLADE A110 - BLADE A110  
281. BLADE A110 - ZTE BLADE A110  
282. BLADE A112 - ZTE BLADE A112  
283. BLADE A310 - Blade A310  
284. BLADE A310 - ZTE BLADE A310  
285. BLADE A320 - BLADE A320  
286. BLADE A320 - ZTE BLADE A320  
287. BLADE A506 - ZTE BLADE A506  
288. BLADE A510 - BLADE A510  
289. BLADE A510 - Blade A510  
290. BLADE A510 - ZTE BLADE A510  
291. BLADE A512 - ZTE BLADE A512  
292. BLADE A520 - BLADE A520  
293. BLADE A520 - ZTE BLADE A520  
294. BLADE A521 - BLADE A521  
295. BLADE A521 - ZTE BLADE A521  
296. BLADE A6 - BLADE A6  
297. BLADE A601 - ZTE BLADE A601  
298. BLADE A602 - BLADE A602  
299. BLADE A602 - ZTE BLADE A602  
300. BLADE A610 - BLADE A610  
301. BLADE A610 - ZTE BLADE A610  
302. BLADE A610C - ZTE BLADE A610C  
303. BLADE A612 - ZTE BLADE A612  
304. BLADE A910 - BLADE A910  
305. BLADE A910 - ZTE BLADE A910  
306. BLADE B112 - ZTE BLADE B112  
307. BLADE III - Skate Pro  
308. BLADE III - ZTE BLADE III  
309. BLADE III - ZTE Blade III  
310. BLADE III\_IL - BLADE III\_IL  
311. BLADE L0510 - ZTE BLADE L0510  
312. BLADE L0510 - ZTE Blade L5 Plus



313. BLADE L110 - Blade L110  
314. BLADE L110 - ZTE BLADE L110  
315. BLADE L111 - ZTE BLADE L111  
316. BLADE L5 PLUS - ZTE BLADE L5 PLUS  
317. BLADE L7 - BLADE L7  
318. BLADE L7 - ZTE BLADE L7  
319. BLADE V0710 - ZTE BLADE V0710  
320. BLADE V0720 - ZTE BLADE V0720  
321. BLADE V0730 - ZTE BLADE V0730  
322. BLADE V0800 - ZTE BLADE V0800  
323. BLADE V0820 - ZTE BLADE V0820  
324. BLADE V0850 - ZTE BLADE V0850  
325. BLADE V7 - BLADE V7  
326. BLADE V7 - ZTE BLADE V7  
327. BLADE V7 LITE - ZTE BLADE V0720  
328. BLADE V7 LITE - ZTE BLADE V7 LITE  
329. BLADE V7 PLUS - ZTE BLADE V7 PLUS  
330. BLADE V8 - BLADE V8  
331. BLADE V8 MINI - BLADE V8 MINI  
332. BLADE V8 MINI - ZTE BLADE V8 MINI  
333. BLADE V8 SE - BLADE V8 SE  
334. BLADE V8 mini - BLADE V8 mini  
335. BOLTON - N9560  
336. BV0701 - ZTE BV0701  
337. BV0701 - ZTE V0721  
338. BV0710 - ZTE BV0710  
339. BV0710T - ZTE BV0710T  
340. BV0720 - ZTE BV0720  
341. BV0720T - ZTE BV0720T  
342. BV0730 - ZTE BV0730  
343. BV0800 - ZTE BV0800  
344. BV0850 - ZTE BV0850  
345. Baker - Baker  
346. Beeline E600 - Beeline E600  
347. Beeline Smart 2 - Beeline Smart 2  
348. Blade - 003Z  
349. Blade - Android Edition StarTrail  
350. Blade - BASE lutea  
351. Blade - BLADE\_N880  
352. Blade - Beeline E400  
353. Blade - Kyivstar Spark  
354. Blade - MF8604  
355. Blade - Movistar Prime  
356. Blade - N880  
357. Blade - Netphone 701  
358. Blade - Optimus San Francisco  
359. Blade - Orange San Francisco  
360. Blade - Orange Tactile internet 2  
361. Blade - RTK V8  
362. Blade - San Francisco  
363. Blade - V8502  
364. Blade - WayteQ Libra  
365. Blade - XCD35  
366. Blade - ZTE Libra  
367. Blade - ZTE V880  
368. Blade - ZTE-BLADE  
369. Blade - ZTE-C N880S  
370. Blade - ZTE-LIBRA  
371. Blade - ZTE-Libra  
372. Blade - ZTE-U V880  
373. Blade - a5  
374. Blade A210 - ZTE BLADE A210  
375. Blade A210 - ZTE Blade A210  
376. Blade A315 - ZTE Blade A315  
377. Blade A410 - Blade A410  
378. Blade A410 - ZTE Blade A410  
379. Blade A452 - NOS FIVE  
380. Blade A452 - ZTE Blade A452  
381. Blade A460 - A460-T  
382. Blade A460 - Blade A460  
383. Blade A460 - ZTE BLADE A460  
384. Blade A460 - ZTE Blade A460  
385. Blade A460 - ZTE T610  
386. Blade A462 - ZTE Blade A462  
387. Blade A465 - Blade A465  
388. Blade A465 - ZTE Blade A465  
389. Blade A470 - ZTE Blade A470  
390. Blade A475 - BGH JOY X2  
391. Blade A475 - Blade A475  
392. Blade A475 - ZTE Blade A475  
393. Blade A475 - ZTE Blade L4 Pro  
394. Blade A476 - BLADE E01  
395. Blade A476 - ZTE Blade A476  
396. Blade A510 - Blade A510  
397. Blade A510 - ZTE BLADE A601  
398. Blade A511 - Blade A511  
399. Blade A511 - ZTE Blade A511  
400. Blade A515 - ZTE Blade A515  
401. Blade A570 - ZTE Blade A570  
402. Blade Apex - Blade Apex  
403. Blade Apex - ZTE Blade Apex  
404. Blade Apex2 - Blade Apex2  
405. Blade Apex2 - ZTE Blade Apex2  
406. Blade Apex3 - ZTE Blade Apex3  
407. Blade C312 - ZTE Blade C312  
408. Blade C340 - ZTE Blade C340  
409. Blade C340 - ZTE T220  
410. Blade C340 - ZTE V812  
411. Blade C370 - NOS NOVU  
412. Blade C370 - ZTE BLADE C370  
413. Blade C370 - ZTE Blade C370  
414. Blade D6 Lite 3G - ZTE Blade D6 Lite 3G  
415. Blade D6 Lite 4G - ZTE Blade D6 Lite 4G  
416. Blade G - ZTE Blade G  
417. Blade G LTE - ZTE Blade G LTE  
418. Blade G LTE - Blade G LTE  
419. Blade G Lux - BGH Joy Smart A6  
420. Blade G Lux - BGH Joy Smart A6D  
421. Blade G Lux - Blade G Lux  
422. Blade G Lux - DIGICEL DL800  
423. Blade G Lux - MEO Smart A40  
424. Blade G Lux - Orange Tado  
425. Blade G Lux - ZTE Blade G Lux  
426. Blade G Lux - ZTE Kis3 max  
427. Blade G Lux - ZTE V830W  
428. Blade HN - ZTE Blade HN  
429. Blade III - Blade III  
430. Blade III - Skate Pro  
431. Blade III - ZTE Blade III  
432. Blade III Pro - ZTE Blade III Pro  
433. Blade L110 - Blade L110  
434. Blade L110 - ZTE Blade L110  
435. Blade L2 - BGH Joy Smart AXS  
436. Blade L2 - BGH Joy Smart AXS D

437. Blade L2 - Blade L2  
438. Blade L2 - MEO Smart A75  
439. Blade L2 - ZTE Blade L2  
440. Blade L2 Plus - Blade L2 Plus  
441. Blade L3 - Blade L3  
442. Blade L3 - DIGICEL DL910  
443. Blade L3 - MEO Smart A80  
444. Blade L3 - X8607  
445. Blade L3 - ZTE Blade L3  
446. Blade L3 Apex - ZTE Blade L3 Apex  
447. Blade L3 Lite - Blade L3 Lite  
448. Blade L3 Lite - ZTE Blade L3 Lite  
449. Blade L3 Plus - Blade L3 Plus  
450. Blade L3 Plus - ZTE Blade L3 Plus  
451. Blade L315 - ZTE Blade L315  
452. Blade L370 - ZTE Blade L370  
453. Blade L5 - Blade L5  
454. Blade L5 - ZTE Blade L5  
455. Blade L5 Plus - Blade L5 Plus  
456. Blade L5 Plus - ZTE Blade L5 Plus  
457. Blade L6 - ZTE Blade L6  
458. Blade L6 - ZTE Blade V6 Lite  
459. Blade Q Lux - BGH Joy Smart A7G  
460. Blade Q Lux - Beeline Pro  
461. Blade Q Lux - UZTE Blade Q Lux  
462. Blade Q Lux - ZTE Blade A430  
463. Blade Q Lux - ZTE Blade Q Lux  
464. Blade Q Lux - ZTE Blade Q Lux 3G  
465. Blade Q Lux - ZTE Fit 4G Smart  
466. Blade Q Lux - ZTE T311  
467. Blade Q Lux - Blade Q Lux  
468. Blade Q Lux - ZTE Blade Q Lux  
469. Blade Q Mini - ZTE Blade Q Mini  
470. Blade Q2 - Blade Q2  
471. Blade Q3 - ZTE Blade Q3  
472. Blade Q3 - ZTE T230  
473. Blade S - Blade S  
474. Blade S - Blade S  
475. Blade S Lite - Blade S Lite  
476. Blade S6 - Blade S6  
477. Blade S6 - LS-5008  
478. Blade S6 - NOS SLIM  
479. Blade S6 Flex - ZTE Blade S6 Flex  
480. Blade S6 Lite - Blade S6  
481. Blade S6 Lite - Blade S6 Lite  
482. Blade S6 Lite - ZTE T912  
483. Blade S6 Plus - Blade S6 Plus  
484. Blade V - Vodafone Blade V  
485. Blade V - ZTE Blade V  
486. Blade V+ - Blade V+  
487. Blade V2 - ZTE Blade V2  
488. Blade V220 - ZTE Blade V220  
489. Blade V580 - Blade V580  
490. Blade V580 - Turk Telekom TT175  
491. Blade V580 - ZTE Blade V580  
492. Blade V6 - BGH Joy V6  
493. Blade V6 - Blade V6  
494. Blade V6 - ZTE Blade V6  
495. Blade V6 - ZTE T660  
496. Blade V6 - ZTE T663  
497. Blade V6 Max - Blade V6 Max  
498. Blade V6 Plus - Blade V6 Plus  
499. Blade V6 Plus - ZTE Blade V6 Plus  
500. Blade V770 - ZTE Blade V770  
501. Blade VEC - ZTE Blade VEC  
502. Blade Vec - Blade Vec  
503. Blade Vec - ZTE Blade Vec  
504. Blade Vec - ZTE Geek 2  
505. Blade Vec 4G - ZTE Blade Vec 4G  
506. Blade Vec Pro - ZTE Blade Vec Pro  
507. Blade X Max - Z983  
508. Bland A610 - ZTE BLADE A610  
509. Bland A610 - ZTE Blade A610  
510. Bolton - Z986DL  
511. Bouygues Telecom Bs 351 - Bouygues Telecom Bs 351  
512. Bouygues Telecom Bs 402 - A4C  
513. Bouygues Telecom Bs 402 - Amazing A4C  
514. Bouygues Telecom Bs 402 - Bouygues Telecom Bs 402  
515. Bouygues Telecom Bs 402 - ZTE Blade Q Mini  
516. C2016 - ZTE C2016  
517. C2017 - ZTE C2017  
518. C310 - L8301  
519. C310 - Movitel M8410  
520. C310 - ZTE Blade C310  
521. C310 - ZTE C310  
522. C880 - ZTE C880  
523. C880A - ZTE C880A  
524. C880D - ZTE C880D  
525. C880S - ZTE C880S  
526. C880S - ZTE C880S  
527. C880S - ZTE C880S  
528. C880S - ZTE C880S  
529. C880U - ZTE C880U  
530. CELL C EMPIRE E8 - CELL C EMPIRE E8  
531. Chapel - Z831  
532. ConeXis A1 - ConeXis A1  
533. ConeXis X1 - ConeXis X1  
534. ConeXis X2 - ConeXis X2  
535. Cosmote Smart Share - Cosmote Smart Share  
536. Cosmote Xplore - Cosmote Xplore  
537. Cosmote Xplore - Cosmote Xplore  
538. Dialog Q143L - Dialog Q143L  
539. Extreme E8 - Extreme E8  
540. FT142D - FT142D  
541. Fanfare 2 - Z815  
542. G601U - ZTE G601U  
543. G717C - ZTE G717C  
544. G718C - ZTE G718C  
545. G719C - ZTE G719C  
546. G720C - ZTE G720C  
547. G720T - ZTE G720T  
548. G720T - ZTE G720T  
549. GEEK II 4G - ZTE GEEK II 4G  
550. GEEK II Pro - ZTE GEEK II Pro  
551. GEEK II Pro - ZTE M1001  
552. Geek - ZTE Geek  
553. Geek 2 LTE - ZTE Geek 2 LTE  
554. Geek 2 pro - ZTE Geek 2 pro  
555. Grand Era - ZTE Grand Era  
556. Grand Memo - Grand Memo  
557. Grand Memo LTE - ZTE Grand Memo  
558. Grand Memo LTE - ZTE Grand Memo LTE

559. Grand S Flex - Grand S Flex  
560. Grand S Flex - ZTE Grand S Flex  
561. Grand S II - ZTE Grand S II  
562. Grand S II - ZTE S221  
563. Grand S II - ZTE Grand S II  
564. Grand S II LTE - ZTE Grand S II LTE  
565. Grand X - Grand X  
566. Grand X - Grand X(M)  
567. Grand X - ZTE Grand X Classic  
568. Grand X - ZTE V970  
569. Grand X - ZTE V970M  
570. Grand X - ZTE-U V970M  
571. Grand X - tmn smart a18  
572. Grand X 2 - Amazing A7  
573. Grand X 2 - ZTE Grand X 2  
574. Grand X 2 - ZTE V968  
575. Grand X 2 - ZTE V969  
576. Grand X In - Grand X In  
577. Grand X In - STARADDICT II Plus  
578. Grand X In - ZTE Grand X In  
579. Grand X Max 2 - Z988  
580. Grand X Pro - Blade Super  
581. Grand X Pro - Grand X Pro  
582. Grand X Pro - KPN Smart 300  
583. Grand X Quad Lite - Amazing A6  
584. Grand X Quad Lite - V8602  
585. Grand X Quad Lite - ZTE Grand X Quad Lite  
586. Grand X Quad Lite - ZTE Grand X2  
587. Grand X Quad Lite - ZTE Skate 2  
588. Grand X Quad Lite - ZTE V967S  
589. Grand X2 In - Grand X2 In  
590. Grand X2 In - ZTE Grand X2 In  
591. GrayJoy - N9136  
592. Helios X1 - Helios X1  
593. I-O DATA - AV-ATB100  
594. Infinity X^2 mini - Infinity X^2 mini  
595. Jasper LTE - Z718TL  
596. K81 - K81  
597. K813 - ZTE-K813  
598. K83 - Amazing\_P8  
599. K83 - K83  
600. K85 - K85  
601. K88 - K88  
602. K92 - K92  
603. K97 - K97  
604. K97 - ZTE K97  
605. KIS - KIS  
606. KIS PLUS - KIS PLUS  
607. KPN Smart 400 - KPN Smart 400  
608. Karbonn\_A1 - Karbonn\_A1  
609. Kis 3 - MEO SMART A16  
610. Kis 3 - MEO Smart A16  
611. Kis 3 - MOCHE SMART A16  
612. Kis 3 - ZTE Kis 3  
613. Kis 3 - ZTE V811  
614. Kis Lite - ZTE Kis Lite  
615. Kis Pro - Optimus Zali  
616. Kis Pro - ZTE Kis Pro  
617. Kis Q - ZTE Kis Q  
618. Kis T3 - Kis T3  
619. LEO M1 - V883M  
620. LEO M1 - ZTE LEO M1  
621. LEO S1 - V972M  
622. LEO S1 - ZTE LEO S1  
623. LEO S2 - ZTE LEO S2  
624. LEO\_Q1 - V765M  
625. LEO\_Q1 - ZTE LEO Q1  
626. LEO\_Q1 - ZTE V765M  
627. LEO\_Q1 - ZTE\_CLARO\_Q1  
628. LEO\_Q1 - ZTE\_LEO\_Q1  
629. LEO\_Q1 - mobifone M9001  
630. LS-5503 - LS-5503  
631. LS-5503 - ZTE Blade S6 Plus  
632. Lannister - Z863DL  
633. Leopard MF800 - Leopard MF800  
634. Light Tab 2 - Light Tab 2  
635. M8402 - M8402  
636. M901C - ZTE M901C  
637. MEDION LIFE P4310 - MEDION LIFE P4310  
638. MEDION Smartphone LIFE E3501 - MEDION Smartphone LIFE E3501  
639. MF97A - MF97A  
640. MF97B - MF97B  
641. MF97B - MF97B\_ROGERS  
642. MF97B\_T - MF97B\_T  
643. MF97E - MF97E  
644. MF97G - MF97G  
645. MF97W - MF97W  
646. MO-01J - MO-01J  
647. MO-01K - MO-01K  
648. MS4A - MS4A  
649. MS4A - MS4A  
650. MTC SMART Run 4G - MTC SMART Run 4G  
651. Majesty Pro LTE - Z798BL  
652. Momodesign MD Droid - Momodesign MD Droid  
653. Movistar Express - Movistar Express  
654. Movistar Motion - Movistar Motion  
655. N5L - ZTE N5L  
656. N5S - ZTE N5S  
657. N720 - N720  
658. N720 - ZTE-U N720  
659. N720 - ZTE\_U N720  
660. N762 - N762  
661. N765\_APT - N765\_APT  
662. N790 - N790  
663. N795 - ZTE N795  
664. N798 - ZTE N798  
665. N798+ - ZTE N798+  
666. N798+ - ZTE N798+  
667. N799D - N799D  
668. N799D - ZTE N799D  
669. N800 - N800  
670. N8000\_USA\_Cricket - N8000\_USA\_Cricket  
671. N8000\_USA\_RS - N8000\_USA\_RS  
672. N8000\_WHITE\_CKT - N8000\_WHITE\_CKT  
673. N8010\_APT - N8010\_APT  
674. N810 - N810  
675. N817 - N817  
676. N818 - N818  
677. N818 - ZTE N818  
678. N8300\_Reliance - N8300\_Reliance  
679. N8303 - N8303  
680. N850 - N850  
681. N850L - N850L



682. N855D - N855D  
683. N860 - N860  
684. N860 - Warp  
685. N861 - N861  
686. N880E - ZTE N880E  
687. N880G - ZTE N880G  
688. N900 - ZTE N900  
689. N900D - ZTE N900D  
690. N909 - ZTE N909  
691. N909D - ZTE N909D  
692. N910 - ZTE-N910  
693. N9100 - N9100  
694. N9101 - N9101  
695. N9120 - ZTE N9120  
696. N9130 - N9130  
697. N9132 - N9132  
698. N9180 - N9180  
699. N918St - BGH Joy Smart AXS II  
700. N918St - BGH Joy Smart AXS II D  
701. N918St - N918St  
702. N918St - ZTE N918St  
703. N919 - ZTE N919  
704. N919D - N919D  
705. N919D - ZTE N919D  
706. N928Dt - ZTE N928Dt  
707. N940Sc - N940Sc  
708. N9500 - N9500  
709. N9510 - N9510  
710. N9511 - ZTE\_N9511  
711. N9515 - N9515  
712. N9516 - N9516  
713. N9518 - N9518  
714. N9520 - N9520  
715. N9521 - N9521  
716. N958St - N958St  
717. N9810 - N9810  
718. N983 - ZTE N983  
719. N9835 - N9835  
720. N9835 - ZTE N9835  
721. N986 - N986  
722. N986 - ZTE N986  
723. N986D - N986+  
724. N986D - N986D  
725. NE501J - NE501J  
726. NE501J - V5  
727. NE501J - ZTE\_V5  
728. NOS NEVA 80 - NOS NEVA 80  
729. NOS NOVU II - NOS NOVU II  
730. NOS NOVU III - NOS NOVU III  
731. NX402 - NX402  
732. NX403A - NX403A  
733. NX404H - NX404H  
734. NX405H - NX405H  
735. NX406E - NX406E  
736. NX40X - NX402  
737. NX40X\_APT - NX40X  
738. NX40X\_APT - NX40X\_APT  
739. NX501 - NX501  
740. NX501\_APT - NX501\_APT  
741. NX503A\_Z4 - NX503A\_Z4  
742. NX503J - NX503J  
743. NX505J - NX505J  
744. NX506J - NX506J  
745. NX507J - NX507H  
746. NX507J - NX507J  
747. NX508J - NX508J  
748. NX510J - NX510J  
749. NX511J - NX511J  
750. NX511J\_V3 - NX511J\_V3  
751. NX512J - NX512J  
752. NX513J - NX513J  
753. NX521J - BGH Joy Smart AXS II  
754. NX521J - NX521J  
755. NX523J\_V1 - NX523J\_V1  
756. NX527J\_V1 - NX527J\_V1  
757. NX529J - NX529J  
758. NX531J - NX531J  
759. NX535J - NX535J  
760. NX541J - NX541J  
761. NX549J - NX549J  
762. NX551J - NX551J  
763. NX563J - NX563J  
764. NX569J - NX569J  
765. NX573J - NX573J  
766. NX575J - NX575J  
767. NX591J - NX591J  
768. NX597J - NX597J  
769. NX601J - NX601J  
770. NX907J - NX907J  
771. NeXT X1 - VFD 710  
772. OWN One Plus - OWN One Plus  
773. Optimus Barcelona - Optimus Barcelona  
774. Orange Hi 4G - Orange Hi 4G  
775. Orange Hi 4G - Orange Hi 4G  
776. Orange Monte Carlo - Orange Monte Carlo  
777. Orange Novi - Orange Novi  
778. Orange Reyo - Avea inTouch 3 Large  
779. Orange Reyo - Blade Q Maxi  
780. Orange Reyo - Orange Reyo  
781. Orange Reyo - ZTE Blade Q Maxi  
782. Orange Rono - Orange Rono  
783. Orange Rono - Orange Rono  
784. Orange Zali - Orange Zali  
785. Own One - Own One  
786. P\_C880S - ZTE P\_C880S  
787. Preo Teknosa P1 - Preo Teknosa P1  
788. Q101T - ZTE Q101T  
789. Q201T - ZTE Q201T  
790. Q2S-C - ZTE Q2S-C  
791. Q2S-T - ZTE Q2S-T  
792. Q301C - ZTE Q301C  
793. Q301C - ZTE Q301C  
794. Q301T - ZTE Q301T  
795. Q302C - ZTE Q302C  
796. Q5-C - ZTE Q5-C  
797. Q5-T - ZTE Q5-T  
798. Q5-T - ZTE Q5-T  
799. Q501T - ZTE Q501T  
800. Q501U - ZTE Q501U  
801. Q503U - ZTE Q503U  
802. Q505T - ZTE Q505T  
803. Q507T - ZTE Q507T  
804. Q508U - ZTE Q508U  
805. Q509T - Amazing X5



806. Q509T - MTC SMART Run 4G  
807. Q509T - ZTE Blade A450  
808. Q509T - ZTE Blade V2 Lite  
809. Q509T - ZTE Q509T  
810. Q519T - ZTE Q519T  
811. Q529C - ZTE Q529C  
812. Q529C - ZTE Q529C  
813. Q529E - ZTE Q529E  
814. Q529T - ZTE Q529T  
815. Q7 - ZTE Q7  
816. Q7 - ZTE Q7  
817. Q7 - ZTE Q7  
818. Q7-C - ZTE Q7-C  
819. Q701C - ZTE Q701C  
820. Q705U - ZTE Q705U  
821. Q801C - ZTE Q801C  
822. Q801L - ZTE Q801L  
823. Q801T - ZTE Q801T  
824. Q801U - ZTE Q801U  
825. Q802C - ZTE Q802C  
826. Q802D - ZTE Q802D  
827. Q802T - ZTE Q802T  
828. Q805T - ZTE Q805T  
829. Q806T - ZTE Q806T  
830. Quartz - Quartz  
831. Quartz - ZW10  
832. R83 - ZTE R83  
833. RACER III mini - RACER III mini  
834. Racer - Carl  
835. Racer - MTC 916  
836. Racer - MTS-SP100  
837. Racer - Movistar Link  
838. Racer - RTK D1  
839. Racer - Racer  
840. Racer - TaiWan Mobile T2  
841. Racer - V8402  
842. Racer - Vip Droid  
843. Racer - XCD 28  
844. Racer - ZTE X850  
845. Racer - ZTE-C N600  
846. Racer - ZTE-C N600+  
847. Racer - ZTE-LINK  
848. Racer - ZTE-RACER  
849. Racer - ZTE-U V852  
850. Racer - ZTE-U X850  
851. Rook from EE - Rook from EE  
852. S118 - Grand S Lite  
853. S118 - ZTE S118  
854. S2004 - ZTE S2004  
855. S2005 - ZTE S2005  
856. S2007 - ZTE S2007  
857. S2010 - ZTE S2010  
858. S2010 - ZTE S2010  
859. S2010 - ZTE S2010  
860. S2010 - ZTE S2010  
861. S2014 - ZTE S2014  
862. S2015 - ZTE S2015  
863. S8Q - S8Q  
864. SKATE - ZTE-SKATE  
865. SMART Start 3 - SMART Start 3  
866. STAR - ZTE GEEK II Pro 4G  
867. STAR - ZTE S2002  
868. STAR - ZTE STAR  
869. STAR - ZTE Star 1  
870. STARNAUTE II - STARNAUTE II  
871. STARTRAIL 4 - Avea inTouch 3  
872. STARTRAIL 4 - STARTRAIL 4  
873. STARTRAIL 4 - ZTE Blade Q  
874. STARXTREM - STARXTREM  
875. STARXTREM 4 - STARXTREM 4  
876. Sapphire 3G - N818S  
877. Skate - ZTE Skate  
878. Skate Pro - Skate Pro  
879. SmartTab10 - SmartTab10  
880. SmartTab7 - SmartTab7  
881. SoshPhone 3 - SoshPhone 3  
882. Soshphone 4G - Soshphone 4G  
883. Soshphone 4G - Soshphone 4G  
884. Spro 2 - 502ZT  
885. Spro 2 - MF97B  
886. Spro 2 - MF97V  
887. Spro 2 - Spro 2  
888. Spro 2 - Spro 2 LTE  
889. Spro 2 - ZKB2A  
890. Spro2 - Spro2  
891. Stack - Z799VL  
892. Switch X1 - ZTE Switch X1  
893. Switch X1 - ZTE V796  
894. T-Mobile Vivacity - T-Mobile Vivacity  
895. T12 - ZTE T12  
896. T221 - Blade C341  
897. T221 - DIGICEL DL755  
898. T221 - KIS C341  
899. T221 - ZTE Blade A5  
900. T221 - ZTE Blade AF5  
901. T221 - ZTE Blade C341  
902. T221 - ZTE Blade C342  
903. T221 - ZTE T221  
904. T221 - ZTE T230  
905. T28 - ZTE T28  
906. T28 - ZTE T28 Prepaid  
907. T3 - T3  
908. T325 - ZTE T325  
909. T520 - ZTE T520  
910. T60 - ZTE T60  
911. T617 - ZTE T617  
912. T620 - ZTE T620  
913. T630 - ZTE T630  
914. T760 - ZTE T760  
915. T790 - ZTE T790  
916. T792 - ZTE B792  
917. T792 - ZTE T792  
918. T80 - ZTE T80  
919. T81 - ZTE T81  
920. T82 - ZTE T82  
921. T83 - ZTE T83  
922. T84 - ZTE R84  
923. T84 - ZTE T84  
924. T85 - T85  
925. T86 - Amazing X1  
926. T86 - ZTE T86  
927. T88 - ZTE T88  
928. T911 - ZTE T911  
929. T912 - ZTE T912

930. T920 - ZTE T920  
931. TQ150 - TQ150  
932. TURKCELL T40 - TURKCELL T40  
933. TURKCELL T50 - TURKCELL T50  
934. TURKCELL T50 - TURKCELL TURBO T50  
935. TURKCELL T60 - TURKCELL T60  
936. TURKCELL T60 - TURKCELL T60  
937. TURKCELL T70 - TURKCELL T70  
938. TURKCELL T80 - TURKCELL T80  
939. Telenor Touch Plus - Telenor Touch Plus  
940. Tempo - N9131  
941. Turkcell Maxi Plus 5 - Turkcell Maxi Plus 5  
942. U N721 - ZTE-U N721  
943. U V760 - MD Smart  
944. U V760 - Telenor Touch Mini  
945. U V760 - ZTE-U V760  
946. U V760 - ZTE-U V856  
947. U V760 - ZTE-U V857  
948. U V760 - moii E598  
949. U5S - ZTE U5S  
950. U809 - ZTE U809  
951. U816 - ZTE U816  
952. U817 - ZTE U817  
953. U818 - ZTE U818  
954. U879 - ZTE U879  
955. U880 - ZTE-T U880  
956. U889 - ZTE U889  
957. U9180 - U9180  
958. U9180 - ZTE U9180  
959. U968 - ZTE U968  
960. U969 - ZTE U969  
961. U9815 - ZTE U9815  
962. U988S - ZTE U988S  
963. UZTE V790 - UZTE V790  
964. UZTE V817 - UZTE V817  
965. Uhura - Z968  
966. Ulytm 5.2 - Ulytm 5.2  
967. V55 - V55  
968. V5S - ZTE Grand Memo lite  
969. V5S - ZTE V5S  
970. V6500 - Etisalat Smartphone  
971. V6500 - ZTE-V6500  
972. V70 - ZTE V70  
973. V7073 - ZTE V7073  
974. V72 - MT7A  
975. V72 - ZTE V72  
976. V72 - myPad P4 Lite  
977. V72C - V72C  
978. V72M - V72M  
979. V768 - ZTE V768  
980. V769M - V769M  
981. V769M - ZTE LEO Q2  
982. V769M - ZTE V769M  
983. V779M - ZTE V779M  
984. V790 - ZTE V790  
985. V791 - V791  
986. V791 - ZTE V791  
987. V792C - ZTE V792C  
988. V793 - Amazing A3  
989. V793 - Cellcom 4G  
990. V793 - M9000  
991. V793 - Telcel T20  
992. V793 - ZTE KIS Flex  
993. V793 - ZTE V793  
994. V793 - tmn smart a6  
995. V795 - BGH Joy Smart A1  
996. V795 - V795(A3S)  
997. V795 - ZTE B795  
998. V795 - ZTE KIS II  
999. V795 - ZTE KIS II PRO  
1000. V795 - ZTE Kis II  
1001. V795 - ZTE V795  
1002. V797 - VIETTEL V8411  
1003. V797 - ZTE V797  
1004. V8000\_USA\_Cricket - V8000\_USA\_Cricket  
1005. V807 - Amazing A4  
1006. V807 - Beeline E700  
1007. V807 - Leopard MF900  
1008. V807 - UZTE V807  
1009. V807 - V8501  
1010. V807 - ZTE BLADE C  
1011. V807 - ZTE V807  
1012. V807 - ZTE V889S  
1013. V808 - UZTE V808  
1014. V808 - ZTE V808  
1015. V809 - BGH Joy Smart A2  
1016. V809 - ZTE Blade C2  
1017. V809 - ZTE T809  
1018. V809 - ZTE V809  
1019. V809 - meo smart a12  
1020. V811 - Beeline Smart2  
1021. V811 - ZTE V811  
1022. V8110 - V8110  
1023. V811C - ZTE V811C  
1024. V811W - ZTE V811  
1025. V811W - ZTE V811W  
1026. V813W - ZTE Blade C2 Plus  
1027. V813W - ZTE V813W  
1028. V815W - Amazing A4S  
1029. V815W - B8405  
1030. V815W - BGH Joy Smart A5C  
1031. V815W - BGH Joy Smart A5d  
1032. V815W - KIS II Max  
1033. V815W - SMART Start  
1034. V815W - UZTE GRAND V7  
1035. V815W - ZTE B815  
1036. V815W - ZTE B816  
1037. V815W - ZTE Blade Buzz  
1038. V815W - ZTE Blade C320  
1039. V815W - ZTE Blade Q1  
1040. V815W - ZTE Kis II Max  
1041. V815W - ZTE Kis II Max Plus  
1042. V815W - ZTE Kis II Max plus  
1043. V815W - ZTE Maxx  
1044. V815W - ZTE T815  
1045. V815W - ZTE T816  
1046. V815W - ZTE V815W  
1047. V815W - ZTE V816W  
1048. V817 - V817  
1049. V817 - ZTE V817  
1050. V817 - ZTE V817  
1051. V818 - ZTE Blade 2  
1052. V818 - ZTE V818  
1053. V8200plus - V8200plus

1054. V8285 - V8285  
1055. V829 - BGH Joy Smart A3  
1056. V829 - Blade G Pro  
1057. V829 - V8507  
1058. V829 - ZTE Blade G Plus  
1059. V829 - ZTE Blade G Pro  
1060. V829 - ZTE V829  
1061. V831W - Amazing A5S  
1062. V831W - UZTE Blade Q Pro  
1063. V831W - ZTE T320  
1064. V831W - ZTE V831W  
1065. V8403 - V8403  
1066. V8514 - V8514  
1067. V856 - ZTE-V856  
1068. V865M - V865M  
1069. V879 - ZTE V879  
1070. V880E - ZTE V880E  
1071. V880G - ZTE V880G  
1072. V887 - ZTE Blade L  
1073. V887 - ZTE V887  
1074. V887 - tmn smart a20  
1075. V889D - ZTE V889D  
1076. V889M - UZTE V889M  
1077. V889M - ZTE V889M  
1078. V891 - ZTE V891  
1079. V9 - A100  
1080. V9 - BASE Tab  
1081. V9 - BLACK 03  
1082. V9 - Beeline M2  
1083. V9 - Light  
1084. V9 - Light Tab  
1085. V9 - MTC 1055  
1086. V9 - One Pad  
1087. V9 - RTK V9  
1088. V9 - TO101  
1089. V9 - TT101  
1090. V9 - V9  
1091. V9 - V9C  
1092. V9 - V9c  
1093. V9 - V9e  
1094. V9 - myPad P2  
1095. V9180 - V9180  
1096. V956 - ZTE V956  
1097. V965 - ZTE Blade G2  
1098. V965 - ZTE R880H  
1099. V965 - ZTE V880H  
1100. V965 - ZTE V965  
1101. V969 - ZTE V969  
1102. V96A - V96A  
1103. V970 - UZTE V970  
1104. V970 - ZTE V970  
1105. V975 - V975  
1106. V975 - ZTE Geek  
1107. V975 - ZTE V975  
1108. V9800 - ZTE V9800  
1109. V9820 - ZTE V9820  
1110. V983 - ZTE V983  
1111. V987 - UZTE GRAND X Quad  
1112. V987 - ZTE Grand X  
1113. V987 - ZTE V987  
1114. V993W - ZTE V993W  
1115. V9A - Light Tab 2  
1116. V9A - V9A  
1117. V9A - ZTE V9A  
1118. V9A - my Pad P3  
1119. V9A - myPad P3  
1120. V9S - V9S  
1121. V9S - myPadP4  
1122. VERGATARIO 5 - VERGATARIO 5  
1123. VERGATARIO5PLUS - VERGATARIO5PLUS  
1124. Vesta - Z965  
1125. Vip Racer III - Vip Racer III  
1126. Vodafone Smart Chat - Vodafone Smart Chat  
1127. Vodafone Smart ultra 6 - Vodafone Smart ultra 6  
1128. Warp 7 - N9519  
1129. X500 - X500  
1130. X500 - ZTE-X500  
1131. X501\_USA\_Cricket - X501\_USA\_Cricket  
1132. X501\_USA\_Cricket - X501\_USA\_RS  
1133. X501\_USA\_OM - X501\_USA\_OM  
1134. X9180 - X9180  
1135. Z10 - ZTE Z10  
1136. Z353VL - Z353VL  
1137. Z557BL - Z557BL  
1138. Z660G - Z660G  
1139. Z665C - Z665C  
1140. Z667 - Z667  
1141. Z667T - Z667T  
1142. Z716BL - Z716BL  
1143. Z717VL - Z717VL  
1144. Z730 - Z730  
1145. Z740 - Z740  
1146. Z740G - Z740G  
1147. Z750C - Z750C  
1148. Z752C - Z752C  
1149. Z753G - Z753G  
1150. Z755 - Z755  
1151. Z768G - Z768G  
1152. Z777 - Z777  
1153. Z787 - Z787  
1154. Z791G - Z791G  
1155. Z792 - Z792  
1156. Z793C - Z793C  
1157. Z795G - Z795G  
1158. Z796C - Z796C  
1159. Z797C - Z797C  
1160. Z812 - Z812  
1161. Z813 - Z813  
1162. Z818L - Z818L  
1163. Z819L - Z819L  
1164. Z820 - Z820  
1165. Z826 - Z826  
1166. Z828 - Z828  
1167. Z828 - Z828TL  
1168. Z830 - Z830  
1169. Z832 - Z832  
1170. Z833 - Z833  
1171. Z835 - Z835  
1172. Z836BL - Z836BL  
1173. Z836F - Z836F  
1174. Z837VL - Z837VL  
1175. Z839 - Z839  
1176. Z850 - Z850  
1177. Z861BL - Z861BL

1178. Z862VL - Z862VL  
1179. Z899VL - Z899VL  
1180. Z916BL - Z916BL  
1181. Z917VL - Z917VL  
1182. Z930L - Z930L  
1183. Z932L - Z932L  
1184. Z932L - ZTE Z932L  
1185. Z933 - Z933  
1186. Z936L - Z936L  
1187. Z955L - Z955A  
1188. Z955L - Z955L  
1189. Z956 - Z956  
1190. Z957 - Z957  
1191. Z958 - Z958  
1192. Z959 - Z959  
1193. Z962BL - Z962BL  
1194. Z963U - Z963U  
1195. Z963VL - Z963VL  
1196. Z970 - Z970  
1197. Z971 - Z971  
1198. Z980L - Z980L  
1199. Z981 - Z981  
1200. Z986U - Z986U  
1201. Z987 - Z987  
1202. Z990 - ZTE-Z990  
1203. Z990G - ZTE-Z990G  
1204. Z992 - Z992  
1205. Z993 - Z993  
1206. Z995 - Z995  
1207. Z998 - Z998  
1208. ZPAD - K90U  
1209. ZTE A2018 - ZTE A2018  
1210. ZTE A520S - ZTE A520S  
1211. ZTE BLADE A0620 - ZTE BLADE A0620  
1212. ZTE BLADE A0621 - ZTE BLADE A0621  
1213. ZTE BLADE A0622 - ZTE BLADE A0622  
1214. ZTE BLADE A320 - ZTE BLADE A320  
1215. ZTE BLADE A321 - ZTE BLADE A321  
1216. ZTE BLADE A506 - ZTE BLADE A506  
1217. ZTE BLADE A520 - ZTE BLADE A520  
1218. ZTE BLADE A520C - ZTE BLADE A520C  
1219. ZTE BLADE A521 - ZTE BLADE A521  
1220. ZTE BLADE A6 - ZTE BLADE A6  
1221. ZTE BLADE A602 - ZTE BLADE A602  
1222. ZTE BLADE A610 - ZTE BLADE A610  
1223. ZTE BLADE A612 - ZTE BLADE A612  
1224. ZTE BLADE L111 - ZTE BLADE B111  
1225. ZTE BLADE L111 - ZTE BLADE L110  
1226. ZTE BLADE L111 - ZTE BLADE L111  
1227. ZTE BLADE L7 - ZTE BLADE L7  
1228. ZTE BLADE V0710 - ZTE BLADE V0710  
1229. ZTE BLADE V0720 - ZTE BLADE V0720  
1230. ZTE BLADE V0800 - ZTE BLADE V0800  
1231. ZTE BLADE V0820 - ZTE BLADE V0820  
1232. ZTE BLADE V0850 - ZTE BLADE V0850  
1233. ZTE BLADE V7 PLUS - ZTE BLADE V7 PLUS  
1234. ZTE BLade Zmax - Z982  
1235. ZTE BV0870 - ZTE BV0870  
1236. ZTE Blade A522 - ZTE Blade A522  
1237. ZTE Blade L5 - ZTE Blade L5  
1238. ZTE Blade V8 Arc - ZTE Blade V8 Arc  
1239. ZTE C2017 - ZTE C2017

1240. ZTE Fanfare 3 - Z852  
1241. ZTE Overture 3 - Z851  
1242. ZTE Tempo X - N9137  
1243. ZTE V0840 - ZTE V0840  
1244. ZTU31 - ZTU31  
1245. ZXY-ZTE\_N8010 - ZXY-ZTE\_N8010  
1246. ZXY-ZTE\_V6700 - ZTE V6700  
1247. ZXY-ZTE\_V6700 - ZXY-ZTE\_V6700  
1248. Zmax 3 - Z978  
1249. Zmax One - Z719DL  
1250. Zmax Pro - Z981  
1251. blade S - Blade S  
1252. dtac phone M1 - dtac phone M1  
1253. myPad P5 - Amazing\_P5  
1254. myPad P5 - myPad P5  
1255. nubia Z5 - nubia Z5  
1256. tmn smart a15 - tmn smart a15  
1257. tmn smart a60 - tmn smart a60  
1258. tmn smart a7 - tmn smart a7

## Zebex

1. Z-2252 - Z-2252

## Zebra

1. CC5000 - CCHUB1
2. ET5X - ET5X
3. ET5X - ET5X
4. ET5X - ET5X
5. ET5X - ET5X
6. MC18 - MC18N0
7. MC36 - MC36
8. MC40 - MC40N0
9. Pollux - TC700H
10. Pollux - TC75
11. TC51 - TC51
12. TC51 - TC51
13. TC55 - TC55
14. TC56 - TC56
15. TC70x - TC70x
16. TC75x - TC75x
17. TC75xDF - TC75x
18. TC8000 - TC8000
19. WT6000 - WT6000

## Zeki

1. TBDG1073 - TBDG1073
2. TBDG734 - TBDG734
3. TBDG874 Tablet - TBDG874
4. TBQC1063B - TBQC1063
5. TBQG1084 - TBQG1084
6. TBQG774 - TBQG774
7. TBQG855 - TBQG855
8. Zeki TBQG884 - TBQG884

## Zen

1. ZEN ADMIRE NEO PLUS - ADMIRE NEO+
2. ZEN ADMIRE UNITY - ADMIRE\_UNITY
3. Zen Admire Curve + - ADMIRE\_CURVE+
4. Zen Admire Glory+ - ADMIRE\_GLORY+
5. Zen Admire Sense+ - ADMIRE\_SENSE+



6. Zen Admire Swadesh+ - ADMIRE SWADESH+
7. Zen M72 Smart - M72 Smart

## Zettaly

1. ZA-407 - Zettaly Avy ZA-407

## Zilo

1. Zilo - Zilo

## Ziox

1. Astra Blaze - Astra Blaze
2. Astra Curve 4G - Astra Curve 4G
3. Astra NXT Pro - Astra NXT Pro
4. Astra Star - Astra Star
5. Astra Young Pro - Astra Young Pro
6. Duopix F1 - Duopix F1
7. Duopix R1 - Duopix R1

## Zopo

1. L63 - L63
2. PRO1 - PRO1

## Zuk

1. Lenovo Z2 Plus - ZUK Z2132
2. Z1 - Z1
3. Z1 - ZUK Z1
4. Z1 - ZUK Z1
5. Z2 - ZUK Z2131
6. Z2 Pro - ZUK Z2121
7. ZTE B2015 - ZTE B2015
8. ZTE BLADE A5 PRO - ZTE BLADE A5 PRO

## Zuum

1. COVET - COVET
2. Gravity - Gravity
3. LIMIT - LIMIT
4. MAGNO - MAGNO
5. MAGNO - MAGNO-S
6. ONIX - ONIX
7. ZUUM AKUS - AKUS

## bq

1. Aquaris A4.5 - Aquaris A4.5
2. Aquaris A4.5 - Aquaris\_A4.5
3. Aquaris E10 - Aquaris E10
4. Aquaris E10 3G - Aquaris E10 3G
5. Aquaris E4 - Aquaris E4
6. Aquaris E4.5 - Aquaris E4.5
7. Aquaris E5 - Aquaris E5
8. Aquaris E5 FHD - Aquaris E5 FHD
9. Aquaris E5 HD - Aquaris E5 HD
10. Aquaris E6 - Aquaris E6
11. Aquaris M10 - Aquaris M10
12. Aquaris M10 4G - Aquaris M10 4G
13. Aquaris M10 FHD - Aquaris M10 FHD
14. Aquaris M4.5 - Aquaris M4.5
15. Aquaris M4.5 - Aquaris\_M4.5
16. Aquaris M5 - Aquaris M5
17. Aquaris M5.5 - Aquaris M

18. Aquaris M5.5 - Aquaris M5.5
19. Aquaris U - Aquaris U
20. Aquaris U Plus - Aquaris U Plus
21. Aquaris U lite - Aquaris U Lite
22. Aquaris U2 - Aquaris U2
23. Aquaris V - Aquaris V
24. Aquaris X - Aquaris X
25. Aquaris X Pro - Aquaris X Pro
26. Aquaris X5 - Aquaris X5
27. Aquaris X5 Plus - Aquaris X5 Plus
28. Edison 3 - Edison 3
29. Edison 3 3G - Edison 3 3G
30. Edison\_3\_mini - Edison 3 mini
31. M8 - Aquaris M8

## i-Buddie

1. TA10CA1 - TA10CA1
2. TA10CA2 - TA10CA2
3. TA10CA3 - TA10CA3
4. TA10CA4 - TA10CA4
5. TA71CA1 - TA71CA1
6. TA71CA5 - TA71CA5
7. TA80CA1 - TA80CA1
8. TM75A-V2 - TM75A-V2
9. TR10CD1 - TR10CD1
10. TR10CD1 - TR10CD1
11. TR10CD1\_P - TR10CD1
12. TR10CS1 - TR10CS1
13. TR10CS1 - TR10CS1
14. TR10CS1\_P - TR10CS1

## i-Mobile

1. IQ II - i-mobile IQ II
2. IQX KEN - IQX KEN
3. Y1 - i-mobile Y1
4. i-STYLE 713 - i-STYLE 713
5. i-STYLE 812 4G - i-mobile i-STYLE 812 4G
6. i-note WiFi 1.1 - i-mobile M1703

## iCraig

1. CLP288 - ICRAIG\_CLP288
2. CLP293 - CLP293
3. CLP\_291 - ICRAIG\_CLP291
4. CMP 756 - CMP 756
5. CMP 759 - CMP 759
6. CMP770 - ICRAIG\_CMP770
7. CMP791 - CMP791
8. CMP793 - CMP793
9. CMP797 - CMP797
10. CMP798 - CMP798
11. CMP821 - CMP821
12. CMP823 - CMP823
13. CMP826 - CMP826
14. CMP828 - CMP828
15. CMP\_771 - ICRAIG\_CMP771
16. CMP\_773 - ICRAIG\_CMP773

## iDea USA

1. CT8 - CT8

## **iDeaUSA**

1. CT10 - CT10
2. CT7 - CT7

## **iGet**

1. S100 - S100
2. SMART - SMART
3. SMART\_G101 - SMART\_G101
4. SMART\_G102 - SMART\_G102
5. SMART\_G71 - SMART\_G71
6. SMART\_G81 - SMART\_G81
7. SMART\_G81H - SMART\_G81H
8. SMART\_L102 - SMART\_L102

## **iLa Mobile**

1. D1 - D1
2. S1 - S1

## **iNO Mobile**

1. S9 - iNO S9

## **iNanny**

1. NC1000 - NC1000

## **iRiver**

1. smdkc110 - ILT-MX100
2. DMT580D - DDA800R
3. DMT580D - DMT580D
4. DMT580D - MIT700
5. MM3202 - MM-3201
6. MM3202 - MM-3202
7. ULALA - I-K1
8. WOW Tab+(ITQ1000) - ITQ1000
9. WPT005 - WPT005
10. Wow TAB + - ITQ701
11. Wow(Window of the world) - ITQ700
12. Wow(Window of the world) - YBMK01

## **iRulu**

1. Irulu - X10

2. L20 - L20
3. L21 - L21
4. X18 - X18
5. X27 - X27
6. X37 - X37
7. X4 - X4
8. X40 - X40
9. X47 - X47
10. X57 - X57
11. X58 - X58
12. X67 - X67
13. iRULU\_G36 - G36

## **iVOOMi**

1. Me 1 - iV 505
2. Me 1+ - Me 1+
3. Me 2 - Me 2
4. Me 3 - Me 3
5. Me 3S - Me 3S
6. Me 4 - Me 4
7. Me 5 - Me 5

## **pendo**

1. PNDPP44QC10 - PNDPP44QC10
2. PNDPP44QC7 - PNDPP44QC7

## **sugar\_aums**

1. QPOINT - QPI-1

## **tecmobile**

1. OmnisOne - Omnis One

## **ucall**

1. EASY1 - EASY1

## **videocon**

1. Delite 11 - V503630
2. Krypton 22+ - V505024
3. Metal Pro 1 - V505820
4. Metal Pro 2 - V505920
5. Starr 100 - V406018